


# OpenMES™

Previously OpenCIM



## Manufacturing Execution Software for Industrial Training Applications

Version 6

# *User Manual*

Catalog No. 34-8000-0025 Rev. A

September 2023



Copyright © 2023 Intelitek Inc.

Tel: (603) 625-8600

OpenMES User Manual

Fax: (603) 437-2137

Cat.# 34-8000-0025 Rev. A

September 2023

website: <http://www.intelitek.com>

email: [info@intelitek.com](mailto:info@intelitek.com)

All rights reserved. No part of this publication may be stored in a retrieval system, or reproduced in any way, including but not limited to photocopy, photography, magnetic or other recording, without the prior agreement and written permission of the publisher. Program listings may be entered, stored, and executed in a computer system, but not reproduced for publication.

This manual is designed to provide information about the **OpenMES**, system and software. Every effort has been made to make this book complete and as accurate as possible. However, no warranty of suitability, purpose or fitness is made or implied. Intelitek Inc. is not liable or responsible to any person or entity for loss or damage in connection with or stemming from the use of **OpenMES** and/or the information contained in this publication.

## Table of Contents

1. Introduction .....	3
2. System Overview .....	9
3. Safety .....	36
4. Installation .....	40
5. Project Manager .....	65
6. Operating OpenMES Manager .....	77
7. OpenMES Manager Utility Programs .....	110
8. Virtual OpenMES Setup .....	177
9. OpenMES Device Drivers .....	213
10. Web Viewer .....	256
11. OpenMES Programming.....	267
12. Inside OpenMES.....	348
13. Errors and Troubleshooting .....	397
14. Glossary.....	411
15. Intelitek Software Licensing.....	417

# 1. Introduction

This chapter introduces the OpenMES software and describes the various chapters of this manual, the information included in each chapter, how to use this manual and so on. It includes the following sections:

- **1.1 About OpenMES** introduces general CIM and MES concepts and advantages, and describes the list of chapters available in this manual.
- **1.2 What's New?** lists the new features in OpenMES
- **1.3 About This Manual**, the list of chapters available in this manual.
- **1.4 How This Manual is Organized** describes which chapters are intended for which target audience.
- **1.5 Who Should Use This Manual** describes which chapters are intended for which target audience.
- **1.6 How to Use This Manual** describes how to get the most out of this guide.

To stay competitive, factories are increasingly automating their production lines with Computer Integrated Manufacturing (CIM) systems. A CIM cell is an automated assembly line that uses a network of computers to control robots, production machines, and quality control devices. The CIM cell can be programmed to produce custom parts and products.

CIM provides many advantages:

- Computer integration of information gives all departments of a factory rapid access to the same production data.
- Accessibility of production data results in faster response to change, which in turn shortens lead times, increases the company's responsiveness to customer demands and competition, and improves due-date reliability.
- Computer aided scheduling optimizes the use of the shop floor. This improves the utilization of machine tools and reduces work-in-progress and lead times.
- Real-time production data can be used to optimize the production processes to improve quality, using techniques such as statistical process control.
- Computer analysis and prediction of material requirements for production can reduce inventory levels and lead times. Integration with suppliers and customers can provide even greater benefits.
- Downloading machining instructions, including tool changes, from CAM (computer aided manufacturing) systems to CNC machines (computer numerically controlled) reduces machine setup times and increases machine utilization.

The trend among manufacturers today is to produce smaller batches of more varied products. Without CIM automation, this trend would result in higher costs associated with increased setup time and additional labor.

There is a shortage of qualified CIM technicians and engineers. Manufacturers demand graduates who understand the integration of all elements of a CIM. Intelitek's OpenMES system addresses this need by providing an industrial-level training system for the educational environment.

## 1.1. ABOUT OPENMES

MES stands for Manufacturing Execution System. An MES is a software-based system used in manufacturing to monitor, control, and manage various aspects of the production process.

OpenMES is a system which teaches students the principles of automated production using robotics, computers, and CNC machines. It also allows advanced users to search for optimal production techniques by experimenting with different production techniques.

OpenMES offers a simulation mode in which different production strategies can be tested without actually operating the CIM equipment.

OpenMES provides a realistic, expandable environment through interfaces to third party hardware (CNC machines, robots, peripheral equipment, etc.). Students can learn first-hand how other disciplines such as Production Scheduling, Manufacturing Resource Planning (MRP), Order Entry Systems, and Database Management Systems (Xbase) can be used to optimize the production process.

In this version of OpenMES, two additional products are also available:

- **OpenFMS** – for a small CIM system which may include a single robot and one or two CNC machines.
- **OpenMES Offline** – a simulation only version of OpenMES.

OpenMES was previously known as OpenCIM. The software is backwards compatible with OpenCIM, so any projects that you have created in OpenCIM can be opened in OpenMES.

## 1.2. WHAT'S NEW?

OpenMES has the following new features that were not present in the latest version of OpenCIM:

- A new user interface. See chapters 5 and 6 to learn more.
- Updated PC requirements. See section 2.6.5 to learn more.
- Additional Manager Views. See sections 6.4.10 and 6.4.11 for more information.

## 1.3. ABOUT THIS MANUAL

This manual is a complete reference guide to the OpenMES system. It explains how to install, configure, and operate the OpenMES software. Indications as to which information is not relevant to the additional OpenMES products are provided in the appropriate sections.

This manual includes complete details on how to produce custom parts, add your own computer-controlled equipment, and how to interface with other software.

## 1.4. HOW THIS MANUAL IS ORGANIZED

- Chapter 1     **Introduction:** Introduces OpenMES this OpenMES User Manual.
- Chapter 2     **System Overview:** Describes the hardware and software components which comprise a CIM cell.
- Chapter 3     **Safety:** Provides the general rules, followed by a brief discussion of the safety requirements of each component.
- Chapter 4     **Installation:** Describes the hardware assembly process and the software installation and configuration procedures.
- Chapter 5     **Project Manager:** Describes the Project Manager application that launches the Virtual OpenMES Setup and OpenMES Manager. It enables users to manage their own projects, and administrators to manage the projects in the archive.
- Chapter 6     **Operating OpenMES Manager:** Describes how to operate the OpenMES Manager which is used for operating the OpenMES system and controlling production.
- Chapter 7     **Utility Programs:** Describes the OpenMES Utility Programs which are used for preparing the OpenMES system for production.
- Chapter 8     **OpenMES Setup:** Describes the Virtual OpenMES Setup application which is an interactive graphic module that enables you to create a simulated CIM cell.
- Chapter 9     **OpenMES Device Drivers:** Describes the OpenMES devices drivers, which are interface programs that translate and transmit messages between the OpenMES Manager and the various machines and controllers at CIM stations.
- Chapter 10    **Web Viewer:** Describes the Web Viewer application enabling you to remotely access a specific OpenMES Manager cell and track the production cycle.
- Chapter 11    **OpenMES Programming:** Provides various programming and advanced OpenMES features.
- Chapter 12    **Inside OpenMES:** Describes various OpenMES administration procedures for the advanced user and describes the OpenMES directory structure.
- Chapter 13    **Troubleshooting:** Describes device error handling, OpenMES error messages and more.
- Chapter 14    **Glossary:** Provides the abbreviations and terminology used in OpenMES
- Chapter 15    **Intelitek Software Licensing:** Describes the various procedures involved in registering your OpenMES software.

## 1.5. WHO SHOULD USE THIS MANUAL

This manual is intended to be used by the following:

**Students** Students can operate the OpenMES system to gain experience with computer integrated manufacturing (CIM) or Flexible Manufacturing Systems (FMS). By working with a complete CIM system, students are encouraged to think “globally” about the manufacturing process. Students can also concentrate on a particular aspect of a CIM system such as controlling robots, CNC machines, etc.

**Industrial Management Students** OpenMES allows advanced users to implement and experiment with theories concerning optimal computer integrated manufacturing techniques such as:

- The effect of different machines which can perform the same process
- Modifying a process by changing a machine’s control program
- Alternate part definitions

OpenMES can also be used in simulation mode to search for optimal production strategies by experimenting with the following:

- The causes of production bottlenecks
- The effects of alternative production schedules
- What-if analyses

For example, OpenMES can help answer questions such as:  
*Is it more efficient to do a quality control check at the end of each operation or just once at the end of the manufacturing process?*

With OpenMES you can use a simulation mode to easily test both methods and then observe the results.

**Instructors** Instructors who want to demonstrate automated production techniques using the OpenMES system.

**System Administrators** System administrators in charge of installing, maintaining, and troubleshooting the OpenMES system will want to become familiar with all aspects of this manual.

## 1.6. HOW TO USE THIS MANUAL

The OpenMES software can be operated and used fully without OpenMES hardware. Therefore, the emphasis in this manual is placed on the use of the software.

This manual assumes all users are familiar with the following topics:

- Safety and basic operating procedures associated with robots, CNC machines, and all other equipment in the CIM environment.
- Basic operation of MS Windows.

System administrators and advanced users should be familiar with the following topics:

- Robotic programming using Scorbace language
- Controlling and operating machines (e.g., CNCs)
- RS232 communications
- PC LAN administration, operation, and troubleshooting
- Setting up programmable logic controllers (PLCs)

Even if you will not be using the software in conjunction with an actual OpenMES system, all users should read the background information provided in Chapter 1, Introduction, and Chapter 2, System Overview and the Safety in Chapter 3.

The installation instructions provided in Chapter 4, Installation, are intended for instructors and technical personnel who will be handling software and hardware installation.

Chapter 5, Project Manager, which activates the OpenMES applications (OpenMES Manager and Virtual OpenMES Setup), enables you to manage your own projects and provides an archive containing read-only projects managed by the CIM administrators.

Chapter 6, Operating OpenMES Manager and Chapter 7, OpenMES Manager Utility Programs, are organized to help all users begin using the OpenMES system as quickly as possible. The material is presented in the order required to prepare and operate the OpenMES system and the procedures guide you through the basic steps of software operation.

Chapter 8, Virtual OpenMES Setup presents the Virtual CIM module, and teaches you how to set up the CIM by means of a graphic editor.

Chapter 9, OpenMES Device Drivers, describes the operation of OpenMES device drivers that are used in OpenMES.

Chapter 10, Web Viewer, describes how you can remotely access a specific OpenMES Manager cell and track the production cycle.

Chapter 11, OpenMES Programming, enables advanced users to do their own production experiments beyond the scope of the sample applications in order to explore new CIM techniques.

Chapter 12, Inside OpenMES, contains details about the OpenMES software, files, and directory structure, and provides the information necessary for customizing the OpenMES environment.

Chapter 13, Errors and Troubleshooting, provides detailed information on error handling and troubleshooting.

Chapter 14, Glossary, presents explanations of abbreviations and terminology used in the OpenMES system.

Chapter 15, Intelitek Software Licensing discusses the OpenMES software licensing process.



## 2. System Overview

This chapter describes the hardware and software components which comprise an OpenMES cell. It discusses each component individually and also how all components work together. It includes the following sections:

- **OpenMES Description** describes the OpenMES unique features, and the additional OpenMES software packages that are provided.
- **Production Operations**, describes the operations performed in the CIM cell when producing a product and provides an OpenMES sample application.
- **Components of the CIM Cell**, describes the basic elements (hardware and software) of the OpenMES cell.
- **Stations**, describes the various stations (such as ASRS, Assembly, QC stations) including their functionality and provides a schematic example of the OpenMES cell.
- **Material Flow in the OpenMES Cell**, describes the basic flow of parts in a CIM Cell and provides descriptions of the various components involved in material flow. These may include templates, pallets, robots and so on.
- **CIM Control & Optimization**, describes how the OpenMES cell is controlled and provides descriptions of the elements involved in the control of the CIM cell. These include the OpenMES Manager, the station manager, the graphic display and so on.
- **Device Drivers**, describes the various device drivers in OpenMES. These include ACL device driver, CNC machine device driver, PLC device driver, Scorbace device drivers and so on.
- **OpenMES Communication Network**, describes the communication networks that currently exist in OpenMES. These include LAN, RS232, and I/O (inputs/outputs).
- **Integration**, provides an example scenario containing a step-by-step description of the various systems and devices that are associated with making a product in OpenMES.

### 2.1. OPENMES DESCRIPTION

This section describes the OpenMES features as well as the OpenMES software packages (such as OpenFMS and OpenMES Offline that are provided in OpenMES).

#### 2.1.1. Unique Features

This section gives the background for understanding what is special about OpenMES and basic operations performed in the OpenMES system.

OpenMES software provides unique industrial capabilities not found in other educational CIMs:

- OpenMES “feels” familiar to first-time users because it is based on the standard Windows Graphic user interface.
- OpenMES allows for targeted training at a given station or device.
- OpenMES is realistic because it uses equipment found in actual industrial CIMs.

- OpenMES resembles industrial CIMs in its ability to grow by using distributed processing at each production station. Distributed processing also makes for a more robust system. Even if the PC performing the central manager function goes down, each machine can still be operated in a stand-alone mode.
- OpenMES uses a sophisticated network of PCs which allows various devices to perform multiple operations simultaneously. This network also allows CIM devices to communicate with each other.
- OpenMES provides you with a powerful, yet flexible report generator. This utility program allows you to access nine types of predefined reports or gives you the option of creating your own user-defined reports.
- OpenMES uses the latest object-oriented techniques in:
  - Defining the CIM Layout: Click on a Graphic object and drag it to the appropriate location on the CIM layout screen (e.g. Drag a robot in order to place it beside a CNC machine).
  - Defining an Object's Properties: Click on an object to set its properties, e.g. the type of parts a machine can handle.
  - Graphic Production Tracking: Uses Graphic objects to simulate CIM operations on screen.
- OpenMES allows you to run a production simulator on a PC to observe results without actually operating the CIM production line.
- OpenMES provides the opportunity to observe how a set of diverse hardware components work together in a real-world environment.
- OpenMES is more comprehensive than other limited function CIMs. It can use a variety of equipment including:
  - A variety of robots
  - Processing machines
  - Quality control devices (machine vision, laser scan meter, height gauge, CMM, caliper)
  - Automated storage and retrieval systems (ASRS)
  - Peripheral devices (barcode scanner, X-Y table, electric screwdriver, laser engraver, etc.)
  - Custom devices by allowing you to easily set up your own device interfaces
- OpenMES offers Graphic production tracking allowing you to observe each production operation on a central display.
- OpenMES provides an open environment for advanced users who want to:
  - Add their own devices
  - Design their own products
  - Interface their own software (e.g. MRP and cost analysis)
  - Analyze CIM production data

OpenMES is a robust system that enables recovery from errors without the need to reset the entire CIM cell.

## 2.1.2. OpenMES Additional Software Packages

The additional OpenMES software packages, OpenFMS, OpenMES Offline that are provided, are each described in detail in the following sections.

### 2.1.2.1. OpenFMS

OpenFMS is designed for use with flexible manufacturing systems. OpenFMS includes all the software modules and features of OpenMES, and is intended to support systems with one robot tending one or two machines and quality control devices.

The following items are not included in the Virtual FMS Setup module, nor can they be configured for online operation.

<b>Included in OpenFMS</b>	<b>Not included in OpenFMS</b>
All types of robots	
Slidebases, linear conveyors, XY and linear positioning tables	Closed loop conveyor
ASRS-36 and all smaller storage device and part feeders	ASRS <sup>2</sup> and ASRS carousel
All CNC machines	Laser engraver
ViewFlex machine vision system, electronic calipers, laser scan meter	Coordinate measuring machine, electronic height gauge, barcode reader
Automatic gluing application; Automatic screw driving application	Hydraulic robot and pressing station; Pneumatic part feeding/sorting station; Process control station

### 2.1.2.2. OpenMES Offline

OpenMES Offline is the simulation version of OpenMES. The user can design and run an unlimited variety of CIM or FMS cells in simulation mode.

It does not support hardware or online operation.

Device drivers are not included in this package.

## 2.2. PRODUCTION OPERATIONS

The following operations are performed in the CIM cell when producing a product:

- Supplied parts (raw materials) are loaded into storage locations.
- Manufacturing orders are generated by the OpenMES Manager or by an external production scheduling package such as Fourth Shift or MAPICS.
- Parts are removed from the ASRS and transported on the conveyor to production stations.
- Robots take parts from the conveyor and move them to various production machines (e.g. CNC machines) at a station (machine tending).
- Typical production tasks include:
  - Processing in a CNC machine
  - Assembling two or more parts
  - Quality control tests
  - Robots return processed parts to the conveyor for transportation to the next station.
  - Finished products are removed (unloaded) from the cell.

### 2.2.1. OpenMES Sample Application - The Covered Box

The following Covered Box sample application is used in this manual to demonstrate the concepts of the OpenMES system and can be found in the TUTORIAL\_SAMPLE provided in the archive project list. The steps shown below are explained in more detail as each topic is introduced later in this manual.

The sample application produces a simple, covered box from a small, solid cube and a matching cover. Each component part is assumed to be in place on a separate template in the ASRS.




Figure 1: Part Definition Tree for Sample Application

The following steps detail the process of making a covered box:

1. The ASRS robot takes a solid cube and a cover from a storage cell and places them on separate pallets on the conveyor.
2. When the cover arrives at the assembly station, the assembly robot places it in a rack until the matching box arrives.
3. When the cube arrives at a CNC station, the CNC robot places the cube into a milling machine. The CNC machine reams out the center of the cube to form a box.
4. The CNC robot places the box on the conveyor.

5. When the box arrives at the assembly station, the robot places it on a rack. When all the parts required for the assembly are on their rack, the robot places the base part (box) on the jig. The robot then retrieves the matching cover from the rack and places it on the box. The robot places the covered box on the conveyor.

When the covered box arrives at the ASRS, the robot places the finished product in a storage cell.

## 2.3. COMPONENTS OF THE CIM CELL

This section describes the elements of the CIM cell. The topics covered include the physical configuration of the cell, material flow, control and production devices and communication networks. The emphasis is on the role each component plays in the integrated system, rather than on providing a detailed description of the component. Later chapters cover OpenMES software in greater detail. Consult the appropriate user's manuals for details about each hardware component.

CIM cells are composed of the following basic elements:

Component	Description
Conveyor	Device that transports parts from station to station.
Production (Work) Stations	Locations around the cell where parts are processed and stored by machines and robots. Robots move parts between the conveyor and station machines.
OpenMES Manager	The PC that contains the OpenMES Manager software which coordinates the functioning of all devices in the cell using a LAN.
Station Manager	A PC that controls the different devices at a station and has a communication link with the OpenMES Manager. Device control is performed by OpenMES device drivers that run on this PC. A device driver controls the operation of a device at the station in response to commands from the OpenMES Manager and other CIM elements.
Other Software Tools	OpenMES Modules: Virtual OpenMES Setup, OpenMES Manager (with integrated Part Definition, Machine Definition, Storage Definition, MRP, Scheduler-Gantt, Reporter, Graphic Tracking modules), Project Manager, Performance, Optimization and Web Viewer.

- ① *Third Party Software: Other production related software that interfaces to OpenMES such as Production Scheduling, Manufacturing Resource Planning (MRP and MRP-II), Order Entry Systems, Data Base Management Systems (Xbase), etc.*

Typically, a separate PC is dedicated to running or controlling each of the above elements. While two or more functions can be combined on a PC, the following discussion assumes the use of dedicated PCs.

## 2.4. STATIONS

The CIM cell (also referred to as an OpenMES cell) is composed of a set of stations located around a conveyor as shown schematically in the figure below:




Figure 2: Schematic Example of a CIM Cell

Each station is controlled by a Station Manager PC. An OpenMES Manager PC coordinates the activities of all stations. The number of stations may vary from cell to cell. A typical educational OpenMES cell ranges from up to eight stations arranged around one conveyor to as few as a single station consisting of a robot tending a machine. The software can be adapted to more stations and conveyors.

Production commands are sent from the OpenMES Manager computer to the device drivers via the Station Manager PC. Status messages generated by devices are interpreted by the device driver and sent back to the OpenMES Manager.

Just as each industrial cell is an individual application of CIM technology, every OpenMES cell has its own configuration. Generally, the stations that are usually available are described in the following table:

Station	Description
ASRS Station	Automated Storage and Retrieval System. Automatic warehouse which supplies raw materials to the OpenMES cell, stores parts in intermediate stages of production, and holds finished products.
Machine Station	Station where materials are shaped, formed, or otherwise processed (e.g. using a CNC machine or laser engraver).
Assembly Station	A station where parts are put together. The resulting new part is called an assembly. Peripheral equipment and devices at an Assembly Station include an automatic screwdriver, Welder, X-Y table, part feeders, various robot grippers, etc.
QC Station	Quality Control. Inspection of parts using machine vision, laser scan meter, height gauge, continuity tester, CMM, caliper or other QC machines.

Each station is controlled by a Station Manager PC. An OpenMES Manager PC coordinates the activities of all stations. The number of stations may vary from cell to cell. A typical educational CIM cell ranges from up to eight stations arranged around one conveyor to as few as a single station consisting of a robot tending a machine. The software can be adapted to more stations and conveyors.

Production commands are sent from the OpenMES Manager computer to the device drivers via the Station Manager PC. Status messages generated by devices are interpreted by the device driver and sent back to the OpenMES Manager.

Just as each industrial cell is an individual application of CIM technology, every CIM cell has its own configuration. Generally, the stations that are usually available are described in the following table:

Station	Description
ASRS Station	Automated Storage and Retrieval System. Automatic warehouse which supplies raw materials to the OpenMES cell, stores parts in intermediate stages of production, and holds finished products.
Machine Station	Station where materials are shaped, formed, or otherwise processed (e.g. using a CNC machine or laser engraver).
Assembly Station	A station where parts are put together. The resulting new part is called an assembly. Peripheral equipment and devices at an Assembly Station include an automatic screwdriver, Welder, X-Y table, part feeders, various robot grippers, etc.
QC Station	Quality Control. Inspection of parts using machine vision, laser scan meter, height gauge, continuity tester, CMM, caliper or other QC machines.

Various functions may be combined at one station, such as quality control and assembly.

Stations contain devices that perform production activities such as material processing or inspection. The following elements are generally present at a station:

Element	Description
Robot	A device which moves parts around a station (e.g. inserts parts into a CNC machine) and/or performs assembly operations.
Robot Controller	For example, an ACL controller which controls the robot and certain optional peripheral devices (e.g. X-Y table, barcode scanner).
Station Manager PC	A Station Manager PC where the device drivers are located that:  Translate OpenMES production messages and commands to/from each station device (e.g. the ACL controller).  Provide a user interface for controlling station devices by manually sending OpenMES commands (e.g. to CNC machines or an ACL controller).

Element	Description
	Function as a terminal for devices that use an RS232 interface for setup and programming (such as the ACL controller).
Machine	A device that processes parts at a station. CNC machines such as lathes and mills process parts according to user-supplied G-code programs.
Robot Peripheral	A peripheral device which aids the robot in material handling tasks (e.g. a linear slidebase that supports a robot, an X-Y table, a tool adapter, various grippers such as pneumatic or suction models, etc.).

An example of a CIM cell is shown schematically in the following figure:




Figure 3: Sample OpenMES Cell

## 2.5. MATERIAL FLOW IN THE OPENMES CELL

Material handling tasks can be divided into two groups:

- **Primary Material Handling:** These tasks perform the transportation of parts between stations.
- **Secondary Material Handling:** These tasks perform the handling of parts within a station, such as placing a template on the conveyor, removing a part from a feeder, inserting a part in a CNC machine, assembling parts and so on.

In a CIM cell, the primary material handling tasks are usually performed by the conveyor. A robot (in combination with its peripherals) performs the secondary material handling tasks at each station.

When a robot removes a template from the conveyor, it typically places it on a buffer. (A buffer is a tray designed to hold a template when it is removed from the conveyor. The standard buffer is attached to the outer rim of the conveyor.) Once the template is on the buffer, the robot can remove a part from the template and take it to a station device.



The following scenario describes the basic flow of parts within the CIM cell:

- In response to production orders, the OpenMES Manager issues instructions to release parts from the ASRS and move them from station to station for processing.
- A robot at each station takes parts from the conveyor and places them in station machines.
- After a part has been processed at the station, the robot places the part back on the conveyor where it moves to the next station according to its production plan.

### 2.5.1. Templates

Templates are plastic trays which can hold various types of parts. They allow parts to be transported on the conveyor.




Figure 4: An Empty Template

A template contains a matrix of holes in which pins are placed to fit the dimensions of a part. Each arrangement of pins defines a unique template type. Each part may only be held by its assigned template. The handle, located on top of or in front of the template, facilitates grasping by a robot's gripper.

An optional passive RFID tag on the inside of the template can be used for tracking and identification of templates. When RFID tags are used, an RFID reader can verify the identity of each template inserted or removed from the ASRS. See section 7.3.6 How to Define a Template for more information about assigning template IDs.

### 2.5.2. Storage

An ASRS station is typically used as the main source of raw material for the cell. The ASRS can also serve as a warehouse for parts in various stages of production. Storage cells in the ASRS contain templates, either empty or loaded with parts. A CIM cell may contain any number of ASRS stations.

Part feeders can also be used to supply raw materials at various stations around the cell.

The following ASRS models exist in OpenMES:

- **ASRS Carousel:** The ASRS carousel is a three-tier rotating warehouse which is tended by a robot, and controlled by an ACL controller.
- **ASRS-36:** The ASRS-36 is a cartesian robot with an additional rotary axis. It has a set of storage racks (divided into six levels with six cells each). The robot, which is controlled by a standard ACL Controller-A, moves the parts between the shelves and the conveyor.
- **ASRS-36u, ASRS-36uX2:** The ASRS36u and ASRS-36uX2 are cartesian robots with additional rotary axes. They each have a set of storage racks (divided into six levels with six cells each). The

robots, which are controlled by USB controllers, move the parts between the shelves and the conveyor.

- **ASRS Rack:** The ASRS rack has a small number of cells, and is designed for use in a Micro-CIM work cell.

### 2.5.3. Conveyor and Pallets

A pallet is a tray which travels on the CIM conveyor and is designed to carry a template. To transport a part to another station, a robot places the template carrying the part on a pallet on the conveyor. The OpenMES conveyor carries pallets in a continuous circuit from station to station. The conveyor is controlled by a PLC (programmable logic controller).

Each pallet has an ID number which is magnetically encoded in a bar on the pallet. In normal cell operation, each pallet is stopped briefly when it arrives at a station so that its ID can be read. If the PLC determines that the pallet is needed at this station, it informs the OpenMES Manager. The pallet remains at this station until the OpenMES Manager sends a release command. While a pallet is stopped, the conveyor continues to transport other pallets which are moving between stations.

The location at which a pallet is stopped is called a conveyor station. Each OpenMES station has its own conveyor station, which contains two pneumatically operated pallet stops, a magnetic pallet-arrival sensor, a magnetic pallet-in-place sensor, and a set of magnetic pallet-code sensors.




Figure 5: Pallet at Conveyor Station

Piston stops at each conveyor station can be raised to hold a pallet in place while the conveyor continues to cycle past the stations. The PLC controls the operation of these pneumatically driven piston stops, using input from pallet detection sensors located at the conveyor station.

The PLC keeps track of pallets which are empty and those which are carrying parts. It sends the destination station of each pallet to the PLC (default destination for each pallet is #99, allowing the pallet to continuously circle on the conveyor). Magnetic code readers at each station enable the PLC to identify the pallet ID numbers. Through a look-up-table the OpenMES Manager can instruct the PLC to do the following:

<b>If ...</b>	<b>Then the PLC stops the pallet if ...</b>
Pallet is empty	A template containing a part is ready to be picked up at this station.
Pallet carries an empty template	A part with no template needs to be picked up at this station.
Pallet carries a template with a part	This part needs to be delivered to this station.

If the part carried by the pallet does not require processing at the station, the pallet is allowed to continue on the conveyor.

Even though a pallet may be needed at a station, the OpenMES Manager may direct the PLC to release it if the robot that handles templates at this station is busy. Otherwise, a bottleneck could occur on the conveyor since other pallets would not be able to pass until the robot becomes available. The PLC would then stop the next appropriate pallet and try again.

If the robot is free it is instructed to remove the template containing the part from the pallet and place it on a station buffer. The empty pallet is then released and can continue on the conveyor, ready to pick up another template.

### 2.5.3.1. Conveyor Signal Lamps

Signal lamps at each conveyor station indicate the following:

Option	Description
Green On	Station is idle waiting for a pallet to arrive.
Red On	A pallet has been stopped for use at this station.
Flashing Red	An error has been reported at this station by an OpenMES device driver (e.g. robot impact, Emergency button pressed).
Flashing Red at All Stations	All stations have stopped because someone has pressed the Emergency Stop Button.

### 2.5.4. Robots and Controllers

CIM robots move parts within a station (secondary material handling) and perform assembly operations. Robots vary in speed, payload, accuracy, range of movements (degrees of freedom), working envelope (horizontally or vertically articulated), and drive mechanism (DC servo, AC servo or pneumatic).

The following Intelitek robots may be integrated in an OpenMES environment:

Robots controlled by Scorbase:

- SCORBOT-ER 4u
- ASRS-36u
- ASRS-36uX2
- SCORBOT-ER 9Pro
- SCORA-ER 14Pro
- HP3 with NXC100 and XtraDrive controllers
- SCORBOT-ER 5, SCORBOT-ER 5 Plus
- SCORBOT-ER 7
- SCORBOT-ER 9
- SCORA-ER 14
- ABB IRB 140 with IRC5 controller
- Fanuc LR Mate 200iC with controller R-30iA
- KUKA AGILUS
- Square ASRS
- Yaskawa HC10
- Yaskawa MH5F
- Yaskawa GP8
- Yaskawa MHJF




Figure 6: Robot, Controller, Teach Pendant, and Station Manager PC

### 2.5.5. Processing Machines

Processing machines process parts according to processing programs stored in their memory. The OpenMES Manager keeps track of the programs that reside in a machine's memory and downloads a new program to process an upcoming part as needed.

OpenMES can interface to machines that use either I/O lines or an RS232 interface to control operations such as opening/closing a door, turning on/off the machine, etc. Status lines report information, such as whether a door is open or closed and when a process is finished.

## 2.6. CIM CONTROL & OPTIMIZATION

To understand how the CIM cell is controlled, it is necessary to look at its control elements, the communication channels that each element uses to control the devices, and the network that links the various control elements as an integrated whole.

The OpenMES system consists of various software modules which perform command, control, and monitoring functions:

- Virtual OpenMES Setup Software
- OpenMES Manager Software with integrated modules (Storage Definition, Machine Definition, Part Definition, MRP, etc.)
- Device Managers (device drivers located on Station PC)
- Conveyor Manager (PLC device driver located on a Station PC)
- Graphic Tracking (integrated in OpenMES Manager and/or as external module)

OpenMES uses a distributed control strategy as follows:

- Each Station Manager PC runs a set of device drivers that control the devices at its station.
- A PLC controls the operation of the conveyor.

- The OpenMES Manager provides the highest level of control and integrates the activities of the entire cell. It sends command messages to the various device drivers via the network. These units attempt to execute the command and respond with status messages describing the results.

### 2.6.1. What is Optimization?

In multiple productions (when producing more than one part in a manufacturing cycle) it is required to optimize the timing synchronization to maximize system functionality at minimum costs. This process is called *System Optimization*.

There are two types of system optimization methods. In the first method, the schedule is defined in advance and a detailed schedule is set for each machine. In the second method, a set of rules is defined, according to which the system acts, and during run-time, decisions are made according to this set of rules. The Optimization Approach used by OpenMES implements this second method which enables the system to overcome failures, imprecision, and inaccurate assumptions, and still provide you with an efficient system.

In a CIM system, the Time, Cost and Quality factors determine the efficiency of the overall system performance. These factors are the target functions of the different algorithms (or of the system). Generally, combinations of these three factors are used in a CIM manufacturing cycle. Additional factors, such as the machine type, can also affect the performance of the CIM cell.

The OpenMES Manager controls the efficiency of a manufacturing cycle, by performing the following tasks:

- **Scheduling:** The OpenMES Manager determines the time schedule that a part will be released from storage and in what order.
- **Dispatching:** The OpenMES Manager determines which part will be processed in which machine and when.

These Scheduling and Dispatching tasks are controlled by the CIM Optimization Definition, as described in Optimization in Chapter 7, OpenMES Manager Utility Programs.

### 2.6.2. CIM Definition Modules

The OpenMES Manager maintains the OpenMES database which contains information on the physical and communication configuration of the cell, inventory of raw materials and parts, manufacturing processes, part definitions, and orders. Interactive software lets you define:

- The layout of machines and stations in the CIM cell.
- Machines and the production processes they can perform
- The bill of materials used to produce each part.
- An order which specifies the parts you want to produce.
- The contents of all storage locations.

The CIM Definition modules also allow you to back up and restore the above information.

The CIM Definition modules are usually run on the same PC used for the OpenMES Manager. Each of these modules creates data files in a DBF format. These files can be viewed and edited with a dBASE editor or with the DataBase Tool which can be activated from the Manager software (for details refer to

Chapter 6: Operating OpenMES Manager). They can also be modified by a user-supplied application (e.g. using an MRP program to create an order file).

### 2.6.3. The OpenMES Manager

The OpenMES Manager performs the following basic functions:

- **Evaluates the Production Plan:** Fills in details in the production plan on how to produce the parts submitted in an order.
- **Executes the Production Plan:** Controls and monitors the CIM equipment to produce the parts as specified in the production plan.

The OpenMES Manager program provides centralized control of on-line production activities. It sends commands to station devices and receives responses which enable it to track the flow of parts during production.

After the production plan has been prepared, you can issue commands to start and stop production from the OpenMES Manager. When you start production, the OpenMES Manager begins sending commands over the LAN to Station Manager PCs in order to:

- Direct the flow of parts between stations on the conveyor.
- Gather at a station (e.g. in a storage rack) the parts that are needed in order to perform an assembly operation.
- Synchronize processes which can be performed concurrently and those which must be performed consecutively.

The OpenMES Manager runs a virtual machine that corresponds to each physical machine in the CIM. This virtual machine keeps track of the status and parts queue at the physical machine. The OpenMES Manager uses this information to decide when to send routing messages to bring parts to the machine.

### 2.6.4. The Station Manager

A Station Manager PC can be connected to a variety of robots and machines. It runs a separate device driver in order to communicate with the controller for each device connected to this PC. These device drivers run simultaneously in individual windows using the multitasking capabilities of MS-Windows. A PC running a set of OpenMES device drivers is said to be acting as a station manager. These OpenMES device drivers perform the following functions:

- Translate OpenMES commands into instructions understood by station devices.
- Translate status information from a device into OpenMES messages and relay these messages to the appropriate OpenMES entities.
- Allow the user to interactively control devices such as CNC machines, robots, and other station devices.
- Download G-code programs to a CNC machine.

If desired, the station computer can be used to operate the station as a stand-alone manufacturing cell. Each device driver on a station PC has a control panel which provides this capability.

### 2.6.5. PC Requirements in OpenMES

The OpenMES system provides great flexibility in the way in which PCs are used around the cell. You can control the degree of distributed processing in the OpenMES environment based on how you assign the following software modules to PCs:

- OpenMES Manager
- Device Manager (i.e. OpenMES device drivers)
- Graphic Tracking

In a busy CIM cell, performance is enhanced by installing most of the above software modules on a separate PC. In this scenario, each station would have a dedicated Station Manager PC. A LAN is used to connect all of the PCs that are running OpenMES software. The OpenMES software modules use this LAN to exchange information.

At the other extreme, all of the above OpenMES software modules could be loaded on one high-performance PC. Multiple OpenMES software modules can run on the same PC in the multi-tasking environment provided by Windows. In this case, inter-module communication is internal, where services are provided by the operating system. When a single PC is used, no LAN is required, although Network Settings for the PC still have to be configured for TCP/IP.

Intermediate configurations are also possible. For example, one PC may be used to run both the OpenMES Manager module as well as the PLC device driver. A single Station Manager PC may be connected to devices at different stations.




Figure 7: OpenMES Modules Distributed Among PC's





Figure 8: OpenMES Module

Minimum PC requirements are:

- CPU Intel i7 processor, equivalent, or above (for Manager Computer. Station computers require i5 or above.)
- 8 GB RAM (16 GB Recommended)
- Windows 10/11 pro or above
- Hard drive with at least 1 GB of free disk space
- On-Board Ethernet or fully Windows compatible LAN interface card
- USB port

- ① *Note: Your operating system may have additional hardware requirements.*
- ① *If a PC is used for multiple functions, the PC must be powerful enough to keep up with the flow of information in the OpenMES real-time environment. For example, a very high performance PC would be required to simultaneously run the OpenMES Manager program, control the conveyor, function as a Station Manager, and show the Graphic production display in real-time.*

## 2.7. DEVICE DRIVERS

Each device at a station is controlled by an OpenMES device driver program running on the Station Manager PC. A device driver translates OpenMES messages in two directions:

- OpenMES instruction messages into a set of commands understood by the target device.
- A response from the device into an OpenMES status message.

After a device driver translates an instruction into a command, it sends the command to the destination machine or robot.

OpenMES instructions can come from:

- The OpenMES Manager
- Other OpenMES device drivers
- The device driver's user interface
- User application programs

When a device returns a response, the device driver translates this information into a standard OpenMES message format. It then relays this information as follows:

- Device status information to the OpenMES Manager.
- Real-time production data to the Graphic Tracking module.
- Designated messages from a device to a user defined process that is monitoring this device.
- Specific messages to other device drivers.

A separate copy of a device driver is run on a Station Manager PC for each device at the station. Each device driver presents a control panel which allows you to:

- Observe the command and response messages on-screen as they are sent to and from a device.
- Issue commands interactively to a device and observe responses on-screen.
- Capture all commands and responses in a log file if you want to analyze the behavior of a device.

Parameters which control the operation of each device driver are found in the device driver's configuration files (ACLVD1.INI, CNCVD1.INI). You can view and change these parameters by editing this file with a text editor.

### 2.7.1. Robotic Device Drivers

The robotic device driver communicates with a robotic controller, which controls robots (including the **ASRS**). This robotic device driver receives command messages from the OpenMES Manager to perform robotic operations. The robotic device driver then translates these requests into commands to run the corresponding robotic programs residing in the robotic controller. When the controller has finished moving the robot, it sends a confirmation message back to the device driver which forwards it to the OpenMES Manager.

The following robotic device drivers are used in OpenMES:

- **ACL Device Driver:** The ACL device driver uses an RS232 port on the Station Manager PC to communicate with the ACL controller.

- **Scorbase for Controller USB Device Driver:** The Scorbase software operates the Controller USB, using the Scorbase device driver (residing in the software).
- **Scorbase for Controller USB-Pro Device Driver:** The Scorbase for Controller USB-Pro software operates the Controller USB-Pro, using the Scorbase device driver (residing in the software).
- **Scorbase for CIM Device Driver:** The Scorbase for CIM driver operates specific models of Yaskawa, Fanuc, and Kuka controllers.

The primary operation performed by a robot using pick-and-place. Pick-and-place means taking a part from one location (source) and placing it at another location (target). For example, a common pick-and-place operation involves taking a part from a template and placing it in a CNC machine. The coordinates for each pick-and-place operation are defined in advance and assigned a Location ID. The OpenMES Manager sends a pick-and-place command to the controller which includes two Location IDs (source and target).

The actual path a robot follows when moving from a source location to a target is defined in a robotic program residing in the robotic controller. The CIM is not involved with the complexities of robot movement. It only sends pick-and-place commands which specify the action to take, not how to take it.

In specific CIM station configurations, the robotic controller also controls the various devices (such as, barcode readers and CNC machines). In some cases, the communication between the OpenMES Manager and these devices is handled via the robotic device drivers by activating a robotic program that is responsible for communicating with the device. This is performed according to the ACL or USB configuration, as follows:

- **ACL Configuration:** The RS232 from the peripheral device (such as, CNC or barcode reader), is connected to the ACL controller and is controlled by an ACL program. The ACL device driver then activates this program to operate the device. For example, write specific code into the RS232 line that is connected to the device.
- **Scorbase for Controller USB:** The RS232 from the peripheral device (such as, CNC or barcode reader), is connected to the PC COM port and is controlled by the Scorbase program. The Scorbase device driver then activates the appropriate sub-routine to activate the device. For example, write specific code into the RS232 line that is connected to the device.
- **Scorbase for Controller USB PRO:** The RS232 from the peripheral device (such as CNC or barcode reader), is connected to the PC COM port and is controlled by the Scorbase for USB-PRO controller program. The Scorbase for USB-PRO controller device driver then activates the appropriate sub-routine to activate the device. For example, write specific code into the RS232 line that is connected to the device.
- **Scorbase for CIM:** The RS232/TCP/IP from the peripheral device is connected to the PC (COM port or LAN port) and is controlled by the Scorbase for CIM controller program. The Scorbase for CIM device driver then activates the appropriate sub-routine to activate the device. For example, send/receive specific commands through the RS232/LAN line that is connected to the device.

### 2.7.2. CNC Machine Device Driver

OpenMES uses a CNC device driver to interface with any CNC machine that uses I/O lines, TCP/IP, or an RS232 interface to receive commands and report machine status. This device driver can be adapted to work with any such CNC machine using a built-in language to write short interface routines. The CNC

device driver can control a machine, read the status of a machine, send status messages to other CIM entities, and download G-code programs to the machine using an RS232 interface.

The normal sequence of events is:

1. The OpenMES Manager instructs the robot to load a part into the CNC machine.
2. The CNC device driver receives a command to process a part.
3. The device driver activates the appropriate output line to turn on the machine.
4. The device driver waits for the operation to be completed by monitoring a status line.
5. The device driver sends a status message back to the OpenMES Manager.
6. The OpenMES Manager instructs the robot to remove the part in the CNC machine.

The following sample scenario demonstrates the role of the CNC device driver:

1. The OpenMES Manager sends a command to the CNC device driver to download a G-code file needed to machine an upcoming part.
2. When a robot is ready to insert a part into the CNC machine, its Scorbace or ACL program sends commands to the CNC machine to:
  - Open the door of the CNC machine
  - Open the chuck/vice of the CNC machine
3. The robot inserts the part into the chuck/vice. The Scorbace or ACL program sends commands to the CNC machine to:
  - Close the chuck/vice of the CNC machine
  - Close the door of the CNC machine
4. The OpenMES Manager waits for status lines to indicate that the part is in place ready to be machined.
5. The OpenMES Manager sends a signal to the CNC machine (via the CNC device driver) to begin machining the part.
6. The CNC device driver waits for a status line to indicate that the machining operation is complete.
7. The CNC device driver sends an “Operation Complete” status message to the OpenMES Manager. The Manager in turn sends a command to the ACL controller to signal the robot that it can now remove the part from the CNC machine.
8. The Scorbace or ACL program sends commands to the CNC device driver to:
  - Open the chuck
  - Open the door

9. The Scorbase or ACL program directs the robot to remove the part. It then sends a status message to the OpenMES Manager signaling that the unloading is finished.

The CNC device driver can communicate with a machine using either an RS232 interface or a special I/O board in the Station Manager PC. For an I/O interface, each status line and command line for a machine is connected to this board.

In most cases the CNC device driver uses the ACL device driver or Scorbase device driver to communicate with the machine on RS232 and I/O level.

### 2.7.3. PLC Device Driver

The PLC device driver communicates with the programmable logic controller which directs the operation of the conveyor. This device driver receives messages from the OpenMES Manager about the contents and destination of the pallets traveling on the conveyor. The PLC device driver translates these messages into commands understood by the PLC.

When the PLC detects a pallet arriving or leaving a station, it sends a status message to the PLC device driver on a station PC. This device driver in turn translates the message into a standard OpenMES format. It then broadcasts the message to the OpenMES Manager, the Graphic Tracking module, and any user applications which have registered for this type of message.

The control panel of the PLC device driver lists the destination of each pallet and can show which pallet is at each station. It also lets you interactively issue commands to stop a pallet at a station.

The PLC is normally connected to one of the Station Manager PCs (using an RS232 connection). This PC communicates with the OpenMES Manager PC using the LAN.

OpenMES can accommodate any type of PLC. If a PLC cannot support the pallet look-up table in its memory, this information is stored on the PLC Manager PC. However, better performance results when the look-up table is stored in the PLC. This arrangement eliminates the serial communication overhead associated with performing frequent look-ups every time a pallet passes a station.

### 2.7.4. Quality Control Device Drivers

OpenMES uses a set of device drivers to communicate with different types of quality control devices such as:

- Vision Systems (ViewFlex for Cognex)
- Coordinate Measuring Machine (CMM)
- Laser scan meters, calipers
- Barcode Readers (BCR)
- RFID Readers (RFIDR)

These device drivers receive instructions from the OpenMES Manager to perform a predefined quality control check on a part. These instructions specify the type of test to perform and the range of acceptable results. The quality control tests for each part are defined according to the instructions for each quality control device.

A quality control device driver translates OpenMES messages into commands understood by its associated quality control device. The device driver can communicate with quality control devices attached to either a Station Manager PC or ACL controller via an RS232 interface or I/O port. When the

quality control device performs a test, it sends the result back to the quality control device driver on the Station Manager PC. The device driver translates the message into a standard OpenMES format. It then sends this status message to the OpenMES Manager.

The control panel of each quality control device driver lets you observe the results of each quality control test. It also allows you to interactively issue commands to a quality control device or send status messages to the OpenMES Manager.

## 2.8. OPENMES COMMUNICATION NETWORK

This section describes the OpenMES Communication Architecture.




Figure 9: Communication Networks Used in OpenMES

### 2.8.1. LAN

The OpenMES Manager and device drivers exchange command and status messages via the OpenMES Network. This network is based on the Windows TCP/IP communication protocol. Each module (manager, device drivers) in the TCP/IP protocol has two communication sockets: the server and the client. A socket represents an endpoint for communication between processes across a network. Both the server and the client have an IP address and a port number that are unique. The OpenMES Network transparently delivers the message to the destination application whether it is running on the same PC or on a PC connected via a LAN. Communication can also be performed using functions in a PLC.

OpenMES uses a LAN to exchange information between software modules running on separate computers. When the following software modules are configured to run on separate PCs (or PLCs), the LAN allows them to exchange commands and status information in real-time:

- The OpenMES Manager software
- The Device Driver software / PLC function
- The Graphic Tracking PC (optional)
- Any PCs running user supplied applications that are interfaced to OpenMES

OpenMES uses the LAN to:

- Send commands from the OpenMES Manager to Device Drivers (e.g. data such as part ID #, task to perform, machine to use, etc.)
- Send real-time production status messages from Device Drivers to the OpenMES Manager.
- Allow Device Drivers to retrieve control programs (e.g. G-code) stored on the server.
- Send real-time production status messages to the Graphic Tracking software.
- Transfer CIM messages between different device drivers.
- Transfer CIM messages between devices and a user application running on a networked PC.
- Perform central backup and restore of all PCs attached to the LAN.

OpenMES can use any LAN using a TCP/IP protocol which is supported by Windows to transfer files and send real-time messages.



### 2.8.2. RS232

An RS232 interface (also known as a serial port or com port on a PC) is a low-speed data communications port that typically transmits and receives information at the rate of 300-19,200 bits per second (bps). Data is transmitted serially, i.e. one bit at a time. There is a separate line for transmitting and receiving data.

The following OpenMES devices use RS232 connections:

<b>Station Manager PCs</b>	<p><b>Station Manager PCs use RS232 to:</b></p> <ul style="list-style-type: none"> <li>Download programs to processing machines</li> <li>Pass OpenMES messages to/from an ACL controller</li> <li>Provide a terminal interface for programming ACL controllers</li> <li>Pass OpenMES messages to/from other station devices such as QC systems.</li> </ul>
<b>PLC</b>	<p>The PLC Manager PC uses RS232 to:</p> <ul style="list-style-type: none"> <li>Send pallet destination information to the PLC</li> <li>Send commands to the PLC</li> <li>Receive status messages from the PLC</li> </ul>
<b>Peripheral Devices</b>	<p>Peripheral devices can be attached to the RS232 ports of an ACL controller (e.g. barcode reader).</p>

### 2.8.3. Inputs/Outputs

I/O connections can be used to turn production devices on and off, and to transmit binary information about the status of a device. A separate wire carries each I/O signal. I/O connections use a low voltage DC signal. The exact voltage depends on the specifications of the devices being connected.

I/O connections are used for signaling purposes only. An output signal should never be used to directly drive a piece of electrical equipment. In this case, an output signal should be buffered through a relay or other device to prevent overloading the circuit.

The following CIM devices use I/O connections:

- PLC (to raise and lower piston stops)
- Magnetic sensors at conveyor stations used to send pallet IDs to the PLC
- Processing machines (to operate the machine and report its status)
- Devices attached to an ACL controller's I/O ports (e.g. an automatic screwdriver, a pneumatic gripper for a robot, etc.)

## 2.9. INTEGRATION

In the previous sections you were given an overview of the entire cell. This section describes the integration of various systems and devices by considering the sequence of events when a part moves from station to station for processing.

When the user activates a production order, the OpenMES Manager builds a production plan. This plan includes the parts to be processed, the stations where they are to be processed, and the production activities they will undergo.

In the sample scenario presented below, a cube moves from storage in the ASRS to a CNC station where it is machined into a box. The table below provides a step-by-step description of the flow of information throughout the CIM associated with making a box. Note that operations which are listed in the same grid take place concurrently.

Message Source	Message Destination	Message Content (Command messages in normal typeface) (Status messages in italics)
<b>ASRS Station</b>		
OpenMES Manager	⇒PLC	Stop the next empty pallet that arrives at the ASRS station.
PLC	⇒OpenMES Manager	<i>Empty pallet has arrived at the ASRS station.</i>
OpenMES Manager	⇒Robot Controller	Use robot to remove a template with a cube from storage and place it on the pallet..
Robot Controller	⇒OpenMES Manager	<i>Template is in place on pallet.</i>
OpenMES Manager	⇒PLC	Release this pallet from the ASRS station. Stop this pallet when it arrives at the CNC station.
PLC	⇒OpenMES Manager	<i>Pallet with cube has arrived at the CNC station.</i>
<b>CNC Station</b>		
OpenMES Manager	⇒Robot Controller	Use robot to remove template from pallet and place it on buffer of CNC Station.
Robot Controller	⇒OpenMES Manager	<i>Template with part is waiting on buffer of CNC station.</i>
OpenMES Manager	⇒PLC	Release pallet from CNC station.
OpenMES Manager	⇒Robot Controller	Use robot to place part in CNC machine.
Robot Controller	⇒OpenMES Manager	<i>Part is in CNC machine.</i>

Message Source	Message Destination	Message Content (Command messages in normal typeface) (Status messages in italics)
	Manager	
OpenMES Manager	⇒CNC Machine	Use the CNC machine to ream a hole in the cube to form a box.
CNC Machine	⇒OpenMES Manager	<i>Process complete. Box ready.</i>
OpenMES Manager	⇒Robot Controller	Use robot to place box on template in buffer.
OpenMES Manager	⇒PLC	Stop next empty pallet at CNC station.
Robot Controller	⇒OpenMES Manager	<i>Box is in place on template.</i>
PLC	⇒OpenMES Manager	<i>Empty pallet has arrived at CNC station.</i>
OpenMES Manager	⇒Robot Controller	Use robot to place template with box on pallet.
Robot Controller	⇒OpenMES Manager	<i>Template is in place on pallet.</i>
OpenMES Manager	⇒PLC	Release pallet from the CNC station. Stop this pallet when it arrives at the Assembly Station ...

## 3. Safety

The OpenMES cell is a complex system containing many different machines, each potentially dangerous if proper safety practices are not followed. Certain safe operating practices apply to all, while others are device specific. This chapter presents the general rules, followed by a brief discussion of the safety requirements of each component and contains the following sections:

- **General Safety Rules**, describes the general safety rules that must be followed in the CIM cell and surrounding area.
- **Robot and Controller Safety**, describes the safety rules that must be followed when using the OpenMES robots and controllers.
- **CNC Machine safety**, describes the safety instructions that must be followed when using the OpenMES CNC machines.
- **ASRS Safety**, describes the safety instructions that must be followed when using the OpenMES ASRS storage systems.
- **Conveyor and PLC Safety**, describes the conveyor and PLC safety instructions.

In addition, the User Manuals for all robots and CNC machines contain full descriptions of the safety procedures and warnings for these devices. The user is strongly urged to read these manuals before working with the devices.



Warning!

- ① *Do not approach any OpenMES equipment before reading the safety guidelines in this chapter.*

### 3.1. GENERAL SAFETY RULES

The following rules should be followed when in the vicinity of all moving machinery in the CIM cell such as robots, ASRS, or conveyor.



Warning!

- ① *Exercise caution whenever you are in the area of the CIM cell.*

- Be sure you know the location of the ON/OFF switch, and any emergency shutoff switches, on the following equipment:
  - Robot controller
  - Pallet conveyor
  - CNC machines
- Be alert since any idle piece of equipment could start up suddenly. All CIM machinery can be turned on and off unexpectedly via computer control.
- Exercise special caution in the vicinity of robots since they can start up without notice and move in unexpected ways.
- Members of a group should be careful not to crowd too close to moving equipment when observing the activities at a given station.

- Do not come near a moving device when it is in operation. Be careful that hair, clothes (especially loose sleeves), and jewelry are kept away from the mechanism.
- Do not stick your fingers into a device while it is in operation; they may get caught in the mechanism.
- Keep the work area clean and free of clutter.
- Do not exceed the loading capacity of a device.
- Turn off a device before attempting adjustments, performing maintenance, or measuring a part.

## 3.2. ROBOT AND CONTROLLER SAFETY

Extreme caution must be exercised in the use of OpenMES robots. Recklessness may cause physical harm to the operator and other people in the vicinity.

- Set up a protective screen or guardrail around the robot.
- Make sure the robot base is properly bolted to a table or pedestal. Otherwise, the robot may become unstable and topple during operation.
- Do not use physical force on the robot arm to change its position, or for any other reason.
- Be sure the robot arm has sufficient space in which to operate freely, especially during homing.
- Before connecting any input or output to the controller, and before approaching or handling the robot, make that the controller's main power switch is turned off.
- Before opening the controller housing, be sure to unplug the controller power cable from the AC power outlet. It is not sufficient to switch off the power; the power supplies inside the controller still contain dangerously high voltages.
- Before removing any fuses, be sure to turn off the controller and unplug the controller power cable from the AC power outlet.

ⓘ *To immediately abort all running programs and stop movement of all robot axes:*

- Press the *Emergency Stop* key on the teach pendant (TP)
- Press the controller's red Emergency button (If the controller has one)

### 3.3. CNC MACHINE SAFETY

The following list contains general safety instructions for the use of CNC machines. Be sure you adhere to the safety rules for the specific machines included in your cell.

- Always wear safety goggles when near the machine. Be aware that some materials, such as the brass bars, spray chips while being processed. Make sure all persons near the machine are protected.
- Keep children and visitors away. Set up the machine so that children or visitors unfamiliar with the machine cannot start it. Protect the machine against unintentional use by removing the switch key.
- Secure parts and tools firmly and safely in the chucks or vices.
- Perform measuring and chucking work only when the machine is at a standstill.
- Remove adjusting key and wrenches even when the machine is not being used. Never attach chuck keys to a machine with a chain or similar connector.
- Never work with damaged or dull tools.

### 3.4. ASRS SAFETY

This section describes the safety instructions that must be followed when using the OpenMES ASRS storage systems (ASRS Carousel, ASRS<sup>2</sup>, ASRS-36, ASRS-36u, ASRS-36uX2), each of which is described in the sections that follow.

#### 3.4.1. ASRS Carousel

The following list contains safety instructions for the use of ASRS Carousel:

- Do not place your hand or any other object in or near the main drive belt, located under the lowest level of the ASRS carousel, while the device is operating. The belt is extremely dangerous and can cause severe injury.
- Make sure that the carousel has been disconnected from the AC power supply before approaching the motor and belts.

#### 3.4.2. ASRS<sup>2</sup> and ASRS-36

The following list contains safety instructions for the use of ASRS<sup>2</sup> and ASRS-36

- Do not enter the robot's working envelope or touch the robot when the system is in operation.
- Use caution when moving the ASRS<sup>2</sup> and ASRS-36 robots by means of the teach pendant.
- To halt movement of the ACL robots which tend the ASRS<sup>2</sup> and ASRS-36 units, do any of the following:
  - Press the Abort or Emergency Stop key on the teach pendant, or
  - Press the controller's red Emergency button, or
  - Use the ACL command A <Enter>.

### 3.4.3. ASRS-36u and ASRS-36uX2

The following list contains safety instructions for the use of ASRS-36u and ASRS-36uX2:

- Do not enter the robot's working envelope or touch the robot when it is in operation.
- Exercise caution when moving the ASRS-36u and ASRS-36uX2 robots by means of the teach pendant.
- To halt movement of the USB robot which tends the ASRS-36u and ,ASRS-36uX2 units, do any of the following:
  - Press the Abort or Emergency Stop key on the teach pendant, or
  - Press the controller's red Emergency button, or
  - Use the Stop icon in the Scorbace software toolbar.
- ① *Opening any of the plexiglass doors which enclose the ASRS<sup>2</sup> will automatically and immediately halt all movement of the ASRS robot. Upon closing the door, movement will resume.*

## 3.5. CONVEYOR AND PLC SAFETY

The following list contains the conveyor and PLC safety instructions:

- **Be sure you know the location of the conveyor's power ON/OFF switch.** To immediately stop the conveyor, simply shut off this switch.
- **Keep hands and objects away from the conveyor drive unit.**
- **Do not tamper with the conveyor motor. Do not remove the conveyor motor covers under any circumstances.**
- **Do not touch or tamper with the power supply inside the PLC near the conveyor motors.**
- **Do not tamper with the switch and connector box for the 100/110/220/240/380V AC power supply (depending on device)**

## 4. Installation

This chapter describes the hardware assembly processes, the wiring connections, the software installation and configuration procedures and system verification and more. It includes the following sections:

- **OpenMES Installation Workflow**, describes the required order for installing the OpenMES system components.
- **Hardware Installation**, describes the assembly instructions of the hardware components of the OpenMES system.
- **Wiring**, describes the wiring connection procedures of the hardware components in the OpenMES system.
- **Software Installation**, describes the network setup and the OpenMES software installation and configuration.
- **Robot Positions and Homing**, describes how to teach the robot positions at the OpenMES stations.
- **System Check**, describes the verification and adjustment procedures of the hardware components and device drivers.

### 4.1. OPENMES INSTALLATION WORKFLOW

The OpenMES system is normally installed in the following order:

1. Hardware Assembly, described in Hardware Installation.
2. Wiring connections including network hardware, described in Wiring.
3. Software installation including software protection keys and network setup, described in Software Installation.
4. Teaching of robot positions, described in Robot Positions.
5. Checking and adjustment of devices, for standalone and system operation, described in System Check.

OpenMES hardware configurations vary. This chapter presents the basic guidelines for setting up CIM equipment. Additional installation instructions will be provided separately for the specific equipment and configuration of your OpenMES cell.

### 4.2. HARDWARE INSTALLATION

Before installing the CIM cell, examine it for signs of shipping damage. If any damage is evident, contact your freight carrier, and begin appropriate claims procedures.

Make sure you have received all the items listed on the shipment's packing list. If anything is missing, contact your supplier.



For personal safety and for sufficient access to the stations from all open sides, a free area of at least one meter around each station is recommended.

Be sure you comply with all safety guidelines and warnings in the user manuals supplied with the robot, controller, and other devices.

Some stations may have tables with slotted surfaces or predrilled holes to facilitate the mounting of the robots and devices.

#### **4.2.1. Conveyor and Pallets**

Refer to the instructions provided with your conveyor and/or OpenMES cell.

Set up the conveyor within reach of the power supply and the air supply.

Assemble the conveyor and attach the conveyor buffers at each station.

Make sure the conveyor is assembled so that it moves clockwise or counterclockwise depending on your specific system layout.

Place the pallets supplied with the system anywhere along the conveyor with the arrow on the pallet pointing in the direction of movement of the conveyor.

#### **4.2.2. Robots and Robot Controllers**

The basic steps for installing a robotic system for use in the OpenMES cell *are described below:*

1. Setup the robotic system according to the instructions in the User's Manual supplied with the robot/controller.
2. Interface the robotic system with relevant accessories (I/O devices and so on.)
3. Once the robotic system is functional, create a communication interface using the OpenMES software.

For detailed instructions on connecting the robot and controller, refer to the User's Manual supplied with the robot/controller. In addition, refer to the instructions provided with your CIM cell.

#### **4.2.3. ASRS**

Most ASRS systems are pre-assembled units that have to be placed near a conveyor station so that pallets can be loaded/unloaded. If you customize the ASRS make sure that the tending robot can reach all relevant elements and optimize the layout with respect to the tending time of the robot.

Refer to the instructions provided with your ASRS and/or CIM cell.

#### **4.2.4. Barcode Reader**

The standard Barcode reader is normally mounted within robot reach on the conveyor next to the ASRS stop station in order to check outgoing and incoming template IDs. It requires a 5.6V DC power supply and an RS232 connection either to the Station PC or to the robot controller.

Refer to the instructions provided with your barcode reader and/or OpenMES cell.

#### 4.2.5. RFID Reader

RFID (Radio-frequency Identification) is a commonly used automatic identification technology that transmits an identification serial number using radio waves.

The standard RFID reader is normally mounted within robot reach on the conveyor next to the ASRS stop station in order to check outgoing template IDs. It requires a 12V DC power supply and an RS232 or USB port on the Station PC.

Refer to the instructions provided with your RFID reader and/or OpenMES cell.

#### 4.2.6. Pneumatic Devices

Pneumatic devices in a station (pneumatic door, fixtures, caliper, air blows, etc.) including position sensors are normally interfaced through the I/Os of the robot controller. They can also be controlled by a separate PLC if requested by the customer. In any case, pneumatic devices require the appropriate supply of compressed and conditioned air.

Refer to the instructions provided with the specific device and/or OpenMES cell.

#### 4.2.7. Palletizing Racks and Buffers

Normally, buffers are mounted on the conveyor but, for a specific station layout, it is possible to attach them to a table. Palletizing racks are used as a flexible storage that can be adapted to various parts by using sets of different sized pins. Make sure the pins are arranged identically for each part of the same type in the palletizing rack.

Refer to the instructions provided with the OpenMES cell.

#### 4.2.8. Templates

Templates are used to transport parts within the system. Templates, which have a grid of holes together with different sized pins, allow flexible adjustment for different parts in a similar way to the palletizing racks. Make sure the pins are arranged identically on all templates which will hold identical parts.

Refer to the instructions provided with the OpenMES cell.

### 4.3. WIRING

Wiring depends on the actual stations, machines and devices included in your installation. Most systems are installed by a trained engineer who will supply you with specific wiring documentation (communication layout) to enable you to easily understand and maintain the system.

Refer to the documentation and wiring instructions provided with the CIM cell.

#### 4.3.1. Network

It is possible to operate OpenMES on any desktop or laptop PC which complies with the required hardware specifications in which a network board (adapter) has been installed, providing that you have installed the software driver which enables the adapter to work with the Windows Operating System. For further details, see Network Setup. Network wiring, which is documented in the communication layout, is performed through a hub.

## 4.4. SOFTWARE INSTALLATION

This section describes how to set up the OpenMES network as well as how to install and configure the various OpenMES software components such as the OpenMES projects, the web viewer and more.

### 4.4.1. Network Setup

Once Windows has been installed and all PC devices (mouse, graphic card, network card, and so on ) have been set up on each PC that is to be used in the OpenMES network, set up the network as described in the following procedure:

To set up the network:

1. Define the Network Workgroups and computer names. Computer names are case-sensitive. It is recommended that you use names such as these:

Network Workgroup	CIM
OpenMES Manager PC	CIM-MANAGER
Station PCs	CIM-PC1, CIM-PC2, etc. on which the logical workstations (WS1, WS2, etc.) of the CIM are located

2. Set the TCP/IP network protocol as your communication protocol. Select the IP address as follows: If your network Workgroup is part of a global network (i.e. is connected to a server) choose the option: Obtain an IP address automatically.  
If your network workgroup is local (i.e. not connected to a server) set the IP address, for example, as 200.1.1.1 and increment the last digit for each additional PC.  
For all PCs in the CIM, specify the same subnet mask, for example, 255.255.0.0. For details, contact your network administrator.
3. If you are using more than one PC, it is a good idea to verify that the PCs are connected to the network.

To see the names of the connected PCs, follow one of the procedures outlined below.

- *In Windows 10/11:*
  - Access **This PC**.

If you don't see the PC names, wait a few seconds and press **F5**. If the names are still not displayed, check the network setup again.

#### 4.4.2. Installing the OpenMES Software

After setting up the network, the next step is to install the OpenMES software. The following procedure describes how to install one of the OpenMES products (OpenMES, OpenMES Offline, OpenFMS). You can cancel the setup process at any time by pressing Cancel.

To install the OpenMES software:

1. Download and run the OpenMESsetup.exe file.
2. In the Welcome window of the Installation Wizard choose **Next**. The License Agreement window is displayed.




Figure 10: License Agreement Window

Review the Intelitek software license agreement. You must accept the terms of this agreement in order to complete the installation. If you do not accept the agreement, you cannot proceed with the installation. To accept, click Yes. The Installation Mode window is displayed.




Figure 11: Installation Mode Window

3. Select the desired language and then click **Next**.
  4. Select the OpenMES product that you want to install and click **Next**. The Project Selection window is displayed.
- ① *The WorkStation Environment option is used (by Intelitek technical support personnel) to install system components necessary to run device drivers from a PC which is not the OpenMES Manager PC. For further details, see Software for WorkStation PCs.*




Figure 12: Project Selection Window

5. Select the required projects to install.
  6. Select the required option as follows:
    - Select **OpenMES Projects** to add the default OpenMES projects to your existing OpenMES installation.
    - Select **OpenMES Curriculum Projects** to add the OpenMES Curriculum Projects to your existing OpenMES installation.
- ① *You can select one or both of the above.*

7. Click **Next**. The Web Viewer Configuration window is displayed.




Figure 13: Web Viewer Configuration Window

8. Check the Web Viewer box and click **Next** to add the Internet Information Services (IIS) Web Server (necessary for the web viewer), and to configure the Web Server to work with the Web Viewer. The Choose Destination Location window is displayed.




Figure 14: Choose Destination Location Window

9. Click **Next** to install to the default folder or click **Browse** and choose another folder. The Select Program Folder window is displayed.
10. Click **Next** to accept the default Program Folder name. (You may also type a new folder name or select another folder from the existing folders list.)
11. The installation progress bar is displayed on the screen. When prompted by the on-screen instructions, click **OK** to install the launch icon on your desktop.
12. The Installation Complete window is displayed when installation has been successfully completed as shown in Figure 15.




Figure 15: Installation Complete Window

13. Click **Finish** to exit the InstallShield Wizard.

If selected during the installation, the OpenMES launch icon is displayed on the desktop.



OpenMES can also be launched via the Windows start or program menus.



### 4.4.3. Manual Web Viewer Installation

It is recommended that you choose to install and configure the Internet Information Server (IIS) automatically by checking the box in the Web Viewer Configuration window which appears during the OpenMES installation procedure.

The following section describes how to install the Internet Information Server (IIS) and configure the Web Viewer manually.


After installing the OpenMES software, the Web Viewer can be installed and configured manually as shown in the steps outlined below:

- **Installing the IIS**, describes the installation procedure for the Internet Information Server (IIS).
- **Configuring the Web Viewer**, describes the configuration of the web server.


#### 4.4.3.1. Installing the IIS

**In Windows 10/11:**


1. From the Start/Search menu, access the Turn Windows features on or off window.



- Expand **Internet Information Services | Web Management Tools | IIS 6 Management Compatibility**. Verify that all its branches are checked.



- Expand **Internet Information Services | Web Management Tools | IIS 6 Management Compatibility**. Verify that all its branches are checked.
- Expand **Internet Information Services | Web Management Tools | World Wide Web Services | Application Development Features** and check the following branches:
  - ASP
  - ISAPI Extensions



5. Click **OK**.

#### 4.4.3.2. Configuring the Web Viewer

After installing the IIS manually, the next step is to configure the Web Viewer. When reinstalling or upgrading the Open CIM application, the configuration procedures described in this section are not required.

This section describes how to configure the Web Viewer.

- ① *In order for the Web Viewer to work when the firewall is enabled, Port 80 in the firewall must be opened.*

#### 4.4.4. Configuring the Web Viewer

The following procedure describes how to configure the web viewer.

1. From your windows **Start** menu, select **Run**. The Run window is displayed.




Figure 16: Component Services Window

1. In the tree menu in the left pane, browse to **Component Services | Computers | (My Computer for Windows 8.1/10) | DCOM Config**.

2. Right-click **Manage Document** and select **Properties**. The Manage Document Properties window appears displaying the **General** tab.




Figure 17: Manage Document Properties Window- General Tab

3. From the Authentication Level dropdown list, select **None**.

4. Select the **Identity** tab, as shown in Figure 18.




Figure 18: Manage Document Properties Window-Identity Tab

5. Select **The interactive user** and click **Apply** and then **OK** to close the Management Document Properties window.

To change security settings, repeat steps 1-5 above, and proceed as follows:

1. Select the Security tab as shown in Figure 5-19:




Figure 19: Manage Document Properties-Security Tab

2. In the Launch and Activation Permissions area, select **Customize** and click **Edit**. The Launch and Activation Permission window is displayed.



Figure 20: Launch and Activation Permission Window

3. Select the **Allow** check boxes for Local Launch and Local Activation.
4. Click Add | Advanced | Find Now
5. Scroll through the list of search results to find the following user:
  - **IUSR**
6. Double-click the name.
7. Click **OK**.



8. Return to the Manage Document Properties window. In the Access permissions area in the Security Tab, select **Customize** and click **Edit**.





Figure 21: Access permissions Window

9. Repeat steps 4 to 7.
10. Select **Allow** for Local Access in the Access Permissions window.
11. Click **OK**.
12. Restart your computer, in order for the changes to take effect.

Before you can activate the Web Viewer, you must activate the Web Viewer in the CIM Modes window, accessed from the Modes  button on the OpenMES Manager toolbar, as described in Modes Dialog Box in Chapter 6, Operating OpenMES Manager. In addition, the HTTP protocol must be enabled in order to access the Web Viewer.

#### 4.4.5. Software for Workstation PCs

- ❶ *For workstation PCs which require ViewFlex and/or Scorbace software, it is highly recommended that they be installed before the installation of the Workstation Environment*
- ❶ *They can however be defined manually within the project directory by modifying the configuration files which they use. Refer to Chapter 12 OpenMES Loader: DDLoader.EXE for more details.*
- ❶ *Microsoft .Net Framework 4.0 is required on the client PC for the use of the OpenMES RFID driver and will be installed automatically if it is not already installed on the workstation PC.*

##### 4.4.5.1. Installing the Workstation Software

To install Workstation software:

1. From the Install folder, run the OpenMESsetup.exe file.
2. In the Welcome window of the Installation Wizard choose **Next**. The License Agreement window is displayed.
3. Review the Intelitek software license agreement. You must accept the terms of this agreement in order to complete the installation. If you do not accept the agreement, you cannot proceed with the installation. To accept, click **Yes**. The Installation Mode window is displayed.
4. Select **Workstation Environment** and click **Next**. The Choose Project window is displayed.
5. Browse to the location of the project that the workstation environment will be using and click **Next**. The Select a Workstation window is displayed.
6. Select the workstation to install, and Remote Graphic Display if desired (Refer to Chapter 6: Operating OpenMES Manager for information on configuring the Remote Graphic Display). Several Workstations may be installed on one computer. Click **Next**.
  - If the workstation you are installing uses ViewFlex, the ViewFlex Path window is displayed. Refer to the next step.
  - If the workstation you are installing uses Scorbace, the Scorbace Path window is displayed. Refer to step 8.
  - If the workstation does not require ViewFlex nor Scorbace, skip to step 9.
7. Browse to the location of ViewFlex on your system and click **Next**. The ViewFlex Path window is displayed.
- ❶ *If you have not yet installed ViewFlex, click Skip to continue the installation process.*
8. Browse to the location of Scorbace on your system and click **Next**. The Choose Destination Folder window is displayed.
- ❶ *If you have not yet installed Scorbace, click Skip to continue the installation process.*
9. Browse to the folder in which you want to install the Workstation Environment files and click **Next**. The installation will begin.

Shortcuts for the DDLoaders for the installed Workstations, and for the Remote Graphic Display if it was installed, will be added to the Desktop and to the Start menu.

#### 4.4.5.2. Configuring Workstations

To use the OpenMES modules on a station PC, ensure that you perform the following procedures:

- **On the OpenMES Manager and all Workstations**, configure the firewall for communication with other Workstations in the local network.
- **On all Workstations**, enable all workstations in the local network to access the Manager PC Drive in which the projects are installed by sharing the projects folder.
- Note: In order to work with the Remote Graphic Display with CIM custom parts displayed correctly on the Workstation, the following folder must be shared:
  - C:\Users\Public\Documents\Intelitek\OpenCIM.

##### 4.4.5.2.1. Firewall Configuration

If the firewall of a Workstation is enabled, ports must be opened for them for the Workstation to be used in the local network. Open the Map.ini file to see which ports to open. For more details on this file, refer to Chapter 12: Inside OpenMES.

In order for the Web Viewer to work, Port 80 must also be opened in the firewall.

##### 4.4.5.2.2. Enable Access to OpenMES Manager

Before you begin, you must verify that the settings displayed in Figure 39 are on, to enable you to set the folders for sharing.




Figure 22: Sharing and Discovery Window

To verify that the correct options are on, follow these steps:

1. Click Start | Control Panel | Network and Internet | Network and Sharing Center.
2. In the Sharing and Discovery area, ensure that the first three items are on, as illustrated in Figure 22.

The projects are installed in the following locations:

- C:\Users\Public\Documents\Intelitek\OpenCIM\Projects.

**To share a folder:**

1. Access **This PC**.
2. Browse to and right-click the required folder.
3. Select **Properties | Sharing | Advanced Sharing** (if you are not the administrator you will need to enter the user name and password).
4. Click Continue.
5. Select Share this folder.
6. Confirm that the Share name is correct.
7. Click Permissions.
8. Check the **Full Control** option.
9. Click **OK**.
10. In the Advanced Sharing window click **OK**.
11. In the Properties window click **Close**.

On the Station PCs, map the drive of the Manager PC (where the projects are installed) through the network, as follows:

1. Select and right-click **My Computer**.
2. Select Map Network Drive.
3. Select a free drive and write the path for the Manager's projects directory.  
For example: Drive E: <path> \\Manager\Projects.
4. Check **Reconnect at Logon** and click **OK**.

On the Remote Graphic Display Station PC, map the drive of the Manager PC (where the OpenMES shared directory is located) through the network, as follows:

1. Select and right-click **My Computer**.
2. Select Map Network Drive.
3. Select a free drive and write the path for the Manager's projects directory.  
For example: Drive E: <path> \\Manager\OpenMES.
4. Check **Reconnect at Logon** and click **OK**.

#### 4.4.6. Other Software

An OpenMES system can include many devices which require additional software (e.g., Vision Systems, CNC machines, CAD/CAM, etc.).

Refer to the documentation and software installation instructions provided with each device.

#### 4.4.7. ACL Controller Configuration

The following procedure is valid only for ACL controller types A and B. For other controllers, refer to the documentation and software installation instructions provided with each device.

At each station which contains an ACL controller, you will need to configure the controller and download the file ALL.CBU from the Station Manager PC to the ACL controller. This file contains all programs, positions and parameters required for controller operation in the OpenMES environment.

To configure the controller from the ATS main screens:

1. Press **<Ctrl>+F1** to configure the controller.
2. Press **Y** to confirm the prompt to configure the controller. You are then prompted by a short series of Controller Configuration options. Refer to the ATS Reference Guide provided with your ACL controller for complete instructions on configuring the controller.

Once you have confirmed the configuration, ATS will perform the configuration procedure. You can ignore the message about the missing SETUP.PAR parameter file.

3. When the **>** prompt appears, press **[Shift] + F10**. The ATS Backup Manager screen opens.
4. Perform the following selections and entries:

Backup directory:

C:\Users\Public\Documents\Intelitek\OpenCIM\Projects\microcim\ws1\robot1

Make sure the path correctly shows the working directory defined during the configuration, as shown in this example.

Backup / Restore: ALL

5. Use the arrow keys to highlight **ALL** and press **[Enter]**.
6. During Restore: ERASE.
7. Use the arrow keys to highlight ERASE and press **[Enter]**.
8. File name: all
9. Type **ALL** and press **[Enter]**.
10. Press **[Enter]** again. Press **F5** to RESTORE from disk.
11. Press **Y** to confirm all prompts to overwrite and erase.

#### 4.4.8. Scorbace and Scorbace PRO Configuration

At each station which uses Scorbace, you will need to configure the software to match the robot and peripherals that the Controller will control.

To configure Scorbace, select **Options | Hardware Setup** from the Menu bar in Scorbace. Configure the settings in the Hardware Setup dialog box to match the robot and peripherals (and gripper if appropriate), that will be controlled by the Controller. Once you have configured the Hardware Setup,

click the **Search Home**  icon to home the robot.

Note: Scorbace must be in On-line mode before configuring the Hardware Setup. To change to On-line mode, select **Options | On-line** from the Menu bar.

For more information on configuring Scorbace, refer to the Scorbace for SCORBOT-ER 4u and Scorbace User Manuals.

### 4.5. ROBOT POSITIONS AND HOMING

The actual location of robot positions will differ depending on the actual stations, machines and devices included in the OpenMES installation. You will therefore need to record (teach) new coordinates for the positions which were downloaded to the controller.

For further details on defining the positions, refer to the instructions supplied with your OpenMES installation. In addition, refer to the User Manual that is provided with the robot or controller.

The procedures in this section describe how to home the robot from the ACL and USB controllers. For other controllers, refer to the documentation and software installation instructions provided with each device.

#### 4.5.1. Homing the Robot from the ACL Controller

The following procedure describes how to home the robots from the ACL controller (types A and B). The teaching of robot positions is performed from the **ATS**. You must home the robot before you teach positions, as described in the following procedure.

To home robot from the ACL controller:

1. Enter the ACL command: RUN HOMES
12. Wait until the robot has completed the homing twice. All positions used in the OpenMES belong to the vector CIM[n]. The size of the vector can vary from station to station. The standard size is  $n = 500$ . To teach the robot the positions required for the application, you must attach this vector to the teach pendant. Enter the ACL command: ATTACH CIM
13. When you have finished recording the positions, use the ATS Backup Manager to save the programs, positions and parameters to disk. Save each item as a separate file. Make the following selections and entries:

Backup directory:

C:\Users\Public\Documents\Intelitek\OpenCIM\Projects\microcim\ws1\robot1

(for example)

Backup / Restore: ALL




File name: All

14. Press **[Enter]** again. Press F3 to SAVE to disk
15. Backup / Restore: PROGRAMS
16. File name: programs
17. Press **[Enter]** again. Press F3 to SAVE to disk.
18. Backup / Restore: POSITIONS
19. File name: position
20. Press **[Enter]** again. Press F3 to SAVE to disk.
21. Backup / Restore: PARAMETERS
22. File name: parameter
23. Press **[Enter]** again. Press F3 to SAVE to disk.

### 4.5.2. Homing the Robot from Scorbase

This procedure describes the basic instructions for homing the robot from the Scorbase software. For additional information on homing and recording the positions, refer to the Scorbase User Manual. To home the robot from Scorbase:



1. Activate the Scorbase software, by double clicking the Scorbase  icon on your desktop.
  2. From the Scorbase Main Window select Options | On-line to activate on-line mode and click the  icon to home the robot. Refer to the Scorbase User Guide for additional details on homing and recording the robot positions.
  3. Select File | Open Project and navigate to the required project file for this station. For example:
    - \\CIM-MANAGER\Public\Documents\Intelitek\OpenCIM\Projects\M-CIM-SCBS\WS1\ROBOT1-program sample\Station1.WS
-  *Select the Reload last Project at Startup from the Options menu, to load this project automatically the next time you load Scorbase.*

## 4.6. SYSTEM CHECK

The system check depends on the actual stations, machines and devices included in the OpenMES installation. Refer to documentation and instructions supplied with your OpenMES installation.

Check the following hardware and device drivers and make sure they are functioning properly:

- Power Supply
- Conveyor
- Robots (for ACL controller use the ACL program DEBUG)
- PLC Device Driver
- Robotic Device Drivers
- CNC Device Driver
- Quality Control Device Drivers




## 5. Project Manager

This chapter describes the Project Manager application that launches the Virtual OpenMES Setup and OpenMES Manager. It enables users to manage their own projects and enables administrators to manage the projects in the archive. It includes the following sections:

- Accessing the Project Manager, describes how to access the Project Manager application.
- Project Manager Main Window, describes the main components of the Project Manager interface.
- Project Manager User Mode, describes the various project management tasks that can be performed by the user. These include adding, importing, and exporting projects as well as other tasks.
- Project Manager Administration Mode, describes the additional tasks performed by the administrators enabling them to manage the projects displayed in the archives.

### 5.1. ACCESSING THE PROJECT MANAGER

After the OpenMES installation is complete, the Project Manager icon is displayed on your windows desktop and Start menu.

To log in to the Project Manager application, click the OpenMES Project Manager  icon on your desktop.

The CIM Project Manager window appears displaying the **User Projects** tab, as shown in Project Manager Main Window in the following section.

## 5.2. PROJECT MANAGER MAIN WINDOW

The CIM Project Manager Main window is displayed, as follows:




Figure 23: Project Manager Main Window

The CIM Project Manager window, shown above, contains the following elements, each of which is described in the sections that follow.

- Project Manager File Menu
- Project Manager Home Ribbon
- Archive Tab
- User Projects Tab
- 3D Model Preview Window

### 5.2.1. Project Manager File Menu

The Project Manager Menu contains the File menu and the Home ribbon. Each of these are described below.

#### 5.2.1.1. Project Menu

The following table contains a brief description of each option in the Project menu:

Option	Description
New	Enables you to add a new project to the list.
Import	Enables you to import an existing Project from a specified directory. This option is enabled from the User Projects tab only.
Save As	Enables you to save the selected project under a new name. The new project is displayed in the list of projects in the User Projects tab.
Load All	Loads all the projects existing in the Projects directory into the User Projects tab. This feature is used, for example, when upgrading your OpenMES, enabling you to load all previous projects that were created previously. This option is enabled from the User Projects tab only.
Back Up	Enables you to export a project to a specified directory for backup purposes. You can export projects from both the User Projects and Archive tab.
Delete	Removes a project permanently from the list as well as from your computer. You must have administrator access rights to remove projects from the Archive.
Exit	Exits the Project Manager application.

#### 5.2.1.2. Home Ribbon

The following table contains a brief description of each option in the Home Ribbon menu.

Option	Description
New	Enables you to add a new project to the list.
Import	Enables you to import an existing Project from a specified directory. This option is enabled from the User Projects tab only.
Save As	Enables you to save the selected project under a new name. The new project is displayed in the list of projects in the User Projects tab.
Back Up	Enables you to export a project to a specified directory for backup purposes. You can export projects from both the User Projects and Archive tab.
Delete	Removes a project permanently from the list as well as from your computer. You must have administrator access rights to remove projects from the Archive.
OpenMES Manager	Activates the OpenMES Manager application, with the selected project from the User Projects list.

OpenMES Setup	Activates the Virtual OpenMES Setup application, with the selected project from the User Projects list.
Administrator	Enables you to log in as an administrator.
Move to Archive	Moves the selected project from the User Projects tab to the Archive tab. Enabled for administrator's only.
Move to User Projects	Moves the selected project from the Archive tab to the User Projects tab. Enabled for administrators only.
On/Off 3D Model	Displays/hides the 3D model preview.
User Manual	Displays the OpenMES user manual (this manual).
About	Displays the About Project Manager window containing the current software version information.

### 5.2.2. User Projects Tab

The User Projects tab appears automatically when you access the Project Manager application. The User Projects tab contains a list and description of the user's projects and enables you to perform the following:

- Create new OpenMES projects.
- Import projects from an external directory into the user projects list.
- Export projects from the user projects list to an external directory for backup purposes.
- Perform various editing options, such as, save as, delete, move to archive and more.
- Access the Virtual OpenMES Setup or OpenMES Manager applications.

The User Projects tab appears as follows:





Figure 24: CIM Project Manager – User Projects Tab


### 5.2.3. 3D Model Display Area

When **On 3D Model** is selected from the Home ribbon, the selected project is displayed in the 3D model display area. You can zoom in and zoom out, rotate the image, and adjust the viewing angle using the viewing options described in OpenMES Manager’s graphic display module described in Graphic Display and Tracking in Chapter 6, Operating OpenMES Manager.



### 5.2.3.1. User Projects Right-Click Menu

The User Projects right-click menu provides alternate quick access to some of the most commonly used functions in the User Projects tab of the CIM Project Manager window. To access the menu, select a project and then right click on the project name. The menu appears as follows:



The options in the right-click menu shown above are described in the Project Manager Toolbar and Project Manager Main Window sections of this chapter.

### 5.2.3.2. Archive Tab

The Archive tab contains a list and description of all the predefined projects that are provided with the OpenMES software and enables you to perform the following:

- Copy projects to the user projects list (users and administrators)
- Save projects to an external location for backup purposes. (users and administrators)
- Perform various editing options, such as delete, move to user projects and more (administrators only).

The Archive tab appears as follows:





Figure 25: CIM Project Manager – Archive Tab

#### 5.2.3.2.1. Archive Tab Right-Click Menu

The Archive Tab right-click menu provides alternate quick access to some of the most commonly used functions in the Archive tab of the CIM Project Manager window. To access the menu, select a project and then right click on the project name. The menu appears as follows:



The options in the right-click menu shown above are described in the Project Manager Toolbar and Project Manager Main Window sections of this chapter.

## 5.3. PROJECT MANAGER USER MODE

The Project Manager application enables users to manage their projects from the User Projects tab. The tasks that the user can perform include adding projects, importing, and exporting projects, copying projects and more.

### 5.3.1. Adding Projects

You can add new projects from the User Projects tab in the OpenMES Project Manager window. After you have created your project, you can then activate the Virtual OpenMES Setup or OpenMES Manager applications for the selected project.

To add projects:

1. With the User Projects tab selected, click **New** on the Home ribbon. The Save As dialog box is displayed.




Figure 26: Save As Dialog Box

2. In the Project name field, enter the name of the new project, and click **OK**. The new project is added to the list of projects in the User Projects tab.
3. You can now select the new project in the User Projects tab and then select the required option, as follows:
  - **OpenMES Setup** : Activates the Virtual OpenMES Setup application to enable you to edit your simulated CIM cell of the project. (For further details refer to Chapter 8, Virtual OpenMES Setup).



- **OpenMES Manager:** Activates the OpenMES Manager application, enabling you to centrally control all the activities of the OpenMES cell. (For further details refer to Chapter 6: Operating OpenMES Manager).

### 5.3.2. Importing Projects

The Project Manager enables users to import existing OpenMES projects into the User Projects tab from a specified directory.

To import projects:

1. From the Home ribbon, select **Import**. A file browser is displayed.
2. Navigate to the required directory and select the project (containing the **\*.O2C** format) that you want to import.
3. Click **Open**. The selected project is displayed in the list of projects in the User Projects tab.

### 5.3.3. Exporting Projects

The Project Manager enables users to export an existing CIM Project from the User Projects or Archive tab to a specified directory, for future reference.

To export projects:

1. From the User Projects tab, select the project that you want to export.
2. From the Home ribbon, select **Backup**. The Save As dialog box is displayed. Navigate to and select the directory to export and then click **Save**. The project is saved in the selected directory.

### 5.3.4. Loading All Projects

The Project Manager enables users to load all the projects that exist in the OpenMES directory into the User Projects tab. This option is enabled from the User Projects tab only

To load all projects:

With the User Projects tab open, select **File | Load All**. All the projects that exist in your Projects directory on your computer will be displayed in the User Projects tab. This feature is used for retrieval purposes and can be useful when upgrading your OpenMES, enabling you to load all the previous projects created previously.

### 5.3.5. Copying Projects

The Project Manager enables users to create a copy of the selected project by saving it under a new name. The new project is then displayed in the list of projects in the User Projects tab.

To copy projects:

1. From the User Projects or Archive tab, select the project that you want to copy, and from the Home ribbon or File menu, click **Save As**. The Save As dialog box is displayed:




Figure 27: Save As Dialog Box

2. In the Project name field, enter the new project name and click **OK**.
  3. The new project is added to the list of projects in the User Projects tab.
- ❗ *The Save As option always displays the new project to the User Projects tab (even when you select this option from the Archive tab).*

### 5.3.6. Removing Projects

When removing projects from the User Projects tab, you must act cautiously since the project is removed permanently from your computer. Only administrators can remove projects from the Archive tab.

To remove projects:

1. From the User Projects tab, select the project that you want to remove.
2. Click **Delete**. The selected project is removed from the User Projects list.

### 5.3.7. Accessing OpenMES Manager

The OpenMES Manager application enables users to centrally control all the activities of the selected CIM cell. For further details refer to Chapter 6, Operating OpenMES Manager.

To access the OpenMES Manager:

1. From the User Projects tab, select the project for which you want to access the OpenMES Manager.
2. From the Home ribbon, select **OpenMES Manager** to activate the OpenMES Manager application, enabling you to control all the activities of the OpenMES cell. (For further details refer to Chapter 6, Operating OpenMES Manager).

### 5.3.8. Accessing Virtual OpenMES Setup

The Virtual OpenMES Setup application enables users to create and modify the virtual setup of the selected cell. For further details refer to Chapter 8, Virtual OpenMES Setup.

To access OpenMES Setup:

1. From the User Projects tab, select the project for which you want to access the Virtual OpenMES Setup.
2. From the Home ribbon, select **OpenMES Setup** to activate the Virtual OpenMES Setup application, enabling you to edit your simulated CIM cell of the selected project. (For further details refer to Chapter 8, OpenMES Setup).

## 5.4. PROJECT MANAGER ADMINISTRATION MODE

In addition to all the tasks described in the Project Manager User Mode, the Project Manager application also enables administrators to manage the projects displayed in the archives. These include, moving projects from the user projects list to the archives and from the archives to the user list and more.

### 5.4.1. Defining Administrator Access Rights.

After entering your administrators' password, (described below) you are granted additional access rights to the system, enabling you to add, remove, import, and export projects from the Archive tab and more. You must enter this administrators' password each time you enter the Project Manager application.

To log in as an administrator:

2. On the Home ribbon, select **Administrator**. The Administrator dialog box is displayed.




Figure 28: Administrator Dialog Box

3. In the Password field, enter **mypassword** and click **OK**. You now have administrator's access rights.

### 5.4.2. Moving Projects to Archive

Administrators can move projects from the User Projects to the Archive. This is used for example when you want to define a project as read-only.

To move projects to the Archive:

From the User Projects tab, select the project to move to the Archive tab and then click **Move to Archive**. The selected project is removed from the User Projects tab and displayed in the Archive tab.

### 5.4.3. Moving Projects to User Projects tab

Administrators can move projects from the Archive tab to the User Projects tab. This is used for example when a project is no longer required in the archive but is required for the users.

To move projects to the user projects tab:

From the Archive tab, select the project to move to the User Projects tab and then click **Move to User Projects**. The selected project is removed from the Archive tab and is displayed in the User Projects tab.

## 6. Operating OpenMES Manager

This chapter describes how to operate the OpenMES Manager which is used for operating the OpenMES system and controlling production. The OpenMES Manager application is accessed from the Project Manager, as described in Chapter 5, Project Manager. It includes the following sections:


- **Accessing the OpenMES Manager**, describes how to access the OpenMES Manager application.
- **OpenMES Manager Main Window**, describes the main components of the OpenMES Manager interface.
- **OpenMES Operational Modes**, describes the operational modes of the OpenMES Manager application.
- **OpenMES Manager Views**, describes the various view screens in the OpenMES Manager application for tracking the production process.
- **CIM Scheduler**, introduces the CIM scheduler, enabling you to view various production schedules.
- **Graphic Display and Tracking**, introduces the Graphic Display module displaying real-time, 3D animations of the operations being performed in the CIM cell.

### 6.1. ACCESSING THE OPENMES MANAGER

The OpenMES Manager is accessed from the Project Manager main window enabling the user to centrally control all the activities of a selected OpenMES cell.

To access the OpenMES Manager application:

1. Select the desired project.
2. From the Project Manager Main window's Home ribbon, click **OpenMES Manager**. Alternatively, double-click the desired project.



The OpenMES Manager Main window is displayed, as shown in OpenMES Manager Main Window in the next section.

## 6.2. OPENMES MANAGER MAIN WINDOW

The OpenMES Manager Main window appears as follows:




Figure 29: OpenMES Manager Main Window

The CIM Project Manager window, shown above, contains the following elements, each of which is described in the sections that follow.


- OpenMES Manager Menu Bar
- OpenMES Manager Ribbon
- Time Counter
- PLC Status Bar
- Viewing Area
- Order View
- Device View
- Status Bar

### 6.2.1. OpenMES Manager Menu Bar and Ribbons

The OpenMES Manager Menu bar contains the File menu and three ribbons: Home, Production Preparation, and Production Analysis. Each of these is described in detail in the sections that follow.

### 6.2.1.1. File Menu


The following table contains a brief description of each option in the File menu:



Option	Description
Default Storage	Restores a predefined configuration of the storage from the backup database file.
Start	Loads the production work order (A-Plan). Opens communication channel. This sends a command to reset (INIT) all device drivers. The run arrow turns blue, and the stop button turns red, indicating that they are available for use. The production plan will appear in the Program View screen.
Run	Starts executing the A-Plan. CIM production begins. The pause button becomes active.
Continue	Resumes operation after production has been paused.
Stop	Stops production. It can be used as emergency button.
Modes	Displays the Modes dialog box, as described in <i>Modes Dialog Box</i> .
DB Tool	Displays the CIM Database (DB) browser. Recommended only for advanced users.
Exit	Exits the OpenMES Manager application.

### 6.2.1.2. Home Ribbon

The following table contains a brief description of each option in the Home ribbon:




Option	Description
Start	Loads the production work order (A-Plan). Opens communication channel. This sends a command to reset (INIT) all device drivers. The run arrow turns blue, and the stop button turns red, indicating that they are available for use. The production plan will appear in the Program View screen.
Run	Starts executing the A-Plan. CIM production begins. The pause button turns blue, indicating that it is available for use.
Pause	Halts operation at any time; causes the OpenMES Manager to stop sending commands to the device drivers and then wait until the Continue button (which has turned red) is pressed. All device drivers complete the current command. <p style="margin-left: 40px;">ⓘ <i>CIM devices do not stop immediately when you click the Pause button. Each device will complete its current operation before it stops.</i></p>
Resume	Resumes operation after production has been paused.
Stop	Stops production. It can be used as an emergency button.
Reset Storage	Restores a predefined configuration of the storage from the backup database file.
MES Manager Modes	Displays the Modes dialog box, as described in section 6.3.1 OpenMES Modes Dialog Box.
Device View	Displays the Device View window containing information referring to all the robots and machines in the CIM cell.
Event View	Displays the Event View dialog box that lists the events generated by the OpenMES simulation engine.
Leaf View	Displays the Leaf View window, providing a detailed description of the production activities of the CIM cell.
Log View	Displays the Log View window that contains a log of all the messages that have sent and received by the OpenMES Manager.
Machine Queue View	Displays the Machine Queue View showing the parts that are currently in the queue to the various machines for processing.
Order View	Displays data regarding the order of parts and their production status.
Pallet View	Displays the Pallet View window, containing the pallet information in the CIM cell, such as descriptions, status and more.



Program View	Displays the Program View window, that contains a copy of the A-Plan or production work order.
Storage View	Displays the Storage View window containing every location defined in the CIM system.
Automated Storage Dashboard	Graphically displays the quantity of each type of part stored in an ASRS-36u.
Part Tracking Dashboard	Displays the types and locations of all parts and products in the CIM cell.
Message History	Displays the Message History dialog box with three types of messages: External and Internal Messages and CIM Warnings.
About	Displays the About OpenMES Manager window containing the current software version information.
User Manual	Displays the OpenMES user manual (this manual).
Registration	Displays the registration dialog box enabling you to perform various registration options, such as obtaining your software license.

### 6.2.1.3. Production Preparation Ribbon

The following table contains a brief description of each option in the Production Preparation ribbon:




Option	Description
MRP	Displays the CIM MRP window, enabling you to create a list of customers, define the products ordered by each customer, and generate a manufacturing order.
Machine Definition	Displays the CIM Machine Definition window enabling you to define the machines and the specific processes that the machines will perform.
Part Definition	Displays the CIM Part Definition window, enabling you to define the parts that the CIM cell can manufacture, including available parts and the parts that need to be manufactured. These include Supplied Parts, Product Parts and Phantom Parts.
Optimization Definition	Displays the CIM Optimization Manager enabling users to select machine queue algorithms and define their weight.
Storage Manager	Displays the CIM Storage Manager window which manages and keeps track of parts in storage and informs the system of the part location.

Option	Description
Production Metrics Definition	Reserved for future use.

#### 6.2.1.4. Production Analysis Ribbon

The following table contains a brief description of each option in the Windows menu:



Option	Description
Production KPI Dashboards	Reserved for future use.
Performance Analysis	Displays the CIM Performance Manager for viewing and analyzing information generated from the manufacturing cycle.
Report Generator	Displays the CIM Report Part Definition window, enabling you to generate and print various reports from the database. These include part definition reports, machine definition reports and more.
Scheduler Gantt	Displays the CIM Scheduler window, enabling you to plan, coordinate and track various production schedules. For further details, refer to 6.5 CIM Scheduler
Statistical Process Control	Reserved for future use.

#### 6.2.2. OpenMES Manager Time Counter



The CIM time counter indicates the time elapsed since the onset of the production cycle.

#### 6.2.3. PLC Status Bar



The PLC Status Bar informs you whether or not the connection to the PLC is active.

#### 6.2.4. Viewing Area

The Viewing area enables you to monitor various aspects of the production cycle on a real-time basis by selecting one of seven tab views. By default, the Graphic Display tab is selected and the viewing area displays 3D graphic simulation of the CIM production cycle. For further details on the tabs displayed in the Viewing area, refer to Graphic Display and Tracking.

#### 6.2.5. Order View

The Order View, located below the toolbar in the left portion of the window, displays data regarding the order of parts and their production status.

#### 6.2.6. Device View

The Device View, located below the toolbar in the right portion of the window, displays data regarding the activity taking place in the devices during the production process.

#### 6.2.7. Status Bar

The application's status bar, located at the bottom of the window, displays the status and location of the application, such as the current operation mode and the location of the WSO.ini file used by the manager.

#### 6.2.8. Information Bar

The Information Bar displays general messages that occur during production, such as Order is in progress and so on.

### 6.3. OPENMES OPERATIONAL MODES

The OpenMES Manager can operate in the following modes:

- **Simulation Mode:** The OpenMES Manager does not communicate with device drivers. This mode does not require either hardware or device drivers.
- **Real Mode:** The OpenMES Manager communicates with all device drivers, whether or not hardware is in use. This mode requires that *all device drivers which are needed for a specific application (for a specific product order)* be loaded, so that the OpenMES Manager can transmit and receive messages.

Since the OpenMES Manager affects operation of the CIM cell hardware by communicating with the device drivers (and not directly with the hardware), the OpenMES Manager can operate in *real mode* even if the hardware has not been activated, or even if no hardware exists.

The CIM modes are described in the following table:

OpenMES Manager Mode of Operation	Device Driver	Hardware
Simulation	Not required.	Not required
Real Mode	All device drivers must be loaded.	Not required. Hardware may be activated, or it may be simulated by the device drivers, at some or all stations.

### 6.3.1. OpenMES Modes Dialog Box

- The **MODES Dialog Box** is displayed by clicking the **MS Manager Modes** icon on the Home ribbon. This dialog box enables you to define the current modes that are active in the OpenMES Manager, such as whether the OpenMES Manager is working in Real Mode or Simulation Mode and whether the Web Viewer is activated. The modes defined in the MODES dialog box are project dependent.




Figure 30: Modes Dialog Box

CIM Mode	<p><b>Real Mode:</b> In this mode there is message interchange between Manager and Device Drivers.</p> <p><b>Simulation Mode:</b> Production runs on the Manager. There is no message interchange between any devices. You can set the production speed for the simulation, where 1 is the slowest and 100 is the fastest.</p>
Report to Scheduler as	<p><b>None:</b> In this mode, the OpenMES Manager does not send messages to the CIM Scheduler.</p> <p><b>Planned:</b> In this mode, the OpenMES Manager sends messages as planned to the CIM Scheduler (generally, when OpenMES Manager is operating in Simulation Mode).</p> <p><b>Actual:</b> In this mode, the OpenMES Manager sends actual messages to the CIM Scheduler (generally, when OpenMES Manager is operating in Real Mode).</p>
Update Process Time	<p><b>No Duration update:</b> Does not update the duration of any process defined in Machine Definition.</p> <p><b>Duration Update:</b> Updates the duration of any process defined in Machine Definition. The duration is the actual time that a machine has taken to complete a process.</p>
Web Viewer	<p>Specifies whether or not the web viewer is activated. Select the required option, as follows:</p> <ul style="list-style-type: none"><li>• <b>Yes:</b> Activates the Web Viewer.</li><li>• <b>No:</b> Disables the Web Viewer.</li></ul> <p>For information on installing the web viewer server refer to section 4.4.3.</p> <p>For information on installing the web viewer client refer to section 10.1.</p>

## Remote Graphic Display

Specifies whether or not status messages are sent from the devices in operation to the Graphic Display module so that the display is updated accordingly.

- **Yes** - Messages are sent to the Remote Graphic Display.
- **No** - Messages are not sent to the Remote Graphic Display.

By default, the Manager is configured to support only one Remote Graphic Display.

To enable support for more than one Remote Graphic Display:

1. Open Notepad by clicking Start | Accessories | Notepad.
2. Select File | Open and browse to:

C:\Users\public\Documents\Intelitek\OpenCIM\Projects\<project name>\setup\OpenMES.ini.

3. Find the NUMCIMULSOCKETS in the [networking] key and change it to the required number of cim simulations.
4. Click **Save**.

- ① *If the Graphic Display is not activated on any PC, click No, otherwise the manager will work very slowly.*
- ① *Refer to Chapter 4: Software for Workstation PCs for information on installing the Remote Graphic Display.*

To begin producing an order, do the following:

- ❶
  - ❷
  - ❸
- Procedure  
Starting Production

1. Start all OpenMES device drivers by clicking on the Device Driver Loader icon at each Station Manager PC. (Skip this step if you intend to work in Simulation mode.)
2. Select either Real Mode or Simulation Mode from the Modes dialog box.
3. Reset the Storage by clicking the **Reset Storage** button.
4. In the OpenMES Manager, click the **Start** button.
5. Click the **Run** button to start executing the production plan.



- ❶ *For safety reasons, when operating the CIM in Real Mode, you must use the actual hardware EMERGENCY buttons to halt the system in an emergency.*

### 6.3.2. Working in Simulation Mode

To operate the CIM cell in simulation mode, you must verify that the simulation mode is selected in the OpenMES Manager.

To operate the CIM cell in simulation mode:

1. From the Project Manager application, select the required project and click **OpenMES Manager**. The OpenMES Manager main window is displayed, as shown in OpenMES Manager Main Window.
2. From the Home ribbon, select the **MES Manager Modes** button. The OpenMES Modes dialog box is displayed.
3. Select the **Simulation Mode** option. If required, adjust the simulation speed and define additional options. When you are finished, click **SAVE**.
4. Verify that the Graphic Display tab is selected and click the **Reset Storage** button on the Home ribbon.
5. If required, select Production Analysis | Scheduler Gantt to view the production schedule.
6. Click the **Start** button to start and then click **Run**. The selected CIM Cell is runs in simulation mode.

### 6.3.3. Working in Real Mode

To operate the CIM cell in real mode, you must verify that the real mode is selected in the OpenMES Manager.



ⓘ *Before starting actual production, make sure you are in compliance with all the safety measures detailed in Chapter 3, Safety.*

To operate the CIM Cell in real mode:

1. Remove any templates on the conveyor and at station buffers.
2. Remove any parts left at stations: in a robot's gripper, in a machine and on storage racks.
3. Load parts into the ASRS and into any feeders.
- ⓘ *Turn on all hardware: PCs, controllers, CNC machines, etc.*
4. Make sure all PCs have been activated.
5. From the PC of each Station Manager click the **Loader WS1** icon (for example). The CIM Device Driver Loader window is displayed.
6. In the **Simulation** column, select the mode in which you want to load the device drivers by selecting or deselecting the column and click the **Start** button.
7. At each station, home the robot and initialize all the equipment.
8. On the PC that contains the OpenMES Manager, perform the following:
  - a. From the Project Manager application, select the required project and click **OpenMES Manager**. The OpenMES Manager main window is displayed.
  - b. In the Home ribbon, select **MES Manager Modes**. The OpenMES Modes dialog box is displayed.
  - c. Select the **Real Mode** option. If required, define additional options, and then click Save.
  - d. If required, select Production Analysis | Scheduler Gantt to view the production schedule.
9. Click the **Start** button to start, and then click **Run**. The selected CIM Cell runs in real mode:

ⓘ *You can turn on OpenMES workstation PCs and hardware in any order. There is no mandatory boot-up sequence. You can also reboot a PC as long as it is not in the middle of an operation or is not communicating with the OpenMES Manager. If you reset a PC, you do not need to reset other workstation PCs connected to the OpenMES network. When the PC boots up, its applications will resume communication with other PCs on the OpenMES network.*



## 6.4. OPENMES MANAGER VIEWS

During the manufacturing process, you can track production by looking at these view screens:

- Program View
- Order View
- Storage View
- Device View
- Log View
- Machine Queue View
- Pallet View
- Leaf View
- Event View
- Message History

Click the appropriate icon on the Home ribbon to open the desired View screen. Alternatively, you can replace the Graphic Display in the lower half of the Manager with the desired View screen (with the exception of Log and Event) by clicking the appropriate tab.

### 6.4.1. Order View

The Order View is a copy of the Manufacturing Order. It is the most basic of the available views.

No	Part	Total	Done	Fails	In Proc.
1	PROD_BG_ASSEMBLY/1.1	6	0	0	0
2	PROD_CMM_BG_BASE_ST7/2.1	1	0	0	0
3	PROD_LASER_DEMO/3.1	6	0	0	0
4	PROD_LASER_DEMO_ST4/4.1	1	1	0	0
5	PROD_MILL_DEMO/5.1	6	0	0	0
6	PROD_MILL_DEMO_ST3/6.1	2	2	0	0
7	PROD_TURN_DEMO/7.1	11	0	0	0

Figure 31: Order View

The following is an explanation of each column in the **Order View**.

- No.** Line number from Manufacturing Order.
- Part** Name of part; as defined in Part Definition Form used in Manufacturing Order. The grid containing the part name is progressively filled in red from left to right, indicating the production status of the part which is being manufactured.
- Total** Total number of parts to be produced, as defined in Manufacturing Order.
- Done** Number of parts that have been completed. Updated during production.
- Fails** Number of parts that have failed inspection. Updated during production.
- In Process** Number of parts that are being manufactured. Updated during production.

### 6.4.2. Storage View

The Storage View resembles the Location Status Report (see Chapter 5). This view is a detailed listing of every location defined in the CIM system.

Storage	Index	Status	Part	Template	Device ID
72ASRS1	1	Empty	EMPTY	EMPTY	10
ASRS1	1		SUP_ACRYLIC_BLOCK	TEMPLATE#010001	210
ASRS1	2		SUP_ACRYLIC_BLOCK	TEMPLATE#010002	210
ASRS1	3		SUP_ACRYLIC_BLOCK	TEMPLATE#010003	210
ASRS1	4		SUP_ACRYLIC_BLOCK	TEMPLATE#010004	210
ASRS1	5		SUP_ACRYLIC_BLOCK	TEMPLATE#010005	210
ASRS1	6		SUP_ACRYLIC_BLOCK	TEMPLATE#010006	210
ASRS1	7		SUP_ACRYLIC_BLOCK	TEMPLATE#010007	210
ASRS1	8		SUP_ACRYLIC_BLOCK	TEMPLATE#010008	210
ASRS1	9		SUP_ACRYLIC_BLOCK	TEMPLATE#010009	210
ASRS1	10		SUP_ACRYLIC_BLOCK	TEMPLATE#010010	210

Figure 32: Storage View

The following is an explanation of each column in the **Storage View**.

- Storage            A list of all the locations in the CIM cell.
- Index             Indicates the exact location on a device which has more than one location for a part. For example, the conveyor (CVN1) has three indices, one for each station; the robot identified as ROBOT7 has only one index; the ASRS1 has an index for each of its cells.
- Status            Graphic illustration of the contents of the location, as defined in the PART and TEMPLATE columns. For example, EXPERTMILL1 has a part named BOX.
- PART              Status of the specified location: either Empty or the Name of the part if it exists at the location.
- TEMPLATE        Status of the specified location: either Empty or the ID of the template if it exists at the location.
- Device ID        Device ID number defined in the Virtual OpenMES Setup (or assigned by the OpenMES Manager during production).

### 6.4.3. Program View

The Program View is a copy of the A-Plan, or production work order. You can track the current status of production by watching the Program View. This screen shows the commands that the OpenMES Manager executes to produce an order. These commands are executed in bottom-up order.

Level	Part	Action	Subpart	Target	#	Parameters	P1
1		TopBatch					
2	PROD_BG_ASSEM	MAKE	PROD_BG_ASSEMBLY/1.		1	6,3,1,P,1,00:00:0	WAIT
3	PROD_BG_ASSEM	NEXT					
4	PROD_BG_ASSEM	PLACE	TEMPLATE	ASRS1			
5	PROD_BG_ASSEM	RENAME	SUP_BG_BASE				
6	PROD_BG_ASSEM	CHECK_BG_F	SUP_BG_BASE			1,1,1	
7	PROD_BG_ASSEM	End_Assembly	PROD_BG_ASSEMBLY/1.	JIG1		ASSEMBLY_JIG1	
8	PROD_BG_ASSEM	ASSEMBLY_J	PROD_LL_PIN/1.1	SUP_BG_BAS	5		
9	PROD_BG_ASSEM	BASE	SUP_BG_BASE	JIG1			
10	PROD_BG_ASSEM	Assembly	PROD_BG_ASSEMBLY/1.	JIG1		ASSEMBLY_JIG1	
11	PROD_BG_ASSEM	PLACE	SUP_BG_BASE	RACK5			
12	PROD_BG_ASSEM	End_Assembly	PROD_BG_ASSEMBLY/1.	JIG1		ASSEMBLY_JIG1	
13	PROD_BG_ASSEM	ASSEMBLY_J	PROD_UR_PIN/1.1	SUP_BG_BAS	4		
14	PROD_BG_ASSEM	BASE	SUP_BG_BASE	JIG1			
15	PROD_BG_ASSEM	Assembly	PROD_BG_ASSEMBLY/1.	JIG1		ASSEMBLY_JIG1	

Figure 33: Program View

The following is an explanation of each column in the **Program View** screen.

- Level** This hierarchy number indicates the level in the Part Definition tree for each ordered product. Operations at the same level can occur in parallel (except an ONFAIL process).
- Part** Unique name used to identify the subpart currently under production.
- Action** The A-Plan command or user-defined process that the OpenMES Manager executes to produce a part.
- Subpart** The part or object which the A-Plan action operates on.
- Target** The destination where this subpart is to be delivered.
- Index (#)** Parameters used by this command or process.
- P1** Shows the current production status. The number of shaded Part columns corresponds to the total number of parts ordered.  
 When a part is being produced, one of the following symbols appears at the current stage of production:
  - ↵ Command sent, waiting for acknowledgment.
  - ON** Device has begun processing this part

- (device driver has responded with Start message).
- OFF** Device finished processing this part (device driver has responded with Finish message).
- The blue box indicates operation completed (device driver has responded with End message).
- WAIT** OpenMES Manager is waiting for another operation to complete before sending this command.

### 6.4.4. Device View

The Device View is a complete list of every robot and machine (including QC devices) in the CIM cell and a description of the current action being performed by each.

Device	Status	Action	Station	Device ID
72ASRS1	STOP		WS01	10
ROBOT2	STOP		WS02	20
ROBOT3	STOP		WS03	30
ROBOT4	STOP		WS04	40
ROBOT5	FINISH	PLACE PROD_V_ASSEMBLY on TEMPLATE#030001[1]	WS05	50
ROBOT6	STOP		WS06	60
ROBOT7	STOP		WS07	70
ROBOT8	STOP		WS08	80
RFIDR1	STOP		WS01	12
PROTURN1	STOP		WS02	22
PROMILL1	STOP		WS03	32
LSRENGRV1	STOP		WS04	42
CALLER1	STOP		WS05	52

Figure 34: Device View


The following is an explanation of each column in the **Device View**.

- Device** Name of the device or machine, as defined in the Virtual OpenMES Setup.
- Status** When a part is being produced, one of the following symbols appears at the current stage of production:
  - RUN** Command sent, waiting for acknowledgment.
  - Start** Device has begun processing this part (device driver has responded with Start message).
  - Finish** Device finished processing this part (device driver has responded with Finish message).
  - End** Device ended processing this part (device driver has responded with End message).

<b>Stop</b>	Device is ready for next command.
<b>Load</b>	Device is loading the processing program from the Backup or the Database.
<b>Action</b>	The movement or operation command which is currently being executed by the device. For robots, the action is commonly the placement of a part. For machines, the action is usually the name of the process (as defined in the Machine Definition form).
<b>Station</b>	The number which identifies the workstation where the device is located.
<b>ID</b>	The Device ID number, as defined in the Virtual OpenMES Setup.

### 6.4.5. Log View

The Log View is a transcript of the Leaf View. It details all messages which have been sent and received by the OpenMES Manager.



```

Log View
SUP_BG_BASE(2.1) IN PROCESS: FDR3 GET SUP_BG_BASE FDR3
SUP_BG_BASE(2.1) DONE : FDR3 GET SUP_BG_BASE FDR3
SUP_BG_BASE(2.1) IN PROCESS: ROBOT7 PLACE SUP_BG_BASE on CMM1
SUP_ACRYLIC_BLOCK(4.1) IN PROCESS: FDR2 GET SUP_ACRYLIC_BLOCK FDR2
SUP_ACRYLIC_BLOCK(4.1) DONE : FDR2 GET SUP_ACRYLIC_BLOCK FDR2
SUP_ACRYLIC_BLOCK(4.1) IN PROCESS: ROBOT4 PLACE SUP_ACRYLIC_BLOCK on LSRENGRV1
SUP_ACRYLIC_BLOCK(6.1) IN PROCESS: FDR1 GET SUP_ACRYLIC_BLOCK FDR1
SUP_ACRYLIC_BLOCK(6.1) DONE : FDR1 GET SUP_ACRYLIC_BLOCK FDR1
SUP_ACRYLIC_BLOCK(6.1) IN PROCESS: ROBOT3 PLACE SUP_ACRYLIC_BLOCK on PROMILL1
SUP_BRASS_CYLINDER(8.1) IN PROCESS: GFDR1 GET SUP_BRASS_CYLINDER GFDR1
SUP_BRASS_CYLINDER(8.1) DONE : GFDR1 GET SUP_BRASS_CYLINDER GFDR1
SUP_BRASS_CYLINDER(8.1) IN PROCESS: ROBOT2 PLACE SUP_BRASS_CYLINDER on PROTURN1
SUP_WELD_SQUARE(12.1) IN PROCESS: ASRS1 GET SUP_WELD_SQUARE ASRS1
SUP_WELD_SQUARE(12.1) DONE : ASRS1 GET SUP_WELD_SQUARE ASRS1
SUP_WELD_SQUARE(12.2) IN PROCESS: ASRS1 GET SUP_WELD_SQUARE ASRS1
SUP_WELD_SQUARE(12.2) DONE : ASRS1 GET SUP_WELD_SQUARE ASRS1
SUP_BRASS_CYLINDER(7.1) IN PROCESS: ASRS1 GET SUP_BRASS_CYLINDER ASRS1
SUP_BRASS_CYLINDER(7.1) DONE : ASRS1 GET SUP_BRASS_CYLINDER ASRS1
SUP_BRASS_CYLINDER(7.2) IN PROCESS: ASRS1 GET SUP_BRASS_CYLINDER ASRS1
SUP_BRASS_CYLINDER(7.2) DONE : ASRS1 GET SUP_BRASS_CYLINDER ASRS1

```

Figure 35: Log View

You can control the amount of information that is displayed by editing the OpenMES Manager INI file. By default, the system is set to display only IN PROCESS and DONE messages, which allow you to see which commands have been sent and which have been executed.

### 6.4.6. Machine Queue View

The Machine Queue View displays the parts that are currently in the queue to the various machines for processing.

Device	Part ID (grade)					
Device	1	2	3	4	5	6
ASRS1	212 (0.00)	239 (0.00)				
JIG_X9						
RFIDR1	306 (0.00)	309 (0.00)	312 (0.00)	335 (0.00)	343 (0.00)	356 (0.00)
PROTURN1						
RACK1						
PROMILL1						
RACK2						
LSRENGRV1						
JIG1	266 (0.00)	268 (0.00)	270 (0.00)	278 (0.00)	280 (0.00)	282 (0.00)
BALLFDR1	297 (0.00)					
RACK3						
RACK4	375 (0.00)					
RACK5						

Figure 36: Machine Queue View

The following is an explanation of the columns in the **Machine Queue View**:

- Device. Lists the devices in the CIM cell.
- Part ID (grade) Lists the ID and grade value of the color coded parts that are in the queue to the specific device

### 6.4.7. Pallet View

The Pallet View is a complete list of every pallet in the CIM cell and a description of its current status.

No	Status	To St.	Part	Product	Template	Last St.	Sim. Pl.
1	Pass		5 SUP_BG_BASE	SUP_BG_BASE	TEMPLATE#050001	4	1
2	Pass		4 SUP_BG_COVER	SUP_BG_COVER	TEMPLATE#060002	3	1
3	Release		4 SUP_BG_COVER	SUP_BG_COVER	TEMPLATE#060003	1	
4	Pass		1 SUP_ACRYLIC_BLOCK	PROD_LASER_DEMO	TEMPLATE#010002	8	3
5	Pass		5 SUP_BG_BASE	SUP_BG_BASE	TEMPLATE#050002	8	3
6	Pass		7 SUP_BG_BASE	SUP_BG_BASE	TEMPLATE#050003	6	2
7	Pass	999				6	2
8	Pass	999				5	1
9	Ready						
10	Ready						

Figure 37: Pallet View

The following is an explanation of each column in the **Pallet View**.

- No.** Identification number of the pallet
- Status** Describes the status of:
  - Ready** Pallet has not yet reached a station.
  - Pass** Pallet is moving; has passed through the last station.
  - Stop** Pallet has been stopped at a station to be unloaded.
  - Stop[Free]** Pallet has been stopped at a station to be loaded.
  - Released Pallet has been released from a station.
- To Station (To St)** Number of the next workstation which pallet will reach. If pallet status is Free, the destination is Station 999.
- Part** Name of part or subpart being carried by pallet.
- Product** Name of final product to which part belongs.
- Template** Identification number of the template being carried by the pallet.
- Last Station (Last St)** Number of the last workstation which pallet has passed through.
- Sim Place** "Simulated position"; a sector location on the conveyor, as used in the simulated graphic display.

**6.4.8. Leaf View**

The Leaf View provides a detailed description of the production activities of the CIM cell, describing the current operation being performed on each item and the operation that will immediately follow.

Sub Part of Part	Action -> Next Process	Status	Part ID	Bar Code	Leaf ID	L1
SUP_BG_BASE(1) of PROD_CMM_BG_BASE_ST7/.	RENAME SUP_BG_BASE -> PLACE SUP_BG_BASE on TEMPLATE[1]		401	0	22	SUP_BG_BASE 212
SUP_ACRYLIC_BLOCK(1) of PROD_LASER_DEMO_ST4/4.	DONE!		1	0	23	Delete 0
SUP_ACRYLIC_BLOCK(1) of PROD_MILL_DEMO_ST3/6.1	DONE!		1	0	24	Delete 0
SUP_BRASS_CYLINDER(1) of PROD_TURN_DEMO_ST2/8.1	DONE!		101	0	25	Delete 0
SUP_WELD_SQUARE(1) of PROD_WELD_SQUARE/12.1	DONE!		801	90001	26	Delete 0
SUP_WELD_SQUARE(2) of PROD_WELD_SQUARE/12.1	DONE!		801	90002	27	Delete 0
SUP_BRASS_CYLINDER(1) of PROD_TURN_DEMO/7.1	DONE!		101	20001	28	Delete 0
SUP_BRASS_CYLINDER(2) of PROD_TURN_DEMO/7.1	DONE!		101	20002	29	Delete 0
SUP_BRASS_CYLINDER(3) of PROD_TURN_DEMO/7.1	DONE!		101	20003	30	Delete 0

Figure 38: Leaf View

The following is an explanation of each column in the **Leaf View**.

- Subpart of Part** Name of the part and the name of the final product to which it belongs.



<i>Action</i> > <i>Next Process</i>	The action currently in progress (upper line) and the next process to be performed on the part. For example:  MILL2 = process defined in the Machine Definition form BOX = part name. EXPERTMILL1 = name of machine which will perform operation, as defined in the Machine Definition form.
<i>Status</i>	When a part is being produced, one of the following symbols appears at the current stage of production:  ↵ Command sent, waiting for acknowledgment.  <b>ON</b> Device has begun processing this part (device driver has responded with Start message).  <b>OFF</b> Device finished processing this part (device driver has responded with Finish message).  ■ The blue box indicates operation completed (device driver has responded with End message).  <b>WAIT</b> OpenMES Manager is waiting for another operation to complete before sending this command.
<i>Part ID</i>	An internal ID index for the part, generated by the OpenMES Manager.
<i>Bar Code</i>	The ID number of the template which is carrying the part.
<i>Leaf ID</i>	An internal ID index generated by the OpenMES Manager.
<i>L1... Ln</i>	Additional information about other "leaves".

### 6.4.9. Event View

The Event View is used only when the OpenMES Manager is operating in simulation mode; it contains data only after the **Run** button is pressed.

The Event Queue is a list of events that will be generated by OpenMES's simulation engine, in order to ensure proper functioning of the simulation.




Figure 39: Event View

For example:

TIME = 135 (00:02:15)

Indicates amount of time that has passed (135 seconds, or 2 minutes, 15 seconds) since the Run button was pressed.

PLACE: Device start at 7 ROBOT7...  
PLACE: Device finish at 15 ROBOT7

Indicates Robot 7 will send a Start message in 7 seconds and a Finish message in 15 seconds.

### 6.4.10. Automated Storage Dashboard

The Automated Storage Dashboard displays the quantities of each type/stage of part or product stored in the ASRS.




Figure 40. The Automated Storage Dashboard

- ① The Automated Storage Dashboard is only applicable for use with an ASRS-36u.
- ① Part and product names are defined in the project's WSO.INI file. Names must be made up of 1-6 characters.

### 6.4.11. Part Tracking Dashboard

The Part Tracking Dashboard displays the types/stages and locations of parts or products in the CIM cell.




Figure 41. The Part Tracking Dashboard

- ❗ The Automated Storage Dashboard is only applicable for use with an ASRS-36u.
- ❗ Part and product names are defined in the project's WSO.INI file. Names must be made up of 1-6 characters.

### 6.4.12. Message History




Figure 42: Message History Dialog Box

The Message History View allows you to view three types of messages:

- **External Messages:** All messages that the OpenMES Manager sends to drivers via the TCP/IP protocol and vice versa.
- **Internal Messages:** Enables you to check OpenMES Manager setup parameters, e.g. path to database files, path to utilities, simulation speed, etc.
- **CIM Warnings:** All warnings issued by the OpenMES Manager. The last message is highlighted in yellow. When a warning message is issued, the Message History dialog box opens. The most frequently issued warning message is: “Part not currently available. Update storage”.

## 6.5. CIM SCHEDULER

The CIM Scheduler allows you to view various production schedules and determine the most efficient one. The Scheduler is a Gantt utility that displays the exact timing and scheduling of the different phases of production.




Figure 43: CIM Scheduler-Gantt Chart

The Scheduler can display two kinds of production schedules:

- Planned:** This schedule is normally produced and displayed when the OpenMES Manager is operating in Simulation mode. Tracking mode must be activated from the CIM Mode dialog box. For further details, see CIM Modes Dialog Box.
- Actual:** This schedule is normally produced and displayed when the OpenMES Manager is operating in Real mode. The Tracking mode is deactivated.

The left side of the Scheduler screen is a textual description, while the right side is a graphic representation (Gantt chart) of the production schedule.

Click and drag the vertical lines in the table to increase and decrease column widths.

### 6.5.1. CIM Scheduler Toolbar and Menu Bar Options

The following table contains a brief description of each option in the CIM Scheduler toolbar in addition to the corresponding menu bar item:



**Online/Offline:** When the Scheduler operates on-line, it displays data from the OpenMES Manager. (No data is displayed until the OpenMES Manager commences production.)

When the Scheduler operates off-line, it displays information from Manager. Data is displayed as either Actual or Planned, depending on the definition in the [Scheduler] section of the OpenMES Manager’s INI file.

Alternatively, select **Display | Online/Offline** from the CIM Scheduler menu bar.



**Sort by Machine:** Shows the activities of machines and the parts they process.

Alternatively, select **Display | Sort by Machine** from the CIM Scheduler menu bar.



Shows the progress of parts, and the machines which process them.

Alternatively, you can also select **Display | Sort by Part** from the CIM Scheduler menu bar



Enables you to clear the scheduler data. *(Enabled in Online mode only.)*

Alternatively, select **File | Clean** from the CIM Scheduler menu bar.



**i** *Displays the Load Data dialog box, enabling you to load additional production schedules. (Enabled in Offline mode only.)*


Alternatively, select **File | Open** from the CIM Scheduler menu bar.



**i** *Displays the Save as dialog box enabling you to save the current production schedule.*

Alternatively, select **File | Save As** from the CIM Scheduler menu bar.

Display Options



**Zoom:** Value of time interval compression in Gantt chart display.

**Show:** Checked items are displayed in the textual display.

## 6.5.2. Creating a Planned Production Schedule

To create a planned production schedule, do the following:

①  
②  
③

Procedure

Generating a Planned  
Production Schedule

1. Activate the OpenMES Manager.
2. From the OpenMES Modes dialog box, activate the tracking mode.
3. Reset storage.
4. Activate the CIM Scheduler (Production Analysis | Scheduler Gantt).
5. Click **Start**.
6. Click **Run**. Wait for the OpenMES Manager to complete an entire production cycle.

④ **Tip:** *To speed up the simulation, change the value of the simulation speed in Modes Dialog Box.*

After you have generated a planned schedule, you can run the OpenMES Manager in real mode in order to track and display the actual schedule and see how it compares with the planned schedule.

## 6.6. GRAPHIC DISPLAY AND TRACKING

The OpenMES Graphic Display and Tracking module provides a real-time 3D graphic display of a working OpenMES cell, displaying the movement of pallets on the conveyor based on the status messages it receives as each pallet passes a conveyor station. The Graphic Tracking module estimates the position of pallets as they travel between stations and updates its display accordingly. It synchronizes its display with the actual pallet position every time a pallet passes a conveyor station.

### 6.6.1. Status Messages

When a device performs an operation on the part, its device driver transmits status messages to the OpenMES Manager reporting the outcome. The OpenMES Manager forwards these messages to the Graphic Tracking module, which then updates its display accordingly.

Examples of these messages include:

- **Command Response Messages:** A device driver responding to a command sent from the OpenMES Manager, or a device driver responding to a command sent from another device driver (such as, a CNC device driver responding to commands sent by a robot's ACL or Scorbace device driver to open and close its door).
- **Pass Messages:** The PLC device driver sending a Pass message indicating that a pallet that is not needed at this station has just gone by. Pass messages are generated only to allow the Graphic Tracking module to update its conveyor display and are not used by the OpenMES Manager or any other CIM entity.



### 6.6.2. Updating the Display

The OpenMES Manager relays the status messages to the Graphic Tracking module, which then updates its display accordingly. The display can show the following examples:

- **Parts**, as they move from device to device (such as, a robot picking up a part from a template and putting it in a CNC machine).
- **Pallets**, moving around the conveyor.

The screen display includes detailed representations of station elements such as computers, controllers, CNC machines, and robots as shown in the following figure. This module updates its display in response to real-time status messages emanating from the OpenMES Manager and active device drivers.

The Graphic Tracking PC can be used in the following modes:

- **Real Time Mode**, enabling you to observe the flow of parts around the CIM cell.
- **Simulation Mode**, enabling you to observe the results of different production strategies on-screen without actually operating the CIM equipment.

The graphic display module appears in the Graphic Display tab, as follows:
















Figure 44: Graphic Display on Manager

### 6.6.3. Graphic Display Toolbar

The following table contains a brief description of each option in the Graphic Display toolbar:

Option	Description
	<b>Maximize/Restore:</b> Enables you to toggle between maximizing and restoring the Graphic Display tab.
	<b>Redirect Camera:</b> Defines the position that will be in the center of the image.
	<b>Follow Me Camera:</b> Enables you to focus on the location of specific part during a production cycle.
	<b>Drag Scene:</b> Enables you to pan the CIM cell left, right, up, and down.
	<b>Top View:</b> Places the camera on top of the cell at the center of the image
	<b>Save Camera Position:</b> Saves the current position of the graphic display screen until the next time you enter the OpenMES Manager application.
	<b>Toolbar View:</b> Displays or hides the IDs of the objects, templates, parts, and pallets, each of which is described below.
	<b>Show Name:</b> Displays/hides the names of the objects that currently exist in the CIM cell.
	<b>Show ID:</b> Displays/hides the object IDs that exist in the current CIM cell.
	<b>Show Pallets:</b> Displays/hides the pallet numbers that are currently on the conveyer.
	<b>Show Templates:</b> Displays/hides the IDs of the templates in the CIM cell.
	<b>Show Parts:</b> Displays the IDs of the parts in the CIM cell.

In addition, the following options enable you to change the view of the CIM cell:

- **Zoom In/Zoom Out:** Zooms in and out of the image by pressing the right mouse button and moving it forward or backward.
- **Rotate the Image:** Rotates the view of the image by pressing the right mouse button and moving it to the right/left.
- **Moving the Camera Up/Down:** Use the window’s scroll bar to adjust the viewing angle of the image.

Alternatively, the viewing angle can also be adjusted by scrolling the mouse wheel.

The Graphic Display of a working OpenMES cell is displayed in the OpenMES Manager window and it can also be displayed on another PC (WebViewer application and Remote Graphic Display.) It is possible to display three different 3D views at the same time on the same screen as shown below.




Figure 45: Graphic Display – three views

### 6.6.4. Tracking the Production Process

The following procedure describes how to graphically track the production in the OpenMES system:

<p><b>1</b> <b>2</b> <b>3</b></p> <p>Procedure</p> <p>Graphic Tracking of Production</p>	<ol style="list-style-type: none"> <li>1. Launch Project Manager. To do so, select the project and click the OpenMES Manager icon in the Home ribbon.</li> <li>2. Click <b>Start</b>.</li> <li>3. Click <b>Run</b>. You can now observe the operations performed in the CIM cell in both Graphic Displays: The Manager and in the 3D views.</li> </ol>
--	--

### 6.6.5. Manipulating the Graphic Display Views

The Graphic Display module offers two types of views, an overhead view and an elevated side view. This procedure describes how to manipulate these views according to your requirements.

- ① *When the Simulation window opens, it always displays the view that was displayed when you last closed either the Graphic Display or the Virtual OpenMES Setup window.*

To manipulate the views:

1  
2  
3

Procedure

Manipulating the  
Graphic Display

1. To change the angle of the overhead scene, place the cursor on the vertical scroll bar and drag it up and down. (It is recommended that you click on the vertical scroll bar up and down arrows.)
2. To rotate the scene, place the cursor anywhere on the screen and:
  - Click the right mouse button and drag to the right to rotate the display counterclockwise.
  - Click the right mouse button and drag to the left to rotate the display clockwise.
3. To zoom the scene, place the cursor anywhere on the screen and:
  - Click the right mouse button and drag up to zoom in.
  - Click the right mouse button and drag down to zoom out.

### 6.6.6. Changing the Focus of the Graphic Display


The following procedure describes how to change the focus of the Graphic Display.

To change the focus of the Graphic Display:

1  
2  
3

Procedure

Changing the Focus  
of the Graphic  
Display

1. Click the Redirect Camera icon .
2. Click any object in the scene. It now becomes the center point for the display manipulation. The view changes to an overhead scene (if it is not already), which you can now manipulate, as described above.

The **Text** menu allows you to select the kind of captions you want to include in the graphic display. Only *one* kind of text can be selected at a time.

None	No text. Select <b>None</b> to remove the currently displayed caption. You may then select another kind of text. (Note that there is no checkmark in the menu to indicate your selection.)
Name	Name of machines and devices.
Ext. ID	External ID number, as defined in the Virtual OpenMES Setup.
Pallets	Displays the ID number of the pallets.
Templates	Displays the ID number of the templates.
Parts	Displays the ID number of the parts.

The **File** menu offers the following options:

Open	Loads a new graphic CIM cell. <i>Do not use.</i>
Exit	Quits the Graphic Display module.

## 7. OpenMES Manager Utility Programs

This chapter describes the CIM Utility Programs which are used for preparing the OpenMES system for production. These programs are an integral part of the OpenMES Manager software and can be accessed from the Production Preparation and Production Analysis ribbons. The utility programs include the following:

- **Machine and Process Definitions**, introduces the CIM Machine Definition window, enabling you to define the machines and processes in OpenMES.
- **Part Definition**, introduces the CIM Part Definition window, enabling you to define the parts that OpenMES can manufacture.
- **Storage Definition**, introduces the CIM Storage Manager, enabling you to track the parts in storage.
- **MRP (Material Requirements Planning)**, introduces the CIM MRP window, enabling you to create customer lists and product orders.
- **Optimization**, introduces the CIM Optimization Definition window for defining queue algorithms as well as additional optimization methods used in OpenMES.
- **Performance Analysis**, introduces the CIM Performance Analysis window for viewing and analyzing information generated from the manufacturing cycle.
- **Reports**, introduces the CIM Report Generator enabling you to generate predefined or customized reports for viewing and printing.

You can use these programs to view some existing sample definitions to assist you in making your own.

As you read through this chapter, it is recommended that you perform the “Procedures.” These tutorials will help you become familiar with using the OpenMES software.

The examples shown in this manual are based on the sample project TUTORIAL\_SAMPLE which is located in the projects archive list in the project Manager. (For details on transferring a project from Archive to User refer to section ).

### 7.1. MACHINE AND PROCESS DEFINITIONS

When you define a machine, you actually define the specific process a machine will perform. Machine names are usually predefined in the Virtual OpenMES Setup and only need to be selected from the Machine Name drop-down list.

The process name enables the OpenMES Manager to determine which machine is capable of performing the specific work required to produce a part (as defined in the Process field in the Part Process Table in the Part Definition form). If two machines that are capable of performing the specific process are available, the OpenMES Manager tries to optimize the use of these two machines to complete the process (see *Optimization* in this chapter).

The Machine Definition form lets you view any machine that has been defined for the system. You can define new or modify existing processes for the machine to perform. A *machine record* contains the machine name and one or more defined processes (process record). Each field and the control buttons associated with this form are described in detail in chapter 5.

The CIM Machine Definition window displayed below is accessed by from the OpenMES Manager Main Window, by selecting **Product Preparation | Machine Definition**.









Figure 46: Machine and Process Definition Form

### 7.1.1. Machine Definition Window

#### 7.1.1.1. Main Menu

Option	Description
File	Contains these file options: Save All, Save Selected Machine, Print Machine Report, Exit (from Machine Definition screen). The first three options also appear as tool buttons in the Toolbar (see below).
Edit	Contains the following options for editing rows: Insert Before, Insert After, Delete Row. The rows inserted are copies of the original row, enabling you to edit the content.  You can also access these options by right-clicking the process list cell you want to edit.
Help	On-line help.

7.1.1.2. Toolbar

Option	Description
	Saves all machine records to disk.
	Saves the selected machine record to disk.
	Automatically resizes the columns to accommodate long values (when the window is maximized).
	Print machine report.
	Select a machine from the machine name drop-down list. The names that appear in the list are defined in the Virtual OpenMES Setup.

7.1.2. Machine Process Table

The data fields above the table are also displayed as columns in the table. Their descriptions are provided below.

Option	Description
<b>Machine Name</b>	A descriptive name which uniquely identifies the machine. You can edit/examine the record for a specific machine by selecting that machine name from the drop-down list in the toolbar. All machines that are defined in the Virtual OpenMES Setup appear in this list.
<b>Process</b>	<p>The name of a production process that can be performed by this machine. A Process Name can only be used once for a given machine.</p> <p>The name should be easily recognizable to CIM users and may contain the characters A–Z, 0–9 and underscore ( _ ), but no spaces.</p> <p>This Process Name is assigned to a part in the Part Definition form (in the Process field of the Part Processes Table).</p> <p>Assigning a process to a part instead of a machine can have advantages when there are two or more machines capable of performing the same process. Having more than one machine capable of performing a given process allows the OpenMES Manager to select the machine which can process a part most efficiently and redirect production if one machine fails.</p> <p><b>i</b> <i>For different machines that can perform the same process, you should enter the same process name. Likewise, do NOT use the same process name to refer to processes on different machines which do not perform the same operation on the same part.</i></p>



The following reserved words cannot be used as Process names:

ALLOC	GET	PACK
ASSEMBLY	GET_FIX	PLACE
BASE	MAKE	PROCESS
CNC	MOVE	QC
DELIVER	NEXT	RENAME
END_ASSEMBLY	NOP	TARGET
FREE	ONFAIL	TRANSFER

<b>Option</b>	<b>Description</b>
<b>File</b>	<p>A file containing the G-code program or other program associated with this process. This file name can include a valid directory path to a file. If no path is specified, the OpenMES Manager expects to find this file in the current working directory associated with the device driver for this machine.</p> <p>A file can contain one machine control program. Different machines that perform the same process will have their respective control programs stored in different files.</p>
<b>Program</b>	<p>The name of the machine control program associated with the process being defined. This Program Name is used by an ACL controller which is operating a machine.</p>
<b>Fail(%)</b>	<p>Your estimate of the number of rejected parts that will result when this process is run on this machine (0 - 100%). The OpenMES Manager takes this value into consideration only when simulating a quality control process.</p>
<b>Duration</b>	<p>The number of minutes this process takes to produce one part. The OpenMES Manager takes this value into consideration when choosing among multiple machines that can run the same process.</p> <p>Format is <i>hh:mm:ss</i></p>
<b>Parameters</b>	<p>This string of arguments is passed to a machine control program associated with this process.</p>
<b>WS</b>	<p>The workstation in which the machine is placed. Automatically displayed by the system (as defined in the Virtual OpenMES Setup).</p>
<b>Machine Type</b>	<p>The type of machine selected. Automatically displayed by the system (as defined in the Virtual OpenMES Setup).</p>
<b>Action Type</b>	<p>A label that defines the characteristics associated with a process. One of these Action Types (in the data field above the table) is selected by default:</p>

Action Type	Description
Assembly	A process which involves the assembly of two or more subparts.
QC	A process involving a test that reports a Pass/Fail result to the OpenMES Manager. If the result is Fail, the rejected part is redone. A quality control process requires an ONFAIL entry in the Part Processes table in the Part Definition form see “Part Definition” below.
CNC	A process which has G-code program(s) associated with it. The OpenMES Manager downloads the G-code file specified in the File field to the CNC machine (unless this file is already resident in the CNC machine).
Process	A basic machine operation which does not require any special action beforehand or afterwards. Runs the ACL program specified in the Program field.
Place	A robot operation used for non-standard operations performed by a robot. The File and Program fields will be blank.

**Robot- controlled**

Specifies if a robot is needed to perform the process. For example, if a welding action is performed by a robot, specifying YES signals the OpenMES Manager that the robot is in use and is not free to perform another operation. This option is available only if the machine selected can use a robot to perform a task, and if the Action Type is Process.

**Cost per Hour**

Estimated hourly cost to run this machine. The OpenMES Manager uses this as one of the criteria in order to decide on the optimum production method.

### 7.1.3. List of Preloaded Programs

Tasks are control programs that can be downloaded to a machine (e.g., G-code to a CNC machine). The OpenMES Manager keeps track of which programs currently reside in a machine's memory. If a certain process requires a machine control program that is not resident, the OpenMES Manager instructs the CNC device driver to download it to the machine.

Option	Description
Max Preloaded Programs	The number of control programs that can reside in a machine's memory at one time. Once this number is exceeded, the OpenMES Manager begins overwriting programs in the machine's memory when it needs to download a new program.
List of Preloaded Programs	The current status of control programs that are loaded in the machine's memory. This box is for information purposes only; it cannot be used to change the programs residing in a machine.

### 7.1.4. How to Define a Machine

The procedures presented below refer to an OpenMES sample application for producing a simple, covered box (product). When defining the process for the covered box, two processes need to be defined: CNC milling and assembly.

- ① *These procedures represent a simplified example. When defining more complicated applications, entries to other fields will also be required.*

1  
2  
3  
Procedure

**A. Defining the Milling Process**


1. In the Machine Definition form, select EXPERTMILL1 from the Machine Name drop-down list; this is the name for the milling machine, as defined in the Virtual OpenMES Setup. The MILL1 record becomes the current record and appears in green in the Machine Process Table. The record contains the process(es) defined for the machine. The workstation is shown as WS3, the machine type as M-MACHINE, the action type as CNC, and Robot-controlled as No and gray.
2. In the Process column, type in the Process Name MILL2. (You will need to make sure—either now or later—that MILL2 appears in the Process field in the Part Process Table in the Part Definition form).
3. In the File column, type in GCODE.NC, for example, as the name of the G-code program file that contains the instructions for this type of process.
4. In the Duration column, type in the amount of time it takes the mill to perform this operation, e.g., thirty seconds.
5. Your screen should now look like this:

Machine Name	Process	File	Program	Fail (%)	Duration	Parameters
JIGXY4	PLACE ON VISION		PLACE		00:00:10	
RDR1	READ BARCODE			10	00:00:10	TEMPLATETYPE
EXPERTMILL1	MILL1	301.NC			00:00:10	
	MILL2	GCODE.NC			00:00:30	
JIG1	ASSEMBLE XV ASSY				00:00:10 00:00:10	
PLT3000_2	TURN1 TURN2	201.NC 202.NC			00:00:10 00:00:10	
SDRV1	SCREWING				00:00:20	
VSN1	CHECK XV VIEWFLEX				10 00:00:10 10 00:00:10	

List Of Preloaded Programs [ EXPERTMILL1 ]  
302.NC

Figure 47: CIM Machine Definition – Defining the Milling Process

1  
2  
3  
Procedure

6. Click  to save the currently displayed information to the database. You can now generate and view a Machine or Process Report by using the Report Program.
  7. Continue with the procedure Defining the Assembly to define the other process which is required to produce the covered box
- Note:** *The assembly operation is usually performed by a jig device (such as a pneumatic jig) not a machine.*

**B. Defining the Assembly Process**

1. In the Machine Definition form, select JIG1, from the Machine Name drop-down list; this is the name of the device that performs assembly operations, as defined in the Virtual OpenMES Setup. The JIG1 record becomes the current record and appears in green in the Machine Process Table. The workstation is shown as WS3, the machine type as J-JIG, the action type as ASSEMBLY, and Robot-controlled as NO and gray.
2. In the Process column, type in the Process Name ASSY. (You will need to make sure—either now or later—that ASSY appears in the Process field in the Part Process Table in the Part Definition form.)
3. In the Duration column, type in the amount of time it takes the mill to perform this operation, e.g., 12 seconds.
4. Your screen should now look like this:





Figure 48: CIM Machine Definition – Defining the Assembly Process

Click  to save the information to the database.

You can now generate and view a Machine or Process Report by using the Report Program.

## 7.2. PART DEFINITION

A product is manufactured from a group of subparts (bill of materials) that are put together according to a specified set of machine processes. Starting with a set of raw materials (supplied parts), you define parts at the intermediate stages of production required to assemble a final product.

The Part Definition screen, or form, allows you to enter the bill of materials and the associated production processes used to produce a part. Using the Part Definition form, you can either:

- Modify/view the production process for an existing product.
- Describe the production process for a new product.

Defining a new product involves the following steps:

- Drawing a part definition tree.
- Setting up all machine processes necessary to produce a product and all its subparts.
- Determining what new template designs are required to handle all the parts involved and assign these designs template ID numbers.
- Determining the types of racks that can hold each subpart.

The Part Definition form for Product (or Phantom) parts lets you create, view, or modify the current part (either a product or its subparts). A *part record* contains all the fields shown on the Part Definition form below. Each field and the control buttons associated with this form are described in detail in this section.

The screenshot shows a software window titled "CIM PART DEFINITION - (C:\Users\Public\Documents\Intelitek\OPENCIM\Projects\CIM-08-B-DEMO\ws0\)" with a menu bar (File, Edit, Help) and a toolbar. Below the toolbar are three tabs: "Supplied Parts", "Product Parts", and "Phantom Parts". The "Supplied Parts" tab is active, displaying a table with the following data:

Part Name	Part ID	Supplier Name	Catalog Number	Min. Order	Safety Stock	Cost	Supply Time(days)	Desc
SUP_ACRYLIC_BLOCK	1							
SUP_BASE_W_HOLE	201							
SUP_BG_BASE	401							
SUP_BG_COVER	501							

Below the table, the "SUP\_ACRYLIC\_BLOCK details" section is visible, containing the following fields:

- Template Type: 01
- Rack/Feeder: 202,101,102
- Color: (Red color swatch)
- 3D File: MILL\_SUP

The status bar at the bottom left shows "Ready".

Figure 49: Part Definition Form for Supplied Part

If you define the part as Supplied, the Part Process table will be replaced by a section containing data regarding the supplier and supplied material, as shown below:











Figure 50: Part Definition Form for Supplied Part

## 7.2.1. Part Definition Form

### 7.2.1.1. Main Menu

Option	Description
<b>File</b>	Contains these file options: New Part, Save Current Part, Save All, Print, Exit (from Part Definition screen). The first five options also appear as tool buttons in the Toolbar (see below).
<b>Edit</b>	Contains these row and part editing options: Insert Before, Insert After, Copy Part, Paste Part, Delete Row, Delete Part. You can also access these options by right-clicking the process list cell you want to edit.
<b>Help</b>	On-line help.

### 7.2.1.2. Toolbar

Option	Description
	Defines new part
	Saves all part records to database.
	Saves the selected part record to database.
	Automatically resizes the columns to accommodate long values (when the window is maximized).
	Prints part report.
	Selects a predefined part from the part name drop-down list.
	Selects a predefined part ID from the part ID drop-down list.

### 7.2.1.3. Information Bar

#### Option



The screenshot shows four UI elements from the Information Bar:

- Template Type:** A text input field containing the value '01'.
- Rack/Feeder:** A dropdown menu with a plus sign and a downward arrow.
- Color:** A color selection box showing a red color swatch and an ellipsis menu.
- 3D File:** A dropdown menu with 'No change' selected and a 'Browse' button.

#### Description

Defines the template type (01-99) whose pin arrangement can accommodate the selected part.

Defines the types of racks/feeders that are capable of accommodating the selected part.

Defines the color of the parts that can be viewed on the conveyer. You can define a different color for each part. The part color will change after the work on the part is completed.

#### Note:

The color will not be changed for custom parts which are provided in the OpenMES installation.

Defines a part shape from either the list of supplied or previously added shape parts, or by browsing to a new user defined part.

When a new 3D file is added by browsing, the file is added to the project directory for example:

C:\Users\Public\Documents\Intelitek\OpenCIM\Projects\TUTORIAL\_SAMPLE\CIM\_CUSTOM\_parts.

#### 7.2.1.3.1. Designing User Parts and Objects

Users can add other parts and objects over the existing ones that are provided with the installation of the software.

There are two stages to creating new parts and objects.

- Creating Parts and Objects
- Adding Parts and Objects to OpenMES Projects

#### 7.2.1.3.2. Creating Parts and Objects

There are three ways to create new parts and objects:

- Modify an Existing User Part File
- Create a New Part/Object File
- Import a CAD File



### 7.2.1.3.3. Modify an Existing User Part File

Existing user parts that are provided with the installation may be modified to suit the requirements of the user.

To modify an existing user part:

1. Open the CIM\_CUSTOM\_PARTS folder located in the following directory:
  - C:\Users\Public\Public Documents\Intelitek\OpenCIM\CIM\_CUSTOM\_parts.
2. Using a text editor that saves files in plain ASCII format, such as Notepad, open one of the existing user part files in the directory. Below is an example of a part file.

```
ModelBegin  
TransformBegin  
Color 0.0 1.0 1.0  
Surface 0.4 0.3 0.2  
Opacity 1.000000  
LightSampling Facet  
GeometrySampling Solid  
TextureModes Lit  
Texture NULL  
ClumpBegin  
Translate 0.0 0.0251 0.0  
Tag 1  
Block 0.05 0.05 0.05  
ClumpBegin  
Tag 2001  
Color 1 0 0  
Opacity 1  
Block 0.03 0.02 0.07  
ClumpEnd  
TransformEnd  
ModelEnd
```

3. Edit the file to modify the part. (Refer to the documentation provided in Program Files\Intelitek\OpenCIM\sources\Graphics\RW\Documentation for details on RWX commands).

See the Adding Parts and Objects to OpenMES Projects section for details on adding the file to OpenMES project(s).

#### 7.2.1.3.4. Create a New Part/Object File

To create your own user part and user object files:

1. Open a text editor that saves files in plain ASCII text, such as Notepad.
2. Write the program to create your own part. (Refer to the documentation provided in Program Files\Intelitek\OpenCIM\sources\Graphics\RW\Documentation for details on RWX commands).

See the Adding Parts and Objects to OpenMES Projects for details on adding the file to OpenMES project(s).

#### 7.2.1.3.5. Import a CAD File

You can create a 3D object in a CAD program and import it to CIM Part Definition.

To import a CAD file:

1. Create a file in any CAD program and save it as a \*.dxf or \*.3dc file.
2. Use the RW3DCONV converter to convert the file to RWX format. This converter is provided with the installation of OpenMES, and is located in the following directory: Program Files\Intelitek\OpenCIM\Sources\Graphics\RW\ converter.

① *Ensure that there are no more than 1000 polygons in the CAD file.*

See the next section for details on adding the file to OpenMES an project(s).

For more information on RWX files, refer to the RWX help file which is provided with the OpenMES installation, and is located in the following directory: Program Files\Intelitek\OpenCIM\sources\Graphics\RW\Documentation.

#### 7.2.1.3.6. Adding Parts and Objects to OpenMES Projects

Parts and objects can be added to a single project only, or to all projects, such that they will appear in the 3D file are drop-down menu of every project in OpenMES.

To add the part or object to a single project:

1. Save the file as a .rwx file.
2. Open the Part Definition utility by selecting **Utility Programs | Part Definition** from the OpenMES Project Manager.
3. Click **Browse** in the 3d File area at the bottom right of the window.
4. Browse to the location of the file that you saved and click **OK**. The part is added into the project, and appears in the 3D File drop-down menu. A copy of the file is added to the following directory:
  - C:\Users\Public\Documents\Intelitek\OpenCIM\Projects\TUTORIAL\_SAMPLE\CIM\_CUSTOM\_parts.

To add the file to all projects, save the file as a .rwx file in the following directory:

- C:\Users\Public\Public Documents\Intelitek\OpenCIM\CIM\_CUSTOM\_parts.

### 7.2.2. Part Table

Option	Description
<b>Part Type</b>	Select one of the following types for this part:
<b>Product</b>	A part that can be ordered from the CIM. The final part at the top of the part definition tree is always defined as a product. Part is the product that is produced by the CIM system. In some industrial software, the term “MAKE” is often used to refer to the product.
<b>Supplied</b>	A part received from an outside source, i.e. a part not produced by the CIM, therefore it does not require a process definition. Supplied parts do not contain any entries in their Part Process tables. A supplied part is found only at the bottom of the Part Definition tree. In some industrial software, the term “BUY” is often used to refer to the supplied part.
<b>Phantom</b>	A part or subpart which has failed QC. This definition allows the OpenMES Manager to issue instructions on how to handle a rejected part. <i>Phantom parts cannot be ordered.</i>

## 7.2.2.2. Product Part Data

<b>Option</b>	<b>Description</b>
<b>Part Name</b>	A string which uniquely identifies this part (i.e. two parts cannot have the same name). The name should be easily recognizable to CIM users. The string may contain the characters A–Z, 0–9 and underscore ( _ ), but no spaces.
<b>Part ID</b>	A numeric value (1 – 999) which uniquely identifies this part (i.e. two parts cannot have the same ID). This Part ID can be used with devices which require a numeric part identifier. For example, the ACL controller uses the Part ID to activate the appropriate control program to handle this part.
<b>Subpart</b>	<p>The name of a material used to produce the current part.</p> <p>A subpart must be defined in its own Part Definition record. A subpart can either be a raw material (i.e. a Supplied Part) or a part produced by the CIM (i.e. a Phantom Part or a Product).</p> <p>Some rows in the Part Process table require a Subpart name while others do not. A Subpart name is required in the following circumstances:</p> <ul style="list-style-type: none"> <li>▪ A Subpart name is required in row 1 of the Subpart column.</li> <li>▪ A Subpart name is required for each part that is included in an assembly.</li> <li>▪ A Phantom Subpart name is required after each quality control test in order to associate a name with the ONFAIL exception handler.</li> </ul> <p>After the first row, a subpart name is not required if the process being performed operates on the same part that was listed in the previous row. For example, the first row could specify the name of a cube that is to be machined into a box. The second row specifies a process that drills a hole in the box. In this case, the subpart field of the second row would be blank because the drill operates on the same subpart specified in row one.</p> <p>If you need more than one of a subpart, add a separate row to the Part Process table for each unit.</p> <p>A circular definition error will result if you enter a subpart name that matches the name of the part being defined (i.e. Subpart = Part). This error will also occur if any of the subparts in turn contain a subpart that matches the Part Name being defined.</p>
<b>Process</b>	<p>Enter the name of a production process that has been defined in the Process field of the Machine Definition screen.</p> <p>If this process exists on more than one machine, the OpenMES Manager selects the machine to use according to its production strategy (e.g. minimize cost, minimize production time, etc.).</p>
<b>Parameters</b>	The Parameters field specifies how to carry out this process when it is

Option	Description
	performed for the current part. Clicking a parameter field for GET, ONFAIL and TARGET processes displays the storage devices that can be selected.

For quality control devices, the parameter string is used to specify the type of QC test and the range of acceptable values.

For a machine that performs assembly operations, the parameter string specifies where to put the part that is being added to the assembly. If this target location contains compartments, you can add an optional index for the compartment number.

The table below details how parameters are used by several devices:

Device	Example	Description	Note
ViewFlex or ROBOT-VISIONpro	1, 4	type of test, minimum value, [maximum value]	If maximum value is omitted, the minimum value represents the single acceptable value.
Laser Scan Meter	1,150, 160	type of test, minimum value, [maximum value]	If maximum value is omitted, the minimum value represents the single acceptable value (with a tolerance of ±5%).
Assembly Machine	BOX, 2	target location, [target index]	Places subpart assembly BOX in location #2.

The following system variables can be used in the Process definition.

Variable	Description
\$PARTID	Part ID as defined in the Part Definition form.
\$TEMPLATEID	The Template ID (six digits) defined in the Storage Definition form.
\$TEMPLATETYPE	The Template Type (two digits) defined in the Storage Definition form.
\$PRIORITY	The Priority defined in the Manufacturing Order.
\$DURATION	The Duration defined in the Machine Definition form.

### 7.2.2.3. Supplied Part Data

When you select Supplied as the Part Type, the Part Process table is replaced by a form that allows you to define the supplied part.

Option	Description
<b>Part Name</b>	A string which uniquely identifies this part (i.e. two parts cannot have the same name). The name should be easily recognizable to CIM users. The string may contain the characters A–Z, 0–9 and underscore (_), but no spaces.
<b>Part ID</b>	A numeric value (1 – 999) which uniquely identifies this part (i.e. two parts cannot have the same ID). This Part ID can be used with devices that require a numeric part identifier. For example, the ACL controller uses the Part ID to activate the appropriate control program to handle this part.
<b>Supplier Name</b>	The name of the supplier from whom the raw material / supplied part is purchased.
<b>Supplier Catalog Number</b>	The supplier's catalog number for the raw material / supplied part.
<b>Minimum Order</b>	The smallest quantity of this part which can be purchased from the supplier at a time.
<b>Safety Stock</b>	The number of units of this material / part required by the CIM cell to guarantee production without interruption.
<b>Cost</b>	The cost of one unit of the raw material / supplied part.
<b>Supply time (days)</b>	The amount of time it takes the supplier to deliver this material / part to the CIM cell.
<b>Description</b>	A description of the part being defined that explains what it is and where it is to be used.
<b>Template Type</b>	The Template type (01 – 99) whose pin arrangement can accommodate this part.
<b>Rack/ Feeder Types</b>	If this part is to be stored in a feeder, specify which types of feeder are capable of accommodating this part (Feeder Type > 100). Feeder types are defined in the Virtual OpenMES Setup. You can specify multiple feeder types in this field; each one separated by a comma (e.g. 101, 102, 103). Selections are made by choosing from a drop-down list or by typing in the entry.  Similarly, if this part is to be stored temporarily in a rack during processing, specify which types of racks are capable of accommodating this part. See Rack Type definition above.

#### 7.2.2.4. How to Define a Part

In order to define a part, it is important that you understand the entire operation. A part is only the starting point. This part (supplied, raw material) moves within the CIM system according to a predefined path, the part is processed (with another part) and the product is then created.

In order to define a part, you need to:

- Define the supplied material(s)
- Define the process that must be performed on the material(s)
- Define how to assemble the parts (processed and supplied materials)

These concepts can be better explained by referring back to the OpenMES sample application of producing a simple, covered box from a small, solid cube and a matching cover. From this example we can determine that:

Raw Material #1	Box
Raw Material #2	Cover
Product	Covered_Box

1  
2  
3  
Procedure  
Defining the Raw  
Material(s)

1. In the Part Type form, select Supplied parts.
2. From Main Menu select **FILE | NEW PART** or click the “New” button on the toolbar.
3. In the Part Name field, select **BOX** (the solid cube from which the box will be milled) from the drop-down list.
4. In the Part ID field, enter a unique ID for this raw material; for example, 1.
5. In the Template Type field, enter an identifying number for the type of template which will be dedicated to carrying this part; e.g., 01. (This data will be read and used by the Storage Definition program.)
6. In the Rack/Feeder Type, select the type of rack that will be used to hold this part at the workstation; e.g., Rack 201. If a rack or a feeder is not used, leave the field blank.
7. The remaining fields are not required to enable production; they are used to provide statistical data.
8. Click **Save** to save the part.
9. Click **New** and repeat steps #2 – 6 for the other raw material which will be used in the assembly: **COVER**. Your screen should now look like this:

Part Name	Part ID	Supplier Name	Catalog Number	Min. Order	Safety Stock	Cost	Supply Time(days)	Description	Template	Rack/Feeder
BOX	1	SUPPL1	S9-92-BOX	1	1	15	2	PLASTIC BOX	01	201
COVER	2	SUPPL2	C9-79-COV	1	1	10	2	COVER	01	201

BOX details:

Template Type: 01      Rack/Feeder: 201      Color: [red]      3D File: BASE\_HOLE

Figure 51: Part Definition Form for Supplied Parts – Defining a Part

10. Continue on to the procedure “Defining the Product” as described below.

7.2.2.5. When to Define a Subpart (New Part)

Use the following criteria to help determine when to create a subpart at an intermediate stage of production (by entering a name in the Subpart field):

- Define a new subpart if it is needed in the production of other products.
- Define a new subpart to enable an order to be placed for this part (e.g. for use as a spare part).
- Define a new subpart if it requires a different template type.
- Define a new subpart if it is to be used in the assembly of some other product.



### 7.2.2.6. How to Define an Assembly Process

An assembled part (assembly) always has at least two rows. The Subpart name specified in row 1 is referred to as the original material.

The assembly is always performed at or by a machine (such as a pneumatic vise), which is often defined as JIG in the list of Machine Names in the Machine Definition form.

The process for the subpart in the second row must be defined in the Machine Definition form as Action Type **Assembly**.

- 1
  - 2
  - 3
- Procedure  
Defining the Product

1. In the Part Type form, select Product parts.
2. From Main Menu select **File | New Part** or click the **New** button on the toolbar.
3. In the Part Name field, enter COVERED\_BOX (the name of the product).
4. In the Part ID field, enter a unique ID for this product; for example, 3 or accept the default ID number.
5. Select the Subpart cell. Choose box from the drop-down list and type MILL2 as the Process.
6. Add a new process row by right-clicking on any cell into the current row and choose **Insert After** from the edit menu. In the second row in subpart field, choose COVER from drop down list and type ASSY as the Process.
7. In the Template Type field, enter an identifying number for the type of template which will be dedicated to carrying this part; e.g., 01. (This data will be read and used by the Storage Definition program.)
8. It is not necessary to specify a Rack/Feeder type for the final product.

Your screen should now look like this:





Figure 52: Part Definition Form for Product Parts

9. Click  to save .
10. You can now generate and view a Part Definition Report by using the Report Program.

① The above procedures represent a simplified example. When defining more complicated parts it may be necessary to:

- Enter products in the Subpart column of the Part Process Table.
- Use only predefined process names in the Process column of the Part Process Table.
- Add parameters.

### 7.2.2.7. How to Define Quality Control Processes

Whenever you include a quality control process in a Part Definition, you must make provisions for how to handle the rejected part if it fails the quality control test by defining a special part (*quality control exception handler*). While a rejected part is being processed, the OpenMES Manager begins producing a replacement part.




Figure 53: Including a Quality Control Check in a Part Definition

Table Entry	Explanation
PROCESS   VIEWFLEX	Quality Control Test
SUBPART   REJECTED	Quality Control Test Failed (exception handler)
PROCESS   SCREWING	Quality Control Test Passed (continue from here)

The following procedure details the steps involved in handling rejected parts:

**1**  
**2**  
**3**  
 Procedure  
 Setting Up the QC  
 Exception Handler

1. In the Process column of the Part Process table in the Part Definition form, enter a quality control test, i.e., a process whose Action Type is defined as QC in the Machine Definition form, for example: ViewFlex.
2. In the next row of the table, in the Process column, enter ONFAIL.
3. In the Subpart column of this row, enter a unique name for the part, e.g. Rejected, and make sure it has been defined as a Phantom part.
4. Click **Save** when you are finished.
5. For all subsequent rows in the Part Process table, assume that the part has passed the quality control test. Continue defining the normal production steps for this part.

### 7.3. STORAGE DEFINITION

The OpenMES Manager must keep track of which parts are in storage and which templates are available to move these parts from station to station on the conveyor. You can use the Storage Definition form to:

- Update the contents (part and/or template) of storage locations.
- Create/modify template codes.

The screenshot shows the 'CIM Storage Manager' window with a table listing storage locations and their contents. The table has columns for Storage Type, ID, Part Name, and Quantity. The 'ASRS1' storage location (ID 210) contains various parts like PROD\_LASER\_DEMO, PROD\_MILL\_DEMO, etc. Other storage locations include GFDR1 (ID 23) and RACK1 (ID 24).

Storage Type	ID	Part Name	Quantity
ASRS1	210	PROD_LASER_DEMO	6
		PROD_MILL_DEMO	6
		PROD_TURN_DEMO	11
		PROD_CMM_BG_BASE_ST7	1
		SUP_BRASS_CYLINDER	1
		PROD_V_ASSEMBLY	2
		SUP_BASE_W_HOLE	1
			14
		SUP_V_CYLINDER	1
		PROD_WELD_SQUARE	6
		PROD_BG_ASSEMBLY	6
		SUP_BG_BASE	3
		EMPTY	5
		SUP_BG_COVER	3
PROD_WELD_CYLINDER	6		
GFDR1	23	SUP_BRASS_CYLINDER	8
RACK1	24	PROD_TURN_DEMO_ST2	2

To edit storage press <<EDIT>>

Figure 54: CIM Storage Manager Window

### 7.3.1. Storage Manager Form








The Storage Manager administrates all types of materials used in an OpenMES cell. There are three types of Storage: ASRS (automated storage and retrieval system), Rack and Feeder.

Option	Description
ASRS	The ASRS is the main storage device in an OpenMES cell. It serves as a warehouse for parts in various stages of production. ASRS cells contain templates, either empty or loaded with parts.
Rack	This type of storage can contain parts in any stage of production. Templates cannot be stored in racks.
Feeder	Contains raw material only.

### 7.3.2. Main Menu

Option	Description
File	Contains these file options: Save to DataBase, Reset Storage, Create Default Storage, Clear Temporary Storage, Initialize Storage, Exit (from Storage Manager screen). These options also appear as tool buttons in the Toolbar (see below).
Edit	Contains these part editing options: Add Part to Storage, Delete Part from Storage.
Help	On-line help.

### 7.3.3. Toolbar

Option	Description
	Saves the current Storage configuration to the database.
	Adds a new row in the ASRS block. This is used when the location of the part within the ASRS is not important.
	Deletes a row from the ASRS block.
	Resets storage or default storage. Restores a predefined configuration of the storage from the backup database file.
	Creates default storage. Creates a backup database file of the current storage configuration.
	Clears temporary storage. Removes any part or template from Temporary Storage devices.
	Initializes storage. Removes all parts from all devices leaving them empty of parts. <b>Deletes ALL storage data from database.</b>

When you activate Initialize Storage, you must close the Manager window and reopen it again in order to update the storage database

- ③ All devices that do not contain a part or a template at the beginning or at the end of a complete production round are considered temporary storage devices. (e.g. robot, buffer, machine, conveyor pallets, etc.).

### 7.3.4. Storage Data Table

The storage devices that appear in the Storage Type column are defined in the Virtual OpenMES Setup. For further information, see section 8.3.4.

#### 7.3.4.1. ASRS Definition

Click EDIT in the leftmost column of the ASRS row to display the ASRS Storage Definition form:




Figure 55: ASRS Definition Form

Use the following edit options to configure the ASRS:

- |                            |   |
|----------------------------|---|
| <b>Option</b>              | <b>Description</b>  |
| <b>Edit Cell</b>           | Edits the selected cell. You can fill the cell with a defined part on a template or fill the cell with an empty template. You also can edit a cell by double-clicking on any cell to open the Cell Edit form. |
| <b>Delete Part</b>         | Deletes the part placed in the template leaving it empty.   |
| <b>Clear Cell</b>          | Clears the contents of the current cell (i.e. erases both template and part from this cell).  |
| <b>Template Definition</b> | Opens the Templates form where you can define a new template type or delete an existing one.  |


The standard Windows options (copy, paste, undo, redo, etc.) are also available.

### 7.3.5. How to Modify the Contents of an ASRS Storage Cell


Whenever you add or remove a part or a template from a storage cell, use the Storage Definition form to register the change. The following three procedures explain how to:

- Add a part to storage cell.
- Add a blank template to a cell.
- Clear the contents of a cell



①  
②  
③  
Procedure  
Inserting a Part in a  
Storage Cell

1. Move the cursor to the desired cell and double-click it.
2. Select the part to add from the Part name list box.
3. Click  to save this change.

①  
②  
③  
Procedure  
Inserting a Blank  
Template in a  
Storage Cell

1. Move the cursor to the desired cell and double-click it.
2. Select the Template number from the Template list box. If the template is not defined, proceed to define it.
3. Click  to save the change.

①  
②  
③  
Procedure  
Clearing a Storage  
Cell

1. Move the cursor to the desired cell.
2. Click the **Clear Cell**  button.
3. Click the **Save**  button to save the change.

### 7.3.6. How to Define a Template




Templates are special trays that can be customized with an array of pins to hold different parts. Each part has a unique template type that can hold it. A specific type of template can hold various types of parts that fit into its pin arrangement.

Each template has a specific six-digit ID number (standard series starting with 010001 to 010040 and ending with 090001 to 090040) that identifies it. This number appears on an optional sticker that is affixed to the side of the template that faces the barcode or RFID Reader.

The first (leftmost) two of the six digits represent the template type number. All six digits are used as an ID number for the specific template.

RFID tags must be assigned a template ID in the RFID device driver. For more information, refer to the subsection How to Assign a Template ID to an RFID Tag below.

①  
②  
③  
Procedure  
Adding a Template Code

1. Enter the Template Definition in the ASRS form by clicking the **Template Definition**  button.
2. Click the **Add New Template**  button.
3. Type the template's two-digit number.
4. Click the **Save**  button to save the change.

7.3.6.1. How to Assign a Template ID to an RFID Tag

RFID tags each have a unique tag serial number. In order to use RFID tags in a CIM system, they must be assigned a template ID.

To assign a template ID to an RFID tag:

1. Launch the RFID device driver. To do so, locate and launch the relevant workstation launcher as described in OpenMES Loader: DDLoader.EXE, on page 348. The CIM DDLoader is displayed.





Figure 56: CIM DDLoader

2. Check the Load column of the RFIDDRIVER driver, and click the Load Selected Drivers  icon. The RFID Device Driver window is displayed.




Figure 57: RFID Device Driver

3. From the Control Mode drop down list, select Standalone to switch to Standalone Mode.
4. Select Settings | Template Lookup Table. The Template Lookup Table is displayed.




Figure 58: Template Lookup Table



- Click Add Row. The Add Template Information window is displayed.




Figure 59: Add Template Information Window

- Pass an RFID tag in front of the RFID reader. The tag's unique serial number is displayed in the RFID tag field.




Figure 60: RFID Tag in Add Template Information Window

- Insert a template ID in the Template ID field, and optionally, a description in the Comment field.

**①** The RFID tag comment only appears in the RFID Device Driver Lookup Table, and is intended for identification of the RFID tag (for example, Template 6).

- Click Save. An entry for the RFID tag is added to the lookup table.




Figure 61: Template Lookup Table with Entry

- To change the Template ID or Comment for any RFID tag, select the tag in the Template Lookup Table and click Change Row.
- Click Save Table to save the new entry and close the Template Lookup Table.
- Pass the RFID tag in front of the RFID reader and verify that the Template ID is included in the RFID tag entry in the RFID device log.




Figure 62: RFID Device Log Entry in RFID Device Driver

- From the Control Mode drop down list, select Real to switch to Real Mode which is the normal operational mode.

7.3.6.2. Feeder Definition

Click **EDIT** in the leftmost column of the FDR row to display the Feeder Definition form:






Figure 8-18: Feeder Definition Form

During OpenMES production operations, the message **Part not currently available** may be displayed. This indicates that the part feeder, or the ASRS, has run out of the required part.

Option	Description
Part Name	The names of all the parts that have been associated with the specified type of feeder, as defined in the Part Definition form.
Type	The number that identifies a certain type of feeder, as defined in the Virtual OpenMES Setup.
Capacity	The number of units of this type of part / material which can be placed into the feeder, as defined in the Virtual OpenMES Setup.
Quantity	The number of units currently loaded in the feeder. You must manually update the value of this field whenever you add parts to or remove parts from the feeder. The OpenMES Manager automatically updates this field during production.
	Exits and saves any changes.
	Exits without saving any changes.

### 7.3.6.3. Rack Definition

Click **EDIT** in the leftmost column of the RACK row to display the Rack Definition form:




Figure 63: Rack Definition Form

Option	Description
Part Name	This list contains the names of all the parts that are associated with the specified type of feeder, as defined in the Part Definition form.
Type	The number that identifies a certain type of rack, as defined in the Virtual OpenMES Setup.
Capacity	The number of units of this type of part / material which can be placed in the rack, as defined in the Virtual OpenMES Setup.
Quantity	The number of units currently loaded in the rack. You must manually update the value of this field whenever you add parts to or remove parts from the rack. The OpenMES Manager automatically updates this field during production.



Exits and saves any changes.



Exits without saving any changes.

**i** When editing the storage parameters, you must click the create default storage



icon for the parts to be added.

## 7.4. MRP (MATERIAL REQUIREMENTS PLANNING)

### 7.4.1. About MRP

Material Requirements Planning (MRP) enables manufacturers to calculate the material requirements from a list of items they intend to sell. MRP provides a tool for floor control, master production scheduling and capacity planning. Manufacturing Resource Planning (MRP II) coordinates and integrates manufacturing resources together with engineering, marketing, and financial resources.

### 7.4.2. About OpenMES MRP

The OpenMES MRP program is used to create and define three types of orders:

- Customer Orders: products ordered
- Manufacturing Orders: items to be produced
- Purchase Orders: items to be purchased from suppliers

In general, OpenMES MRP allows you to create a list of customers and define the products ordered by each customer. Once Customer Orders are created, the MRP program automatically creates a Manufacturing Order and a Purchase Order. You can view and modify or simply accept the Manufacturing Order, or define a completely new one. When the Manufacturing Order is submitted, the MRP creates an A-Plan file, or production work order. (For further details, see “A-Plan Report” later in this chapter.) In addition, the MRP creates a Purchase Order for items that must be supplied to the CIM. The OpenMES Report Generator can be used to display and print the Purchase Order.

The following figure is a flow chart of the MRP program.




Figure 64: MRP Flow Chart

### 7.4.3. Customer Order Form

When you first activate the MRP, the Customer Order form appears. You can switch to the other order forms (Manufacturing and Purchase) by clicking the appropriate tab.

A customer order is a list of the parts (products) ordered by a customer. The Customer Order form shown below lets you create, view and modify a list of customers and their orders.







Parts must be defined in the Part Definition form before they can be ordered by customers.

Customer	Part Name	Required Quantity	Priority	Due Date
Adani	PROD_BG_ASSEMBLY	6	1	1
	PROD_CMM_BG_BASE_ST7	1	1	1
	PROD_LASER_DEMO	6	1	1
	PROD_LASER_DEMO_ST4	1	1	1
	PROD_MILL_DEMO	11	1	1
	PROD_MILL_DEMO_ST3	2	1	1
	PROD_TURN_DEMO	11	1	1
	PROD_TURN_DEMO_ST2	2	1	1
	PROD_V_ASSEMBLY	2	1	1
	PROD_V_ASSEMBLY_ST5	1	1	1
	PROD_WELD_CYLINDER	6	1	1
	PROD_WELD_SQUARE	6	1	1

Figure 65: Customer Order Screen

#### 7.4.3.1. Toolbar

The following buttons apply only to the Customer Order table. Any changes you make using these buttons will not be stored in the database until you click **Save**.

Option	Description
	Adds a blank row to the Order table.
	Saves the selected Customer Order to the database.
	Automatically resizes the columns to accommodate long values (when the window is maximized).
	Adds a new customer to the customer list.
	Edits the information of the selected customer.
	Creates the selected customer order and saves it to the database.

**Note:** You can only order parts that have been defined as type Product or Supplied. Phantom parts cannot be ordered.

7.4.3.2. Order List

Option	Description
<b>Required Quantity</b>	The number of units required by the customer.
<b>Priority</b>	The priority of this order (1–9). A priority of 1 is most urgent, 9 is least urgent. The OpenMES Manager program uses this priority value to determine the sequence in which to produce orders. Different parts may have the same priority.
<b>Due Date</b>	<p>The shipping deadline for the part. MRP will generate a Manufacturing Order and Purchase Order that will ensure completion of the part by the end of the day preceding the deadline.</p> <p>③ <i>In a commercial CIM environment, this deadline is normally expressed as a specific date and time. In an educational CIM environment, the Due Date is relative to the time an order is submitted. A relative time allows the same order to be resubmitted day after day without the need to edit the date field.</i></p>

7.4.3.3. How to Define a Customer

When you define a Customer, you are defining the name of the customer for whom a finished product or products will be made by the CIM cell.

①  
②  
③  
Procedure  
Defining a New Customer

1. In the Customer Order form, click New Customer. The Customer Data box opens.
2. In the Customer Data box, fill in the name of the customer, and other customer information (e.g., address or phone number). Click Save. The box closes and this customer’s name is added to the Customer List.
3. If you want to make any changes to specific customer information, select the customer from the list, click **Edit Customer** and make the desired changes. Note that the customer name cannot be changed in this option.

### 7.4.3.4. How to Define a Customer Order

When you define a customer order, you define the type and quantity of finished products for a specific customer.

**1**  
**2**  
**3**  
 Procedure  
 Defining a Customer  
 Order

1. Add a new customer order to the list by clicking **New Order**.
2. Right-click in the Customer column to open the customer list. Select the desired customer.
3. Right-click in the Part name column to open the part list. Select the desired part, for example: COVERED\_BOX.
4. In the Required Quantity field, enter the number of units ordered by the customer, in this case 3.
5. In the Due Date field enter a value, in this case 2 (i.e., the part is to be completed in two days). This causes the MRP to instruct the CIM to begin production immediately.
6. Click Save to save the order for this customer.
7. To order more parts for the same customer in the same order, insert a new line by right-clicking on the last cell in the order and choosing **Insert After**. Repeat steps 2-6.
8. When you have finished filling in the order for a specific customer, create the order by clicking on **MRP**.

### 7.4.4. Manufacturing Order Form

A manufacturing order specifies the type and quantity of parts to be produced by the CIM cell on a specific day.

The Manufacturing Order form shown can be generated by the MRP program according to the customer orders currently in the system. You can view and modify or simply accept the Manufacturing Order or define a completely new one. You can define an order at any time, but you must finish defining all machine processes and subparts used in the order before you submit the order for production.

Each row in the Manufacturing Order table represents a total quantity of a particular part which needs to be manufactured on the specified date, so that all customer orders are filled.

Order Date	Part Name	Total Quantity	Initial Quantity	Priority	Due Date
	PROD_BG_ASSEMBLY	6	3	1	1
	PROD_CMM_BG_BASE_ST7	1	1	1	1
	PROD_LASER_DEMO	6	2	1	1
	PROD_LASER_DEMO_ST4	1	1	1	1
Manufacturing order					







Figure 66: Manufacturing Order Screen



7.4.4.1. Tool Bar

You can switch to the other order forms by clicking the appropriate tab.

The following buttons apply only to the Manufacturing Order table. Any changes you make using these buttons will not be stored on disk until you click **Save**.

Option	Description
	Adds a blank row to the Order table.
	Saves the selected Customer Order to the database.
	Auto-resizes the part list columns.
	Prints the Manufacturing report.
	Prints the A-Plan report for the last manufacturing order created. (For further details, see A-Plan Report section in this chapter).
	Creates the selected manufacturing order and its A-Plan and saves them to the database.

The fields described below compose the Manufacturing Order table:

Option	Description
Part Name	<p>The name of the products to be manufactured. This field corresponds to the Part field on the Part Definition form. Right-click in the Part Name column to open the product list.</p> <p><b>ⓘ</b> <i>You can only order parts that have been defined as type Product. Products that have been defined as type Phantom or Supplied cannot be ordered.</i></p>
Total Quantity	The total number of units ordered which must be manufactured on the specified day.
Initial Quantity	The number of parts to be extracted from the ASRS when production begins. The initial quantity is a number that can range from 1 (one) up to the value of the total quantity. Usually, the value is 1 or 2. This field allows you to optimize the manufacturing process. (Refer to <i>Optimizing the Scheduling in OpenMES</i> in Chapter 8, Virtual OpenMES Setup, for more details).
Priority	The priority of this order (1-9). A priority of 1 is most urgent, 9 is least urgent. The OpenMES Manager uses this priority value to determine the sequence in which to produce orders.
Due Date	<p>The shipping deadline for the part, as generated by the MRP.</p> <p><b>ⓘ</b> <i>In a commercial CIM environment, this deadline is normally expressed as a specific date and time. In an educational CIM</i></p>

*environment, the Due Date is relative to the time an order is submitted. A relative time allows the same order to be resubmitted day after day without the need to edit the date field.*

#### 7.4.4.2. How to Create or Modify a Manufacturing Order

A Manufacturing Order is created automatically by clicking the MRP button in the Customer Order form.

The following procedure explains how to edit or create a Manufacturing Order.

❶  
❷  
❸  
Procedure  
Editing and  
Submitting a  
Manufacturing  
Order

1. Select the order date (number) from the Order List.
2. Click the desired row in the Part Name column and open the product list. Select the product required by the customer.  
*❶ In the Total Quantity field, enter the number of items that need to be produced, in this case 5.*
3. In the Initial Quantity field, enter the number of parts to be extracted from the ASRS when production begins, normally 1 or 2.
4. In the Priority field, enter 1 (indicating the highest priority).
5. In the Due Date field enter a value which is one greater than the value in the Order List, in this case 2, indicating that the product will be manufactured today and ready for shipment tomorrow.  
*❶ To order other products at this time, add a new line by right-clicking the last cell in the order, choosing Insert After, and repeating steps 2-6.*
6. Click Save to save the entries without changing the last submitted production plan (A-Plan).
7. Click the MO icon to submit this order and create a new production plan.
8. You can now operate the OpenMES Manager and start production.

**7.4.4.3. How to Submit an Order**

Before you click MO and submit the manufacturing order, make sure that the following CIM definitions are up to date:

- Machines and Processes
- Parts
- Storage

After setting up these CIM elements, you can initiate production. You will receive an error message if you try to submit an order when any one of the following conditions exists:

- An undefined part is referenced on the Manufacturing Order form.
- An undefined subpart is referenced in a Part Process table.
- An undefined machine process is referenced in a Part Process table.

**7.4.5. Purchase Order Form**

A purchase order is a list of the parts that need to be supplied to the CIM cell so that it can complete the Customer Order.

The Purchase Order form shown below can be generated by the MRP program according to the customer orders currently in the system. You can view and modify or simply accept the Purchase Order, or define a completely new one.

The Purchase Order form lets you create, view, and modify a list of suppliers.

Parts must be defined in the Part Definition form before they can be ordered from suppliers.

Each row in the Purchase Order table represents a total quantity of a particular part which needs to be purchased by a specified date, so that all customer orders are filled.







Supplier	Part Name	Quantity	Cost	Due Date	Send Date
UNDEFINED	SUP_BG_BASE	6		1	0
UNDEFINED	SUP_BG_COVER	6		1	0
UNDEFINED	SUP_UL_PIN	6		1	0
UNDEFINED	SUP_LR_PIN	6		1	0

Figure 67: Purchase Order Screen

### 7.4.5.1. Toolbar

You can switch to the other order forms by clicking the appropriate tab above the table.

The following buttons apply only to the Purchase Order table. Any changes you make using these buttons will not be stored on disk until you click **Save**.

Option	Description
	Adds a blank row to the Purchase Order table.
	Saves the selected purchase order in database.
	Auto-resizes the part list columns.
	Allows you to add a new supplier to the Supplier list.
	Allows you to edit the information of the selected supplier.
	Creates the selected purchase order and saves it in the database.

The following fields compose the Purchase Order table.

Option	Description
Part Name	The name of the part you want supplied. This field corresponds to the Part field on the Part Definition screen.  ⓘ <i>You can only order parts that have been defined as type Supplied.</i>
Quantity	The number of units you want to receive from the supplier.
Cost	The cost per unit, as defined in the Part Definition form.
Due Date	The date on which the part must be received from the supplier.  ⓘ <i>In a commercial CIM environment, this deadline is normally expressed as a specific date and time. In an educational CIM environment, it is an advantage to have the Due Time relative to the time an order was submitted. A relative time allows the same order to be resubmitted day after day without the need to edit this field each time.</i>
Send Date	The deadline for sending the Purchase Order to the supplier. Calculated by subtracting the time required by the Supplier (as defined in the Part Definition form) from the Due Date.

### 7.4.5.2. How to Define a Supplier

When you define a Supplier, you are defining the name of the supplier who will provide parts for the CIM cell.

- ❶
- ❷
- ❸

Procedure

Defining a New  
Supplier

1. In the Purchase Order form, click **New Supplier** to open the Supplier Data box.
2. In the Supplier Data box, fill in the Name of the Supplier, and other Supplier information (e.g., address or phone number). Click Save. The box closes and this supplier's name is added to the Supplier List.
3. If you want to make any changes to specific supplier information, select the Supplier from the list, click **Edit Supplier** and make the desired changes. Note that you cannot change your name when editing supplier details.

#### 7.4.5.2.1. How to Create or Modify a Purchase Order

The following procedure explains how to edit or create a Purchase Order.

①  
②  
③  
Procedure  
Defining a Customer  
Order

1. Add a new purchase order to the list by clicking **New Order**.
4. Click the desired row in the Supplier column and open the supplier list. Select the name of the desired Supplier .
5. Click the desired row in the Part name column and open the part list. Select the desired part, for example: BOX .
6. In the Required Quantity field, enter the number of items ordered by the Supplier, in this case 3.
7. In the Due Date field enter a value, in this case 2 (i.e., the part is to be completed in two days). This causes the MRP to instruct the CIM to begin production immediately.
8. Click Save to save the order for this Supplier.
9. To order other products at this time, add a new line by right-clicking on the last cell in the order, choosing Insert After, and repeating steps 2-6.
10. If you want to order more parts in the same order, add a new line by right clicking on the last cell in the order, choose **Insert After** and repeat steps 2-6.
11. After you have finished filling in the order for a specific customer, create the order by clicking **MRP**.
12. Click the PO button to activate the Report Generator, which will display or print the Purchase Order.

#### 7.4.5.3. How to Send a Purchase Order

When you click PO, the MRP program prompts you to enter the date or dates for which you to print out Purchase Orders.

Since you do not want to send orders too far in advance (which will commit the purchase), and since you do not want to send a number of orders day after day, the MRP allows you to consolidate your orders for a period of time, say a week.

Once the dates are entered, the OpenMES Report Generator menu appears on the screen. Refer to “Purchase Order Report” later in this chapter.

## 7.5. OPTIMIZATION

The order of operation (timing), performed by CIM is controlled using the CIM optimizing mechanisms, which run concurrently and make decisions based on real-time situations in the work cell. You can manipulate the behavior of CIM by changing any one mechanism, or a combination of any of these optimizing mechanisms. This section describes the CIM Optimization Definition in CIM as well as the additional optimizing mechanisms, described in *Additional Optimization Methods in OpenMES*, at the end of this section.

When activating OpenMES, parts are dispatched from storage and placed in the queues to the various machines for processing. In certain cases some parts need to be processed in a number of different machines. The OpenMES Manager sorts these parts by creating a virtual queue of parts that are waiting to be processed in each machine, and the machine in turn always processes the first part in the queue. Optimization is performed using different methods for sorting the machine queue. For a general overview of optimization refer to section 2.6.1, What is Optimization?.

- ① *Even though each queue is managed separately for each machine, the performance is tested for the overall system.*

### 7.5.1. CIM Optimization Definition

The CIM Optimization Definition enables users to select machine queue algorithms and define their weight. Users can then observe the effect of the different algorithm combinations on the overall system performance.

The results generated from the CIM Optimization Definition are displayed in the CIM Performance Analysis window as described in *Performance Analysis*.

The CIM Optimization Definition window is displayed by selecting **Production**

**Preparation | Optimization Definition** from the OpenMES Manager main window, and appears as follows:











Figure 68: CIM Optimization Definition

## 7.5.2. CIM Optimization Definition Window

### 7.5.2.1. Main Menu

Option	Description
<b>File</b>	Contains the following file options: Save and Refresh (described in the toolbar options below). The Print, Preview and Print Setup options will be defined later on.
<b>View</b>	Contains the following toggle view options: Toolbar, Status Bar
<b>Help</b>	Displays the online help.

### 7.5.2.2. Toolbar

Option	Description
	<b>Save:</b> Saves the Machine Queue form to the database .
	<b>Refresh:</b> Refreshes the Machine Queue form to the entries that were defined before the last save.
	<b>Queue Per Machine:</b> Displays the list of machines and their algorithms, enabling you to select a different algorithm and weight for parts in the queue for each machine.
	<b>Queue Per System:</b> Displays the system algorithm, enabling you to select the same algorithm for parts in the queue for all the machines in the system.
	<b>Enable Dependency:</b> Enables finish-to-finish dependency. Meaning that the algorithms will plan the manufacturing process, to enable all tasks to finish together (for the overall system). This is performed, for example, by starting the manufacturing process with the part containing the longest process time and ending with the part containing the shortest process time.
	<b>Disable Dependency:</b> Disables finish-to-finish dependency.
	<b>Print Optimization:</b> Displays an optimization report.

### 7.5.2.3. Machine Queue Form





Figure 69: Machine Queue Form Tab in CIM Optimization Definition Window







The Machine Queue Form contains the following fields:

Column	Description
<b>Machine</b>	Contains a predefined list of all the machines defined in the Virtual OpenMES Setup.
<b>Algorithm Name</b>	<p>The name of the algorithm defined for the parts that are in the queue to the selected machine. You can select the required algorithm from the dropdown list, as follows:</p> <p><b>FIFO (First in First Out):</b> Parts are processed according to first in first out. Meaning, the parts that arrive first in the queue are processed first.</p> <p><b>Maximum Priority:</b> Parts are processed according to their priorities (<b>1</b> through <b>10</b>) that were defined in the CIM MRP window. Meaning, the parts with the highest priority (such as, <b>1</b>) will be processed first.</p> <p><b>Random:</b> Parts are processed based on a random selection basis.</p> <p><b>Shortest Process Time:</b> Parts are processed according to their process time period. In this case, the parts with the shortest process time will be processed first.</p>
<b>Algorithm Weight</b>	Enables you to enter the weight of the selected algorithm (the total weight of all algorithms must be 100).
<b>Note</b>	Enables you to enter a text comment for reference purposes.


7.5.2.4. Status Bar



The status bar, shown above, contains the following information:

Option	Description
JIGXY4	The current machine for which the queue is defined.
100	The total algorithm weight.
Queue Per Machine	Defines the current queue characterization, as follows:  <b>Queue Per Machine:</b> Displayed when the  button is selected from the toolbar. The queue is defined specifically for each machine.  <b>Queue Per System:</b> Displayed when the  button is selected from the toolbar. The queue is defined for the whole system.
Finish to Finish Dependency	Defines whether or not finish-to-finish dependency is activated, as follows:  <b>Finish to Finish Dependency:</b> Enables process dependency, displayed when the  button is selected. Meaning, the algorithms will plan the manufacturing process, to enable all tasks to finish together (for the overall system).  <b>No Finish to Finish Dependency:</b> Disables part dependency, displayed when the  button is selected.

7.5.2.5. Optimization Right-Click Menu



The status bar, shown above, contains the following information:

Option	Description
Insert Row Before	Enables you to insert a new algorithm before the selected algorithm.
Insert Row After	Enables you to insert a new algorithm after the selected algorithm.
Delete Row	Enables you to delete an existing algorithm.  <i>ⓘ A minimum of one algorithm exists per machine. When only one algorithm exists, the system does not enable you to delete it.</i>

### 7.5.2.6. Defining Algorithms

The following procedure explains how to define an algorithm in the Optimization Manager and then run the CIM cell to view the virtual queues of parts that are waiting to be processed in each machine.

- 1
- 2
- 3

Procedure

Defining Algorithms

1. From the CIM Project Manager main window, select a project for which you want to define algorithms.
2. From the Project Manager Home ribbon, click the OpenMES Manager button. The OpenMES Manager main window is displayed.
3. Select **Production Preparation | Optimization Definition**. The CIM Optimization Definition window is displayed.









Figure 70: Defining Algorithms in the CIM Optimization Definition

4. Ensure the  Queue per Machine icon is selected (as shown above) displaying the queue per machine.
  5. In the Machine Queue tab select the required algorithm for each machine from the **Algorithm Name** dropdown list.
  6. Enter the required weight in the **Algorithm Weight** field.
  7. If required you can add additional algorithms for a specific machine, as follows:
    - Right click the algorithm. A right-click menu is displayed.
    - Select Insert Row Before or Insert Row After to add an algorithm, and then select the required algorithm from the Algorithm Name dropdown list.
    - In the Algorithm Weight column, enter the weight for each algorithm (ensuring the total algorithm weight per machine is 100.)
-  *The current sum of the algorithms is displayed in the status bar.*

1  
2  
3  
Procedure  
Defining Algorithms

8. Click **Save** and then select **File | Exit** to close the Optimization Manager.
9. From the OpenMES Manager window, select **Production Preparation | Part Definition**. The part definition window is displayed. For each part select a different color. This will enable you to observe the flow of parts according to their color in the manufacturing cycle. Close the Part Definition window. Refer to the Part Definition section in this chapter for further details
10. Select **Production Preparation | MRP**. The CIM MRP window is displayed. In the **Customer Order** tab, select the parts, define their quantities, and then select . Click the **Manufacturing Order** tab, select the order to process and click  and then click **OK**. Refer to the MRP section in this chapter for further details. Close the CIM MRP window.
11. From the OpenMES Manager window and click **Home | Start**. Click **OK** at the confirmation message and then click **Run** and observe the CIM manufacturing cycle.
12. Select **Home | Machine Queue View**. The Machine Queue View window is displayed.



Device	Part ID (grade)	1	2	3	4	5	6
ASRS1							
JIG_X9							
RFIDR1		340 (0.00)	345 (0.00)	350 (0.00)	231 (0.00)	234 (0.00)	237 (0.00)
PROTURN1		335 (0.00)					
RACK1							
PROMILL1							
RACK2							
LSRENGRV1							
JIG1		248 (0.00)	250 (0.00)	252 (0.00)	256 (0.00)	258 (0.00)	260 (0.00)
BALLFDR1							
RACK3							

Figure 71: Machine Queue View

You can now view the parts which are placed in the machine queues based on the algorithms that you selected in the Customization Manager window.

### 7.5.3. Additional Optimization Methods in OpenMES

Further to the Optimization Manager, described in the previous section, additional optimization mechanisms (and their examples) that exist in OpenMES are described below:

- In each manufacturing order line (in the order definition), for each type of part you can decide how many parts of this type will be released from storage at the beginning of the manufacturing process in order to fill the buffers. This number is referred to as "Initial Quantity".

- The release time of each additional part from the ASRS is not set in terms of time, but rather in terms of the work (part) progress. For example, an additional similar part is fed to the system only when the previous part has reached a certain stage in its production plan. This stage is marked by adding the command NEXT in the definition of the part production process. The default used for a production plan is that the system will begin to feed the next part after the last manufacturing process defined for each part. The default can be changed by adding the command NEXT in the Process column in the Part Definition form.

#### Example

This example demonstrates how to use the NEXT command to set the release time of the parts from storage.

We will examine part P1, whose manufacturing process requires the use of three machines, M1, M2, and M3, and the process time of each machine is 2, 7 and 3 minutes respectively.

The “schedule” for the part is represented as follows (neglecting the transfer times between the machines):



Figure 72: Schedule for Part

If a new part is released every time a part finishes its process at M1, there will be an accumulation of parts in front of M2, due to its longer process time. Alternatively, if a new part is released every time a part finishes its process at M2, no queues will be created at any place in the system, since the process at M2 is the longest. Also, releasing a new part only after the end of the last process defined for the part will prevent an accumulation of parts.

The problem in this case is that machine M1 will remain idle until the end of the part process in M2, and even worse, M2, which creates the bottleneck in this example, will remain idle in between parts. The solution is to release more than one part the first time, in order to fill the buffers for each of the machines.

In our example, releasing two parts at the beginning of production, and releasing one additional part each time a part finishes its process at M2, will give maximal throughput of the production line (since machine M2, which forms the bottleneck, will always be busy). This also minimizes the in-process stock and leaves a free time-slot for machines M1 and M3 to work on other parts with a lower priority from the same production process. It can then be seen that the location of the NEXT command immediately after the longest process results in maximal utilization of the system. On the other hand, locating the NEXT command at the end of the production process will result in a system which uses more parts in the buffer, thus continuing to deliver good throughput even in cases of failure, inaccurate data, or a combination of simultaneous production of different types of parts having different priority levels.

The timing for parts of different types (it is possible that they share the same machines for part of their production process) uses the same mechanism for each part, and in addition uses the machine queue mechanism, in order to decide which part will be processed first in a certain machine. As a simple example, the machine queue mechanism will choose a part having a higher priority level.

In the following figure, a further example of the process scheduling is given (the same example but with a different level of detail). Part P1 is the part described above, and part P2 is processed by machines M1 (3 minutes process time) and M4 (2 minutes process time). The order included four parts of each type and the initial quantity of both parts is two (2). Part P1 is defined with a higher priority than part P2. The user did not use the NEXT command for either part, so the system is using the default of putting the NEXT command after the last process defined for each part.




Figure 73: Process Scheduling

- P1.1 is the first part of type P1.**
- P1.2 is the second part of type P1.**
- P2.1 is the first part of type P2.**
- P2.2 is the second part of type P2.**

Time	Machine	Description
0	M1	OpenMES Manager invoked. 2 parts of type P1 and 2 parts of type P2 were sent from storage. M1 selects 1 of the 4 parts based on priority level (P1.1) to begin processing.
2	M1	Finished processing P1.1 and selects one of the 3 parts remaining in the buffer (based on the highest priority level) to begin processing (P1.2).
	M2	P1.1 is sent from M1, for processing.
4	M1	Finished processing P1.2 and selects from the queue, based on priority level one of the two remaining parts (P2.1) to begin processing.
	M2	P1.2 is sent from M1 to wait in the buffer of M2.
7	M1	Finished processing P2.1. Part P2.2 is selected from the queue to begin processing.
	M4	P2.1 is sent from M1 to begin processing.
9	M2	Finished processing P1.1 and begins to process P1.2.
	M3	P1.1 is sent from M2 to begin processing.
	M4	Finished processing P2.1 (the last process) so, the NEXT command is performed and P2.3, is waiting on the buffer of M1
10	M1	Finished processing P2.2 and P2.3 is selected from the queue to begin processing.
	M4	P2.2 is sent from M1 to begin processing.
12	M3	Finished processing P1.1.
	M4	Finished processing P2.2. The NEXT command is activated and part P1.3 is waiting on the buffer of M1.
13	M1	Finished processing P2.3 and P1.3 is selected from the queue to begin processing.
	M4	P2.3 is sent from M1 to begin processing.
14	M1	The NEXT command is performed, so P2.4, is waiting on the buffer.
15	M1	Finished processing P1.3 and P2.4 is selected from the queue to begin processing.
	M2	P1.3 is sent from M1 to wait in the buffer of M2.
	M4	Finished processing P2.3. The NEXT command is activated and P2.4 is waiting on the buffer of M1.
16	M2	Finished processing P1.2 and P1.3 is selected from the queue to begin processing.

Time	Machine	Description
	M3	P1.2 is sent from M2 to begin processing.
18	M1	Finished processing P2.4. The machine remains idle because there are no parts waiting in its queue.
	M4	P2.4 is sent from M1 to begin processing.
19	M1	Receives P1.4 which was released from the ASRS as a result of the NEXT command and begins processing.
	M3	Finished processing P1.2. The NEXT command is performed, so P1.4, is released from the ASRS and sent to M1 for processing. You can eliminate the inactive time period (Time 18) by increasing the initial quantity for part P1.
20	M4	Finished processing P2.4. The NEXT command is not performed because all 4 parts of type P2 are ready.
21	M1	Finished processing P1.4.
23	M2	Finished processing P1.3 and P1.4 is selected from the queue to begin processing.
	M3	P1.3 is sent from M2 to begin processing.
26	M3	Finished processing P1.3. The NEXT command is not performed because all four parts of type P1 are being, or have been processed.

① *The system works in parallel on orders with both high and low priority, taking into consideration that orders with high priority are treated first.*

#### 7.5.4. Benefits of the Optimization Approach

The Optimization Approach offers the following benefits:

- The system continues to follow the priority you define for each part even though the system is required to work on many parts, from different priority levels.
- The Optimization Approach handles incomplete or incorrect predicted process time in a competent manner (i.e. the NEXT command is actually executed when the machine finishes processing the part and not according to some pre-calculated time).
- The Optimization Approach implemented in the CIM environment can handle different combinations of parts, in different quantities and priority levels that need to be produced in an efficient manner.
- In the example illustrated above the transmission time was neglected. However, the OpenMES system still takes the transmission time into account through the use of its optimization mechanisms. This can become a significant point when CIM systems have short process times and the transmission time cannot be overlooked.



- Machines, robots, storage locations and even conveyors have their own priority queue which you can control in order to increase the performance of the production schedule (e.g. in the example given above, we assumed that all four parts were sent to machine 1 simultaneously because we ignored the transmission time. However, in the real CIM, the optimization mechanisms ensure that machine 1 will work on the part with the highest priority level because the ASRS will know to first select and send the part with the highest priority level from the four parts that it was ordered to release by the OpenMES Manager).

The Optimization Approach is completely distributed. Each machine can continue to work independently as long as there are parts in its queue. Computational overload does not occur on any of the station PCs+, even with very large CIM cells.

## 7.6. PERFORMANCE ANALYSIS

The Performance Analysis utility in OpenMES enables users to analyze the impact of different algorithm combinations on the system performance. You can use this utility to view, print and analyze the manufacturing cycle data to improve system performance, such as to shorten the production time and as a result improve efficiency and lower the production costs.

The data in this utility is generated according to the definitions in the CIM Optimization Definition, as described in *Optimization*.

- ① When activating the CIM Performance Analysis utility, ensure that the simulation speed has been set to 1 in the Modes window.

### 7.6.1. CIM Performance Analysis

The CIM Performance Analysis enables you to view information that was generated from the last manufacturing cycle in the system and then save it for comparison and backup purposes. You can then view a summary of data comparing the different previously saved manufacturing cycles. In addition, you can print the currently displayed performance report and the corresponding optimization report (as displayed in the CIM Optimization Definition).

The CIM Performance Analysis window is displayed by selecting **Production Analysis | Performance Analysis** from the OpenMES Manager main window, and appears as follows:

The screenshot shows the 'OpenMES Performance Analysis' window. It has a menu bar (File, View, Tools, Help) and a toolbar with icons for file operations and simulation. Below the toolbar is a summary section with the following data:

Run ID	33
Total Run Time	00:55:44
Note	Last Run Results

The main part of the window is a table with the following columns: Machine, Total Process Time, % Efficiency, Max Queue Length, Production Cost, # Setups (CNC Only), and % Failures (QC only). The data rows are as follows:

Machine	Total Process Time	% Efficiency	Max Queue Length	Production Cost	# Setups (CNC Only)	% Failures (QC only)
BALLFDR1	00:00:00	0.00	0	0.00	0	0.00
CALPST1	00:00:48	1.44	2	0.00	0	0.00
CMM1	00:00:00	0.00	1	0.00	0	0.00
JIG1	00:00:00	0.00	13	0.00	0	0.00
JIG2	00:00:00	0.00	0	0.00	0	0.00
JIG_X9	00:00:00	0.00	0	0.00	0	0.00
LSRENGRV1	00:01:04	1.91	1	0.00	0	0.00
PROMILL1	00:01:04	1.91	1	0.00	0	0.00
PROTURN1	00:03:44	6.70	2	0.00	0	0.00
RFIDR1	00:02:56	5.26	17	0.00	0	0.00
VSN1	00:00:00	0.00	0	0.00	0	0.00
WELDST1	00:00:00	0.00	2	0.00	0	0.00
System Summary	00:09:36	3.44	17	0.00	0	0.00

The status bar at the bottom shows 'Ready' and a 'NUM' field.









Figure 74: CIM Performance Analysis Window

## 7.6.2. CIM Performance Analysis Window

### 7.6.2.1. Main Menu

Option	Description
<b>File</b>	Contains the following file options: Save, Refresh, Delete All, Print Performance, Print Optimization, Exit. Each of these options are described in the <i>Toolbar</i> section below.
<b>View</b>	Contains the Toolbar toggle view option.
<b>Tools</b>	Show Single, Show Summary, Reset Run ID. Each of these options are described in the <i>Toolbar</i> section below.
<b>Help</b>	Displays the online help.

### 7.6.2.2. Toolbar

Option	Description
	<b>Save:</b> Saves the current manufacturing cycle run performance report to the database, using the Optimization settings defined in the CIM Optimization Definition. The Save Report window is displayed, enabling you to add the cycle's description and save it to the PERFORMANCE_X.DBF file. (The system also saves the corresponding optimization file.)
	<b>Refresh:</b> Refreshes the view to display the results from the last manufacturing cycle run.
	<b>Show Single:</b> Displays the Choose Performance File window, enabling you to select and view a previously saved PERFORMANCE_X.DBF file. Information per machine includes total process time, efficiency, Max Queue Length, Production cost and more. For further details, refer to the <i>Single Manufacturing Cycle Performance Table</i> , described in the next section.
	<b>Show Summary:</b> Displays a summary of all the previously saved manufacturing cycles. Information per cycle includes Total Process Time, Efficiency, Max Queue Length, Production Cost and more. For further details, refer to the <i>Summary of Manufacturing Cycle Performance Table</i> , described in the next section.
	<b>Reset Run ID:</b> Resets the run ID number to 0. This option is used for example, when a new Manufacturing Order is created.
	<b>Delete All:</b> Deletes all previously saved reports from the database.
	<b>Print Performance:</b> Prints the currently displayed performance report.
	<b>Print Optimization:</b> Prints the corresponding optimization report as displayed in the CIM Optimization Definition.

### 7.6.2.3. Manufacturing Cycle Performance Table

The CIM Performance Analysis enables you to view the results of the last manufacturing cycle and save it for future reference. The results include the process time, the efficiency per machine and per system, the number of failures that were detected, as well as other results.

Machine	Total Process Time	% Efficiency	Max Queue Length	Production Cost	# Setups (CNC Only)	% Failures (QC only)
BALLFDR1	00:00:00	0.00	0	0.00	0	0.00
CALPST1	00:00:48	1.44	2	0.00	0	0.00
CMM1	00:00:00	0.00	1	0.00	0	0.00
JIG1	00:00:00	0.00	13	0.00	0	0.00
JIG2	00:00:00	0.00	0	0.00	0	0.00
JIG3	00:00:00	0.00	0	0.00	0	0.00

Figure 75: Manufacturing Cycle Performance Table

The Manufacturing Cycle Performance Table contains the following information:

Column	Description
<b>Machine</b>	Contains the list of machines that were defined in the Virtual OpenMES Setup.
<b>Run ID</b>	Contains the ID number of the manufacturing cycle.
<b>Total Run Time</b>	The time period of the manufacturing cycle.
<b>Note</b>	The manufacturing cycle's description.
<b>Total Process Time</b>	The total process time performed on a specific machine, as well as the system summary - the total process time of all the machines in the cycle .
<b>% Efficiency</b>	The efficiency of each machine in the cycle, as well as the system summary which is the efficiency of all the machines together. Machine efficiency is defined as the process time divided by the total manufacturing time of the machine.
<b>Max Queue Length</b>	The maximum number of parts that existed in the machine queue during the manufacturing cycle.
<b>Production Costs</b>	The production costs per machine and per system. Production costs per machine is defined as the process time multiplied by the cost per hour (defined in <i>Machine and Process Definitions</i> ).
<b># Setups (CNC Only)</b>	The number of setups that exist in the CNC machine per manufacturing cycle. A new setup is created each time the OpenMES Manager instructs the CNC machine to load a new program. A new program is required when a new type of part is required for processing in the CNC machine.
<b>% Failures (QC Only)</b>	The number of part failures that were detected in the QC device.

7.6.2.4. Summary of Manufacturing Cycle Performance Table

The CIM Performance Analysis enables you

to view a summary of the different manufacturing cycles that were saved in the system. This enables you to compare the results of the cycles, such as the process time, the efficiency, the number of failures and so on.

Run ID	Total Process Time	% Efficiency	Max Queue Length	Production Cost	# Setups (CNC Only)	% Failures (QC only)	Total Run Time	Note
34	00:05:36	4.22	17	0.00	0	0.00	01:06:24	Performance_5



Figure 76: Summary of Manufacturing Cycle Performance Table

The Summary of Manufacturing Cycle Performance Table contains all the information fields that were described in the previous section (total process time, efficiency, max queue length, production cost and more).

### 7.6.2.5. Creating Manufacturing Cycle Performance Reports

The following procedure explains how to create manufacturing cycle performance reports for backup and retrieval purposes.

①  
②  
③  
Procedure  
Creating  
Manufacturing Cycle  
Performance Reports

1. From the CIM Project Manager main window, select a project for which you want to define algorithms.
2. From the Project Manager Home ribbon, click the **OpenMES Manager** icon. The OpenMES Manager main window is displayed.
3. Select **Production Preparation | Optimization Definition**. The CIM Optimization Definition window is displayed.
4. Select the required algorithm for each machine from the **Algorithm Name** dropdown list, as described in Defining Algorithms.
5. After defining the algorithms for the manufacturing cycle, the next step is to create a manufacturing order, as follows:
  - Select **Production Preparation | MRP**. The CIM MRP window is displayed. In the Customer Order tab, select the parts, define their quantities and then select .
  - Click the Manufacturing Order tab, select the order to process and click  and then click **OK**.
  - Refer to the MRP section in this chapter for further details.
  - Close the CIM MRP window.
6. After creating the manufacturing order, the next step is to run the manufacturing cycle, as follows:
  - From the OpenMES Manager window, select **Home | Start**, and

click **OK** at the confirmation message.

- Click **Run** and observe the CIM manufacturing cycle.
- When the manufacturing order is complete, click **Stop**.

7. The next step is to view the performance data. Select **Production Analysis | Performance Analysis**. The CIM Performance Analysis is displayed showing the performance data from the last manufacturing cycle.


1  
 2  
 3  
 Procedure  
 Creating  
 Manufacturing Cycle  
 Performance Reports

1. Click **Save**. The Save Report window is displayed.

*Figure 77: Save Report Window*

2. Enter a description of the manufacturing cycle and click **OK**. A message is displayed informing you of the performance file name, such as **Performance\_5.DBF** for example.

3. Click **OK** to save the file to the database for later retrieval.

ⓘ You can click Show Summary  to display the Summary of Manufacturing Cycle Performance Table, as shown in Figure 76.

7.6.2.6. Viewing Manufacturing Cycle Performance Reports

The following procedure explains how to view predefined manufacturing cycle performance reports. You can view a single manufacturing cycle report or a summary of all the manufacturing cycle reports that exist in the system for comparison purposes.

- 1
- 2
- 3

Procedure

Viewing the Manufacturing Cycle Performance Table

1. From the CIM Project Manager main window, select a project for which you want to define algorithms.
2. From the Project Manager Home ribbon, click the OpenMES Manager icon. The OpenMES Manager main window is displayed.
3. Select **Production Analysis | Performance Analysis**. The CIM Performance Analysis window is displayed containing the results from the last manufacturing cycle run.

Machine	Total Process Time	% Efficiency	Max. Queue Length	Production Cost	# Setups (CNC Only)	% Failures (QC only)
JIGXY4	00:00:00	0.00	0	0.00	0	0.00
RDR1	00:00:00	0.00	0	0.00	0	0.00
EXPERTMILL1	00:00:55	2.50	1	0.00	1	0.00
JIG1	00:00:10	0.45	2	0.00	0	0.00
PLT3000_2	00:00:00	0.00	0	0.00	0	0.00
SDRY1	00:00:00	0.00	0	0.00	0	0.00
VSM1	00:00:55	2.50	1	0.00	0	0.00
System Summary	00:02:00	1.82	2	0.00	1	0.00

Figure 78: CIM Performance Analysis

4. Click **Show Single** . The Choose Performance File window is displayed.






Figure 79: Choose Performance File Window

5. Select the required performance file from the list and click **Open**. The Manufacturing Cycle Performance Table of the selected file is displayed in the CIM Performance Analysis window.

If required, you can print the required performance and optimization reports as follows:

- Click **Print Performance**  to print the currently displayed performance report.
- Click **Print Optimization**  to print the corresponding optimization report as displayed in the CIM Optimization Definition.

## 7.7. REPORTS

OpenMES provides a powerful, yet flexible report generator. This utility program allows you to view and print information from the various OpenMES databases. You can access ten types of predefined reports, or you can create your own user-defined reports. The predefined reports that can be generated are shown in the following figure:




Figure 80: OpenMES Report Generator Dialog Box

The following procedure details the steps involved in generating a report.

①  
②  
③  
Procedure  
Generating a Report

1. Select Production **Analysis | Report Generator**. The OpenMES Report Generator dialog box appears.
2. Select the requested report.
3. Click the Print button. The desired report will appear on the screen. If you want to print it on a printer, click the printer button on the report screen.



### 7.7.1. Part Definition Report

The Part Definition Report is generated from information that was entered in the Part Definition form. It shows the names and description of all parts used by the CIM cell. The following is an example of a Part Definition Report.

The screenshot shows a window titled 'Part Definition' with a toolbar at the top. The main content area displays the Intelitek logo and the title 'OpenCIM: Part Definition Report'. Below the title, it says 'Printed: 03/03/2009'. A table lists 19 parts with the following columns: #, Part Name, Type, Part ID, Template ID, and Part Description.


#	Part Name	Type	Part ID	Template ID	Part Description
1	BARCODE FAIL	Phantom		09	
2	VISION FAIL	Phantom		09	
3	COMBI LATHE MILL PRO	Product		02	
4	LATHE PROD1	Product		02	
5	MILL PROD1	Product		01	
6	BALL GAME BASE	Product		05	
7	BALL GAME PROD	Product		05	
8	LASER PROD1	Product		01	
9	LATHE PROD2	Product		02	
10	XV PROD	Product		04	
11	CHECK	Product		04	
12	ASSEMBLE XV PROD	Product		03	
13	MILL PROD2	Product		01	
14	MILL SUP	Supplied		01	
15	BASE WITH HOLE SUP	Supplied		03	
16	BALL GAME BASE SUP	Supplied		05	
17	BALL GAME COVER SUP	Supplied		06	
18	XV SUP	Supplied		04	
19	LATHE SUP	Supplied		02	

Each of the columns in the Part Report relates to a specific field in the Part Definition form, as follows:

Part Report	Part Definition Form (Field)
#	Part # as listed in sequential order.
Part Name	Part Name
Type	Part Type: supplied, product or phantom.
Part ID	Part ID
Template ID	Template Type
Part Description	Description

### 7.7.2. Subpart Report

The Subpart Report is generated from information that was entered in the Part Process Table in the Part Definition form. The Subpart Report is a Bill of Material. It shows all the subparts which comprise the finished product. The following is an example of a Subpart Report.




Each of the columns in the Subpart Report relates to a specific field in the Part Definition form.

Subpart Report	Part Process Table (Field)
Part Name	Part Name.
Sub-Part Name	The column <b>Subpart</b> in the Part Process Table.
Manufacturing Process Name	The column <b>Process</b> in the Part Process Table.
Manufacturing Parameters	The column <b>Parameters</b> in the Part Process Table for each corresponding process for a particular subpart.

### 7.7.3. Manufacturing Order Report

The Manufacturing Order Report displays all production orders for a particular date.

The report is generated from the information that was entered in the Manufacturing Order form. The following is an example of a Manufacturing Order Report.




Each of the column headings in the Order Report relates to a specific field in the Manufacturing Order form, as follows:

Manufacturing Order Report	Manufacturing Order Form
Part Name	The column "Part". There can be more than one part listed.
Total Number of Parts Ordered	The column "Total Qty". Each Total Qty listed corresponds to a specific part ordered.
Initial Number to Produce	The column "Initial Qty". Each Initial Qty listed corresponds to a specific part ordered.
Priority	The column "Priority". The Priority level (from 1 - 9) listed corresponds to a specific part ordered.
Final Storage Location (if not ASRS)	Refers to the final storage location listed in the column "Note" (for a specific part).

### 7.7.4. Machine Report

The Machine Report lists the names of all machines in the CIM cell. This report is generated from the information that was entered in the Machine Definition form. The following is an example of a Machine Report.




Each of the columns in the Machine Report relates to a specific field in the Machine Definition form, as follows:

Machine Report	Machine Definition Form (Field)
#	The sequential number of the machine as listed.
Machine Name	Machine Name
Cost Per Hour	Cost Per Hour, in the Machine Process table.
Maximum Number of Preloaded Programs	Max Preloaded Programs
Program 1	List of Preloaded Programs
Program 2	
Program 3	

### 7.7.5. Process Report

The Process Report shows the user-defined name (Process Name field) of each machine in the CIM and the processes performed by the machine. This report is generated from information that was created from the Machine Process Table in the Machine Definition form. The following is an example of a Process Report.



Each of the columns in the Process Report relates to a specific field in the Machine Definition form, as follows:

Process Report	Machine Process Table (Field)
#	The sequential number of the machine as listed.
Machine Name	Machine Name.
Process Name	The column "Process" in the Machine Process Table.
Process Type	The column "Action Type" in the Machine Process Table.
Program File Name	The column "File" in the Machine Process Table.

### 7.7.6. ASRS Report

The ASRS Report shows the contents of the ASRS. It is generated from information that was entered in the Storage Definition form. The following is an example of an ASRS Report.

Name	Index	Part Name	Part ID	Status	Template Number
ASRS14		LATHE PROD1	533	Part on Template	020005
ASRS14			0	Empty Template	060002
ASRS14		LASER PROD1	543	Part on Template	010005
ASRS14			0	Empty Template	060003
ASRS14		LATHE PROD1	587	Part on Template	020008
ASRS14			0	Empty Template	040002
ASRS14		BALL GAME PROD	524	Part on Template	050008
ASRS14		LATHE PROD1	563	Part on Template	020007
ASRS14		BALL GAME PROD	580	Part on Template	050009
ASRS14		LATHE PROD2	642	Part on Template	020003
ASRS14		COMBI LATHE MILL 1	549	Part on Template	020006
ASRS14		LASER PROD1	569	Part on Template	010007
ASRS14		LASER PROD1	594	Part on Template	010008
ASRS14		LATHE PROD2	669	Part on Template	020002
ASRS14			0	Empty Template	060004
ASRS14		BALL GAME BASE		Part on Template	050003
ASRS14		BALL GAME BASE		Part on Template	050004
ASRS14		BALL GAME BASE		Part on Template	050005
ASRS14		BALL GAME BASE		Part on Template	050006
ASRS14		BALL GAME BASE		Part on Template	050007
ASRS14		MILL PROD1	552	Part on Template	010006
ASRS14			0	Empty Template	030010
ASRS14		XV PROD	640	Part on Template	040005
ASRS14		BALL GAME BASE S		Part on Template	050011
ASRS14		BALL GAME BASE S		Part on Template	050012
ASRS14		XV PROD	540	Part on Template	040003
ASRS14		XV PROD	600	Part on Template	040004
ASRS14		BALL GAME PROD	631	Part on Template	050010
ASRS14		BALL GAME COVER S		Part on Template	060005
ASRS14		BALL GAME COVER S		Part on Template	060006
ASRS14		MILL PROD2	537	Part on Template	010004

Each of the column headings in the ASRS Report relates to a specific field in the Storage Definition form, as follows:

ASRS Report	Storage Definition Form (Field)
Name	Name of storage location
Index	The number displayed in parentheses below the ASRS grid; e.g., ASRS (15). This is an internal index used in communication between the OpenMES Manager and the ASRS robot controller (and not the Index of the graphically displayed ASRS cell.)
Part Name	The name of the part residing in the current storage cell as defined in the Part Definition form (refer to cell in grid).
Part ID	Part ID, as defined in the Part Definition form.
Status	Status of the storage cell (Empty, Empty Template or Part on Template).
Template Number	The six-digit template number.

### 7.7.7. Analysis Report

The Analysis Report is detailed information on the status of the entire system and is geared for the more experienced user. The report contains a Log file summary of each action. See below for an example of an Analysis Report.

The screenshot shows a window titled 'Analysis' with a toolbar and a report content area. The report content area features the Intelitek logo, the title 'OpenCIM: Run Time Analysis Report', and a print date of '03/03/2009'. Below this is a table with 8 columns: Part Name, Device, Action, Sub Part Name, Target, Index, Status, and Time. The table contains 30 rows of data representing various system actions like 'GET', 'Pick & Place', and 'ALLOC' for different parts and devices.

Part Name	Device	Action	Sub Part Name	Target	Index	Status	Time
BALL GAME BASE SUP	ASRS14	GET	BALL GAME BASE SUP	ASRS14	0	Activate	11:55:32
BALL GAME BASE SUP	ASRS14	GET	BALL GAME BASE SUP	ASRS14	0	In Process	11:55:32
BALL GAME BASE SUP	ASRS14	GET	BALL GAME BASE SUP	ASRS14	0	DONE	11:55:33
BALL GAME BASE SUP	72ASRS14	Pick & Place	TEMPLATE#050008	CNV1	1	Activate	11:55:33
XV SUP	ASRS14	GET	XV SUP	ASRS14	0	Activate	11:55:33
XV SUP	ASRS14	GET	XV SUP	ASRS14	0	In Process	11:55:33
XV SUP	ASRS14	GET	XV SUP	ASRS14	0	DONE	11:55:33
XV SUP	72ASRS14	Pick & Place	TEMPLATE#040002	CNV1	1	Activate	11:55:33
BASE WITH HOLE SUP	ASRS14	GET	BASE WITH HOLE SUP	ASRS14	0	Activate	11:56:27
BASE WITH HOLE SUP	ASRS14	GET	BASE WITH HOLE SUP	ASRS14	0	In Process	11:56:27
BASE WITH HOLE SUP	ASRS14	GET	BASE WITH HOLE SUP	ASRS14	0	DONE	11:56:27
LATHE SUP	ASRS14	GET	LATHE SUP	ASRS14	0	Activate	11:56:28
LATHE SUP	ASRS14	GET	LATHE SUP	ASRS14	0	In Process	11:56:28
LATHE SUP	ASRS14	GET	LATHE SUP	ASRS14	0	DONE	11:56:28
LATHE SUP	72ASRS14	Pick & Place	TEMPLATE#020005	CNV1	1	Activate	11:56:28
LATHE SUP	PNEUST1FD	GET	LATHE SUP	PNEUST1FDR	0	Activate	11:56:28
LATHE SUP	PNEUST1FD	GET	LATHE SUP	PNEUST1FDR	0	In Process	11:56:28
LATHE SUP	PNEUST1FD	GET	LATHE SUP	PNEUST1FDR	0	DONE	11:56:28
ALLOC BUFFER	CIM	ALLOC	TEMPLATE	PNEUSTBUFF	0	Activate	11:56:28
ALLOC BUFFER	CIM	ALLOC	TEMPLATE	PNEUSTBUFF	0	In Process	11:56:28
ALLOC BUFFER	CIM	ALLOC	TEMPLATE	PNEUSTBUFF	0	DONE	11:56:28
MILL SUP	PNEUST1FD	GET	MILL SUP	PNEUST1FDR	0	Activate	11:56:28
MILL SUP	PNEUST1FD	GET	MILL SUP	PNEUST1FDR	0	In Process	11:56:28
MILL SUP	PNEUST1FD	GET	MILL SUP	PNEUST1FDR	0	DONE	11:56:29
ALLOC BUFFER	CIM	ALLOC	TEMPLATE	PNEUSTBUFF	0	Activate	11:56:29
XV SUP	ASRS14	GET	XV SUP	ASRS14	0	Activate	11:56:29
XV SUP	ASRS14	GET	XV SUP	ASRS14	0	In Process	11:56:29
XV SUP	ASRS14	GET	XV SUP	ASRS14	0	DONE	11:56:29
XV SUP	72ASRS14	Pick & Place	TEMPLATE#040002	CNV1	1	Activate	11:56:29

The following is a description of each of the columns in the Analysis Report:

Heading	Description
Part Name	The name of the part as defined in the Part Definition form or in the Virtual OpenMES Setup.
Device	The name of the robot, machine or conveyor that performs the operation, as defined in the Machine Definition form.
Action	Robot: (pick-and-place) Assembly: (base and pack) Conveyor: (deliver) or machine (the name of process as defined in the

	Machine Process Table).
Subpart Name	Robot: the number of a template or the name of a part. Machine: the name of a part or material.
Target	Where the process should be performed.
Index	Indicates the exact location on a device which has more than one location for a part.
Status	The status of the action .
Time	The time the action started or the time the action was completed.

Each line in the Analysis Report will have one of the following status reports:

- **Activate:** OpenMES Manager has determined that a command can be sent to a machine (e.g., a robot or CNC machine).
- **In Process:** command has been sent to the machine; for example: GET part from device A (source) and PUT part in device B (target).
- **Start:** Operation has started. Source device may now receive its next command (i.e., another “Activate”). Used, for example, to notify OpenMES Manager that a pallet can be released from a conveyor station.
- **Finish:** Operation has been completed. Target device may now receive its next command (i.e., another “Activate”).
- **Done (End):** The machine is now ready to receive its next command.




Figure 81: Analysis Report Flow Chart - Example for ACL Device Driver



## 8. Virtual OpenMES Setup

The Virtual OpenMES Setup is an interactive graphic module that allows you to create a simulated CIM cell. The CIM cell may contain the actual elements and connections of a real CIM installation, or it may define a theoretical (meaning, virtual) CIM cell. This chapter includes the following sections:

- **Virtual OpenMES Setup Overview**, introduces the OpenMES Setup application.
- **Accessing OpenMES Setup**, describes how to access the Virtual OpenMES Setup application.
- **Main Window**, describes the components of the OpenMES Setup interface.
- **Working with OpenMES Setup**, provides guidelines for setting up and working in your CIM cell.
- **Tutorial**, describes step by step instructions for designing and operating a CIM cell.

### 8.1. VIRTUAL OPENMES SETUP OVERVIEW

The first part of this chapter presents the menus and screen elements of the Virtual OpenMES Setup module. You are then encouraged to perform the Tutorial, which will enable you to practice using this module and create a virtual CIM cell.

Click the OpenMES Setup button in the Project Manager's Home ribbon to open the Setup screen. A number of menus are available, but many menu items will not be available until a setup has been created or loaded.

#### 8.1.1. Virtual OpenMES Setup Limitations

The Virtual OpenMES Setup allows you to construct all sorts of CIM cells, although some configurations would be difficult or even impossible, to actually operate. To ensure your success in operating a Virtual CIM cell, create your cell in accordance with the following guidelines:

- Use only one conveyor in the cell.
- Use no more than eight stations around the conveyor.

### 8.2. ACCESSING OPENMES SETUP

The OpenMES Setup application is accessed from the Project Manager main window, enabling the user to create and modify the Virtual OpenMES Setup of the selected CIM Cell.

To access the OpenMES Setup application:

From the Project Manager Main window, shown in Chapter 5, Project Manager, click OpenMES Setup on the Home ribbon. The Virtual OpenMES Setup Main window is displayed, as shown in Figure 82.

### 8.3. MAIN WINDOW

The Virtual OpenMES Setup window is shown here:




Figure 82: Virtual OpenMES Setup Main Window

#### 8.3.1. Virtual OpenMES Home Ribbon

The elements of the Virtual OpenMES Setup Home ribbon are described in the sections below.




Figure 83: OpenMES Setup Home Ribbon

#### 8.3.2. File Section

The following table contains a brief description of the File section:

Option	Description
Save	Saves the current placement of all objects in the CIM cell.

### 8.3.3. Create Section

The following table contains a brief description of each option in the Create section of the ribbon:

Option	Description
<b>Icons Group</b>	<p>The system automatically creates shortcuts to loaders for drivers of all the workstations in the selected project. This group contains shortcuts to loaders that are required in order to operate the CIM cell defined by the Virtual OpenMES Setup.</p> <p>The group can be accessed from the following directory path:            C:\Users\Public\Documents\Intelitek\OpenCIM\Projects\<name of="" p="" project&gt;<="" project&gt;\opencim&lt;name=""> </name></p>
<b>Setup Configuration</b>	Prompts you to confirm the overwrite of the SETUP.CIM file. For full details, refer to <i>Chapter 12</i> Inside OpenMES.
<b>Loader Section</b>	Creates a file WSn.INI for each station (e.g. WS2.INI).

### 8.3.4. Edit Section

The following table contains a brief description of each option in the Edit section of the ribbon:

Option	Description
<b>New Object</b>	<p>Displays the New Objects dialog box, enabling you to add new elements to your new CIM cell.</p> <p>The New Objects dialog box contains all the elements which can be included in the Virtual OpenMES Setup, as follows:</p> <ul style="list-style-type: none"> <li>• Double click on the [+] button of a category in order to expand its list of elements and select an object.</li> <li>• Move the cursor into the graphic scene. The cursor changes to a cube. Point and click on the location where you want to place the object. You may need to wait a moment for it to appear; <i>do not double-click</i>.</li> </ul>
<b>Delete Object</b>	Activates the delete mode in order to delete an object from the cell. Using the cursor, point and click on the object you want to delete. Click Yes to confirm the deletion. If you click No, the delete mode remains in effect, enabling you to select and delete another object.
<b>Drag Object</b>	Enables you to pick an object and drag it through the cell.

Option	Description
<b>Setup IDs</b>	Displays the Edit IDs dialog box, containing a list of all the objects and ID numbers in the cell, enabling you to change the ID number of a device. Double-click on the highlighted line and enter a new number at the prompt.




Figure 84: Edit Setup IDs Menu

Once you have changed an ID, be sure to select **Create | Setup File** and **Create | ACL DMC File** in order for the change to take effect.

<b>Floor Size</b>	Opens the Set Floor Size dialog box that enables you to set the X and Y dimensions of the cell. Click <b>OK</b> to confirm the new size or <b>Cancel</b> to close the dialog box.
-------------------	---

<b>Set Textures</b>	Opens a sub-menu listing cell textures: floor, land and background enabling you to select the required *.bmp file for the specified texture.
---------------------	--

### 8.3.5. View Section

The following table contains a brief description of each option in the View section:

Option	Description
<b>Show Names</b>	Displays the names of all devices in the scene.
<b>Show IDs</b>	Displays the device ID numbers.
<b>Show Positions</b>	Displays the position coordinates of all devices.
<b>Redirect Camera</b>	Allows you to select a different focal point in the scene.
<b>Top View</b>	Displays the overhead view of the scene.

Option	Description
<b>Drag 3D Frame</b>	Allows you to drag the cell.
<b>Scene Origin</b>	Displays the scene origin, e.g. coordinate 0,0 of the room. When selected, a red cross is displayed in the center of the shop floor.

❗ *The options in this menu are similar to those in the View menu of the Graphic Display and Tracking module. For full details, refer to Chapter 6 Operating OpenMES Manager.*

### 8.3.6. Configuration Parameters Popup Menus

The Virtual CIM cell contains configuration parameters popup menus that are displayed when you double-click on an object in the Virtual CIM. The following figure shows some of the variations of the Configuration Parameters menu.




Figure 85: Parameter Configuration Popup Menus

Once defined and saved, these parameters are written to OpenMES INI files, as described in Chapter 12, Inside OpenMES.

The following table contains a list as well as the description of all parameters that can be defined. The parameters for many objects do not normally require manipulation. The Tutorial at the end of this chapter demonstrates the recommended sequence and actions for setting object parameters.

Option	Description
<b>Capacity</b>	Defines the number of items that the device can hold.

Option	Description
	<p>You must define a value for feeders, racks, and trash bin. For most other objects you can accept the system-defined value.</p> <p>When selecting new objects, select <b>Buffer 2</b> for a buffer whose capacity is two items, and select <b>Buffer 1</b> for a buffer that can contain only one item. The capacity parameter is thus already defined as 2 and 1, respectively.</p>




Figure 86: Defining Capacity

**CommPort**

For ACL device drivers, the settings must be as follows:

- BaudRate = 9600
- Parity = None
- DataBits = 8
- StopBits = 1
- XonXoff = No

These are the standard RS232 settings for communicating with ACL controllers (both Controller-A and Controller-B). These settings should not be changed since they match the fixed settings in the controller.

For the PLC device driver, the settings will be one of the following:

OMROM PLC	Allen-Bradley PLC	LG PLC
BaudRate = 9600	BaudRate = 9600	BaudRate = 9600
Parity = Even	Parity = None	Parity = None
DataBits = 7	DataBits = 8	DataBits = 8
StopBits = 2	StopBits = 1	StopBits = 1
XonXoff = No	XonXoff = No	XonXoff = No

These are the RS232 parameters used by the PLC device driver when it communicates with the PLC. You must set these parameters to match the RS232 settings on the PLC.

**Connectivity**

Connects all objects and their associated device drivers.

Also connects robots to all objects which are physically within their reach and to all objects which can be connected by means of an RS232 cable.

Option	Description
--------	-------------

When you click on Connectivity, the Connections menu opens.




Figure 87: Defining Connections

One or more connections can be added or deleted at a time.

- To make a connection, highlight the device driver name(s) for the selected object, click **Add**, and then **OK**.
- To remove a connection, highlight the device driver name(s) for the selected object, click **Remove**, and then **OK**.

**Active Connections:** A list of all connections that have already been established between this and other objects.

**Possible Connections:** A list of all objects to which this object can be connected. For robots, this list will also display all devices that are in physical reach of the robot (i.e., that are in the Work Volume of the robot), and all objects that can be connected by means of an RS232 cable.

Possible Connections for Robots will also display all the device drivers for this robot within the CIM cell, since robot controllers can communicate with any PC in the CIM cell. Normally, you should select only one robot device driver per robot. Do not select device drivers that are not intended for this robot.

If you want to connect an object (not a device driver) to the robot, and the object is not within reach of a robot, reposition it on the screen until you see the object's name appear in the list of possible connections.

Conversely, if you move an object too far away from a robot, the connection will be severed. A warning will prompt you to reposition the objects and reestablish the connections, if desired.


Option	Description
	

Figure 88: Robot Connections

- ❗ *Tip: To see which device driver belongs to an object, click on the object. From the object's Parameter Configuration menu, select **Connectivity | OK**. A line connecting the object and its associated device driver appears on the screen. (Alternatively, click on a device driver to find its associated device.)*

**Green** lines show the connections between device drivers and their associated objects. **Red** lines show the physical connections between robots and other objects; i.e., devices that are within the robot's reach.

**Green** lines indicate which software is running on a PC. Click a PC. To see the green lines, select Show Connection from the Parameter Configuration menu.



Option	Description
--------	-------------



Figure 89: Workstation Connections

**External ID** Unique numerical Device ID that identifies each device in the system. The software defines IDs automatically in sequence as the devices are created in the Virtual CIM cell. You can, however, modify this ID in order to structure the numbering of the devices, for example, in relation to the station they are located in (see example in the tutorial).


**Location** Identifies the location of a feeder when it is placed and used within an ASRS unit. (In an actual CIM cell, a feeder can only be placed on an ASRS carousel, not in the **ASRS<sup>2</sup>**, ASRS-36u, or ASRS-36x2.)

**Properties** Defines the Workstation (WS $n$ ) at which the object’s device driver is connected and running.

Also defines the INI file associated with the object’s device driver. This INI file contains the definitions and parameters for the object, and is invoked by the device driver’s Loader command line.



Figure 90: Defining Workstation for Device Driver

Option	Description
	Once Properties have been defined for a device driver, other options in the Parameter Configuration menu become available.
<b>QC Report</b>	<p>The Quality Control device driver allows you to write the results of a QC test to an ASCII text file that can be input to a spreadsheet program.</p> <p>Delete on Start. This switch controls whether a new quality control report file will be created each time this device driver is activated. If checked (Yes), the previous file is deleted; if not checked (No), results are appended to the existing report file.</p>
	
	<i>Figure 91: Defining Quality Control Report</i>
<b>Rotate</b>	Rotates a displayed object to any degree. Useful, for example, to properly attach buffers to the conveyor, or to logically orient a PC in the Virtual CIM display.
<b>Sub Type</b>	System-defined parameter. Normally, you do not need to manipulate this parameter.
<b>Variables</b>	The default values for the variables used by the CNC script.
<b>Write Load</b>	Creates the <i>WSn.INI</i> file for the particular workstation.

## 8.4. WORKING WITH OPENMES SETUP

This section describes how to set up your CIM Cell and provides guidelines for creating conveyors (user defined, rectangular and L-shaped), as well as adding stations, tables, robots and other components. It includes the following:

- Creating a User Defined Conveyor
- Creating a Rectangular
- Creating an L-Shaped Conveyor
- Adding Tables
- Adding Robots
- Manipulating the Graphic Display
- Changing the Focus of the Graphic Display

### 8.4.1. Creating a User Defined Conveyor

Since the Virtual CIM conveyor is the most difficult of the elements to place in the scene, this section contains detailed, procedural instructions for creating a conveyor.

If you are replicating an actual CIM cell, you will need to know the exact dimensions of the conveyor.

To add a user defined conveyor:

1. Select **New Object**. The New Objects dialog box is displayed.




Figure 92: New Objects Dialog Box

4. From the General tree select **Conveyor**. The Conveyor dialog box is displayed.





Figure 93: Conveyor Dialog Box

5. From the Type area, select **User Defined**.
6. Select **Zoom In** to place a typical 3m X 4m OpenMES conveyor (with straight segments of 1.40m). Each grid represents about 20 cm. When **Zoom In** is not selected, the grid resolution is increased, which enables you to place a larger conveyor (8 m x 10 m) into the CIM cell.
7. Select Table Top to place the conveyor on a table.
8. Click **OK**. A grid will appear on the screen. The set of numbers displayed on the left are the screen pixel coordinates of the cursor, while the numbers on the right are metric coordinates (in meters).

- ① *When creating a conveyor, use the mouse buttons as follows:*
  - ① *Click with the right mouse button and drag to select menu options.*
  - ① *Point and left-click to place objects on the grid.*

To select the starting point of the conveyor, do the following:

1. Place the cursor on the grid and right-click to open this icon menu:



The **key** icon is used to mark the starting point of the conveyor.

The **spectacles** icon opens another icon menu. *Do not attempt to manipulate the displayed values. These settings are for technical support personnel only.*


The **grid** icon toggles the grid display on and off.

2. Drag and select the key icon. A wand-pointer appears on the screen. Use this cursor to click on a starting point for the conveyor. *It should be placed on the right side of the grid, as shown in Figure 9-12: Adding Conveyor Segments. A red dot appears on the grid.*

Since the conveyor movement is normally counterclockwise, the conveyor segments are added in the counterclockwise direction.

To create the conveyor, do the following:

1. Click the right mouse button. An icon menu will open.



**Segment icons:** The first six icons represent **segments** of the conveyor. Segments are added and connected in consecutive order.

To insert a straight segment, select either the horizontal or vertical bar. Using the left mouse button, place the pointer on the square whose upper left hand corner marks the end of the segment you want to add. Carefully position the cursor in order to align the segments of the conveyor



**Reverse:** The white curved arrow in the blue circle is used to **reverse** the direction of conveyor movement. When this icon is selected, conveyor movement is clockwise, and the segments will be added accordingly.



**Undo.** The undo icon cancels the last segment(s) added to the conveyor. Undo is available after the first segment has been placed on the grid.



**OK.** This button will appear when you have completely connected all segments of the conveyor.



**Spectacles:** The **spectacles** icon opens another popup menu. *Do not attempt to manipulate the displayed values. These settings are for technical support personnel only.*

2. Using the icon menu, select and connect each segment of the conveyor.




Figure 94: Adding Conveyor Segments

- ① *Tip: Avoid using too many UNDOs while drawing the conveyor; a faulty display may result.*
- ① *When drawing the conveyor, do not extend the straight segments too close to the edge. Allow enough room for the corner segments.*

3. When you have completed drawing the conveyor, click on the **OK** button. A chain of dots will appear in the conveyor.

### 8.4.2. Creating a Rectangular Conveyor

As an alternative to creating your own user defined conveyor (described in Creating a User Defined Conveyor), the Virtual OpenMES Setup also enables you to select a predefined rectangular conveyor. This includes defining the conveyor dimensions and zoom options.

To add a rectangular conveyor:

1. In the Home ribbon, select **New Object**. The **New Objects** dialog box is displayed as shown Figure 92: New Objects Dialog Box.
2. From the General tree, select **Conveyor** and then click **OK**. The Conveyor dialog box is displayed, as shown in Figure 93: Conveyor Dialog Box.
3. Select Rectangular and define the conveyor dimensions in the Size area.
4. Select the required option, as follows:
  1. Select **Zoom In** to place a typical 3m X 4m OpenMES conveyor (with straight segments of 1.40m). Each grid represents about 20 cm. When Zoom In is not selected, the grid resolution is increased, which enables you to place a larger conveyor (8 m x 10 m) into the CIM cell
  2. Select **Table Top** to place the conveyor on a table.
5. Click **OK**. A Rectangular conveyor is displayed, as shown in the following example:




Figure 95: Rectangular Conveyor

### 8.4.3. Creating an L-Shaped Conveyor

As an alternative to creating your own user defined conveyor,(described in Creating a User Defined Conveyor), the Virtual OpenMES Setup also enables you to select a predefined L-Shaped conveyor. This includes, defining the conveyor dimensions and zoom options and so on.

To add an L-Shaped conveyor:

1. Select **Edit | New Object**. The New Objects dialog box is displayed as shown in Figure 92: New Objects Dialog Box.
2. From the **General** tree, select **Conveyor** and then click **OK**. The Conveyor dialog box is displayed, as shown in Figure 93: Conveyor Dialog Box
3. Select **L-Shaped** and define the conveyor dimensions in the Size area.
4. Select the required option, as follows:
5. Select **Zoom In** to place a typical 3m X 4m OpenMES conveyor (with straight segments of 1.40m). Each grid represents about 20 cm. When **Zoom In** is not selected, the grid resolution is increased, which enables you to place a larger conveyor (8 m x 10 m) into the CIM cell.

Select **Table Top** to place the conveyor on a table.

6. Click **OK**. An L-Shaped conveyor is displayed, as shown in the following example:





Figure 96: L-Shaped Conveyor Segments

### 8.4.4. Adding Stations

After defining the conveyor, you must place the required stations around the conveyor. This includes defining the station location and number and so on.

To add stations around the conveyor:

1. Click on the right mouse button. A popup menu is displayed.
2. Select the **Station**  icon. Then point and click on one of the dots in the conveyor. The Conveyor Stations dialog box is displayed.




Figure 97: Conveyor Stations Dialog Box

3. Enter the station number in the field provided and click OK.
- i** *Tip: The first station should immediately follow the starting point of the conveyor, in accordance with the counterclockwise or clockwise movement of the conveyor. Additional stations should be placed consecutively in the same direction until you reach the starting point again. It is recommended that you plan your conveyor in advance to determine the correct location for each station.*





Figure 98: Adding Conveyor Stations

- i** *Tip: Place stations on straight segments of the conveyor. They cannot be placed on the curves.*
4. Repeat steps 2 through 3 for each conveyor station.



5. Select the **File**  icon to save the conveyor definitions.

Once you have saved the conveyor setup, the conveyor will be drawn on the CIM scene window.

- ① *Do not save the conveyor until you have placed ALL stations around the conveyor. Once a conveyor has been saved, it cannot be altered. To change a conveyor configuration, you will need to repeat the entire procedure.*

### 8.4.5. Adding Tables

Tables should be placed at every station around the conveyor, either after the conveyor is created, or after all elements have been placed in the scene.

When you place objects in the Virtual CIM, you do not need to define a height coordinate, since the system assumes all objects are at their proper heights. All objects will be displayed at the correct height, even if they are not sitting on tables.

You can select size and color of any table you want to create, but only before you create it. Once the table is made it cannot be altered. To make any changes in tables properties you will need to repeat the entire procedure.

**i** *It is recommended that you place tables in the Virtual CIM so that objects at the stations will not appear to float in space.*

To place a table on the Virtual CIM, do the following:

1. From the Home ribbon, select **New Object**. The New Objects dialog box is displayed, as shown in Figure 92: New Objects Dialog Box.
2. From the **General** tree select **Table** and then click **OK**. The Table dialog box is displayed.




Figure 99: Table Dialog Box

3. Click the Colors button to change the table color.
4. In the Size area, define the dimensions of the table and click OK.
5. Point and click on a spot near the first conveyor station to place the first table.
6. Repeat steps 2 through 5 to place tables at all the stations around the conveyor.
7. Click and drag on the cursor to adjust the location of each table in the scene.  
The coordinates that appear on the table (and any other object that you manipulate) mark the

center point of the table or object relative to the cross at the center of the shop floor, which is displayed by selecting Scene Origin from the view menu.




Figure 100: Adding Tables

#### 8.4.6. Adding Robots

As indicated at the beginning of this chapter, after the conveyor is created, you should add the ASRS, robots, machines, and other devices.

By default, the system automatically assigns numbers to the robots (and all other objects) in the order of creation. You should therefore place your first robot (Storage robot ) at Station 1, the second robot at Station 2, and so on.

To add robots:

1. From the Home ribbon, select **New Object** The New Objects dialog box is displayed.
2. From the **Robots** tree **click the Robot to add (ER 4u, for example)** and then click **OK**. The Optional LSB box is displayed.




Figure 101: Optional LSB Dialog Box

3. If the robot is to be placed on a slidebase, enter the slidebase size in meters and click **OK**. Otherwise, click **Cancel**.
4. If the slidebase requires a stand, check LSB Stand in the dialog box and click OK.

5. Point and click on a spot at the first station to place the first robot. Repeat this step for each station around the conveyor.
6. Double-click on a robot to open its Configuration Parameters popup menu.  
The Robot Configuration Parameters menu differs from the Table Configuration Parameters menu. Each object in the Virtual CIM has a particular Configuration Parameters menu, as described in the Configuration Parameters Popup Menus section

### 8.4.7. Manipulating the Graphic Display

The Virtual OpenMES Setup module uses the same method as the Graphic Display module for manipulating the view of the CIM cell.

- 1
- 2
- 3

Procedure

Manipulating the Graphic Display

1. To change the angle of the overhead scene, place the cursor on the vertical scroll bar and drag it up and down.
2. To rotate the scene, place the cursor anywhere on the screen and:
  - Click the right mouse button and drag to the right to rotate the display counterclockwise.
  - Click the right mouse button and drag to the left to rotate the display clockwise.
3. To zoom the scene, place the cursor anywhere on the screen and:
  - Click the right mouse button and drag up to zoom in.
  - Click the right mouse button and drag down to zoom out.

### 8.4.8. Changing the Focus of the Graphic Display

- 1
- 2
- 3

Procedure

Changing the Focus of the Graphic Display

1. From the Home ribbon's view section, select **Redirect Camera**.
2. Click any object in the scene. It now becomes the center point for the display manipulation. The view changes to an overhead scene (if it is not already), which you can now manipulate.

## 8.5. TUTORIAL

In this tutorial you will learn to create and run an OpenMES cell which contains three stations. It includes the following:

- **Stage 1: Designing the CIM Cell:** Describes how to create a graphic CIM cell using the Virtual CIM module.

- **Stage 2: Operating the CIM Cell:** Describes how to define and operate the CIM cell using the CIM Definition and CIM Operation modules. You will also use the Graphic Display module to view your CIM cell in operation.

### 8.5.1. Stage 1: Designing the CIM Cell

The following procedure is the recommended sequence for setting up the Virtual CIM Cell.

**1**  
**2**  
**3**  
Procedure  
**Setting up the Virtual  
CIM Cell**

1. Plan and document your CIM system before starting.
2. Define the conveyor and the location of the workstations.
3. Place tables at the stations.
4. Place an ASRS device at a workstation (station 1 is recommended).
5. Place robots at the stations.
6. Place CNC and any other machines at the stations.
7. Place buffers at the workstations.
8. Place PCs at the workstations.
9. Define the device drivers for the workstations.
10. Define all connections and properties for each device driver.
11. Create the Setup, Map, and Icon Group for this CIM cell.

This section will guide you through a complete procedure for creating an OpenMES cell using the Virtual OpenMES Setup module.

To design the CIM Cell:

1. From the Project Manager main window, click **New**  on the toolbar. The New Project dialog box is displayed.






Figure 102: New Project Dialog Box

12. In the Project name field, enter **CIM-1** and click **OK**. The new project is displayed in the User Project tab in the Project Manager main window (for further details refer to Chapter 5, Project Manager).
13. Select the **CIM-1** project and click the **OpenMES Setup** icon on the Home ribbon.




The Virtual OpenMES Setup main window is displayed.

14. Select **New Object**.



15. In the New Objects window, double-click **General** to expand the tree, select **Conveyor**, and then click **OK**.



The Conveyor dialog box is displayed.









Figure 103: Conveyor Dialog Box

16. From the Type area, select User Defined and click OK. The Conveyor grid appears. Click the right mouse button. Drag the mouse and then select the key icon .
17. A wand appears. Bring the wand into the lower right side of the grid and click the left button. A red dot appears; this is the conveyor starting point.
18. Click the right mouse button. Drag and select the vertical segment. Point and click the cursor on a spot above the starting point.
19. Select an arc-up-and-left segment. (The conveyor is created in the direction of movement; normally counter-clockwise.)



20. Continue selecting and adding segments to the conveyor until it is complete. Use the  curved arrow to undo any mistakes. (Avoid using too many undos.)
21. When the conveyor is complete, click the right mouse button and then click the  icon.
22. Click the right mouse button and select the  **Station** icon from the popup menu, to create a station. Point to a location just above the starting point of the conveyor (not on the curve). Click the left mouse button. Accept the prompt for Station number **1**.
23. Add the stations in accordance with the counterclockwise or clockwise movement of the conveyor.
24. Repeat the previous step for two more stations. Add the stations in consecutive order around the conveyor.
25. When all three stations are marked around the conveyor, click the right mouse button and select the **File**  icon from the pop-up menu to save the conveyor and click **OK** to save the conveyor setup.
26. The grid closes, and a cube cursor appears on the screen. Bring the cursor to the center of the screen and click. (To display a red cross marking the center of the shop floor, select **Scene Origin** from the view menu). The conveyor appears in the Scene Window. Click on the conveyor and drag with the left mouse button to center the conveyor on the floor.
27. Select **Save** to save your work.
28. Select **New Object | Storage | ASRS36**.
29. Click the left mouse button near Station 1. The ASRS36 appears on the screen. (*This object is the robot that has a storage rack with 36 shelves.*)
30. Click on the **ASRS36**. The object's parameter configuration submenu opens. Select **Rotate**. Enter **-90**. The lower small frame should be outside the conveyor. Adjust the orientation and position of the ASRS36.
31. Add Tables for the workstations.
32. Add objects to Stations 2 and 3, as follows:
  - At Station 2, select **Robots | ER 9**, and enter 1.0 (meters) at the prompt for LSB (robot will be mounted on a linear slidebase).
  - At Station 3, select **Robots | ER 14**, and then click **Cancel** at the prompt for LSB.

During the selection and placement of new objects, wait for the cursor to settle in place. Avoid double-clicking.

Your screen should now look like this:




Figure 104: Conveyor Stations and Objects

**33.** Using the same procedure you used for placing robots at stations, add the following objects to the CIM cell:

- At Station 2: EXPERTMILL VMC-600.
- At Station 3: Jig-XY, Screwdriver, and Vision Camera.

As you work, rotate and reposition the objects on the shop floor.

Use Redirect View and Zoom to help you with the placement of objects.

Save your work regularly when creating the CIM cell.

**34.** Add station buffers (Buffer 2) around the conveyor, in the following order:

- Station 1
- Station 2
- Station 3

**35.** From the ribbon, select **Delete Object** and click on the buffer you placed at Station 1. The buffer will be erased. (The ASRS36 does not require a buffer, but a temporary buffer was created at Station 1 causing the buffers at the other stations to be named BFFR2 and BFFR3, respectively.)

**36.** Rotate the buffer at Station 3 90°. Adjust the location of other buffers, so that they are “attached” to the conveyor and within reach of the robot at the station.

37. At station 3, add a Rack, Feeder, and Trash (all from the Storage folder). The following figure will guide you in properly placing all the objects at this station.




Figure 105: Placing Station Objects

38. Save your work at this point.
39. Add workstations (PCs) for each station. Start with the Manager PC and then continue with the Station PC's for Station 1, 2 and 3.

40. Scale Tables for the workstations and arrange them as shown below:




Figure 106: Placing Station Tables

41. Add device drivers near the PC at each station:


- For each robot at the station (including the ASRS36): add Scorbace device driver.
- For a CNC machine (lathe/mill): add a CNC device driver.
- For the Vision Camera: add a ViewFlex device driver.
- For the Conveyor: add a PLC device driver. Place it at Station 1.

The Jig-XY and Screwdriver are controlled by the Scorbace controller (and its device driver), and do not require device drivers of their own.

42. For each device driver, you will need to set its properties and connections. Click on each object in order to open the corresponding parameter configuration menu, and do the following:

- Click on Properties. Select the number of the workstation at which the device driver is running (e.g., WS1 for ASRS36 and PLC).
- Click on the device driver and enter the commport settings
- Click on Connectivity:
  - Connect the PLC device driver (PLCVD1) to the conveyor (CNV1).
  - Connect each Scorbace device driver (A SCBSVDn) to its corresponding robot (ROBOTn).
  - Connect each CNC device driver (CNCVDn) to its corresponding CNC machine (EXPERTMILLn or PLT3000).

- 43.** For each robot, select Connectivity and make the connections to all objects which are physically within its reach. Connect each robot to the conveyor station (CNV1#*n*), the station buffer (BFFR*n*) and all machines and devices at its station. Make sure the appropriate device driver is connected to the robot. If you are unable to make a connection, move the robot and device closer to each other, and try again.
- 44.** Connect the Screwdriver and the Vision Camera to the Jig-XY only.
- 45.** For the Feeder:
- SubType : Set to 101.
  - Capacity: Set to 10.
  - For the Rack:
    - SubType: Set to 201.
    - Capacity: Set to 9.
  - From the Create menu, perform the following:
    - Select Loader Section.
    - Select Setup File and then click OK at the prompt to overwrite the SETUP.CIM file.
    - Select Group. This will create a directory which contains all the shortcuts needed to prepare and operate the CIM-1 project. You can display this folder by browsing to [projects directory]\CIM1\OpenCIM CIM1 in Windows explorer.



- 46.** Save and exit the Virtual OpenMES Setup module.

### 8.5.2. Stage 2: Operating the CIM Cell

This part of the tutorial will give you practical experience in using the CIM operation modules. The following steps all relate to the CIM-1 program group which you have created in the Virtual OpenMES Setup. To operate the CIM Cell:

1. From the Project Manager main window, ensure that the User Projects tab is active and then select the **CIM-1** project.
2. From the Project Manager Home ribbon, select **OpenMES Manager**. The OpenMES Manager main window is displayed for the CIM-1 project.
3. Select **Production Preparation | Machine Definition**. The CIM Machine Definition window is displayed.
4. In the CIM Machine Definition window perform the following:

- From the Machine Name list, select EXPERTMILL1, and enter the following information:

Process Name: PROG\_BOX1

File Name: 1.GC

Program: leave blank

Duration: 00:00:25

5. Click **Save**.
6. Close the CIM Machine Definition window.
7. Select **Production Preparation | Part Definition**. The CIM Part Definition window is displayed.
8. In the CIM Part Definition window perform the following:

- Select the Supplied Parts tab.
- Select File | New Part to define a new part, and enter the following information:

Part Name: CUBE

Part ID: 77

Template Type: 01

9. Click **Save** and check the Errors box. The message **Save done** indicates there are no errors.

10. Select the **Product Parts** tab.

11. Select **File | New Part** to define a new product part, and enter the following information:


Part Name: BOX.

Part ID: 75

Sub part: CUBE



Process: PROG\_BOX1

Template Type: 01

12. Click **Save** and check the Errors box. The message **Save done** indicates there are no errors.
13. Close the CIM Part Definition window.
14. Select **Production Preparation | Storage Manager**. The CIM Storage Manager window is displayed.
15. In the CIM Storage Manager window. Click the **Edit** button of the **ASRS** storage type. The CIM Storage Definition window is displayed.
  1. Double click any cell in the grid. The Cell Edit dialog box is displayed.
  2. Select CUBE from the Part drop-down list and click Save to close the Cell Edit dialog box.
  3. Repeat these steps three more times for other cells.
  4. Close the Storage Definition window to automatically update the storage database.
16. Click the **Create Default Storage**  icon to save this storage definition as the default and close the CIM Storage Manager window to return to the OpenMES Manager main window.
17. Select **Production Preparation | MRP**. The CIM MRP window is displayed.
18. From the CIM MRP window perform the following:
  1. Select Customer | New Customer. The New Customer window is displayed.
  2. In the Name field, enter CUST-A, and if required enter additional information in the relevant fields.
  3. Create two orders for this customer, each one for two parts, but for different supply dates. (To see a list of parts which can be ordered, open the drop-down list when the cursor is on the Part Name field. Click to select a part.) For example:

Part Name:	BOX
Required:	2
Priority:	1
4. Due Date:	2

Part Name:	BOX
Required:	2
Priority:	1
Due Date:	4

19. Save the order by clicking the **MRP**  icon on the toolbar. This runs the MRP program, which creates a Manufacturing Order.
20. Select the **Manufacturing Order** tab and select a Manufacturing Order (from the list of numbers), and click **MO**  to submit the manufacturing order. This creates an A-Plan (production work order) for the order.
21. Close the CIM MRP window.
22. Select **Production Analysis | Report Generator**. The CIM Report Generator window is displayed.

**23.** From the CIM Report Generator window perform the following:

1. From the reports list select the Part Definition report and click the Print Report icon to display the report on the screen. You may also select Subparts, Process, Analysis and A-Plan to view other reports.
2. Close the Reports Generator window.

**24.** From the OpenMES Manager Home ribbon, select the **OpenMES Modes**. From the displayed Modes dialog box, perform the following:


1. In the CIM Mode area, select **Simulation mode** and enter the simulation speed. For example **x5**.
2. In the Remote Graphic Display area, select **No**. This option refers to the external graphic display only; the internal graphic display of the OpenMES Manager is always active.
3. Click **Save** to close the Modes dialog box and return to the OpenMES Manager main window.
4. From the Home ribbon, click **Start** button to execute (meaning, load) the Manufacturing Order.
5. Click **Run** to activate (meaning, run) the production cycle.
6. Congratulations. Your CIM cell is in operation! Look at the Order View, Device View, Program View and Pallets View and follow the progress of the production.
7. Acknowledge the messages “Part has been Finished.” and “Order Finished.”
8. Close the production by clicking **Stop** .

**25.** You will now repeat the production cycle and view it through the Graphic Display module.

**26.** From the OpenMES Manager Home ribbon click **OpenMES Modes**. The Modes dialog box is displayed.

**27.** In the Remote Graphic Display area, select **Yes** and then click **Save**. Make sure that you activate the external Graphic Display (see the last step of this procedure) otherwise the CIM will run slowly.

**28.** From the Home ribbon, click **Reset Storage** .

**29.** Click the **Graphic Display**  icon from **CIM-1** Group (displayed from your windows **Start** menu). The CIM Simulation screen will appear. You will see the CIM cell you created by means of the Virtual OpenMES Setup in three different 3D views.



30. Return to the OpenMES Manager screen and perform the following:

1. Click **Start** button to execute the Manufacturing Order.
2. Click **Run** to activate the production cycle. You also can see your CIM cell in operation by means of the Graphic Display.

### 8.5.3. Location Status Report

The Location Status Report is a detailed listing of every location defined in the CIM system. This report is used by the system administrator or the more experienced user for debugging the system.

There is more than one type of location.

- Locations are defined in the Virtual OpenMES Setup. Every ASRS compartment, every station on the conveyor, locations on a buffer and locations inside a machine.
- Every template, a part of an assembly (e.g. one part is on top of another part), a gripper on a robot, every part in the system.

The Location Status Report enables you to know exactly what and where something is in the system at a given time. The following is an example of a Location Status Report.

Location	ID	Index	Part Name	Status	#1	#2	Template Number	Type
72ASRS14			EMPTY	Empty	0	0	EMPTY	R
ASRS14			LATHE PROD1	Part on Template	533	532	TEMPLATE#020005	A
ASRS14				Empty Template	0	545	TEMPLATE#060002	A
ASRS14			LASER PROD1	Part on Template	543	542	TEMPLATE#010005	A
ASRS14				Empty Template	0	583	TEMPLATE#060003	A
ASRS14			LATHE PROD1	Part on Template	587	586	TEMPLATE#020008	A
ASRS14				Empty Template	0	526	TEMPLATE#040002	A
ASRS14			BALL GAME PRO	Part on Template	524	523	TEMPLATE#050008	A
ASRS14			LATHE PROD1	Part on Template	563	562	TEMPLATE#020007	A
ASRS14			BALL GAME PRO	Part on Template	580	579	TEMPLATE#050009	A
ASRS14			LATHE PROD2	Part on Template	642	645	TEMPLATE#020003	A
ASRS14			COMBI LATHE M	Part on Template	549	548	TEMPLATE#020006	A
ASRS14			LASER PROD1	Part on Template	569	568	TEMPLATE#010007	A
ASRS14			LASER PROD1	Part on Template	594	593	TEMPLATE#010008	A
ASRS14			LATHE PROD2	Part on Template	669	672	TEMPLATE#020002	A
ASRS14				Empty Template	0	634	TEMPLATE#060004	A
ASRS14			BALL GAME BAS	Part on Template			TEMPLATE#050003	A
ASRS14			BALL GAME BAS	Part on Template			TEMPLATE#050004	A
ASRS14			BALL GAME BAS	Part on Template			TEMPLATE#050005	A
ASRS14			BALL GAME BAS	Part on Template			TEMPLATE#050006	A
ASRS14			BALL GAME BAS	Part on Template			TEMPLATE#050007	A
ASRS14			MILL PROD1	Part on Template	552	551	TEMPLATE#010006	A
ASRS14				Empty Template	0	529	TEMPLATE#030010	A
ASRS14			XV PROD	Part on Template	640	639	TEMPLATE#040005	A
ASRS14			BALL GAME BAS	Part on Template			TEMPLATE#050011	A
ASRS14			BALL GAME BAS	Part on Template			TEMPLATE#050012	A
ASRS14			XV PROD	Part on Template	540	539	TEMPLATE#040003	A
ASRS14			XV PROD	Part on Template	600	599	TEMPLATE#040004	A

The following is a description of each of the columns in the Location Status Report :

<b>Heading</b>	<b>Description</b>
Location	The name of the location.
ID	The location ID (numeric) as defined in the Virtual OpenMES Setup.
Index	Indicates the exact location on a device which has more than one location for a part..
Part Name	The name of the part in this location as defined in the Part Definition form.
Status	Status of the specified location (Empty, Part on Template, Empty Template or Part).
Template Number	The number of the template at this location.
Type	The type of device as defined in the Virtual OpenMES Setup.

### 8.5.4. A-Plan Report

The A-Plan Report is a detailed description of the manufacturing process to be performed by the CIM system. The A-Plan is created when you click MO in a completed Manufacturing Order form. The A-Plan is a table of sequential instructions which the OpenMES Manager executes in order to produce the products being ordered.

This report is intended for the more experienced user. See Experimenting with Production Strategies Using the A-Plan in Chapter 11, OpenMES Programming, for detailed information on how the part will be produced.

The following is an example of an A-Plan Report.

The screenshot shows a software window titled 'Aplan' with a toolbar and status bar. The main content area displays the Intelitek logo and the title 'OpenCIM: Aplan Report' with a print date of 03/03/2009. Below this is a table with 8 columns: Part, #, Process, Subpart, Target, Index, Duration, and Parameters. The table lists various manufacturing steps such as ASSEMBLE XV PROD, CHECK A.1, BALL GAME PROD/2.1, and COMBI LATHE MILL P, each with associated process names, subparts, targets, and durations.

Part	#	Process	Subpart	Target	Index	Duration	Parameters
ASSEMBLE XV PROD		MAKE	ASSEMBLE XV PROD/1	1			3,1,1,P,1,00:00:00
ASSEMBLE XV PROD		GET	BASE WITH HOLE SUP	ASRS14			
ASSEMBLE XV PROD		ASSEMBLE XV	CHECK/A.1	JIGXY9		00:00:10	1
ASSEMBLE XV PROD		PRESS		HYDRAPRESS1		00:00:10	
ASSEMBLE XV PROD		NEXT					
ASSEMBLE XV PROD		TARGET		ASRS14			
CHECK/A.1		GET	XV SUP	ASRS14			
CHECK/A.1		CHECK XV				00:00:10	
CHECK/A.1		ONFAIL	VISION FAIL/1.1	TRASH1			
CHECK/A.1		PLACE		RACK1			
CHECK/A.1		FREE	TEMPLATE	ASRS14			
VISION FAIL/1.1		TARGET		TRASH1			
VISION FAIL/1.1		FREE	TEMPLATE	ASRS14			
BALL GAME PROD/2		MAKE	BALL GAME PROD/2.1	2			3,1,1,P,1,00:00:00
BALL GAME PROD/2.1		GET	BALL GAME BASE SUP	ASRS14			
BALL GAME PROD/2.1		FEED BALLS		BALLFDR1		00:00:10	FEED5
BALL GAME PROD/2.1		PLACE		JIG2			
BALL GAME PROD/2.1		GLUE		GLUE1		00:00:10	GLUE
BALL GAME PROD/2.1		PLACE		RACK3			
BALL GAME PROD/2.1		ASSEMBLE2	BALL GAME COVER \$U	JIG2		00:00:10	1
BALL GAME PROD/2.1		NEXT					
BALL GAME PROD/2.1		TARGET		ASRS14			
BALL GAME COVER S		GET	BALL GAME COVER \$U	ASRS14			
BALL GAME COVER S		PLACE		RACK3			
BALL GAME COVER S		FREE	TEMPLATE	ASRS14			
COMBI LATHE MILL P		MAKE	COMBI LATHE MILL PR	3			3,1,1,P,1,00:00:00
COMBI LATHE MILL P		GET	LATHE \$UP	ASRS14			
COMBI LATHE MILL P		MILL1		EXPERTMILL1		00:00:10	201.NC
COMBI LATHE MILL P		TURN1		PLT3000_1		00:00:10	301.NC
COMBI LATHE MILL P		NEXT					
COMBI LATHE MILL P		TARGET		ASRS14			
LATHE PROD1/4		MAKE	LATHE PROD1/4.1	4			3,1,1,P,1,00:00:00

### 8.5.5. Purchase Order Report

As explained earlier in this chapter, clicking on the **PO** icon in the **MRP** program activates the Report Generator, which will display or print the Purchase Order.




Figure 107: Purchase Order Report

### 8.5.6. User-Defined Report

The User-Defined Report allows you to design and customize a report to the exact specifications of your CIM system. You can create an unlimited number of User-Defined Reports.

The Report Generator program employs Seagate (Microsoft) Crystal Report (also available in Visual Basic) to generate the OpenMES reports. The Crystal Report program necessary to create your own user-defined report is not included with the OpenMES software and must be purchased separately. Refer to the documentation provided by the Microsoft Visual Basic Crystal Report for instructions on how to create a report.

## 9. OpenMES Device Drivers

**i** This chapter is not applicable for OpenMES Offline.

This chapter describes the OpenMES device drivers. Device drivers are interface programs that translate and transmit messages between the OpenMES Manager and the various machines and controllers at CIM stations. It includes the following sections:

- **Overview of Device Drivers**, provides a brief overview of the OpenMES device drivers and the devices they control.
- **Device Driver Control Panel**, provides a brief overview of the device driver control panel that is used for sending commands to the device.
- **CNC Device Driver**, describes the CNC device driver that controls various types of CIM machines (lathe, mill and more).
- **Robotic Device Drivers**, describes the robotic device driver that controls the devices attached to robotic controller (such as, robots, barcode scanners and more).
- **Quality Control Device Drivers**, describes the quality control device drivers that control QC devices (such as the laser scan meter)
- **ViewFlex Device Driver**, describes the ViewFlex device driver that controls the Vision Machine System.
- **ULS Device Driver**, describes the ULS device driver that controls all operations of the Laser Engraver.
- **BCR Device Driver**, describes the BCR device driver that controls all operations of the Bar Code Reader.
- **RFID Device Driver**, describes the RFID device driver that controls all operations of the RFID reader.
- **PLC Device Driver**, describes the PLC device driver that controls the operation of the conveyor.

### 9.1. OVERVIEW OF DEVICE DRIVERS

Device drivers are the link between the OpenMES Manager and the devices in the CIM cell. The device drivers are used to perform the following functions:

- Relay command and status messages during production between a device and the OpenMES network.
- Simulate a device.
- Test a device.

OpenMES device drivers can run on both Station Manager PCs and the OpenMES Manager PC, depending on the configuration of the CIM system.

Device Driver	Devices Controlled
CNC	A single CNC machine
<b>Robotic Device Driver (ACL or Scorbase)</b>	Devices connected to and controlled by a robot controller; e.g., robot, automatic screwdriver, barcode reader
<b>Quality Control Device Drivers</b>	ROBOTVISIONpro, Laser Scan Meter, ViewFlex, Barcode reader, RFID reader
ULS	Laser Engraver
PLC	The CIM conveyor

## 9.2. DEVICE DRIVER CONTROL PANEL

Device drivers are loaded automatically by the virtual loader, DDLoader.EXE.

This program loads all device drivers from command lines found in the [Loading] section of the device driver's INI file. Refer to Chapter 12 for more details on the loader program.

All device drivers have the following features:

- A **Control Panel** for manually sending commands to the device and for viewing status information.
- A **Virtual Device Driver Status** window for displaying status information, error messages, and responses from the device when appropriate.

When a device driver is loaded its Virtual Device Driver Status window and its Control Panel appear on the screen. For example:




Figure 108: Device Driver Control Panel (ACL).

You must close the status window in order to close the device driver.

① The device driver Control Panel is discussed in detail in the section on the ACL device driver. The discussion there is applicable to all other device drivers.

### 9.3. MODES OF OPERATION

Like the OpenMES Manager, the device drivers can operate in either Simulation Mode or Real Mode. In addition, Manual Mode allows you to interact with the software and hardware.

In order to operate a device driver (DD) in Real Mode, check the Load column next to the desired driver(s). Similarly, to operate a device driver in simulation mode, check the Simulation column next to the desired driver(s).




Figure 109: DD Loader

The following table describes device driver modes:

Option	Description
<b>Real Mode</b>	<p>Normal operating mode. The device driver is ready to communicate with both the OpenMES Manager and the physical device (or its controller).</p> <p>The message <b>Connected OK</b> is displayed after the device driver successfully receives the first message from the device (either on a serial port or a PC I/O card).</p> <p>In Real Mode, all communications between the device and other CIM entities occur automatically. However, it is also possible to manually send commands to the device using the Control Panel.</p>
<b>Simulation Mode</b>	<p>In Simulation mode, the device driver receives commands as usual from the OpenMES Manager and emulates a device by automatically responding with the appropriate status messages. The device driver does not actually communicate with the physical device.</p> <p>The quality control device drivers randomly return either a successful or unsuccessful status message based on the parameter <code>FailPercent</code>. All other device drivers always return a successful status message in Simulation</p>

Option	Description
	mode.
<b>Manual Mode</b>	In Manual mode, the device driver receives commands as usual from the OpenMES Manager while you interactively emulate the device using the device driver’s Control Panel. The device driver does not generate status messages automatically; they are generated only when you manually make selections from the Control Panel.  In Manual mode the device driver does not actually communicate with the physical device. (See the specific section about each device driver for details on how to use the Control Panel to send responses back to the OpenMES Manager.)
Standalone Mode	The Standalone mode enables you to input manager specific commands and execute them directly to the controller without any intervention from other system components.

### 9.3.1. Device Driver Loading Options

Normally device drivers are started from the Loader program that reads device driver command lines from an INI file. For example:

```
Load2=..\BIN\ACLDriver.EXE ACLVD1.INI 21 /COM:1 /C
Load3=..\BIN\CNCDriver.EXE CNCVD1.INI 23 /COM:2 /C
```

If you are activating a device driver in standalone mode, cancel the TCP/IP Network Messaging between the device driver and the manager. To do so:

From the Device Driver Control Panel, select OPERATION MENU. Select TCP/IP status and click UNABLE.

Once a device driver has been loaded, you cannot change its control mode. You must exit the device driver and restart it in the desired mode.

Option	Description
<b>Real Mode</b>	This mode is the default if no special mode switches are specified on the command line that invokes the device driver.
<b>Simulation Mode</b>	Use the <code>/SIMULATION</code> switch on command line that invokes the device driver.
<b>Manual Mode</b>	Use the <code>/Com: 0</code> switch on command line that invokes the device driver.
<b>Standalone Mode</b>	The Standalone mode enables you to input manager specific commands and execute them directly to the controller without any intervention from other system components.

If a device driver is unable to open an RS232 port in order to communicate with its device, it displays the following message in the Control Mode box:

Cannot Open Com:n



This error message indicates that the device driver could not open the serial port on the Station Manager PC. Possible causes include:

- The port is in use by another application.
- The port number is invalid.
- One of the serial port parameters is invalid.

## 9.4. CNC DEVICE DRIVER

The CNC Device Driver interfaces between the OpenMES system and various types of machines such as a lathe or milling machine.

It receives command messages from the OpenMES Manager, adjacent robots, and other CIM devices. In response, it runs the corresponding CNC script program which operates the machine. The device driver responds with status messages about the CNC machine to CIM elements which have registered for these messages.

The CNC Device Driver performs the following functions:

Device Driver Function	By Using
Sends commands to a CNC machine	the CNC Script Interpreter
Tests and debugs Command Interpreter programs	the CNC Control Panel
Sends CNC status messages to other CIM elements	the OpenMES Network
Loads G-code programs into a CNC machine	an RS232 connection

The CNC Device Driver controls machines connected in either of the following ways:

- A machine connected to an internal I/O controller board in the Station Manager PC
- A machine connected to an ACL controller

An internal I/O board maps 16 CNC control lines to two output ports on the PC. It also maps 16 CNC status lines to two input ports on the PC. These I/O port addresses are stored in the file CNCVD1.INI.

A CNC machine that receives commands via an RS232 interface can be connected to a serial port on an ACL controller. You can write an ACL program to control the machine and activate this program by sending commands to the ACL device driver using the CNC script language.

### 9.4.1. Running the CNC Device Driver

This section describes how to run the device driver. It includes the following sections:

- Loading the CNC Device Driver
- CNC Device Driver Status Window
- Generating a CNC Log File

### 9.4.2. Loading the CNC Device Driver

CNC device drivers are loaded automatically by the DD Loader, DDLoader.EXE. This program loads all device drivers from command lines found in the [Loading] section of the local INI file. To manually start a CNC device driver from the Program Manager (e.g. to run the CNC Control Panel for troubleshooting), select the icon for the appropriate CNC machine.

The following examples assume that the CNC device driver is being invoked from the [Loading] section of the CNCVD1.INI parameter file.

For example, to run the CNC Device Driver for CNC machine # 23, use:

```
Load4=..\BIN\CNCDriver.EXE CNCVD1.INI 23 COM:3
```

### 9.4.3. CNC Device Driver Status Window

The Status window appears while a device driver is running. It displays status and error messages, debug information, and output from the following sources:

- CNC script programs
- ACL programs
- Scorbase programs
- Quality control devices
- PLC programs

### 9.4.4. Generating a CNC Log File

The CNC log file facilitates debugging and troubleshooting. It captures the results of each operation performed by the device driver that are displayed in the Status window. This information is written to a file called CNC\_DeviceID.PRT where DeviceID is the 3-digit device ID number of the CNC machine (e.g. CNC\_023.PRT).

```
17:21:48.72 PULSBIT( 0x500, 0x0, "00001000", 500 )
17:21:49.33 --- OPEN DOOR ---
17:21:49.44
17:21:49.44 --- DOOR IS OPENED ---
17:21:49.55 WAITBIT( 0x500, "00000010", 10000 )
17:21:49.66 --- Condition is true ---
17:21:56.52 PULSBIT( 0x500, 0x0, "00010000", 500 )
17:21:57.13 --- CLOSE DOOR ---
17:21:57.23
17:21:57.23 --- DOOR IS CLOSED ---
17:21:57.34 WAITBIT( 0x500, "00000100", 10000 )
17:21:57.45 --- Condition is true ---
```

Figure 110: Sample CNC Log File

The log information includes each CNC script command executed, display messages, OpenMES network messages received and sent, and error messages. Even messages that have scrolled off the screen are recorded. Each entry in the log file is time stamped to the nearest 1/100 of a sec.

The log file is placed in the same directory as the CNCVD1.INI file after the device driver has been closed.

The log file is saved as ASCII text. You can use any text editor to examine and print its contents.

*The log file is overwritten each time you save it. If you want to preserve the previous contents, rename the file CNC\_DeviceID.PRT first.*

### 9.4.5. Downloading G-Code

A CNC device driver downloads a G-code file to a machine in response to a command from the OpenMES Manager (in preparation for running a CNC process).

The device driver uses one of the following download mechanisms depending on which you specify:

- A download utility that you supply called from a specified batch file (recommended)
- The built-in downloader of the CNC device driver

This section discusses how to use a utility program that you supply to download G-code. This method is usually preferable to using the device driver's internal downloader because a utility program provided by the CNC manufacturer can take advantage of all of a machine's features (e.g. providing error correction during the download).

The commands required to invoke a machine's downloader are inserted into a DOS batch file. The last command in this batch file creates a flag file which signals that the download is complete. The CNC device driver automatically deletes this flag file each time it invokes the batch file.

To build this batch file and direct the device driver to use it, do the following:

- 1
- 2
- 3

Procedure

Creating a Utility for  
Downloading G-code

1. Write a batch file named CNC\_L.BAT which calls the utility downloader as shown in the following example:

```
DLOADG.EXE %1 %2
ECHO Task Loaded > <%project directory%\WS3\TASK.CNC
```

2. When the CNC device driver calls this batch file, it specifies the following two parameters (which appear on the first line of the batch file above):

- The G-code file to download (which includes the full DOS path)
- The memory region within the CNC's RAM that stores this G-code program.

3. Define the following parameter entries in the [CNCDriverDefinitions] section of the INI file for this CNC device driver:

```
Loader      = <%project directory%\WS3\CNC_L.BAT
TaskLoadedMark = <%project directory%\WS3\TASK.CNC
```

When these parameters are defined, they tell the device driver to use the specified download utility program instead of its internal downloader.

### 9.4.6. The CNC Control Panel

The CNC Control Panel is a feature of the CNC Device Driver that allows you to perform the following functions:

- Run CNC programs interactively.
- Control CNC operations by setting bits on the Output Panel.
- Read the status of the CNC machine by examining bits on the input panel.




Figure 111: CNC Device Driver Control Panel

This section includes the following sections:

- Running CNC Programs Interactively
- PC-Input/Output Panel
- Output Panel
- Input Panel
- Program History List
- Closing the Control Panel

### 9.4.7. Running CNC Programs Interactively

The CNC Control Panel allows you to run CNC programs created with the CNC Script Interpreter and view the results.

To run a Command Interpreter program using the Control Panel, do the following:

①  
②  
③  
Procedure

Running a Command  
Interpreter Program

1. Determine the parameter(s), if any, that are to be passed into the program. Type these value(s) in the box labeled CNC Command Parameters (e.g. 500 for a 500 millisecond delay)
2. Use the mouse to scroll through the CNC Command List in order to find a program. Double-click on a program name to run that program.

If the CNC machine is connected to the I/O board in the PC, you can observe the effects of a program by observing the line indicators in the PC-Inputs and PC-Outputs panels in the Control Panel. In addition, status messages and instructions generated by the program appear in the Status window.

### 9.4.8. PC-Input/Output Panel

To display the PC-Input/Output Panel, select from the main menu Operation | Input/Output.

### 9.4.9. Output Panel

The Output panel allows you to observe and set the state (On or Off) of 16 CNC control lines. Control lines may be hard-wired to specific CNC functions. Alternatively, the CNC machine may be configured to activate a certain G-code program associated with a control line. Check the documentation of your CNC machine for specifics on the use of each control line.

The PC-Output panel allows you to set CNC control lines on and off by clicking bits in the appropriate output port. The layout of the panel reflects the way the control lines are mapped to bits in two designated PC output ports. By using a mouse to click on the bits in the panel, you can:

- Toggle the state of a control line.
- Pulse a control line by clicking its bit, waiting the desired interval, and clicking it again to restore it to its original state.

### 9.4.10. Input Panel

The Input panel allows you to observe the state (On or Off) of 16 CNC status lines. Status lines may be hard-wired to specific CNC components. Alternatively, the CNC machine may use a G-code program to set the state of a status line. Check the documentation of your CNC machine for specifics on the meaning of each status line. The layout of the panel reflects the way the status lines are mapped to bits in two designated PC input ports.

The PC-Input panel displays the state of CNC status lines. It cannot be used to change the value of a status line. Only the CNC machine can change the value of a status line.

### 9.4.11. Program History List

You can view a list of programs that were run by clicking on the drop-down list box labeled Task History.

### 9.4.12. Closing the Control Panel

It is a good idea to close the Control Panel in order to prevent others from tampering with it while the CNC machine is active. Use one of the following standard Windows methods for closing a window:

1. Double-click the control bar in the X button of the Control Panel window.
2. Click the control bar and select **Close**.
3. Press **[Alt + F4]** while in the Control Panel window.



① *You should always close the Control Panel if you are going to leave the CIM unattended. Otherwise, someone might cause damage if they inadvertently activate a machine (such as a CNC machine) by making selections on the Control Panel (e.g. by clicking on the Output panel or by selecting a task which starts the machine).*

## 9.5. ROBOTIC DEVICE DRIVERS

The robotic device driver relays messages between the OpenMES network and the devices attached to a robotic controller such as:

- An Intelitek robot
- An automatic screwdriver
- A barcode scanner
- An X-Y table
- ASRS-36
- ASRS-36U

This device driver receives command messages from the OpenMES Manager and adjacent CNC machines (for ACL only). In response, it runs the corresponding robotic program. The robotic device driver communicates with the controller using an RS232 port on the Station Manager PC.

The robotic device driver performs the following functions:

- Activates robotic programs.
- Receives status messages from robotic programs and relays them to a CIM entity.
- Allows you to interactively operate robots and peripheral devices attached to a robotic controller.
- Allows you to test and debug robotic programs by sending commands from the Control Panel.
- Emulates a robot in Simulation mode.

The primary robotic command is to run a set of pick-and-place programs which direct a robot to move a part from one location to another at a station. Robotic ACL or Scorbase programs can also direct a robot to perform other tasks such as assembly operations or they can control peripheral devices such as the Rotary Table.

### 9.5.1. Robotic Device Drivers User Interface

The robotic device driver's user interface enables you to perform the following functions:

- Simulate a robot.
- Issue robotic commands interactively.
- Debug pick-and-place programs by running them interactively.
- Test a robot and its positions and programs by issuing a series of pick-and-place commands stored in file.
- Create a file of pick-and-place commands.

### 9.5.2. Robot Operation

The ACL and Scorbase device drivers contain different interfaces for operating the robot, each of which is described in the following sections.

- Scorbase Device Driver
- ACL Device Driver

### 9.5.3. Scorbase Device Driver

Since the Scorbase device driver is part of the Scorbase software, you can use Scorbase software functionality in order to operate the robot. The Scorbase device driver window (for OpenMES) is displayed, as follows:





Figure 112: Scorbase Device Driver (for OpenMES)

You can select one of the following modes: Online Mode, Simulation Mode (Automatic or Manual) and Standalone Mode. For further details refer to Control Modes for the Robotic Device Driver in the following section.

### 9.5.4. Reloading Last Project at Startup

When loading the Scorbace device driver for the first time, perform the following procedure enabling you to reload the last project the next time you activate the Scorbace device driver.

To reload the last project at startup:

1. From your windows start menu, click the **Loader** icon of your workstation . The CIM DDLoder window is displayed.





Figure 113: CIM DDLoder

2. Ensure the **Load** column is selected  for the Scorbace device driver and click the **Load Selected Drivers**  icon. The Scorbace device driver window is displayed.




Figure 114: Main Scorbace Device Driver Window



3. From the **File** menu select **Open Project**. The Load Project window is displayed.
4. Select the required project in accordance with your OpenMES workstation configuration and click **OK**. The project is displayed in the main window.

From the **Options** menu, select **Reload Last Project at Startup**. The next time you access the **Scorbase Device Driver**, this project will automatically be displayed.

### 9.5.5. ACL Device Driver

You can use the ACL device driver, as a limited terminal to send commands to a controller. Commands that you type in the Send to Controller field are sent out the PC's serial port when you press Enter. Responses from the controller are displayed in the status window of the device driver. This capability is useful for testing and debugging individual ACL programs. The ACL device driver window is displayed, as follows:




Figure 115: ACL Device Driver

### 9.5.6. Control Modes for the Robotic Device Driver

The robotic device driver, like all other device drivers, can pass actual messages or can generate simulated messages. In Real Mode, the device driver relays messages between the OpenMES system and a robotic controller. In one of the simulation modes, the robotic device driver can be used to emulate a robot or to test a robot.

The following list shows the messages that can appear in the Control Mode box on the Control Panel. In each mode, the device driver treats command messages the same whether they originate from the OpenMES Manager or from selections you make from the device driver's Control Panel.

The activation examples show command lines from the Loader's INI file used to start the device driver in the designated mode. Bold command line switches highlight the specific switch used to invoke that mode.

Option	Description
Real Mode (Online)	Normal operating mode. The device driver relays command messages to the robotic controller from the OpenMES Manager, CNC machines, etc. In turn, it broadcasts status messages from the controller to the OpenMES network.  <b>Command line for ACL:</b> ACLDriver.EXE ACLVD3.INI 31 /COM:1  <b>Command line for Scorbases:</b> /O /I=ACLVD1.INI /N=11 /CIMDD_ONLINE
<b>Real Mode: Connected OK</b>	The robotic device driver shows that it has received the first message from the robotic controller on the serial port.
<b>Cannot Open Com:n</b>	The robotic device driver could not open its serial port on the Station Manager PC.
<b>Simulation Mode (Automatic)</b>	The robotic device driver receives commands as usual but emulates a robot and a barcode reader by generating status messages automatically.  In this mode, the device driver does not actually communicate with the robotic controller; only with the OpenMES Manager (and other devices that send it commands).  <b>Command line for ACL:</b> ACLDriver.EXE ACLVD3.INI 31 /COM:1 /SIMULATION  <b>Command line for Scorbases:</b> /I=ACLVD1.INI /N=11 /CIMDD_SIMUL_AUTO
<b>Simulation Mode (Manual)</b>	The robotic device driver receives commands as usual but only generates status messages when you double click on a line in the Task History box.  In this mode, the device driver does not actually communicate with the robotic controller; only with the OpenMES Manager (and other devices that send it commands).  <b>Command line for ACL:</b> ACLDriver.EXE ACLVD3.INI 31 /COM:0
<b>Standalone Mode</b>	The Standalone mode enables you to input manager specific commands and execute them directly to the controller without any intervention from other system components.



ⓘ *The ACL and Scorbases device drivers enable controlling the robot from both the OpenMES Manager and Station PC simultaneously. This is useful for development and testing procedures of the robotic programs. However, it can be dangerous when operating the CIM system in online mode. Therefore, you should always close the Control Panel to prevent others from tampering with it when the robot is turned on. Otherwise, someone might cause damage if they inadvertently activate the robot by making selections from the robotic device driver window (for example, by clicking on the Play From P/P File button).*


### 9.5.7. Task History List

The Task History box shows the last several commands sent to the controller. You can scroll the background to see commands that have scrolled off the screen.

### 9.5.8. Testing Pick-and-Place Commands

The pick-and-place buttons of the Control Bar allow you to send commands to the robot to move parts around the station. (These options are available in stand alone mode only when using the Scorbase device driver.)

A brief description of the each these pick-and-place buttons is described in the following table:

Option	Description
<b>Enter P/P Command</b> 	<p>Allows you to manually send a pick-and-place command to the robot instead of the command being sent by the OpenMES Manager. Selecting this button presents you with the Run 'Pick-and-Place' dialog box .This dialog box requests the following six parameters:</p> <p><b>Part ID</b> - Number of the part/template to be moved (template = 0)</p> <p><b>Source ID</b> - Device ID of source location where the robot is to pick up the part/template. Located next to the Source ID field is a drop-down list that allows you to select the Source ID by name and not by index.</p> <p><b>Source Index</b> - Compartment number if source location is divided into cells. Located to the right of the Source Index field is another field that displays the number of the compartment.</p> <p><b>Target ID</b> - Device ID of target location where the robot is to place the part/template. Located next to the Target ID field is a drop-down list that allows you to select the Target ID by name and not by index.</p> <p><b>Target Index</b> - Compartment number if target location is divided into cells. Located to the right of the Target Index field is another field that displays the number of the compartment.</p> <p><b>Note</b> - Can be used to send special instructions to assembly programs or user-developed programs.</p> <p>① <i>The names and the range that appear in the Pick-and-Place dialog box are taken from the INI file used by this device driver.</i></p>

Option	Description
--------	-------------




Figure 116: Run 'Pick-and-Place' Dialog Box

**Play from P/P File**



Begins executing a series of pick-and-place commands stored in a special text file designated for this robot, ACL\_XXX.PNP. The XXX is the device ID of this robot (found in the title bar of the Control Panel). These commands are sent one at a time.

This file can be used to thoroughly test a robot's ability to retrieve and deliver parts from every device at a station. Pick-and-place commands involving every device can be stored in the pick-and-place file. Playing this file would then allow you to observe if the robot was able to properly access every device.

**% Complete from P/P File**

This display activates when you select the Play button. It shows what percentage of the pick-and-place file has already been executed.

**Save P/P Cmds**



Saves a pick-and-place text file containing all pick-and-place commands found in the Task History box. This file is saved in the current working directory under the name ACL\_XXX.PNP.

**Close P/P File**

Terminates the playback of a pick-and-place file.

## 9.6. QUALITY CONTROL DEVICE DRIVERS

A quality control device driver interfaces between the OpenMES network and a quality control device such as the Cognex vision sensor.

A device driver communicates with a QC device using an RS232 connection.




Figure 117: A QC Device Driver Passing Messages to and from a QC Device

The QC device driver receives a command message from the OpenMES Manager specifying the type of quality control test to run. It then performs the following steps:

1. Activates the specified test on the QC device (a ViewFlex Job).
2. Receives the test result from the device.
3. Compares the result to a range of acceptable values specified in the command message.
4. Sends a pass/fail status message back to the OpenMES Manager.

If the result is fail, the OpenMES Manager:

- Disposes of the defective part as specified by an ONFAIL process in the Part Definition table.
- Automatically reproduces the part.

Each QC test is defined as a separate process in the Machine Definition module. The test type and acceptable range of test results may be specified in the Parameters field of the Part Definition table.

If the quality control device is connected to an ACL controller (e.g. a barcode reader), the name of the ACL program that activates this device should be specified in the Program field of the Machine Process table in the Machine Definition module.

**Tips** It is possible to use a robot as a quality control device. You can write special ACL programs which perform quality control tests such as:

Have a robot try to place a part in a mold. If the part is too big, you can detect the collision. If it is too small, you can detect free play when the robot tries to move the part after it has placed it in the mold.

You can measure the dimensions of a part by reading the span of the robot's gripper when it is holding the part.

The following table shows how to set up test parameters for each type of QC device driver:

QC Device	Test Type	Acceptable Range of Values
<b>ROBOTVISIONpro Camera</b>	The system scans a part looking for an object(s) that was defined as a Pattern ID in the ROBOTVISIONpro software. (e.g. Are three screws in place?)	The number of objects the ROBOTVISIONpro system should find. If the minimum and maximum values are the same, the system must find this exact number in order for the part to pass the test.
<b>Laser Scan Meter</b>	Checks the diameter of a cylinder. Test type = 1.	Minimum and maximum values represent the tolerance surrounding the desired diameter.

There is a customized version of the quality control device driver for each of the quality control devices listed above. Since these three device drivers are essentially similar except for the internal message format used to communicate with the quality control device, this section discusses the operation of all three. In this discussion, these device drivers are interchangeable and are referred to simply as the quality control device driver. All QC device drivers “look” the same to the OpenMES Manager, i.e. it sends the same type of command message to each type and receives the same type of pass/fail status message from each.

A quality control device driver performs the following functions:

- Activates a test on a quality control device.
- Receives status messages from a quality control device and sends them to the OpenMES Manager.
- Allows you to test and debug a quality control device by sending commands from the Control Panel.
- Emulates a quality control device in Simulation mode.

### 9.6.1. The QC Control Panel

The QC Control Panel is a feature of the QC device driver. It allows you to perform the following functions:

- Determine the control mode the device driver is running in.
- Simulate the test results from a QC device.
- Monitor test results in real - time.
- Test the QC device by manually issuing command messages to it and observing the results.




Figure 118: Control Panel for a Quality Control Device Driver

### 9.6.2. Control Modes for Quality Control Device Drivers

A QC device driver, like all other device drivers, can pass actual messages or can generate simulated messages. In Real Mode, the device driver relays messages between the OpenMES system and the quality control device. In one of the simulation modes, the QC device driver can be used to emulate a quality control device or to test a device. For more details, refer to Device Driver Loading Options.

The table below shows the messages that can appear in the Control Mode box on the Control Panel. In each mode, the device driver treats command messages the same whether they originate from the OpenMES Manager or from selections you make from the device driver's Control Panel.

The activation examples show command lines from the Loader's INI file used to start the device driver in the designated mode. Bold command line switches highlight the specific switch used to invoke that mode.

Option	Description
<b>Real Mode</b>	<p>Normal operating mode. The device driver relays command messages to the QC device from the OpenMES Manager. In turn, it broadcasts pass/fail status messages from the device to the OpenMES network.</p> <p><b>Activation:</b> LSMDriver.EXE LSMVD1.INI 13 /COM:2</p>
<b>Real Mode: Connected OK</b>	<p>The QC device driver shows that it has received the first message from the QC device on the serial port.</p>
<b>Cannot Open Com:n</b>	<p>The QC device driver could not open its serial port on the Station Manager PC.</p>
<b>Simulation Mode</b>	<p>The QC device driver receives commands as usual but emulates a quality control device by generating pass/fail status messages automatically based on the value in the <b>Fail %</b> field.</p> <p>In this mode, the device driver does not actually communicate with the QC device; only with the OpenMES Manager.</p> <p><b>Activation:</b> LSMDriver.EXE LSMVD1.INI 13 /COM:2 /SIMULATION</p>
<b>Manual Mode</b>	<p>The QC device driver receives commands as usual but only generates pass/fail status messages when you click on the <b>Success</b> or <b>Fail</b> buttons.</p> <p>In this mode, the device driver does not actually communicate with the QC device; only with the OpenMES Manager.</p> <p><b>Activation:</b> LSMDriver.EXE LSMVD1.INI 13 /COM:0</p>
<b>Standalone Mode</b>	<p>The Standalone mode enables you to input manager specific commands and execute them directly to the controller without any intervention from other system components.</p>



### Controlling a QC Device from the Control Panel

The buttons on the Control Panel allow you to send commands to the quality control device and status messages to the OpenMES Manager. These buttons are described below.

Option	Description
<b>Check</b>	<p>Activates a test on the quality control device. This button only functions in Real Mode. It is useful for testing communications with the quality control device. The response from the device appears in the device driver's Status window.</p> <p>This button resends the last command message from the OpenMES Manager as shown in the fields Low, High, and Type described below. If no command message has yet been received, the default values are:</p> <p style="text-align: center;">Type = 1, High = 0, Low = 0</p>
<b>Success</b>	Generates a status message to the OpenMES Manager indicating that a part passed its quality control test. Used in Manual mode.
<b>Fail</b>	Generates a status message to the OpenMES Manager indicating that a part failed its quality control test. Used in Manual mode.

The following fields on the Control Panel show the parameters associated with the last command that was sent to the quality control device. These values are used when you select the Check button (described above) to manually send a command to the device.

Option	Description
<b>Low</b>	The minimum acceptable test value.
<b>High</b>	The maximum acceptable test value.
<b>Type</b>	An ID number specifying which sort of quality control tests the device should perform.

The Fail % field allows you to control how the device driver responds when it is operating in a simulated mode:

Option	Description
<b>Fail %</b>	<p>Used only in Simulation mode. Randomly determines how often the simulated test result will be Success or Fail (0% = always successful, 100% = always failure). Pass/fail results are generated randomly.</p> <p>The default failure percentage is read from the parameter <b>SimulationFailPercent</b> in the device driver's INI file. Changing this value on the Control Panel affects the current session but does not save the new value to the INI file.</p>

### 9.6.3. QC Device Settings

Each quality control device driver uses a duplicate set of INI file parameter settings shown in the following figure (Figure 119: Sample INI File Settings for a Laser Scan Meter). These settings relate to:

- Format of a quality control log file.
- Running the device driver in Simulation mode.
- RS232 communication settings.
- Appearance of the device driver's Control Panel on screen.

When you want to simulate the operation of a QC device, the QC device driver provides simulated test results to the OpenMES Manager stating whether a part passed or failed a QC test. The parameter **SimulationFailPercent** allows you to set the default failure percentage that a QC device driver uses when running in Simulation mode.

The following sections discuss particular settings for each type of quality control device driver.

### 9.6.4. ROBOTVISIONpro Settings

The **ROBOTVISIONpro** device driver works best with v2.3 or later of the ROBOTVISIONpro software. Use the parameter Snap = Yes to indicate version 2.3 or later.

You can use the **Frame** parameter to specify the frame area in the camera's field of view where the **ROBOTVISIONpro** system should scan for objects.

When you train the **ROBOTVISIONpro** to recognize a new object, the **ROBOTVISIONpro** software assigns a unique Pattern ID. Use this number as the test type when setting up the Parameter field in the Part Definition table.

### 9.6.4.1. Laser Scan Meter Settings

A laser scan meter is a straightforward quality control device that performs only one type of test. Use a test type of 1 for this device when entering values in the Parameter field of the Machine Process table or the Part Definition table.

```
[General]
CimSetupPath=C:\OpenCIM\SETUP\SETUP.CIM

[LSMDriverDefinitions]
QCReport = Yes
QCReportTemplateFile = VC2_QC.INI
QCReportFileName =
QCReportFileMarker =
QCReportFileDeleteOnStart =
SimulationFailPercent = 20
BaudRate=9600
Parity=None
DataBits=8
StopBits=1
XonXoff=No
MainWindowBkgndColors=40,150,100
MainWindowTextColors=100,50,200
```

Figure 119: Sample INI File Settings for a Laser Scan Meter

## 9.7. VIEWFLEX DEVICE DRIVER

The ViewFlex Device Driver interfaces between the OpenMES network and the Vision Machine System as a quality control device. For more information, see the latest [ViewFlex User Manual](#).

## 9.8. ULS DEVICE DRIVER

The ULS device driver operates the ULS Laser Engraver. In the same way that the CNC device driver controls all operations of a CNC machine, the ULS device driver controls all operations of the Laser Engraver.

The ULS device driver communicates with the Laser Engraver via parallel and RS232 links. It uses the parallel connection in order to download the appropriate engraving program (CorelDraw or Freehand file) to the device. The serial RS232 is used to establish communications between the laser machine and the ULS device driver so that programs from the laser machine's memory can be selected and messages transmitted to and from the device driver.

When a part is to be placed on the laser table, the OpenMES Manager sends a message to the device to descend to the lowest level and then rise to the loading level. The robot always picks & places a part from/to the same level.

ⓘ  *Warning!*

ⓘ *Do not place any objects in the laser machine's front cabinet. When the table descends to its lowest level, it could crash into objects that may have been placed there.*

### 9.8.1. Downloading Print Files

The laser has two connectors at the back: a 9-pin connector from the device driver, and an LPT port for connecting to the computer from which the CorelDraw or Freehand files are downloaded.

The laser has two methods of file storage: one file saves only one file to the memory and when a new file is downloaded it replaces the old one; when multiple files are stored in the laser memory, each file is numbered sequentially according to the download order.

ⓘ  *Warning!*

ⓘ *Working with multiple files in on-line mode could cause the wrong file to be activated.*

In one file mode, the fileload.bat file enables the OpenMES Manager to automatically download the specific file that is required for the process and later activate other files as ordered by the OpenMES Manager.

### 9.8.2. User Interface

The Laser Engraver interface enables you to perform the following:

- Download a file to the laser machine.
- Select a file for engraving.
- Delete all engraving programs from the laser machine.
- Display the properties of the communications port.
- Create a log file of all the messages sent during a session.
- Specify the TCP/IP status between the OpenMES Manager and the device driver.

The device driver can be in one of three states: Ready (yellow), Disabled (red), Working (green).





Figure 120: ULS Device Driver (On Line Mode)

### 9.8.3. Setting the Zero Point

When you activate the ULS device driver, you are reminded to set the machine's Z axis zero point.



At this point, the laser's focal length should always be 2 inches. This ensures that the laser is focused and produces maximum efficiency.

To manually set the zero point:

1. Press the Z button from the main menu on the machine or from the file display menu.
2. Select the Focal Length option.
3. Place the gauge on the table (if a template is always used, place the gauge on the template).



*Warning! To prevent impact, be careful not to raise the table with the gauge directly under the lens carriage.*

4. Raise the table carefully to the position where the upper chamfered part of the gauge lies firmly against the side of the focus lens carriage.
5. Continue raising the table to the point where the gauge tilts outwards.
6. Gently lower the table to the exact point where the gauge straightens, i.e., it is aligned with the side of the carriage. This is the zero point of the laser engraver and the loading/unloading position of the robot.
7. Select the Set Focal Length option and confirm to set the zero point.
8. Once you have set the zero point, click **OK** in the ULS device driver to display the Laser Engraver Device Driver window, as shown in User Interface.

### 9.8.4. Control Modes

Like all the device drivers, the ULS device driver can operate in Real, Simulation and Manual modes; it can also be operated in standalone mode.

Option	Description
<b>Real Mode</b>	Normal operating mode. The device driver relays command messages to the Laser Engraver from the OpenMES Manager. In turn, it broadcasts start/finish/end status messages from the device to the OpenMES Manager.




Figure 121: Laser Engraver Device Driver - On Line Mode

In the OpenMES Manager Part Definition, the user specifies the name of the engraving program as the “filename” and the Z-axis as the “parameter”. The current Z-axis is displayed during operation.

**Simulation Mode**

The device driver emulates Real Mode by communicating with the OpenMES Manager. The Laser Engraver is disabled in this mode.




Figure 122: Laser Engraver Device Driver - Simulation Mode

**Manual Mode**

In this mode, each command received from the OpenMES Manager (displayed in the Action field) must be confirmed by the user (click Do).




Figure 123: Laser Engraver Device Driver - Manual Mode



### Standalone Mode

In this mode, the user is in direct control of the laser machine without any interference from the OpenMES Manager. It is therefore the user's responsibility to verify that the laser is operational.





Figure 124: Laser Engraver Device Driver - Standalone Mode

The  button can be pressed at any stage during the operation.

## 9.9. BCR DEVICE DRIVER

The BCR device driver operates the Bar Code Reader. In the same way that the CNC device driver controls all operations of a CNC machine, the BCR device driver controls all operations of the Bar Code Reader.

The BCR device driver communicates with the Bar Code Reader via parallel and RS232 links.

### 9.9.1. User Interface

The BCR device driver interface is accessed from the CIM DDLloader window, as described in the following procedure.





Figure 125: BCR Device Driver

To access the BCR device driver user interface:

1. Select the Loader icon of the workstation where the BCR device driver is installed. The CIM DDLoader window is displayed, as shown in Figure 109: DD Loader.
2. To operate the device driver in Real Mode check the **Load** column of the **BCRDRIVER**. To operate the BCR device driver in Simulation mode check the **Simulation** column of the **BCRDRIVER** and then click the **Load Selected Drivers**  icon to load the BCR device driver software. The various modes of operation are described in the following section.

### 9.9.2. Control Modes

Like all the device drivers, the BCR device driver can operate in Real, Simulation and Manual modes. It can also be operated in Standalone mode.

**Real Mode** Normal operating mode. The device driver relays command messages to the Bar Code Reader from the OpenMES Manager. In turn, it broadcasts start/finish/end status messages from the device to the OpenMES Manager.




Figure 126: BCR Device Driver (Real Mode)

To operate the BCR device driver in Real Mode:

- From the Control Mode drop down list, select **Real Mode**. The result is displayed in the Barcode Scan Result area.

**Simulation Mode**

The device driver emulates Real Mode by communicating with the OpenMES Manager. The Bar Code Reader is disabled in this mode.




Figure 127: BCR Device Driver (Simulation Mode)

To operate the BCR device driver in Simulation Mode:

1. From the Control Mode drop down list, select **Simulation Mode**.
2. In the Barcode Operation area enter the failure rate percentage. For example, enter 50 to randomly determine a 50 percent failure rate. (meaning, 50 percent of the parts will pass the BCR test and 50 percent will fail).

**Manual Mode** In this mode, the Bar Code Reader receives commands as usual from the OpenMES Manager, but only generates Pass/Fail status messages when you click on the **Pass** or **Fail** buttons.




Figure 128: BCR Device Driver (Manual Mode)

To operate the BCR device driver in Manual Mode:

1. From the Control Mode drop down list, select **Manual Mode**.
2. Select **Pass** to indicate the part has passed the BCR test or **Fail** to indicate the part has failed its BCR test.

**Standalone Mode**

In this mode, the user is in direct control of the Bar Code Reader device without any interference from the OpenMES Manager. It is therefore the user's responsibility to verify that the Bar Code Reader Device is operational.




Figure 129: BCR Device Driver (Standalone Mode)

To operate the BCR device driver in Standalone Mode:

1. From the Control Mode drop down list, select **Standalone Mode**.
2. Select **Barcode On** to activate the barcode reader.
3. Select **SCAN Barcode** to scan the part in order to identify the Template Type or Template ID, as required. The result is displayed in the Barcode Scan Result area.
4. Press **Barcode Off** at any time to deactivate the barcode reader.

## 9.10. RFID DEVICE DRIVER

The RFID device driver communicates with the RFID Reader and the OpenMES Manager.

The RFID device driver connects to the RFID Reader via an RS232 cable. For computers without a RS232 port, a USB to RS232 adapter may be used.

In order to use the RFID reader with OpenMES, Template IDs must be assigned to RFID tags using the RFID Device Driver. For more information, refer to the subsection How to Assign a Template ID to an RFID Tag, on page 149.

### 9.10.1. User Interface

The RFID device driver interface is accessed from the CIM DDLoader window, as described in the following procedure.





Figure 130: RFID Device Driver

To access the RFID device driver user interface:

1. Select the Loader icon of the workstation where the RFID device driver is installed. The CIM DDLoader window is displayed, as shown in Figure 109: DD Loader.
2. To operate the device driver in Real Mode check the **Load** column of the **RFIDDRIVER**. Then click the **Load Selected Drivers**  icon to load the RFID device driver software. The various modes of operation are described in the following section.

### 9.10.2. Control Modes

Like all the device drivers, the RFID device driver can operate in Real, Simulation and Manual modes. It can also be operated in Standalone mode.

**Real Mode** Normal operating mode. This is the default Driver mode. The device driver relays command messages to the RFID Reader from the OpenMES Manager. In turn, it broadcasts a QC result message to the OpenMES Manager.




Figure 131: RFID Device Driver (Real Mode)

To operate the RFID device driver in Real Mode:

- From the Control Mode drop down list, select **Real**. A <Real Mode> message is displayed in the Open CIM Messages area.

**Simulation Mode** The device driver emulates Real Mode by communicating with the OpenMES Manager. Communication with the RFID Reader is disabled in this mode.




Figure 132: RFID Device Driver (Simulation Mode)

To operate the RFID device driver in Simulation Mode:

1. From the Control Mode drop down list, select **Simulation**.

The RFID Operation area is updated with the failure rate percentage that is defined in the Machine Definition utility. For example, 50 indicates a 50 percent failure rate.



**Manual Mode**

In this mode, the Device Driver receives commands from the OpenMES Manager, but only generates Pass/Fail status messages when you click on the **Pass** or **Fail** buttons.




Figure 133: RFID Device Driver (Manual Mode)

To operate the RFID device driver in Manual Mode:

2. From the Control Mode drop down list, select **Manual**.
3. Select **Pass** to indicate the part has passed the RFID test or **Fail** to indicate the part has failed its RFID test.

**Standalone Mode**

In this mode, the user is in direct control of the RFID Reader device without any interference from the OpenMES Manager. It is therefore the user's responsibility to verify that the RFID Reader Device is operational.




Figure 134: RFID Device Driver (Standalone Mode)

To operate the RFID device driver in Standalone Mode:

1. From the Control Mode drop down list, select **Standalone**.
2. Pass an RFID tag in front of the RFID reader. The reader will sound a beep and an entry for the RFID tag will be added to the RFID device log in the RFID Device Driver.

## 9.11. PLC DEVICE DRIVER

The PLC device driver relays messages between the OpenMES network and the programmable logic controller which controls the operation of the conveyor. These messages pertain to the movement of pallets on the conveyor.

This device driver runs on a PLC Manager PC which is usually designated as workstation 99. This PC is connected to the PLC via an RS232 link.

The PLC device driver:

- Receives a command message and tells a PLC control program to execute the corresponding function.
- Receives status messages from PLC control programs and broadcasts them on the OpenMES network.
- Allows you to test and debug PLC control programs by sending commands from the Control Panel.
- Emulates pallets traveling on a conveyor in Simulation mode.

The PLC continually broadcasts the status of pallets on the conveyor as they move past stations. This flow of status messages enables you to see a real-time display of the conveyor in the Graphic Tracking module or on the Control Panel of the PLC device driver.

You can manually rearrange pallets on the conveyor while the CIM is running. However, if you manually change a pallet's payload, an error will eventually result since the payload in the OpenMES Manager's database will no longer correspond.

The PLC operates in a demanding real-time environment. It tracks the status and destination of every pallet on the conveyor without requiring constant communication with the OpenMES Manager. Each time a pallet arrives at a station, the PLC functions autonomously to stop the pallet; identify it; decide if this pallet is needed at this station, and if so, alert the OpenMES Manager. This sequence of events is continuous and is multiplied by the number of stations in the CIM.

In order to give the best possible response time, the PLC functions independently of the OpenMES Manager. When the OpenMES Manager needs a pallet at a station, it sends a command message to the PLC. The OpenMES Manager then waits for the PLC to inform it that the pallet has arrived. The PLC holds the pallet at the station until the OpenMES Manager sends a release command.

The OpenMES Manager does not track the continuous flow of pallets as they move around the conveyor. As with other devices, the OpenMES Manager specifies what it wants but does not get involved in the details of how to carry out the request.

### 9.11.1. PLC Messages

The PLC device driver receives the following command messages from the OpenMES Manager and relays them to the PLC. These commands correspond to the buttons on the PLC Control Panel.

Commands to the PLC	
Device Driver	Description
<b>GetFree</b>	Orders the PLC to stop the next empty pallet at the specified station. Used when a part (or empty template) needs to be picked up at this station (including the ASRS station).
<b>Release</b>	<p>The OpenMES Manager allows a needed pallet continue on the conveyor if the station is busy when the pallet arrives. Releasing the pallet prevents a traffic jam on the conveyor. This can occur if the robot that loads/unloads pallets is busy or if a pallet cannot be unloaded because the buffers are full. The pallet's destination remains unchanged.</p> <p><b>Pallet Carrying Template</b> - If the pallet's destination = this station, it will be stopped the next time it comes around to this station.</p> <p><b>Empty Pallet</b> - If the pallet's destination = 99, the next empty pallet to arrive at this station will be stopped.</p>
<b>Deliver</b>	Orders the PLC to stop the specified pallet at the specified station. The OpenMES Manager issues this command in order to assign a destination to a pallet at the time it is loaded with a template (i.e. every pallet carrying a template should have a destination).
<b>Free</b>	Release a pallet that was unloaded at this station. Flag it as available (i.e. destination = 99). This command is similar to Release except that the pallet's destination is changed to 99 to indicate that the pallet is empty and available.

The following status messages from the PLC are forwarded to the OpenMES Manager by the PLC device driver:

- A pallet carrying a template for this station has arrived.
- An empty pallet has stopped to pick up a template.

If the Graphic Tracking module is running, a Pass message can be generated each time a pallet passes through a station where it was not needed. These messages keep the real-time conveyor display updated. However, if the frequency of these messages slows down the system, you can improve performance by disabling them.

The following sample scenario demonstrates the role of the PLC device driver in relaying command and status messages between the OpenMES Manager and the PLC. This scenario assumes that a part is being picked up from the ASRS station 1 and delivered to production station 2.

<b>Message</b>	<b>Description</b>
<b>(Command messages in bold)</b> <b>(Status messages in italics)</b>	
<b>GetFree</b> <b>Stop an empty pallet at station 1</b>	The OpenMES Manager sends a command to the PLC to stop the next empty pallet that arrives at the specified station.
<i>Empty pallet has arrived at station 1</i>	The PLC responds with a status message when an empty pallet has arrived.
<b>Deliver</b> <b>Stop loaded pallet at station 2</b>	After the ASRS robot loads a part template on the pallet, the OpenMES Manager sends a command to the PLC specifying that the PLC should stop this pallet at station 2. The PLC releases the pallet from the ASRS station 1.
<i>Loaded pallet has arrived at station 2</i>	The PLC sends a status message to the OpenMES Manager when the pallet arrives at the station.
<b>Free</b> <b>Allow empty pallet to leave station 2</b>	After a robot removes the template from the pallet, the OpenMES Manager sends a command to the PLC to release this empty pallet. This empty pallet is now tagged as available (i.e. destination = 99). It circulates on the conveyor until the OpenMES Manager sends a request to the PLC for an empty pallet (return to step 1).

### 9.11.2. PLC Control Panel

The PLC Control Panel is a feature of the PLC device driver. It allows you to perform the following functions:

- Monitor the location and destination of every pallet on the conveyor.
- Test the PLC and conveyor by manually issuing command messages to the PLC.
- Simulate the movement of pallets on the conveyor.
- Determine the control mode the device driver is running in.




Figure 135: PLC Control Panel

### 9.11.3. Pallet Status Display

The Pallet Status display shows the status, location, and destination station for each pallet on the conveyor. This display is updated each time the PLC stops a pallet and identifies it at a station.

A code of 99 indicates an empty pallet that is available for use, i.e. it has no destination. The status of a pallet (listed in the Status column) can be one of the following:

Pallet Status	Description
<b>Run</b>	<p>This is the default condition for all pallets when the CIM starts up. This status remains in effect until a pallet passes its first station and an update message from the PLC is received. If the Run status for a pallet never changes, this indicates that the pallet is not currently present on the conveyor.</p> <p>The Run status can also be assigned as a result of a Free command. The pallet retains this status only until it reaches the next station at which time it changes to either Pass or Arrive.</p> <p>A pallet with a Run status has a destination of 99, i.e. no destination has been assigned to it.</p>
<b>Arr (Arrive)</b>	Assigned to an empty pallet that is being held at a station waiting to be loaded. The pallet is stopped at the station as a result of a GetFree command.
<b>Stp (Stop)</b>	Indicates that a loaded pallet has arrived at its destination.
<b>Rls (Release)</b>	<p>A pallet required by this station has arrived, but the station is too busy to deal with the pallet. Usually this occurs as a result of a busy robot or when all the station's buffers are full.</p> <p>Rather than hold up traffic on the conveyor, the pallet continues on the conveyor. If the pallet is carrying a template for this station, it will be stopped the next time it comes around. If the pallet is empty, the next empty pallet will be stopped in its stead.</p> <p>The Release status changes to either Pass or Arrive when the pallet reaches the next station.</p>
<b>Pss (Pass)</b>	Indicates that the pallet just passed through a station that was not its destination.

#### 9.11.4. Controlling Pallets from the Control Panel

The buttons at the bottom of the Control Panel allow you to send commands to control the movement of pallets on the conveyor. The buttons described below correspond to the commands that the OpenMES Manager sends to the PLC device driver.

Before using these buttons, you must first select a station. In order to select a station for the operations shown below, use the list box of station numbers found along the right-hand edge of the Control Panel.

Option	Description
<b>Deliver</b>	Stops the specified pallet when it arrives at the specified station. Select the desired pallet by clicking on the line with the correct pallet ID. Then select a station before using this button.
<b>GetFree</b>	Stops the next empty pallet that arrives at the specified station. Select the desired station before using this button.
<b>Free</b>	Allows a pallet that was unloaded at this station to continue on the conveyor and flags it as available (i.e. assigns the pallet's destination station = 99). Select the desired station before using this button.
<b>Release</b>	Lowers the piston at the specified station to allow a pallet that is just passing through this station to continue moving along the conveyor. You can also use this button to allow a needed pallet to pass if the station is currently busy. Select the desired station before using this button.

It is NOT recommended to manually select **GetFree** or **Deliver** while the CIM is running in Real Mode. If you do, the OpenMES Manager will receive an unexpected status message indicating the arrival of a pallet that did not actually arrive. The OpenMES Manager will attempt to recover from this situation by issuing a Free command for this pallet.

#### 9.11.5. Pallet Command Box

You can use the PLC Control Panel as a limited terminal to send commands to a controller. Commands that you type in the Pallet Command Box are sent out via the PC's serial port when you press [Enter]. Responses from the PLC are displayed in the Status window of the device driver.

This capability, which should only be used by PLC programmers, is useful for testing and debugging PLC control programs.

#### 9.11.6. Simulating a Conveyor

When you want to run a CIM simulation, the PLC device driver can simulate the operation of pallets moving along the conveyor (when running in Simulation mode or Manual mode). You can set the following parameters in the appropriate INI file in order to customize the simulation of the conveyor:

- The number of pallets traveling on the conveyor (**SimulationStations**)
- The number and order of stations around the conveyor (**SimulationPallets**)
- The distance between stations (**SimulationPosPerStation**)
- The direction in which the conveyor moves (**SimulationDirection**)

## 10. Web Viewer

The Web Viewer application enables you to remotely access a specific OpenMES Manager cell and track the production cycle of the CIM cell from the various view tabs. This includes the graphic display of the operations being performed, the actions performed on system devices as they occur in the production cycle, information regarding the storage locations and more.

This chapter describes how to install and access the Web Viewer client. It includes the following:

- **Installing the Client**, describes how to install the web viewer client application.
- **Accessing the Web Viewer**, describes how to activate the web viewer application.
- **Web Viewer Main Window**, introduces the elements of the web viewer main window.

① *Before accessing the Web Viewer, you must first verify that the IIS is installed and that the DCOM has been configured (described in Chapter 4, Installation). You must then verify that the Web Viewer mode is activated (described in section 6.3, OpenMES Operational Modes).*

### 10.1. INSTALLING THE CLIENT

The Web Viewer client is installed through Internet Explorer (version 5.0 and higher). If required, you can save the installation file to a specified directory for future installations.

To install the Web Viewer client:

1. Run Internet Explorer.
2. In the Address field enter the IP or hostname of the computer containing the OpenMES Manager that you want to install from, as in the following examples:

`http://<hostname>/webcimviewer/start.asp`

OR

`http://<IP Address>/ webcimviewer/start.asp`



The OpenMES Web Viewer Initial page is displayed.




Figure 136: Web Viewer Installation Window

3. Click **Download**. The File Download window is displayed.



Figure 137: Web Viewer Download Window

4. Select the required option, as follows:

- Select Run in order to run this program from its current location.
- The Web Viewer Client Setup window is displayed. When the installation is complete, click Finish. OR
- Select Save in order to save this program to a specified directory for future installations.

After you have installed the client, the next step is to access Web Viewer, as described in Accessing the Web Viewer.

## 10.2. ACCESSING THE WEB VIEWER

Before accessing the Web Viewer, ensure that the OpenMES Manager that you want to access is currently open.

To access the Web Viewer:

1. Run Internet Explorer.
2. In the Address field enter the IP or hostname of the computer containing the OpenMES Manager that you want to access according to the following examples:

`http://<hostname>/webcimviewer/start.asp`

OR

`http://<IP Address>/webcimviewer/start.asp`

The OpenMES Web Viewer Initial window is displayed, as shown in Installing the Client.

- ① **Click *Start*.** *The Open CIM Web Viewer appears displaying the Graphic Display tab, as shown in Graphic Display Tab.*  
*If the OpenMES Manager of the computer that you want to access is currently inactive, an information dialog box is displayed, informing you that OpenMES Manager that you currently want to access is currently closed.*

## 10.3. WEB VIEWER MAIN WINDOW

The Web Viewer main window contains the following elements, each of which is described in the sections that follow:

- **Graphic Display Tab**, displays a 3D display of the operation being performed in the CIM cell.
- **View Scheduler Tab**, displays the scheduler information of the CIM cell.
- **View Program Tab**, displays the A-Plan (meaning, the production work order) of the CIM cell.
- **View Leaf Tab**, displays the production activities in the CIM cell.
- **View Order Tab**, displays the current manufacturing order.
- **View Storage Tab**, displays the current location of parts in the CIM cell.
- **View Device Tab**, displays the actions performed by system devices.
- **View Pallet Tab**, displays the pallets in the CIM cell the current status of each pallet.
- **Web Viewer Status Bar**, displays CIM cell information, such as current status, elapsed time and more.
- **View About Tab**, displays dialog with information about Web CIM Viewer software and CIM software of the Cell that is current in view.

### 10.3.1. Graphic Display Tab



Figure 138: Graphic Display Tab

The Graphic Display tab enables you to view the graphic display that currently appears on the OpenMES Manager of the computer that you are currently accessing. For further information refer to section 6.6 Graphic Display and Tracking .

### 10.3.2. View Scheduler Tab




Figure 139: View Scheduler Tab

The View Scheduler tab enables you to view the current (planned and actual) scheduler information of the OpenMES Manager that you are accessing. For further information refer to CIM Scheduler in Chapter 6, Operating OpenMES Manager.

### 10.3.3. View Program Tab

Level	Part	Action	Subpart	Target	Inc	Parameters	P1
1		TopBatch					
2	ASSEMBLE XV PROD/1	MAKE	ASSEMBLE XV PROD/1.1		1	1.1.1.P.1.00:00:00	WAIT
3	ASSEMBLE XV PROD/1.1	PLACE	TEMPLATE	ASRS14			
4	ASSEMBLE XV PROD/1.1	RENAME	BASE WITH HOLE SUP				
5	ASSEMBLE XV PROD/1.1	NEXT					
6	ASSEMBLE XV PROD/1.1	PRESS	BASE WITH HOLE SUP	HYDRAPRESS1			
7	ASSEMBLE XV PROD/1.1	End_Assembly	ASSEMBLE XV PROD/1.1	JIGXY9		ASSEMBLE XV	
8	ASSEMBLE XV PROD/1.1	ASSEMBLE XV	CHECK/1.1	BASE WITH HOI	1		
9	ASSEMBLE XV PROD/1.1	BASE	BASE WITH HOLE SUP	JIGXY9			
10	ASSEMBLE XV PROD/1.1	Assembly	ASSEMBLE XV PROD/1.1	JIGXY9		ASSEMBLE XV	
11	ASSEMBLE XV PROD/1.1	GET	BASE WITH HOLE SUP	ASRS14			
11	CHECK/1.1	ToAssembly	ASSEMBLE XV PROD/1.1	JIGXY9		ASSEMBLE XV	
12	CHECK/1.1	RENAME					
13	CHECK/1.1	FREE	TEMPLATE	ASRS			
14	CHECK/1.1	PLACE	XV SUP	RACK1			
15	CHECK/1.1	CHECK XV	XV SUP				
16	CHECK/1.1	GET	XV SUP	ASRS14			

Figure 140: View Program Tab

The View Program tab enables you to view the current production work order of the OpenMES Manager that you are currently accessing. This enables you to track the current production status of the OpenMES Manager. For further information refer to *Program View* in *Chapter 6, Operating OpenMES Manager*.

### 10.3.4. View Leaf Tab




Figure 141: View Leaf Tab

The View Leaf tab enables you to view the description of the current production activities in the current CIM cell of the OpenMES Manager that you are accessing, describing the current operation being performed on each item as well as the operation that will follow immediately. For further information refer to Leaf View in Chapter 6, Operating OpenMES Manager.

### 10.3.5. View Order Tab




Figure 142: View Order Tab

The View Order tab enables you to view a copy of the manufacturing order of the current cell of the OpenMES Manager that you are accessing. For further information, refer to Order View in, Chapter 6, Operating OpenMES Manager.

### 10.3.6. View Storage Tab

Storage	Index	Status	Part	Template	Device ID
72ASRS14	1	Empty	EMPTY	EMPTY	11
ASRS14	1		LATHE SUP	TEMPLATE#020005	211
ASRS14	2		LATHE SUP	TEMPLATE#020006	211
ASRS14	3		LATHE SUP	TEMPLATE#020007	211
ASRS14	4		LATHE SUP	TEMPLATE#020008	211
ASRS14	5		LATHE SUP	TEMPLATE#020009	211
ASRS14	6		MILL SUP	TEMPLATE#010005	211
ASRS14	7		MILL SUP	TEMPLATE#010006	211
ASRS14	8		MILL SUP	TEMPLATE#010007	211
ASRS14	9		MILL SUP	TEMPLATE#010008	211
ASRS14	10		MILL SUP	TEMPLATE#010009	211
ASRS14	11		XV SUP	TEMPLATE#040002	211
ASRS14	12		XV SUP	TEMPLATE#040003	211
ASRS14	13		XV SUP	TEMPLATE#040004	211
ASRS14	14		XV SUP	TEMPLATE#040005	211
ASRS14	15		XV SUP	TEMPLATE#040006	211
ASRS14	16		BALL GAME BASE	TEMPLATE#050003	211
ASRS14	17		BALL GAME BASE	TEMPLATE#050004	211
ASRS14	18		BALL GAME BASE	TEMPLATE#050005	211
ASRS14	19		BALL GAME BASE	TEMPLATE#050006	211
ASRS14	20		BALL GAME BASE	TEMPLATE#050007	211

Figure 143: View Storage Tab

The View Storage tab enables you to view a list of every storage location defined in the CIM system. For further information, refer to Storage View in Chapter 6, Operating OpenMES Manager.

### 10.3.7. View Device Tab




Figure 144: View Device Tab

The View Device tab enables you to view a list of every robot and machine (including QC devices) as well as a description of the current action being performed in the current CIM Cell of the OpenMES Manager that you are accessing. For further information, refer to Device View in Chapter 6, Operating OpenMES Manager.



### 10.3.8. View Pallet Tab




Figure 145: View Pallet Tab

The View Pallet tab enables you to view a list of every pallet in the CIM Cell and a description of its current status. For further information, refer to Pallet View in Chapter 6, Operating OpenMES Manager.

### 10.3.9. Web Viewer Status Bar



The Web Viewer status bar consists of the following elements:

**Option**

**Status:**




**Description**

Displays information regarding the status of the OpenMES Manager that you are accessing, as follows:

- Manager is Open: Displayed as soon as the OpenMES Manager is opened.
- Manager is Closed: Displayed when the OpenMES Manager is closed.
- Synchronizing Graphics: Displayed when synchronizing graphics of the current state of the OpenMES Manager that you are accessing.
  - Current State: Displayed when the current graphic state of the OpenMES Manager is displayed in the Graphic Display tab.

**Time:**



The time that has passed since the start of production in the OpenMES Manager.

**Mode:**



OpenMES Manager modes of operation:

- Simulation Mode: The OpenMES Manager does not communicate with device drivers. This mode does not require either hardware or device drivers in order to operate.
- Real Mode: The OpenMES Manager communicates with all device drivers, whether or not hardware is in use. This mode requires that all device drivers which are need for a specific application be loaded, so that the OpenMES Manager can transmit and receive messages.

**Graphic Messages:**



Graphic messages that appear describing the graphic process. The **Order is Completed** message appears at the end of the production process, indicating the order has been complete.

**10.3.10. View About Tab**

The Web Viewer About tab displays a dialog with information about CIM software and Web CIM Viewer software, and a shortcut to the Intelitek web site for support and information.




Figure 146: View About Tab

# 11. OpenMES Programming

This chapter provides various programming and advanced OpenMES features. It includes the following sections:

- **Robotic Programming for OpenMES**, describes the robotic programming commands in OpenMES.
- **CNC Programming for OpenMES**, describes the CNC programming commands in OpenMES.
- **Robot and CNC Interface**, describes the CNC synchronization mechanism in OpenMES.
- **Optimization Enhancement Using Open Source**, describes how to add new algorithms to the existing list of algorithms in the CIM Optimization Manager.
- **Experimenting with Production Strategies Using the A-Plan**, describes the structure of the A-Plan and provides instructions how to modify it.

## 11.1. ROBOTIC PROGRAMMING FOR OPENMES

In the course of production, OpenMES uses a set of robotic programs which control the movement of robots and the operation of peripheral devices connected to a robotic controller. When you want to teach a robot (or other device) to perform a new task or to achieve better performance at a task, you need to edit or create robotic programs. This need arises when you:

- Install a new device at a station.
- Move a device or a robot to a new location.
- Add or change a process or part definition (in the Machine Definition or Part Definition utility programs) that relies on a robotic program.
- Add or change robot tasks or parameters. For example: speed (slow, medium, fast) or the way the robot moves (linear, circular, etc.).
- Add or change the parameters of the devices attached to the robotic controller.

This section describes how to write robotic programs in the OpenMES environment. These programs direct a robot (or other device attached to a robotic controller) to:

- Move an object from place to place (pick-and-place operation).
- Perform certain system functions (e.g. how to react in case of a robot collision).
- Perform some other production process (e.g. bar code, pneumatic screwdriver, CNC interface, etc.)

### 11.1.1.1. The Pick-and-Place Strategy

OpenMES uses the pick-and-place strategy to minimize the number of custom robotic programs required to transfer parts between locations at a station.

Having fewer programs yields several benefits:

- Less programming effort to write the original programs.
- Fewer changes to be made in the event devices are added, deleted, or moved.
- Fewer problems and easier to debug since all GET and PUT programs share a common structure.
- Requires less memory in the robotic controller

Instead of writing individual robotic programs to move a part between two locations (a point-to-point approach), the pick-and-place strategy provides a more systematic method that requires only two programs for each location, a GET and PUT. A GET program picks up a part from a location. A PUT program places a part at a specific location. GET and PUT programs for different locations are designed to work together to allow the robot to take a part from any location (GET) and deliver it to any other location (PUT).

For example, if there are six locations at a station, it would require 30 point-to-point programs to cover all the possible combinations of moving a part between any two locations. The pick-and-place approach requires only 12 programs (6 GETs and 6 PUTs).

A *Free Movement Zone* is the key to getting GET and PUT programs to work together. This zone is a region approximately ½ meter above work surface in which the robot can move freely and quickly between locations without encountering any obstacles.

The first operation in a GET or PUT program is to move the robot in a straight line to a position directly above the location where it is needed. From there, a program uses a set of detailed robotic commands to maneuver the robot arm to a point where it can pick up or place a part at a specific location. When a GET or PUT begins executing, it assumes that the robot arm is in the Free Movement Zone waiting for a command.

A typical pick-and-place scenario is shown in the figure below. In this scenario, the OpenMES Manager sends a command to move a part from buffer 2 to a ROBOTVISIONpro camera for a quality control test. This pick-and-place command is sent to the robotic device driver. The device driver in turn sends commands to the robotic controller to run the corresponding GET and PUT programs described below.




Figure 147: Robot Movements Controlled by Separate GET and PUT Programs

### GET (from buffer 2)

3. Move the empty robot arm in a straight line through the Free Movement Zone to a point directly above the buffer.
4. Lower the arm and grab the part from the template sitting in the buffer.
5. Raise the arm back up to the Free Movement Zone directly above the buffer.
4. PUT (under the camera)
1. Move the robot arm holding the part through the Free Movement Zone to a point above the ROBOTVISIONpro camera's viewing area.
2. Lower the arm and set the part within the camera's field of view.
3. Raise the arm back up to the Free Movement Zone directly above the camera.

At end of the GET, the robot is holding the part in the Free Movement Zone while it waits for the PUT program to begin executing.

At the end of the PUT, the robot is empty and it waits in the Free Movement Zone for the next GET operation.

### 11.1.2. Overview of a Pick-and-Place Command

The OpenMES Manager tells a robot to move a part/template from one device at a station to another by sending a pick-and-place command to the appropriate robotic device driver. The device driver tells the controller to run the robotic programs GET and PUT that are associated with the locations specified in the pick-and-place message.

Each device has a GET program associated with it which tells a robot how to move in order to pick up a part at this location. Similarly, each device has a PUT program which tells a robot how to place a part at this location. The names of these robotic programs take the form of GTxxx and PTxxx (for ACL programs) and GETxxx and PUTxxx (for Scorse programs), where xxx is the ID of the device.

The device driver tells the controller to run the appropriate GTxxx and PTxxx that are associated with the locations specified in a pick-and-place command.

Each GET program is dedicated to picking up an object from a single location. Each PUT program is dedicated to delivering an object to a single location.

In order to move a part from any location at a station to any other location, all GET and PUT programs are designed to be used together in any combination.

For example, to move a template from the ASRS to a pallet waiting on the conveyor, a pick-and-place command would specify running the following robotic programs:

- GT002 - Take template from ASRS (002 = ASRS device ID).
- PT001 - Put template on conveyor pallet (001 = device ID for conveyor)

Note that the device IDs for GET and PUT are different. If they were the same this would mean that the robot was returning the part/template to the same location where it had just picked it up.

All GET and PUT programs for a robot must be designed to work together. This entails that:

- They read the same set of pick-and-place parameters (stored in global variables).
- When a program ends, it must leave the robot in a position that enables it to move in any subsequent direction (since you do not know at the time of writing the programs where the next GET or PUT will send the robot).
- They use the same synchronization mechanism which allows a GET program to activate any PUT program.

① *The names of the Robotic programs are different for ACL programs and Scorse programs, as follows:*

*GTXXX and PTXXX are used for ACL programs.*

*GETXXX and PUTXXX are used for the Scorse programs.*

### 11.1.3. Teaching Robot Positions

The path that a robot follows is made up of points called *robot positions*. These positions can be “taught” using a teach pendant or robotic software, for example, ACL or Scorbase. The coordinates associated with these positions are normally stored in the required program file. See the robotic documentation for a complete discussion of how to teach robot positions.

- ❗ *Tip: When planning robot movements, take into consideration obstacles caused by parts under production. For example, after placing a part, the robot may not be able to retrace its movements without colliding with the part it just placed.*

*Also note that the same part at the same location may require two different robot positions before and after an assembly operation.*

#### 11.1.3.1. Response Messages (from Robotic Programs to the OpenMES Manager)

The programs GET and PUT send the Start, Finish and End status messages to the OpenMES Manager via the robotic device driver, each of these messages is described in the table below.

Status Message	Description
<b>Start</b>	<p>The GET program sends a Start message to report that the robot has grasped the part/template and has moved clear of the source device. This Start message indicates that the source device can continue with other processing even while the robot continues to move.</p> <p>The Start message can speed up time critical operations in the CIM. For example, strategic placement of the Start message can be used to expedite the flow of pallets on the conveyor. As soon as a robot has lifted a template from a pallet, the GET program sends a Start message. The OpenMES Manager can then release the pallet even while the robot continues to move the template.</p>
<b>Finish</b>	<p>The PUT program sends a Finish message to report that the robot has placed the part/template at the destination device. The Finish message indicates that the destination device can now proceed to process the part/template even while the robot continues to move back to its idle position.</p> <p>The Finish message can be used to speed up time-critical operations in a manner similar to the Start message. For example, as soon as a robot has placed a template on a conveyor pallet and moved out of the way, the PUT program can send a Finish message. The OpenMES Manager can then release the pallet even while the robot continues to move to its final resting position.</p>
<b>End</b>	<p>The PUT program sends an End message to report that the robot has completed this pick-and-place operation and is now available for the next command.</p>

- ① *Tip: In order to avoid delaying the conveyor unnecessarily, send the Start and Finish messages as soon as possible when writing GET and PUT programs that deal with moving a part template to/from a conveyor pallet.*

*For most other devices, the Finish and End messages typically come one right after the other at the end of the PUT program.*

#### 11.1.3.1.1. Sending Response Messages from ACL Programs to the OpenMES Manager

The code that actually sends the response messages from the ACL program is contained in the macros .START, .END, .FINISH. These are found in the PROGRAM\_GET XXX and PROGRAM\_PUT XXX example programs.

To send response messages from ACL Programs to the OpenMES Manager:

- Insert the following macros in the appropriate places in your own GET and PUT programs:
  - Start: The Start message is sent by the macro **.START**.
  - Finish: The Finish message is sent by the macro **.FINISH**.
  - End: The End message is sent by the macro **.END**.

The macros for all three messages, Start, Finish, and End, take care of returning the command sequence number stored in the parameter variable \$ID. This value allows the OpenMES Manager to identify the source of the message.

#### 11.1.3.2. Sending Response Messages from the Scorbase Software to the OpenMES Manager/Device Driver

The Send Message window is used for creating the Send Message command in the Scorbase program. When the program is activated and begins to run, the Send Message command is then forwarded to the OpenMES Manager or device driver, as described in the following procedures:

To send response messages from Scorbase to the OpenMES Manager:

1. From the Scorbase main window, select **Window | Teach & Edit**. Select **Options | Pro** from the Menu bar. From the Workspace window expand the **Program Flow** tree and double click **SendMessage...** The Send Message window is displayed:






Figure 148: Send Message Window – OpenMES Manager Option Selected

2. From the **Send To** dropdown list select the **MANAGER** option.
- ① *In the Send To dropdown list the Manager option is displayed by default. In the Task ID field the TASK\_ID option is displayed by default.*
3. From the **Type** dropdown list select the required response message as follows:
  - \$Start
  - \$Finish
  - \$End
4. Click **OK**. The response message is displayed in the program window.
- ① *This procedure is applicable only when the Scorbace device driver is in online mode.*

To send response messages from Scorbase to the Device Driver:

1. From the Scorbase main window, select **Window | Teach & Edit**. Select **Options | Pro** from the Menu bar. From the Workspace window expand the **Program Flow** tree and double click **SendMessage...**. The Send Message window is displayed.




Figure 149: Send Message Window – Device Driver Option Selected

2. From the **Send To** dropdown list select the **Device Driver** option.
3. In the **Device ID** field enter the ID of the device.
4. In the **String** field enter the string that the Device Driver is waiting to receive.
5. Click **OK**. The response message is displayed in the program window.

**i** This procedure is applicable only when the Scorbase device driver is in online mode.

### 11.1.3.3. Viewing the Response Messages in OpenMES Manager

You can monitor the progress of robotic programs at run-time by looking at the Program, Leaf or Device Views in the OpenMES Manager program. When a robot is performing a pick-and-place command, the following messages let you follow the progress of the GET and PUT programs as they execute.

Run-Time Message	Description
<b>ON</b>	The Start macro in the GET program has executed.
<b>OFF</b>	The Finish macro in the PUT program has executed.
<b>Blue Box</b>	The End macro in the PUT program has executed.

### 11.1.3.4. Pick-and-Place Parameters

The OpenMES Manager sends a set of parameters to a robotic device driver whenever it issues a pick-and-place command. The device driver in turn activates the PCPLC program in the robotic controller which receives these parameters and assigns them to the following global variables:

Robotic Pick & Place Parameters		Description
Scorbase	ACL	
<b>TASK_ID</b>	\$ID	A sequence number generated by the OpenMES Manager for each command (a pick-and-place command in this case). Whenever a robotic program sends a status message, it includes this command ID so that the status message can be associated back to the original command.
<b>PART_ID</b>	PART	The ID number of the part that the robot is to handle. This number corresponds to the Part ID field in the Part Definition form. For each part type, the instructions for how the robot grasps the part is defined in the robotic program (ACL or Scorbase). For example, the positions for each part ID is stored in an array (such as, CIM[ ]). The part ID can be used to calculate an index into this array.  A template is identified with a Part ID of zero.
<b>SOURCE_DEVICE_ID</b>	\$DEV1	The device ID of the source location where the robot will pick up the part/template.
<b>SOURCE_DEVICE_INDEX</b>	INDXG	For a source device that has multiple compartments (e.g. a storage rack), this parameter specifies in which compartment (or buffer) the robot will find the part/template.
<b>TARGET_DEVICE_ID</b>	\$DEV2	The device ID of the target location where the robot will place the part/template.
<b>TARGET_DEVICE_INDEX</b>	INDXP	For a target device that has multiple compartments (e.g. a storage rack), this parameter specifies in which compartment (or buffer) the robot should place the part/template.

PICK_AND_PLACE_NOTE	\$NOTE	This parameter is available for user-defined purposes to send special instructions to a GET or PUT program. For example, when the part to be handled is a template (with ID=0), the note parameter will indicate the part ID of the part on the template. This enables the Scorbase programmer to include special instructions for specific parts, such as, slower movements for sensitive parts and more.
---------------------	--------	--

---

#### 11.1.4. Writing Scorbase Source Code

The Scorbase program consists of two parts. The first part (lines 1 through 14) is created automatically when you select the parameters from the Pick and Place window, the second part (from line 15 to the end) contains GET XX and PUT XX programs for each device in the CIM system. These GET XX and PUT XX programs are written by the programmer.

An example of a Scorbase program is displayed, as follows:

```

Remark: $ Beginning of the automatically generated code
Call Subroutine $PICK_AND_PLACE_0,1,3,15,2,0
Set Subroutine $PICK_AND_PLACE_0,1,3,15,2,0
Set Variable TASK_ID = 110000
Set Variable PART_ID = 0
Set Variable SOURCE_DEVICE_ID = 1
Set Variable SOURCE_DEVICE_INDEX = 3
Set Variable TARGET_DEVICE_ID = 15
Set Variable TARGET_DEVICE_INDEX = 2
Set Variable PICK_AND_PLACE_NOTE = 0
Call Subroutine AUTOEXEC
Call Subroutine GET001
Call Subroutine PUT015
Return from Subroutine
Remark: $ End of the automatically generated code
Remark: Intelitek Open CIM robot device driver demonstration
Remark: The ER-4u robot serves the Conveyor (CNV1)
Remark: The ER-4u robot serves the MINI-ASRS (M6AS2)
Set Subroutine GET015
Print to Screen: GET TEMPLATE FROM MINI-ASRS (M6AS2)
Go to Position 21 Speed 5

```

Open Gripper  
Set Variable ABOVE\_TEMPLATE\_POSITION = SOURCE\_DEVICE\_INDEX + 110  
Go to Position ABOVE\_TEMPLATE\_POSITION Speed 8  
Set Variable AT\_TEMPLATE\_POSITION = ABOVE\_TEMPLATE\_POSITION -100  
Go Linear to Position AT\_TEMPLATE\_POSITION Speed 2  
Close Gripper  
Go Linear to Position ABOVE\_TEMPLATE\_POSITION Speed 2  
Go to Position 21 Speed 5  
Go to Position 20 Speed 5  
Go Linear to Position 2 Speed 2  
Open Gripper  
Go to Position 20 Speed 5  
Send Message \$Start to MANAGER for task TASK\_ID  
Return from Subroutine  
Set Subroutine PUT015  
Print to Screen: PUT TEMPLATE ON MINI-ASRS (M6AS2)  
Open Gripper  
Go to Position 20 Speed 5  
Go Linear to Position 2 Speed 3  
Close Gripper  
Go Linear to Position 20 Speed 2  
Go to Position 21 Speed 5  
Set Variable ABOVE\_TEMPLATE\_POSITION = SOURCE\_DEVICE\_INDEX + 110  
Go to Position ABOVE\_TEMPLATE\_POSITION Speed 8  
Set Variable AT\_TEMPLATE\_POSITION = ABOVE\_TEMPLATE\_POSITION -100  
Go Linear to Position AT\_TEMPLATE\_POSITION Speed 2  
Open Gripper  
Go Linear to Position AT\_TEMPLATE\_POSITION Speed 2  
Go to Position 21 Speed 5  
Send Message \$Finish to MANAGER for task TASK\_ID  
Go to Position 20 Fast  
Send Message \$End to MANAGER for task TASK\_ID  
Return from Subroutine

Set Subroutine GET001  
Print to Screen: GET TEMPLATE FROM CONVEYOR (CNV1)  
Open Gripper  
Go to Position 10 Fast  
Go Linear to Position 1 Speed 3  
Close Gripper  
Go Linear to Position 10 Speed 2  
Go to Position 20 Speed 5  
Go Linear to Position 2 Speed 3  
Open Gripper  
Go Linear to Position 20 Speed 2  
Send Message \$Start to MANAGER for task TASK\_ID  
Return from Subroutine  
Set Subroutine PUT001  
Print to Screen: PUT TEMPLATE ON CONVEYOR (CNV1)  
Go to Position 20 Speed 5  
Go Linear to Position 2 Speed 2  
Open Gripper  
Send Message \$Finish to MANAGER for task TASK\_ID  
Go Linear to Position 20 Speed 3  
Send Message \$End to MANAGER for task TASK\_ID  
Return from Subroutine

- ① *If the programmer defined an AUTOEXEC subroutine in the program, then the Call AUTOEXEC SUBROUTINE will appear in the automatically generated section of the program (lines 1 through 14).*

### 11.1.5. Writing ACL Source Code

The Robot programs are comprised of all the associated programs necessary to run the robot. The Robot programs are divided into individual programs as follows:

- Get and Put programs of each device.
- Quality Control programs of each peripheral QC device (e.g. Bar code).
- Process (PRL programs) programs of each peripheral machine (e.g. automatic screwdriver, CNC machine)

#### 11.1.5.1. Structure of the ACL Program

File	Description
<b>CIMSYS.DMC</b>	Located in the Projects\LIB\ACL LIB\ACL directory. This file contains system macros.
<b>CIMSYS.SYS</b>	Located in the Projects\LIB\ACL LIB\ACL directory. This file contains system programs.

All of the following files are located at the current directory of Robotn:

File	Description
<b>WSn.DNL</b>	Includes all of the files that are to be downloaded from your station PC to the ACL controller.
<b>PROLOGn.DNL</b>	In this file you modify system programs, such as Global System variables (e.g. SPSA - speed slow group A), predefined positions or any other settings that need to be predefined for that station. This file contains all the documentation for positions and I/O.
<b>GET/PUT.DNL</b>	Pick-and-place programs.
<b>QC.QCL</b>	Quality Control programs.
<b>PROCESS.PRL</b>	Process programs.
<b>EPILOGn.DNL</b>	In this file you modify Initialization System programs.

You can manage all of your Robot programs through the Robot Programs window. Any editing changes, however small, should be made to the original DNL, QCL or PCL files.

### 11.1.5.2. Device Definition

The Setup directory contains a file which defines numbers to their ACL logical name. This file includes all the devices in the system. For example:

```
#IFDEF _DEVICE_DMC
  #DEFINE _DEVICE_DMC
  #DEFINE CNV1          001
  #DEFINE ASRS         003
  #DEFINE ASMBUF      004
  #DEFINE BFFR1       005
  #DEFINE FDR1        006
  #DEFINE TRASH1      007
  #DEFINE RACK1       008
  #DEFINE RDR1        009
  #DEFINE LATHE1     010
  #DEFINE MILL1      011
#ENDIF
```

### 11.1.5.3. ACL Macro Programs

The Projects\LIB\ACL directory contains the file **CIMSYS.DMC**. This file includes the system programs and macros which you will use in writing your own ACL programs:

- Part ID Group (PID)
- Robot Movements
- Synchronization
- Open/ Close Gripper
- Speed
- GET/ PUT Programs
- QC Programs
- Process Programs



The following listing is the source code of CIMSYS.DMC. This file contains system programs, macros, and global variable definitions that are needed when writing your own ACL programs.

```

;
;           OpenMES-ACL Program
;
;           This Is The Cim Macro File
;           For All Stations

;Global definitions
#IFDEF _CIMSYS_DMC
#DEFINE _CIMSYS_DMC
#DEFINE _CIMSYSM_DMC

;Part macro
#MACRO PID           ; part id 1=1..10  2=11..20  etc.
    SET PID = PART - 1
    SET PID = PID / 10
    SET PID = PID + 1
#ENDM

;Group B movement macros
#IF __GROUP_B
    ;Check if Group B is Define
    #MACRO  MOVEDB
        MOVED  .1 .2
    #ENDM

    #MACRO  MOVEB
        MOVE  .1 .2
    #ENDM
#ELSE
    #MACRO  MOVEDB
    #ENDM

    #MACRO  MOVEB
    #ENDM
#ENDIF

;Synchronize macros
#MACRO STARTSYNC
    SET  $SYNC = 0
#ENDM

#MACRO SYNC           ;Should be at the beginning of
                    ;all the put programs.
    WAIT  $$SYNC = 1  ;Wait to the end of get.
    SET  $$SYNC = 0
#ENDM

```

```

#MACRO ENDGET      ;At the end of all the get programs.
  SET  $SYNC = 1 ;Can start the put program.
#ENDM

;Gripper macros
#MACRO OPEN        ;Open the gripper.
  GOSUB OGRIP
#ENDM

#MACRO CLOSE       ;Close the gripper.
  GOSUB CGRIP
#ENDM

;Speed macros

#MACRO FAST        ;Set group A and B speed to fast.
  .FASTA
  .FASTB
#ENDM

#MACRO MEDIUM     ;Set group A and B speed to medium.
  .MEDIUMA
  .MEDIUMB
#ENDM

#MACRO SLOW        ;Set group A and B speed to slow.
  .SLOWA
  .SLOWB
#ENDM

#MACRO FASTA       ;Set group A speed to fast.
  SPEEDA SPFA
#ENDM

#MACRO MEDIUMA    ;Set group A speed to medium.
  SPEEDA SPMA
#ENDM

#MACRO SLOWA      ;Set group A speed to slow.
  SPEEDA SPSA
#ENDM

#IF __GROUP_B
      ;Check if group B is define.
#MACRO FASTB      ;Set group B speed to fast.
  SPEEDB SPFB
#ENDM

```

```

#MACRO MEDIUMB      ;Set group B speed to medium.
  SPEEDB  SPMB
#ENDM

#MACRO SLOWB        ;Set group B speed to slow.
  SPEEDB  SPSB
#ENDM
#ELSE
#MACRO FASTB        ;Set group B speed to fast.
#ENDM

#MACRO MEDIUMB      ;Set group B speed to medium.
#ENDM

#MACRO SLOWB        ;Set group B speed to slow.
#ENDM
#ENDIF

;Programs macros (for GTxxx and PTxxx).
#MACRO PROGRAM      ;The header of all the programs.
  PROGRAM .1
  DEFINE $I
#ENDM

#MACRO PROGRAM_GET  ;The header of get programs.
  PROGRAM GT.1
  DEFINE $I
  SET $I = 1
  .STARTSYNC
#ENDM

#MACRO PROGRAM_PUT  ;The header of put programs.
  PROGRAM PT.1
  DEFINE $I
  SET $I = 1
#ENDM

#MACRO END_GET      ;The tail of get programs.
  .ENDGET
  END
#ENDM

#MACRO END_PUT      ;The tail of put programs.
  END
#ENDM

;Controller D.D protocol macros
#MACRO GETID        ;Get ID from D.D to $ID

```

```

LABEL 11
READ "%ID?" $ID
IF $ID = 0 ;Check if the ID is zero (invalid).
  GOTO 11
ENDIF
SET $I = 1
#ENDM

#MACRO GETIDL ;Get local ID for a not PCPLC program.
LABEL 11
DEFINE $IDL ;$IDL hold the local ID (instead of $ID).
READ "%ID?" $IDL
IF $IDL = 0 ;Check if the ID is zero (invalid).
  GOTO 11
ENDIF
DEFINE $I
SET $I = 1
#ENDM

#MACRO GETPAR ;Get Parameter from D.D.
PEND $PDF FROM $PDD
PRINTLN
READ "%PAR?" .1
PRINTLN
POST 1 TO $PDD
#ENDM

;Controller manager protocol macros for global ID
#MACRO START ;Send start to manager.
PEND $PDF FROM $PDD
PRINTLN
PRINTLN "%START" $ID
PRINTLN
POST 1 TO $PDD
#ENDM

#MACRO FINISH ;Send finish to manager.
PEND $PDF FROM $PDD
PRINTLN
PRINTLN "%FINISH" $ID
PRINTLN
POST 1 TO $PDD
#ENDM

#MACRO END ;Send end to manager.
PEND $PDF FROM $PDD
PRINTLN
PRINTLN "%END" $ID .1 .2
PRINTLN

```

```
POST 1 TO $PDD
#ENDM

#MACRO QC      ;Send quality control result to manager.
PEND $PDF FROM $PDD
PRINTLN
PRINTLN "%QC" $ID .1 .2
PRINTLN
POST 1 TO $PDD
#ENDM

#MACRO ERROR   ;Send robot error message to manager.
PEND $PDF FROM $PDD
PRINTLN
PRINTLN "%ERROR " $ID .1 .2
PRINT .3
PRINT ".4 .5 .6 .7 .8 .9"
PRINTLN
POST 1 TO $PDD
#ENDM

;Controller manager protocol macros for local ID
#MACRO STARTL  ;Send start of local program to manager.
PEND $PDF FROM $PDD
PRINTLN
PRINTLN "%START" $IDL
PRINTLN
POST 1 TO $PDD
#ENDM

#MACRO FINISHL ;Send finish of local program to manager.
PEND $PDF FROM $PDD
PRINTLN
PRINTLN "%FINISH" $IDL
PRINTLN
POST 1 TO $PDD
#ENDM

#MACRO ENDL    ;Send end of local program to manager.
PEND $PDF FROM $PDD
PRINTLN
PRINTLN "%END" $IDL .1 .2
PRINTLN
POST 1 TO $PDD
#ENDM

#MACRO QCL     ;Send quality control result of local
               ;program to manager.
PEND $PDF FROM $PDD
```

```

PRINTLN
PRINTLN "%QC" $IDL .1 .2
PRINTLN
POST 1 TO $PDD
#ENDM

#MACRO ERRORL ;Send robot error message of
                ;local program to manager.
PEND $PDF FROM $PDD
PRINTLN
PRINTLN "%ERROR " $IDL .1 .2
PRINT .3
PRINT ".4 .5 .6 .7 .8 .9"
PRINTLN
POST 1 TO $PDD
#ENDM

;Controller Other Devices protocol macros
#MACRO STOP ;Stop a device (like conveyor) or pcplc process.
STOP GT.1
STOP PT.1
#ENDM

#MACRO CNCREQ ;Request from VC2_CNC
PEND $PDF FROM $PDD
PRINTLN
PRINTLN "%CNCREQ .1 .2 .3 .4 .5 .6 .7 .8 .9"
PRINTLN
POST 1 TO $PDD
#ENDM

#MACRO CNCSTR ;String to VC2_CNC
PEND $PDF FROM $PDD
PRINTLN
PRINTLN "%CNCSTR .1 .2 .3 .4 .5 .6 .7 .8 .9"
PRINTLN
POST 1 TO $PDD
#ENDM
#ENDIF

```

The file **WS1.DNL** contains sample ACL source code. This is the type of file you would edit when you want to change the way a robot moves.

#### 11.1.5.4. ACL System Programs

The `.\LIB\ACL` directory contains the file **CIMSYS.SYS**. This file includes system programs for:

Name	Identity (TP Run #)	Explanation
------	------------------------	-------------

Name	Identity (TP Run #)	Explanation
HOMES	1	Prepares the robot to work in the OpenMES environment.
CIM	2	Reserved for future use.
RESET	3	Resets the variables and the programs.
CLEAR	4	Reserved for future use.
CIMP	5	Attaches the vectors CIM and CIMB to the teach pendant.
USER1	6	User-defined program.
USER2	7	User-defined program.
USER3	8	User-defined program.
USER4	9	User-defined program.
INIT	10	Reserved for future use.
OGRIP	11	Opens the gripper.
CGRIP	12	Closes the gripper.
DIAG	13	The ACL device driver runs this program when it receives an asterisk (*) from the controller (Diagnostic).
PCPLC	14	The ACL device driver runs this program in order to download OpenMES parameters to the ACL controller (Pick-and-Place).
\$REST	15	The system reset program.
AUTO	16	This program runs each time the device driver is loaded and the ACL controller is turned on.
INITC	17	This program is activated each time you load the ACL device driver.

**i** *If you want to modify one of the ACL System program files, enter these changes in the unique PROLOGn.DNL file only.*

### 11.1.5.5. ACL Variables

In the ACL controller there are three types of global variables and two types of local variables.

The global variables are:

- **ACL Controller System Variables**

Variable	Description
IN[16]	Input status
ENC[6]	Encoder
TIME	Time
LTA	Last time for group A
LTB	Last time for group B
MFLAG	Motion Bitmap
ERROR	Error
OUT[16]	Output status
ANOUT[6]	Direct analog current to axis

For more information refer to the ACL Reference Guide.

- **ACL Controller User Variables (OpenMES System Variables)**

Variable	Description
ERRPR	Error program
ERRLI	Error line
\$SYNC	Synchronization
\$PDD	Pend/ post printing to ACL programs
\$PDF	Pend/ post printing to ACL programs
SPFA	Speed fast group A
SPMA	Speed medium group A
SPSA	Speed slow group A
SPFB	Speed fast group B
SPMB	Speed medium group B



<b>Variable</b>	<b>Description</b>
SPSB	Speed slow group B
\$ID	ID message number from the ACL device driver
PART	Part number
PID	Part ID group
\$DEV1	Get device number
\$DEV2	Put device number
INDXG	Get device index
INDXP	Put device index
\$NOTE	Note number
P1	Last position in the device group A
P2	Position before P1
P3	Position before P2
P4	Position before P3
P5	Position before P4
P6	Position before P5
P7	Position before P6
P8	Position before P7
P9	Position before P8
P10	Position before P9
TB	Time needed for group B
NEWB	New group B position
LASTB	Last group B position
KB	Time constant variable for group B
\$NEW	Temporary new position for group B
\$LAST	Temporary last position for group B
PB1	Last position in the device group B
PB2	Position before PB1
PB3	Position before PB3

- **ACL Controller User Variables** (OpenMES User Variables)

① From the ATS, type LISTVAR to display a list of variables.

The local variables are:

- **OpenMES Local System Variables** (ACL Controller Variables)

Variable	Description
\$I	
\$IDL	\$ID Local

- **OpenMES User-Defined Local Variables** (ACL Controller Variables)

If you want to modify one of the ACL System program files, enter these changes in the unique PROLOGn.DNL file only (e.g. If you want to change the SPFA, go to the EPILOGn.dnl file and type SETSPFA=80).

### 11.1.5.6. PROLOG (PROLOGn.DNL)

In the **PROLOGn.DNL** file you can modify system programs, such as Global System variables (e.g. SPSA - speed slow group A), predefined positions or any other settings that need to be predefined for a particular station.

The following examples show how the PROLOGn.DNL file can be modified:

#### 11.1.5.6.1. Modify Operating System Programs

```

, ***** HOME *****
PROGRAM HOMES /Y
* HOMING THE ROBOT
HOME
* HOMING THE L.S.B
HHOME 7
END
    
```

### 11.1.5.7. Define Positions

The principle here is to have fewer positions for better performance and faster backup/restore.

Definition of a CIM position vector: P= lower point, P+10= highest point.

In the file PROLOG.DNL, all the positions are as follows:

1. Divide all of the positions into groups of 10 (ten).
2. The template positions 1 through 20 are for conveyors and buffers (e.g. conveyor 1/11, first buffer 2/12, etc.).
3. Put=Get + 100
4. The last two spaces are used for OPENSACE and OPENSACE FOR TEMPLATE.

Example of how to define a position:

```

,***** POINTS *****
,
DIMP CIM[xxx]

; CIM:
; 1..9 P1          TEMPLATE
; 10..19 P2       TEMPLATE
; 21..29 P1       GET PART FROM BFFR1
; 31..39 P2       GET PART FROM BFFR1
; 41..49 P1       GET PART FROM
; 51..59 P2       GET PART FROM
; 61..69 P1
; 71..79 P2
; 81..89 P3
; 90..91
; 92..93
; 101..109 P1
; 111..119 P2
; 121..129 P1     PUT PART AT BFFR1
; 131..139 P2     PUT PART AT BFFR1
; 141..149 P1     PUT PART AT ASMBUF
; 151..159 P2     PUT PART AT ASMBUF
; 161..169 P2     OPENSOURCE
; 171..179 P1     OPENSOURCE FOR TEMPLATE
; 181..189 FREE
; 191..199 FREE
    
```

### 11.1.5.8. GET/PUT Programs

The GET/PUT.DNL files contain the pick-and-place programs.

#### 11.1.5.8.1. GET/PUT Program Structure

The following table shows the sample GET and PUT programs found in the file \*.DNL. The customization instructions explain how to add your own code to complete these programs.

Example Programs	Customization Instructions
<b>.PROGRAM_GET xxx</b>	Replace the xxx with the device ID as defined in DEVICE.DMC.
<b>; move robot</b>	Insert a command to quickly move the robot to a point above the source device (in the Free Movement Zone).
<b>; grab part/template</b>	Insert commands to lower the robot arm to the source device and grab the part/template. Use the part ID and index parameters ( <b>PART</b> , <b>INDXG</b> ) as needed to grab the object.
<b>; move robot</b>	Insert commands to move clear of the source device.

Example Programs	Customization Instructions
<b>.START</b>	This macro informs the OpenMES Manager that the source device is free.
<b>; move robot</b>	Insert commands to continue moving the robot to a point above the source device (in the Free Movement Zone) where the PUT program will take over.
<b>.END_GET</b>	This macro activates the PUT program.
<b>.PROGRAM_PUT xxx</b>	Replace the <code>xxx</code> with the device ID as defined in <code>DEVICE.DMC</code> .
<b>.SYNC</b>	This macro waits for the GET program to finish moving the robot that is carrying the part/template into position.
<b>; move robot</b>	Insert a command to quickly move the robot to a point above the target device (in the Free Movement Zone).
<b>; move robot</b>	Insert commands to lower the robot arm to the target device. Use the part ID and index parameters ( <b>PART</b> , <b>INDXP</b> ) as needed to set the part/template in its place.
<b>; deliver part/template</b>	Insert commands to move clear of the target device.
<b>.FINISH</b>	This macro informs the OpenMES Manager that the part is in place and the target device is ready to be activated.
<b>; move robot</b>	Insert commands to move the robot to its standard idle position (in the Free Movement Zone).
<b>.END</b>	This macro informs the OpenMES Manager that the robot is ready to perform the next GET operation.
<b>.END_PUT</b>	

The following figure shows an example of GET and PUT programs after customization.

```
.PROGRAM_GET .ASRS
.FAST
MOVED CIM[11]
.SLOW
.OPEN
MOVED CIM[1]
.CLOSE
MOVED CIM[11]
.START
.END_GET

.PROGRAM_PUT .ASRS
.SYNC
.FAST
MOVED CIM[11]
.SLOW
MOVED CIM[1]
.OPEN
MOVED CIM[11]
.FINISH
.END
.END_PUT
```

Figure 150: Sample GET and PUT Programs After Customization

#### 11.1.5.8.2. Synchronizing the GET and PUT

The ACL device driver activates the appropriate GET and PUT programs simultaneously. Since a robot must first pick up a part before it can place it, the GET program must execute before the PUT program. A synchronization mechanism is used to suspend the PUT program until the GET program is finished.

The synchronization mechanism is handled automatically with macros if you base your ACL programs on the sample GET and PUT programs found in CIMACL.DNL. The following sample code shows the synchronization code after macro expansion.

```

PROGRAM GT001 - Get Template from Conveyor
*****
Set $SYNC = 0 ; causes PUT program to wait
.
.
Set $SYNC = 1 ; activates PUT program
End

PROGRAM PT001 - Put Template in Buffer
*****
Wait $SYNC = 1 ; wait for GET program to set activate flag
Set $SYNC = 0 ; reset the activate flag
.
.
    
```

Figure 151: Synchronization Example for GET & PUT (Object Code)

### 11.1.6. QC Programs

The ACL can only hold integers. If you want to test integer quality control, you can send your QC result to the ACL device driver (Barcode) once. If you want to test a decimal number you need to send it string by string.

#### 11.1.6.1. Integer Quality Control

ACL Source Format*.QCL Format	ATS / ACL Controller *.CBU Format	
.PROGRAM QC .GETIDL	PROGRAM QC ***** LABEL 11 READ "%ID?" \$IDL  IF \$IDL = 0 GOTO 11 ENDIF SET \$I = 1	1. Receives the "ID" message number from the ACL device driver.
.	.	2. Process to read the QC test.

ACL Source Format*.QCL Format	ATS / ACL Controller *.CBU Format	
<pre>SET QCRES = xx .QCL QCRES  END</pre>	<pre>SET QCRES = xx   PEND   \$PDF FROM \$PDD   PRINTLN   PRINTLN "%QC" \$IDL QCRES   PRINTLN   POST   1 TO \$PDD  ENDIF END</pre>	<p><b>3.</b> This variable receives the QC result. You send the result to the ACL device drivers.</p>
		<p><b>4.</b> The OpenMES Manager sends two values (a package), a higher limit and a lower limit. Each package has its own sequence # so that it can be identified by the ACL device driver. These are the values that you defined in the Part Definition form and in the field parameters.</p> <p><b>5.</b> The ACL device driver sends the sequence # for the package via the RS232 link to the ACL controller.</p> <p><b>6.</b> The ACL controller runs a QC test and receives a value. This value is sent back to the ACL device driver.</p> <p><b>7.</b> The ACL device driver verifies that the value it received is within the higher and lower limits of the original package (values) sent. If the value is within the limits, then the ACL device driver sends a message that the QC is OK. If the value is not within the limits then the ACL device driver sends a FAIL message.</p>

11.1.6.2. Process Programs

The Process programs include all of the utility programs necessary to operate the ACL Input/Output (e.g. if you want to open the door of a CNC).

11.1.6.3. EPILOG (EPILOGn.DNL)

The EPILOGn.DNL file can be used to modify initialization system programs (INITC, RESET) in the following ways:

ACL Source Format EPILOGn.DNL	ATS /ACL Controller *.CBU Format
<pre> PROGRAM      RESET /Y GOSUB        \$REST GOSUB BCOFF STOP RVP DELAY 50 RUN RVP DELAY 50 GOSUB SEMER END           </pre>	<pre> PROGRAM RESET ***** GOSUB \$REST GOSUB BCOFF STOP      RVP DELAY 50 RUN      RVP DELAY 50 GOSUB SEMER END           </pre>
<pre> PROGRAM      INITC /Y STOP RVP DELAY      30 RUN      RVP .STOP      .CNV1 .STOP      .ASRS .STOP      .BFFR1 .STOP      .FDR1 .STOP      .RACK1 .STOP      .RDR1 .STOP      .TRASH1 .STOP      .ASMBUF POST 1 TO \$PDD GOSUB      SEMER END           </pre>	<pre> PROGRAM INITC ***** STOP      RVP DELAY 30 RUN      RVP STOP      GT001 STOP      PT001 STOP      GT003 STOP      PT003 STOP      GT005 STOP      PT005 STOP      GT006 STOP      PT006 STOP      GT008 STOP      PT008 STOP      GT009 STOP      PT009 STOP      GT007 STOP      PT007 STOP      GT004 STOP      PT004 POST      1 TO \$PDD GOSUB SEMER END           </pre>



### 11.1.7. ACL Off-Line Utilities


OpenMES requires the use of the ACLoff-line utility program version 1.65 or later. The following ACL features are used when writing structured ACL code for OpenMES:

- Symbolic constants (#DEFINE)
- User defined macros (#MACRO, #ENDM)
- Include files (#INCLUDE)
- Download Flags
- # IF
- # IFDEF
- # IFNDEF
- # ELSE
- # ENDIF
- Parameter passing using global variables.
- Synchronization between programs running simultaneously.
- Using the ACLoff-line utility program to send ACL source code to the ACL controller.

You should be familiar with the system information contained in the include files CIMSYS.SYS and CIMSYS.DMC before you start writing your own ACL programs for the OpenMES environment. This file contains system macros, programs, and global variable definitions which perform the following functions:

- Synchronize the running of GET and PUT programs.
- Start and end GET and PUT programs.
- Error handling.
- Send status messages to the OpenMES Manager, to a CNC machine, and to other CIM entities
- 



 You should NOT edit the CIMSYS.SYS or CIMSYS.DMC files without guidance from Intelitek technical support.

The program DOWNLOAD.EXE sends ACL source code files to the controller. While it is sending programs to the ACL controller, this downloader checks syntax and substitutes the program code associated with #DEFINE, #MACRO, and #INCLUDE. These three language directives function similarly to their counterparts in C or Assembly language. For more details, see the *ACLoff-line program User's Manual* and the *ACL Reference Guide*.

- ④ *You must run the DOWNLOAD utility program on the Station Manager PC that is connected to the controller in order to download programs (because the downloader requires an RS232 connection to the controller). However, the ACL source code files can reside on any PC accessible via the network. Before trying to download code with the DOWNLOAD utility, be sure to close the ACL device driver for this controller. Otherwise, a conflict will occur when the ACL program tries to open the same serial port as the device driver.*

#### 11.1.7.1. Robot Programs

The Robot Programs consist of all the relevant programs necessary to run the robot. These programs are divided into two categories: generic and unique, “generic” referring to the fact that the program can be used by all the robots and “unique” referring to programs that are specific for the robot at that station.

The Robot Programs are located in two places:

- Generic
- C:\Users\Public Documents\Intelitek\OpenCIM\Projects
- Unique
- \Project#\WS#\ROBOT#

The following tables describe the file name conventions used for the ACL system programs and sample applications supplied with OpenMES. You should use these naming conventions in your own programming to simplify technical support. You can use the ACL off-line utility, the Robot Programs window or the text editor of your choice to edit these files.

We recommend that you use a Robot Programs window when editing these files. Save the files in ASCII format.

- ④ *Tip: It is recommended that you add a Robot Programs program group on a Station Manager PC. This group should contain the following icons, as shown in the figure below.*
- **ATS:** Terminal emulation program which allows you to interact with the ACL controller connected to a Station Manager PC.
  - **Download:** Sends ACL programs from a Station Manager PC to an ACL Controller.
  - **Download Report:**
  - **Notepad WS1:** Allows easy editing of a station’s configuration file.
  - **Additional Notepads:** for editing other .DNL files.




Figure 152: Robot Programs Group Window

11.1.7.1.1. Generic Robot Programs

File Extension	Meaning
*.DNB	<b>DownLoad - ACL source Blocks that are later copied to the DNL.</b>
*.DMC	<b>Defines &amp; MaCros</b> - An include file (library file) containing user-supplied defines and macros. The contents of this file are inserted in a DNL file at the point specified by an INCLUDE command.
*.SYS	<b>All of the SYStem programs necessary to operate and communicate in the OpenMES environment.</b>
*.QCB	<b>All the Quality Control Block programs and Communication Block programs necessary for peripheral devices that connect directly to the ACL controller.</b>
*.PRB	<b>All the Process Block programs necessary to Communicate with devices (e.g. CNC machine).</b>
*.DLD	<b>DownLoad utilities.</b>




Unique Robot Programs

File Extension	Meaning
*.DNL	<b>DownLoad</b> - <i>ACL source code</i> file that is sent to an ACL controller using the ACL Downloader.
*.QCL	This file is copied from a QCB file. After the original file is modified to the editing application, the file is then unique to the specific QC device.
*.PRL	This file is copied from a PRB file. After the original file is modified to the editing application, the file is then unique to the specific process activation (e.g. a program that speaks through I/O with a CNC machine).

- 1
- 2
- 3

Procedure

**Editing and Downloading a Robot Program Separately**


1. In the Robot Programs window, select the Edit icon  for the file you want to edit; the file is displayed.
8. Edit the file.
9. Select the Download icon  for the file you just edited; the file is downloaded to the controller.
10. Select the Download Report icon . Verify that the file ends with >>>>>END DOWNLOAD FILE! "Device file name"

- 1
- 2
- 3

Procedure

**Downloading All of the Robot Programs at One Time**

① *If any Robot program files need to be edited, edit them before downloading.*

  
Download WS1 ;

In the Robot Programs window, select the Download Station icon ; the files for the entire station are downloaded to the controller. When the files are downloaded together, they are sent in the following order:

1. CIMSYS.SYS
11. PROLOGn.DNL
12. DEVICES.DNL, DEVICES.QCL and DEVICES\*.PCL
13. EPILOGn.DNL

You should not edit ACL object code by using the ATS utility or by backing up a program from a controller and modifying it. Either of these methods would result in an ACL file that is *very* difficult to maintain.

Editing ACL object code (i.e. an \*.CBU file) from the controller results in a program which is out of sync with the original DNL file. This code is harder to read since all #DEFINE, #MACRO, and #INCLUDE statements have been expanded in the controller and all remarks have been deleted.

Note that the ATS utility can still be used for the following functions in the OpenMES environment:

- Configure the controller
- Back up and restore robot positions and downloaded ACL programs
- Teach robot positions

- Test a robot
- Debug ACL programs by running them manually

#### 11.1.8. Adding a New Pick-and-Place Operation

When you add a new device at a station (e.g. CNC machine, storage rack, assembly jig, etc.), you must write two new ACL programs (GT<sub>xxx</sub> and PT<sub>xxx</sub>) that enable a robot to pick up and deliver parts (or templates) from this device.

A program which directs a robot to pick up a part/template from a specific location is called GT<sub>xxx</sub>. The <sub>xxx</sub> represents the unique three-digit device ID for a *source location* that is found in the file SETUP.CIM.

Similarly, a program which directs a robot to deliver a part/template to a specific location is called PT<sub>xxx</sub>. Once again, <sub>xxx</sub> represents a unique device ID, this time for the *target location*.

For each pick-and-place operation, the OpenMES Manager sends a set of parameters to the ACL controller. The ACL program PCPLC reads these parameters from the ACL device driver and assigns them to a set of global variables. These variables are used to pass the parameters to the appropriate GET and PUT programs.

A GET program's main function is to pick up a part/template, which involves the following:

- Direct the robot to grasp a part/template
- Move the robot to a safe position; clear of the source device
- Send a Start status message
- Continue moving the robot to an intermediate point from which it can reach any device
- Activate the PUT program

A PUT program's main function is to place a part/template in a designated location. This operation involves the following steps:

- Wait for an activation signal from a GET program
- Move the robot to the target location
- Set the part/template down at the target location
- Move the robot clear of the target device
- Send a status message that the part/template is in place and ready to be processed
- Move the robot to safe position from which it can reach any device
- Send a status message that the robot is ready to perform the next operation

To write a set of GET and PUT programs for a new device that has been defined in SETUP.CIM, follow the steps outlined below:

Summary	Details
<p><b>1.</b> Add the device to the file DEVICE.DMC (connects the name of the device and the # of the device).</p>	<p><b>1.</b> Use a text editor to insert a symbolic constant into the file DEVICE.DMC. For example:</p> <p><b>14.</b> #DEFINE ASRS 002</p> <p><b>15.</b> In this example, 002 is the device ID (3 digits required) and ASRS is the symbolic name you will use throughout your ACL programs to refer to this device. It is much easier to maintain ACL programs that use symbolic constants (e.g. .ASRS) instead of literal device IDs (002). If a device ID ever changes, it is only necessary to make the change in one place, i.e. in the file DEVICE.DMC.</p> <p><b>16.</b> You should observe the following conventions when assigning device IDs in order to simplify technical support:</p> <p><b>17.</b> 001 Pallet at this conveyor station 002 ASRS (or other central storage)</p>
<p><b>2.</b> Copy the files from ..\LIB\ACL to ..WSn\ROBOTn</p>	<p><b>1.</b> If you have a workstation with an ACL robot then add the directory ROBOTn.</p> <p><b>18.</b> Copy the files from ..\LIB\ACL as follows:</p> <p>If the Type (FLD #5) from SETUP.CIM is: A, B, C, D, F, K, L, Q, J, M, S, X, Y, Z, then copy from: to:</p> <p>..\LIB\ACL\WS.BLK ..\WSn\ROBOTn\WSn.DNL ..\LIB\ACL\PROLOG.BLK ..\WSn\ROBOTn\PROLOGn.DNL ..\LIB\ACL\EPILOG.BLK ..\WSn\ROBOTn\EPILOGn.DNL ..\LIB\ACL\CONFIG.DLD ..\WSn\ROBOTn\CONFIG.DLD</p> <p><b>19.</b> Refer to “OpenMES Setup File: SETUP.CIM” for more information. (Physical Name is FLD #3, Logical Name is FLD #4)</p> <p><b>20.</b> Rules for Creating DNL Files</p> <p><b>21.</b> If the Object Type in the SETUP.CIM (FLD #5) is: A, B, C, D, F, K, L, J, Q, M, S, X, Y, Z, then copy from: to:</p>





Summary	Details
<p><b>5.</b> Use standard ACL procedures for teaching a robot to grab and release a part from the source and target locations.</p>	<p><b>33.</b> Use a teach pendant (or other means) to train the robot how to move and grasp.</p> <p><b>34.</b> Enter the coordinates of the source and target locations in the appropriate array.</p> <p><b>35.</b> Determine how the robot should grip the part/template.</p> <p><b>36.</b> Fill in the appropriate robot movement commands in the GET and PUT programs.</p> <p><b>37.</b> If the location has multiple compartments (or buffers), you can use the variables INDXG and INDXP to help calculate the array index for CIM[ ] (the array that contains all robot positions). These index parameters specify the cell location when dealing with a storage rack or ASRS.</p>

When a robot wants to insert (or remove) a part in a CNC machine, it must tell the machine when to open its door and chuck so the robot can enter the machine. The GET and PUT programs associated with a CNC machine must communicate with CNC script programs that open and close the door and chuck on the machine.

### 11.1.8.1. Robot Errors

#### 11.1.8.1.1. Crash

When the ACL controller detects that a robot has collided with something, it responds as follows:

- The controller goes into COFF mode (Controller Off) and immediately stops all motors on this robot.
- The controller immediately terminates all programs which are trying to move this robot. If any subsequent program attempts to move this robot, it will terminate with a run-time error.
- The ACL device driver automatically executes the DIAG program. (This program should be loaded at initialization time as part of CIMSYS.SYS.)
- The DIAG program sends a status message to the OpenMES Manager to report the collision. See “Sample ACL Programs,” for a listing of the DIAG program.

The OpenMES Manager displays the Device Error screen to alert the operator.

#### 11.1.8.1.2. Emergency

Refer to your system user manual for details.

## 11.2. CNC PROGRAMMING FOR OPENMES

This section introduces the CNC script language and describes how to write CNC programs in the OpenMES environment.

### 11.2.1. CNC Script Language

This section provides an overview of the CNC script language and describes various parameters, such as the initialization, parameters the system variables, CNC script error messages and so on.

#### 11.2.1.1. Introduction

The *CNC Script Language* is a language which allows you to write programs to control a CNC machine. These programs can initiate machine operations by turning the machine's control lines on and off. Programs receive information from the machine via status lines. These control lines and status lines are connected to a station manager PC via an interface board. This board maps the control lines to output ports on the PC, and maps the status lines to input ports. Each line corresponds to a bit in an I/O port. CNC script programs communicate with a CNC machine by reading and writing these bits.

The CNC Script Interpreter is part of the CNC Device Driver. When the CNC Device Driver receives a system message containing a CNC command, it finds the corresponding program in the file CNC\_SCR.DBF and runs it.

#### 11.2.1.2. Language Overview

The following table lists the commands and parameter variables in the CNC Script Interpreter:

Code	Function
V1 - V16	Parameter variables read at initialization time.
P1 - P8	Parameter variables containing values passed to CNC script programs at run time.
BV0, BV1	Current value of the two output ports.
PORT0, PORT1	PC I/O port addresses mapped to CNC control and status lines.
SetBit( )	Modifies the bits of the specified output port.
Wait( )	Suspends program execution for a specified duration.
WaitBit( )	Suspends execution until the specified bit(s) are set to one or until the specified bit pattern appears on an input port.
WaitBitLow( )	Suspends execution until the specified bit(s) are set to zero or until the specified bit pattern appears on an input port.
PulsBit( )	Turns on the designated bits of an output port for a specified duration.
Draw( )	Prints a line to the screen.
Draw2( )	Prints two lines to the screen.
SendMsg( )	Sends a predefined message to another CIM entity.
DownloadD( )	Sends a G-Code program to the CNC machine via RS232.
SendStr( )	Sends a string to the specified OpenMES device (e.g. robot).
WaitStr( )	Suspends execution until the specified string arrives from the Open-CIM-CIM network.
WaitFile( )	Suspends execution until the specified file is created.
MSDOS( )	Performs any MS-DOS command.
MSWINDOWS( )	Launches any MS-WINDOWS executable file.
ABORT( )	Unconditionally aborts the current CNC device driver program.

### 11.2.1.3. Initialization Parameter Variables

The CNC Script Interpreter supports up to 16 general purpose parameter variables and two special purpose variables which are defined at initialization time. The general purpose variables contain values that are 0 to 80 bytes long. These variable names, *V1 - V16*, are fixed. The two special purpose variables, *PORT0* and *PORT1*, contain the addresses of I/O ports used to interface to the CNC machine.

The CNC Device Driver assigns the values of the parameter variables *V1-V16*, *PORT0*, and *PORT1* at initialization time. It reads these values from the section *[CNCDriverDefinitions]* in the file *CNC.INI*.

These variables are global to all CNC script programs. Their values do not change during execution of a script program.

General purpose variables can contain the following types of values:

Variable Type	Range	Example
Integer	Integers range in value from 0 - 2,147,483,647	V8 = 60000
String	A set of ASCII characters enclosed in quotation marks. A string can range in length from 0 - 80 characters.	V1 = "Door Open"
Bit Mask	A string of 8 ASCII text characters enclosed in quotation marks. Each character is either 0 or 1.	V16 = "01000111"

The following table describes the special purpose variables:

Variable	Description	Default Value
PORT0	The address of the first input and output ports on the PC used to communicate with a CNC machine.	0x500 (for both input and output ports)
PORT1	The address of the second PC input and output ports on the PC used to communicate with a CNC machine.	0x501 (for both input and output ports)

### 11.2.2. Passing Run-Time Parameters to Programs

Up to eight run-time parameters can be passed to a CNC script program. Each parameter contains a value that is 0 to 80 bytes long. The parameter names, *P1-P8* are fixed.

You specify a string of parameter values when you invoke a CNC script program. Parameters in this string are separated by commas. The first value in the string is assigned to the parameter variable *P1*, the second to *P2*, etc. The parameter string can be a maximum of 32 characters long (including the comma separators). The rules regarding parameter values described in the previous section also apply to run-time parameter values.

The following sample parameter string contains both numeric and string values:

```
1000,Please wait,60,Finished
```

The way in which you specify the parameter string depends on which of the following methods you are using to invoke the CNC script program:

- Network Message**      A CIM message sent to a CNC Device Driver contains two strings, the name of the CNC script program immediately followed by its parameter string.
- CNC Control Panel**      The string containing the list of parameters is specified in the Parameters window of the Control Panel.

The CNC Device Driver initializes the values of run-time parameters read from the file CNC.INI.

The values of run-time parameter variables do not change after they have been passed into a CNC script program.

### 11.2.3. System Variables

System variables BV0 and BV1 are used to read the current value of their respective output ports during execution of a script program. These variables are global to all CNC script programs for a device driver.

These system variables are assigned in the device driver's INI file in the section [CNCDriverDefinitions]. These 8-bit values, which range from 0–255 are assumed to be the initial state of the control lines of a CNC machine when the system is turned on.

The following table shows the CNC script system variables and their default values (i.e. the values used if no assignment appears in CNC.INI):

System Variable	Description	Default Value
BV0	The current status (Port Value) of output port # 0.	0
BV1	The current status (Port Value) of output port # 1.	0

### 11.2.4. Command Arguments and Syntax

Numeric command arguments can take one of the following forms:

- Integer**                      0 - 2147483647
- Parameter Variable**      V1 - V16, P1 - P8

Spaces that appear in a command's argument list are ignored. Case is not significant in the spelling of command names or for variable names in the argument list. The following examples are equivalent:

SetBit(PORT1, BV1, &, V16)

SetBit (PORT1,BV1,&,V16)

### 11.2.5. Editing CNC Script Language Programs

All CNC script programs for a station (those that you write and those that come with the system) are stored in the script file CNC\_SCR.DBF. More than one CNC device driver can share the same script file. This file normally resides either:

- On the server in a subdirectory designated for this station
- On the station manager PC running the CNC Device Driver

Use a dBASE editor to write your CNC programs to the appropriate CNC\_SCR.DBF file. If a CNC device driver is running, you must close it before you begin editing its CNC\_SCR.DBF file. Otherwise you will get an **Access Denied** error message.

Enter the name of each CNC script program in the *REQUEST* column. A program name can be up to 32 characters long. It can contain any combination of letters, numbers, spaces, and punctuation.

The *ACTION* column contains the CNC script commands that comprise a program. There is no limit on the number of commands contained in a program.

The *RETURN* column is reserved for internal use. Do not enter any values in this column.

This file uses the following format:

REQUEST	ACTION	RETURN
Program Name 1	script command 1	
	script command 2	
	script command 3	
	script command 4	
	script command 5	
End		
Program Name 2	script command 1	
	script command 2	
	:	
	:	

Then the OpenMES Manager wants to run a CNC program, it issues a Run command to the appropriate CNC Device Driver at a station. The device driver finds the program in the file CNC\_SCR.DBF and executes it.

Request	Action	Return
go in RS232 receive	pulsbit( port0, bv0, "00000001", 500 ) Draw("-- go to RS232 receive --")	
end		
go in auto	pulsbit( port0, bv0, "00000010", 500 ) draw("-- go in auto --")	
end		
start for 0001	pulsbit( port0, bv0, "00000100", 500 ) draw("-- start for 0001 --" ) draw2( v16, "-- machine is running -- " )	
end	waitbit( port0, "00000001", 10000 )	
open door	pulsbit( port0, bv0, "00001000", 500 ) draw( "-- open door --" ) draw2( v16, "-- door is opened --" )	
end	waitbit( port0, "00000010", 10000 )	
close door	pulsbit( port0, bv0, "00010000", 500 ) draw( "-- close door --" ) draw2( v16, "-- door is closed --" )	
end	waitbit( port0, "00000100", 10000 )	
open clamping device	pulsbit( port0, bv0, "00100000", 500 ) draw( "-- open clamping device -- " ) draw2( v16, "-- clamping device is opened" )	
end	waitbit( port0, "00001000", 10000 )	
close clamping device	pulsbit( port0, bv0, "01000000", 500 ) draw( "-- close clamping device --" ) draw2( v16, "-- clamping device is closed" )	
end	waitbit( port0, "00010000", 10000 )	
feedhold	pulsbit( port0, bv0, "10000000", 500 ) draw2( "-- feedhold --", "*** ALARM ***" )	
end	waitbit( port0, "00100000", 10000 )	
start for 0002	pulsbit( port1, bv0, "00000001", 500 ) draw( "-- start for 0002 --" ) draw2( v16, "-- machine is running --" )	
end	waitbit( port0, "00000001", 10000 )	
pinole out	pulsbit( port1, bv0, "00000010", 500 ) draw( "-- pinole out --" ) draw2( v16, "-- pinole is out --" )	
end	waitbit( port0, "01000000", 10000 )	
pinole in	pulsbit( port1, bv0, "00000100", 500 ) draw( "-- pinole in --" ) draw2( v16, "-- pinole is in --" )	
end	waitbit( port0, "10000000", 10000 )	

Figure 153: Sample CNC Programs in the file CNC\_SCR.DBF

### 11.2.6. CNC Script Error Messages

The error messages listed below appear in the CNC Status window when the CNC Script Interpreter encounters an invalid statement.

"(" expected OR ")" expected	<ul style="list-style-type: none"><li>• A parenthesis surrounding the command's argument list is missing.</li></ul>
End of program not found	<ul style="list-style-type: none"><li>• No <code>End</code> statement was found for the current program in the Request column of <code>CNC_SCR.DBF</code>.</li></ul>
Invalid command name	<ul style="list-style-type: none"><li>• The command name is not valid. Check the spelling.</li></ul>
Program not found	<ul style="list-style-type: none"><li>• The program name is not valid. Check the spelling.</li></ul>
Invalid system variable - Use BV0 or BV1	
Invalid bit mask	<ul style="list-style-type: none"><li>• The bit mask must be an 8-character string composed of 1s and 0s.</li></ul>
Invalid port address - Use PORT0 or PORT1 parameter variable	<ul style="list-style-type: none"><li>• Replace the invalid address with the variable <code>PORT0</code> or <code>PORT1</code>. OR Check the value assigned to parameter variables <code>PORT0</code> and <code>PORT1</code> in <code>CNC.INI</code>.</li></ul>
Unexpected number of arguments	<ul style="list-style-type: none"><li>• There are either too few or too many values in the argument list for this command.</li></ul>
Unexpected string in argument	<ul style="list-style-type: none"><li>• An argument contains a string value instead of a numeric value.</li></ul>
Unrecognized bitwise operator	<ul style="list-style-type: none"><li>• A character other than <code>&amp;</code>, <code> </code>, <code>^</code>, or <code>~</code> was specified as a bitwise operator.</li></ul>



### 11.2.6.1. CNC Script Language Commands

This section describes the CNC script language commands. Each of which is described in detail in the following sections.

#### 11.2.6.2. DownloadD()

<b>DownLoadD( )</b>		<i>Sends a G-Code file to the CNC machine via RS232</i>	
<b>Name:</b>	DownLoadD( <i>FileName</i> , <i>MemArea</i> )		
<b>Inputs:</b>	<i>FileName</i>	<ul style="list-style-type: none"> <li>• Full DOS path of G-code program to be sent to the CNC machine</li> </ul>	<ul style="list-style-type: none"> <li>• 0 - 9999</li> </ul>
	<i>MemArea</i>	<ul style="list-style-type: none"> <li>• Region in the CNC machine's memory where this program is to be loaded</li> </ul>	<ul style="list-style-type: none"> <li>• 1 - 5</li> </ul>

##### 11.2.6.2.1. Purpose

Normally a G-code file is assigned to a CNC process in the Machine Definition module. In this case, the OpenMES Manager takes care of automatically downloading this file prior to invoking the process and the DownLoadD( ) command is not needed. You should only use the DownLoadD( ) command if you cannot set up a downloading batch file.

##### 11.2.6.2.2. Function

The DownLoadD( ) command sends the G-code file *FileName* to the CNC machine using the RS232 port specified in the device driver's command line. For machines capable of retaining more than one program, you can specify the memory region where the current program is to reside.

If the parameters *Loader* and *TaskLoadedMark* have been defined, the device driver uses the batch file specified by *Loader* to perform the download (recommended). Otherwise, the device driver's internal downloader is used.

##### 11.2.6.2.3. Examples

DownLoadD(

C:\Users\Public Documents\Intelitek\OpenCIM\WSn\filename,  
memory area (optional))

This statement sends the file MILLPART.G to memory region 1 in the CNC machine.

DownLoadD(P1, P2)

When testing a machine, the following statement receives the G-code file and memory region that were defined in the Parameter field of the device driver's Control Panel.

## 11.2.6.3. Draw( )

<b>Draw( )</b>		<i>Prints a line to the screen</i>	
<b>Name:</b>	Draw(line_of_text)		
<b>Inputs:</b>	line_of_text	<ul style="list-style-type: none"> <li>• String to display in the CNC Status window</li> </ul>	<ul style="list-style-type: none"> <li>• 0 - 80 characters</li> </ul>

## 11.2.6.3.1. Purpose

Viewing status messages during the operation of a CNC machine can be helpful in troubleshooting problems and verifying the proper functioning of the machine. Messages can also instruct the operator of the machine when a manual procedure must be performed.

These messages can be particularly helpful when dealing with machines which have either no display of their own or only a very limited status panel.

## 11.2.6.3.2. Function

The **Draw( )** command prints the string line\_of\_text in the CNC Status window. This window appears on the PC running the CNC Device Driver. The Draw( ) command prints each string on a new line.

The message string can be from 0 - 80 characters long. This argument can consist of either a string literal enclosed in quotation marks (e.g. "Drilling in progress") or a parameter variable (V1 - V16, P1 - P8).

## 11.2.6.3.3. Examples

```
Draw(P3)
```

```
Draw(V5)
```

```
Draw("Door Open")
```

## 11.2.6.4. Draw2( )

<b>Draw2( )</b>		<i>Prints 2 lines to the screen</i>	
<b>Name:</b>	Draw2( <i>text_line_1</i> , <i>text_line_2</i> )		
<b>Inputs:</b>	<i>text_line_1</i>	• First string to display in the CNC Status window	• 0 - 80 characters
	<i>text_line_2</i>	• Second string to display in the CNC Status window	• 0 - 80 characters

## 11.2.6.4.1. Purpose

When there is more than one line of text to display, it is convenient to use the **Draw2( )** command to print two lines of text with one command call. Using the **Draw2( )** command is also faster than making two successive calls to the **Draw( )** command. This can be an advantage when running in a busy, real-time environment.

## 11.2.6.4.2. Function

The **Draw2( )** command prints the strings *text\_line\_1* and *text\_line\_2* in the CNC Status window. This window appears on the PC running the CNC Device Driver. The **Draw2( )** command prints each string on a new line.

Each message string can be from 0 - 80 characters long. These arguments can consist of either a string literal enclosed in quotation marks (e.g. "Machine overheated!") or a parameter variable (V1 - V16, P1 - P8).

## 11.2.6.4.3. Examples

```
Draw2(P3, V2)
```

```
Draw2(V16, V5)
```

```
Draw2("Part ready", P8)
```

11.2.6.5. PulsBit( )

<b>PulsBit( )</b>		<i>Turns on the designated bits of an output port for a specified duration</i>	
<b>Name:</b>	<b>PulsBit</b> ( <i>portn, mask1, mask2, time_to_puls</i> )		
<b>Inputs:</b>	portn	<ul style="list-style-type: none"> <li>Address of the output port to be modified</li> </ul>	<ul style="list-style-type: none"> <li>0x0000 - 0xFF</li> </ul>
	mask1	<ul style="list-style-type: none"> <li>An 8-character string containing 1's and 0's representing a bit mask. All bits set to 1 are held high for the duration of time_to_puls.</li> </ul>	<ul style="list-style-type: none"> <li>"00000000" - "11111111"</li> <li>V1 - V16</li> <li>P1 - P16</li> </ul>
	mask2	<ul style="list-style-type: none"> <li>An 8-character string containing 1's and 0's representing a bit mask. All bits set to 1 are held high for the duration of time_to_puls.</li> </ul>	<ul style="list-style-type: none"> <li>"00000000" - "11111111"</li> <li>V1 - V16</li> <li>P1 - P16</li> </ul>
	time_to_puls	<ul style="list-style-type: none"> <li>Number of milliseconds to pause program execution while asserting the specified high bits</li> </ul>	<ul style="list-style-type: none"> <li>CNCDriverTimer - 2147483647</li> <li>V1 - V16</li> <li>P1 - P16</li> </ul>

11.2.6.5.1. Purpose

Some operations of a CNC machine are time-based as opposed to operations that signal their completion via a status line. The PulsBit( ) command provides a convenient way of executing an operation for a specified time period.

For example, after a part has been machined, it may be necessary to rinse it with water for 30 seconds before removing it from the CNC machine. The PulsBit( ) command can be used to turn on the bit which controls the rinse cycle for the required period of time.

11.2.6.5.2. Function

The PulsBit( ) command gives you the means to control CNC operations for a specified period of time. It turns on the designated bits of an output port for a specified duration.

The portn argument specifies the output port which contains the bit(s) that operate the control line(s) you are interested in.

mask1 can be set to either:

- The current value of the output port, BVn

- An absolute bit mask value (see description of *mask2* below)

You specify which ctrl lines should be pulsed on and off by constructing a bit mask, *mask2*. The *mask2* argument is an 8-character string composed of 1's and 0's in ASCII text. This argument can consist of either a string literal enclosed in quotation marks (e.g. "10000000") or a parameter variable (V1 - V16, P1 - P8).

The `PulsBit( )` command performs a bitwise OR operation between *mask1* and *mask2*. It assigns the result to the output port for *time\_to\_puls* milliseconds. It then resets the port to its original value. The minimum `TIME_TO_WAIT` is the value of the parameter `CNCDriverTimer` found in `CNC.INI`.

The following table shows all the possible ways that `PulsBit( )` can affect a single bit position of an output port when *mask1* = BVn:

<b>PulsBit( )</b>			
Starting Value of an Output Port Bit ( <b>mask1 = BVn</b> )	Corresponding Bit in Bit Mask ( <b>mask2</b> )	Control Line During Execution of <b>PulsBit( )</b>	Control Line After Execution of <b>PulsBit( )</b>
0	0	0 - Off	0 - Off
0	1	1 - On	0 - Off
1	0	1 - On	1 - On
1	1	1 - On	1 - On

### 11.2.6.5.3. Examples

`PulsBit(PORT0, BV0, "10000000", 30000)`

This example turns on control line # 7 that is connected to the PC's output port 0 for 30 seconds. The remaining bits in the port retain their current values during and after execution of `PulsBit( )` since their values in the bit mask are 0.

`PulsBit(PORT1, BV1, V5, 100000)`

The bits in output port 1 are ORed with the bit mask in variable *V5*. The result is written to output port 1 and the corresponding control lines are set on and off for 100 seconds. Afterwards, the original value of output port 1 is restored.

`PulsBit(PORT1, BV1, P4, P7)`

The bits in output port 1 are ORed with the bit mask in parameter variable *P4*. The result is written back to output port 1 and the corresponding control lines are set on and off for a period of *P7* milliseconds. Afterwards, the original value of output port 1 is restored.

## 11.2.6.6. SendMsg( )

<b>SendMsg( )</b>		<i>Sends a predefined message to another CIM entity</i>	
<b>Name:</b>	SendMsg(msg_to_send)		
<b>Inputs:</b>	msg_to_send	• Index to predefined messages stored in VC2_WM.DBF	• 0 - 9999

## 11.2.6.6.1. Purpose

In a CIM environment, a CNC machine must report its status to other CIM entities such as:

- The OpenMES Manager which handles production scheduling and tracking
- Devices which are dependent on this machine (e.g. the robot that tends the machine)
- The Graphic Production Module which displays the machine's status

The *SendMsg( )* command informs these entities when the CNC machine has completed processing a part, when there is a problem that causes an alarm condition, etc. This command uses a set of predefined messages to perform this function. Each message has an associated ID and destination device address.

You can generate real-time status messages by inserting the *SendMsg( )* command throughout a program.

You can add your own custom messages to the message file. For example, this capability is useful if you are programming a robot to tend this CNC machine. You could define a message to notify the robot when the machine is ready to receive a part and another message to inform the robot that the part is ready to be picked up. You would use the *SendMsg( )* command to send these messages.

## 11.2.6.6.2. Function

The *SendMsg( )* command sends predefined real-time status messages to any CIM entity. The argument *msg\_to\_send* specifies the ID number of a message stored in the file VC2\_WM.DBF. This ID number is sufficient to deliver the message because there is a destination address associated with each message in this file.

### 11.2.6.6.3. Examples

SendMsg (2582)

This statement finds the message with the ID number of 2582 in the file VC2\_WM.DBF. It then sends this message to the destination device listed in this message record.

SendMsg (P4)

SendMsg (V12)

### 11.2.6.7. SetBit( )

<b>SetBit( )</b>		<i>Modifies the bits of the specified output port</i>	
<b>Name:</b>	<b>SetBit(portn, mask1, bo, mask2)</b>		
<b>Inputs:</b>	<i>portn</i>	<ul style="list-style-type: none"> <li>Address of the output port to be modified</li> </ul>	0x0000 - 0xFFFF
	<i>mask1</i>	<ul style="list-style-type: none"> <li>An 8-character string containing 1's and 0's representing a bit mask (typically the current value of output portn, BVn)</li> </ul>	"00000000" - "11111111" V1 - V16 P1 - P16
	<i>bo</i>	<ul style="list-style-type: none"> <li>A single character designating the bitwise operation to be performed</li> </ul>	& - AND   - OR ^ - XOR ~ - NOT
	<i>mask2</i>	<ul style="list-style-type: none"> <li>An 8-character string containing 1's and 0's representing a bit mask</li> </ul>	"00000000" - "11111111" V1 - V16 P1 - P16

#### 11.2.6.7.1. Purpose

The control lines of CNC machine are commonly mapped to bits in a PC's output port(s). When a bit is toggled on and off, it controls the corresponding function on the CNC machine. For example, suppose bit 3 is mapped to the door on the CNC machine. Setting bit 3 to one would close the door and setting it to zero would open the door.

By setting the appropriate bit(s) to the desired value, the *SetBit( )* command allows you to control a CNC machine.

#### 11.2.6.7.2. Function

The *SetBit( )* command allows you to modify a set of bits in an output port in order to control the operation of a CNC machine.

The *portn* argument specifies the output port which contains the bit(s) that operate the control line(s) you are interested in setting. Each I/O port on a PC contains 8 bits.

*mask1* can be set to either:

The current value of the output port, BVn

An absolute bit mask value (see description of *mask2* below)

Typically, *mask1* would be set to the system variable BVn, the current value of the output port. Using BVn allows you to set only the bits you are interested in while preserving the values of the rest.

Alternatively, you could set the port to an absolute value by specifying a bit mask for *mask1* instead of BVn. For example, to reset the port to a known value, you could specify the same bit mask value for *mask1* and *mask2* and use an OR operation between them. This would assign the value of the bit masks to the output port regardless of the port's previous value.

You can set the value of any group of bits in an output port by using the appropriate bit mask, *mask2*, and bitwise operator, *bo*. The *mask2* argument is an 8-character string composed of 1's and 0's in ASCII text. This argument can consist of either a string literal enclosed in quotation marks (e.g. "10000000"), or a parameter variable (V1 - V16, P1 - P8).

The following truth tables show the results of using each of the four C Language bitwise operators available:

& - AND		
Bit in <i>mask1</i>	Corresponding Bit in <i>mask2</i>	Result after SetBit ( )
0	0	0
0	1	0
1	0	0
1	1	1

- OR		
Bit in <i>mask1</i>	Corresponding Bit in <i>mask2</i>	Result after SetBit ( )
0	0	0
0	1	1
1	0	1
1	1	1

^ - XOR		
Bit in <i>mask1</i>	Corresponding Bit	Result after



	<i>in mask2</i>	<b>SetBit ( )</b>
0	0	0
0	1	1
1	0	1
1	1	0

---

~ - NOT

<b>Bit in <i>mask1</i></b>	<b>Corresponding Bit in <i>mask2</i></b>	<b>Result after SetBit ( )</b>
0	<b>Not used</b>	1
1	<b>Not used</b>	0

**11.2.6.7.3. Examples**

SetBit(PORT0, BV0, |, "10000000")

This example turns on control line # 7. This control line is connected to the PC's output port 0. The OR truth table indicates that when the mask contains a 1 in a given position, that bit will be set to 1 regardless of the bit's initial value in the output port.

SetBit(PORT1, BV1, &, V16)

The bits in output port 1 are ANDed with the bit mask in variable V16. The result is written back to output port 1 and the corresponding control lines are set on and off accordingly.

SetBit(PORT1, BV1, ^, P8)

The bits in output port 1 are XORed with the bit mask in parameter variable P8. The result is written back to output port 1 and the corresponding control lines are set on and off accordingly.

**11.2.6.8. Wait ( )**

<b>Wait ( )</b>	<i>Suspends program execution for a specified duration</i>		
<b>Name:</b>	Wait(time_to_wait)		
<b>Inputs:</b>	time_to_wait	Number of milliseconds to suspend program execution	CNCDriverTimer - 2147483647, V1 - V16, P1 - P16

**11.2.6.8.1. Purpose**

After performing an operation on a CNC machine, it is sometimes desirable to pause for a while before continuing with the next operation. For example, it may be necessary to wait 2 minutes after a certain

procedure to allow a part to cool down before a robot extracts it from the CNC machine. In this case the command *Wait(120000)* can provide the required delay before the CNC script program signals the OpenMES Manager that the part is ready.

**11.2.6.8.2. Function**

When the CNC Script Interpreter encounters the *Wait( )* command, it pauses for the indicated amount of time before executing the next program statement. The argument *time\_to\_wait* specifies the number of milliseconds the interpreter waits before resuming execution. This argument can be either an integer or a parameter variable (V1 - V16, P1 - P16). The minimum *time\_to\_wait* is the value of the parameter *CNCDriverTimer* found in *CNC.INI*.

**11.2.6.8.3. Examples**

*Wait(2000)*

This statement causes the CNC Script Interpreter to pause for 2 seconds.

*Wait(V16)*

*Wait(P8)*

The length of the pause resulting from each of these two statements depends on the values of variables *V16* and *P8*.

**11.2.6.9. WaitBit( )**

<b>WaitBit( )</b>		<i>Suspends execution until the specified bit(s) are set to one or until the specified bit pattern appears on an input port</i>	
<b>Name:</b>	<b>WaitBit(portn, mask, time_to_wait)</b>		
<b>Inputs:</b>	<i>portn</i>	<ul style="list-style-type: none"> <li>Address of the output port to be modified</li> </ul>	0x0000 - 0xFFFF
	<i>mask</i>	<ul style="list-style-type: none"> <li>An 8-character string containing 1's and 0's representing a bit mask</li> </ul>	"00000000" - "11111111", V1 - V16, P1 - P16
	<i>time_to_wait</i>	<ul style="list-style-type: none"> <li>Maximum number of milliseconds to suspend program execution while waiting for a bit pattern</li> </ul>	CNCDriverTimer - 2147483647, V1 - V16, P1 - P16

### 11.2.6.9.1. Purpose

After performing an operation on a CNC machine, it is frequently necessary to wait for a status line to signal that the operation was successfully performed. Status lines from a CNC machine are connected to an I/O board which maps each line to a bit in a PC input port.

By examining the value of these input port bits, it is possible to determine information about a machine such as:

Status Line	Example
An operation is completed.	Bit 0 Drilling in progress = 0 Hole drilled = 1
An alarm condition has occurred.	Bit 1 Normal temperature = 0 Machine overheated = 1
The position of a component on a CNC machine.	Bit 2 Door open = 0 Door closed = 1

The `WaitBit()` command allows you to read a set of status lines in order to monitor the operation of a CNC machine.

### 11.2.6.9.2. Function

The `WaitBit()` command monitors an input port, `portn`. It compares the value of this port with the bit mask argument, `mask`. This command waits for the specified interval for one of the following conditions to be true:

- An exact match occurs between all 8 bits of the input port and the bit mask.
- A bit equal to 1 in `mask` matches up with the corresponding bit equal to 1 in the output port. For example, bits 7 and 5 below meet this condition:
  - 10100000 ⇐ `mask`
  - 11110000 ⇐ `BVn`

When one of these conditions is true, the Command Interpreter prints in the Status window:

```
--- Condition is true ---
```

It then proceeds to execute the next command.

The `WaitBit()` command monitors the port for the period of time specified in the argument `time_to_wait` (in milliseconds). This argument can be either an integer or a parameter variable (`V1 - V16`, `P1 - P16`). The minimum `time_to_wait` is the value of the parameter `CNCDriverTimer` found in `CNC.INI`.

If neither of the above conditions occurs during this interval, the command times out. The CNC Script Interpreter aborts program execution and generates the error message `WM_CIMDDE_CNCERROR`. The CNC Device Driver relays this error message back to the OpenMES Manager.

11.2.6.9.3. Examples

WaitBit(PORT1, "100001", 2000)

This statement causes the CNC Script Interpreter to check port 1 for up to 2 seconds. If status lines 0 and 7 in this port are high, the condition is true and execution resumes with the next CLINT statement. If this match does not occur within 2 seconds, an error is generated.

WaitBit(PORT0, V3, P2)

The variables *PORT0* and *V3* contain the address of the input port and the bit mask respectively. Variable *V3* is assigned its value at initialization time from the file VC2\_CNC.INI. The time out interval, *P2*, is specified at run time when this program is invoked.

11.2.6.10. WaitBitZ( )

<i>WaitBitZ</i>		<i>Suspends execution until the specified bit(s) are set to zero</i>	
<b>Name:</b>	<i>WaitBitZ(portn, mask, time_to_wait)</i>		
<b>Inputs:</b>	<i>portn</i>	<ul style="list-style-type: none"> <li>Address of the output port to be modified</li> </ul>	0x0000 - 0xFFFF
	<i>mask</i>	<ul style="list-style-type: none"> <li>An 8-character string containing 1's and 0's representing a bit mask</li> </ul>	"00000000" - "11111111", V1 - V16, P1 - P16
	<i>time_to_wait</i>	<ul style="list-style-type: none"> <li>Maximum number of milliseconds to suspend program execution while waiting for a bit pattern</li> </ul>	CNCDriverTimer - 2147483647, V1 - V16, P1 - P16

11.2.6.10.1. Purpose

The *WaitBitZ( )* command allows you to read a set of status lines in order to monitor the operation of a CNC machine. See the *WaitBit( )* command above for details.

11.2.6.10.2. Function

The *WaitBitZ( )* command monitors an input port, *portn*. It compares the value of this port with the bit mask argument, *mask*. This command waits for the specified interval for one of the following conditions to be true:

- An exact match occurs between all 8 bits of the input port and the bit mask.

A bit equal to 1 in *mask* matches up with the corresponding bit equal to 0 in the output port. For example, bits 5 and 7 below meet this condition:

- 10100000 ⇐ *mask*  
01011111 ⇐ BVn

When one of these conditions is true, the Command Interpreter prints in the Status window:

--- Condition is true ---

It then proceeds to execute the next command.

The *WaitBitZ()* command monitors the port for the period of time specified in the argument *time\_to\_wait* (in milliseconds). This argument can be either an integer or a parameter variable (*V1 - V16, P1 - P16*). The minimum *time\_to\_wait* is the value of the parameter *CNCDriverTimer* found in *CNCVDn.INI*.

If neither of the above conditions occurs during this interval, the command times out. The CNC Script Interpreter aborts program execution and generates the error message *WM\_CIMDDE\_CNCERROR*. The CNC Device Driver relays this error message back to the OpenMES Manager.

11.2.6.10.3. Examples

WaitBitZ(PORT1, "10000001", 2000)

This statement causes the CNC Script Interpreter to check port 1 for up to 2 seconds. If status lines 0 and 7 in this port are low, the condition is true and execution resumes with the next CLINT statement. If this match does not occur within 2 seconds, an error is generated.

WaitBitZ(PORT0, V3, P2)

The variables *PORT0* and *V3* contain the address of the input port and the bit mask respectively. Variable *V3* is assigned its value at initialization time from the file *CNCVDn.INI*. The time out interval, *P2*, is specified at run time when this program is invoked.

11.2.6.11. WaitFile( )

<b>WaitFile( )</b>		<i>Suspends execution until the specified file is created</i>	
<b>Name:</b>	WaitFile( <i>String, time_to_wait</i> )		
<b>Inputs:</b>	<i>String</i>	<ul style="list-style-type: none"> <li>Any valid MS-DOS file name.</li> </ul>	Any valid MS-DOS file name.
	<i>time_to_wait</i>	<ul style="list-style-type: none"> <li>Number of milliseconds to suspend program execution</li> </ul>	CNCDriverTimer - 2147483647, V1 - V16, P1 - P16

11.2.6.11.1. Purpose

The command is generally used to get a status message in order to continue execution of the process after uploading a G-code program to a CNC machine.

11.2.6.11.2. Function

The *WaitFile()* command waits until the specified file is created during a specified interval. If the specified file has not been created during the specified interval, the command times out. The CNC Script Interpreter aborts program execution and generates the error message WM\_CIMDDE\_CNCERROR. The CNC Device Driver relays this error message back to the OpenMES Manager.

11.2.6.11.3. Examples

```
WaitFile(P1, V1)
WaitFile(V1, P1)
WaitFile(V1, V2)
WaitFile(P1, P2)
WaitFile("
C:\Users\Public Documents\Intelitek\OpenCIM\WSn\filename"),
wait time)
```

11.2.6.12. WaitString()

<b>WaitString()</b>		<i>Suspends execution until the specified string arrives from Network</i>	
<b>Name:</b>	WaitString( <i>String</i> , <i>time_to_wait</i> )		
<b>Inputs:</b>	<i>String</i>	<ul style="list-style-type: none"> <li>A string that specifies the beginning or end of an operation.</li> </ul>	Any string that contains an address in the OpenMES environment.
	<i>time_to_wait</i>	<ul style="list-style-type: none"> <li>Number of milliseconds to suspend program execution</li> </ul>	CNCDriverTimer - 2147483647, V1 - V16, P1 - P16

11.2.6.12.1. Purpose

After performing an operation on a CNC machine, it is usually necessary to wait for a status message in order to confirm that the operation was performed successfully.

11.2.6.12.2. Function

The *WaitString()* command waits for a string during a specified interval. If the CNC device driver doesn't receive the string during the specified interval, the command times out. The CNC Script Interpreter aborts program execution and generates the error message WM\_CIMDDE\_CNCERROR. The CNC Device Driver relays this error message back to the OpenMES Manager.

11.2.6.12.3. Examples

```
WaitString(V1, V2)
WaitString(V1, P1)
WaitString(P1, V1)
WaitString("Test is done", 10000)
```

11.2.6.13. SendString( )

<b>SendString( )</b>		<i>Sends a string to the specified OpenMES device ( e.g. to a robot)</i>	
<b>Name:</b>	SendString( <i>Address</i> , <i>String</i> )		
<b>Inputs:</b>	<i>Address</i>	<ul style="list-style-type: none"> <li>Name of the workstation in the OpenMES environment.</li> </ul>	<ul style="list-style-type: none"> <li>Any of the OpenMES predefined commands.</li> </ul>
	<i>String</i>	<ul style="list-style-type: none"> <li>String to be sent to be sent to the defined address</li> </ul>	<ul style="list-style-type: none"> <li>Any string that contains an address in the OpenMES environment.</li> </ul>

11.2.6.13.1. Purpose

When a program is to be run in the ACL controller, a string (recognizable by the ACL controller) is sent to the ACL controller and the address tells the controller where to send the string.

11.2.6.13.2. Function

The *SendString( )* command sends predefined commands to any CIM entity.

11.2.6.13.3. Examples

```
SendString(P1, P2)
SendString(V1, V2)
SendString(V1, P1)
SendString("WS0 DDE ACL 25", "RUN SSCNC")
```

11.2.6.14. MSDOS( )

<b>MSDOS( )</b>		<i>Performs any MS-DOS command</i>	
<b>Name:</b>	MSDOS( <i>String</i> )		
<b>Inputs:</b>	<i>String</i>	<ul style="list-style-type: none"> <li>Any valid MS-DOS command.</li> </ul>	<ul style="list-style-type: none"> <li>Any valid MS-DOS command.</li> </ul>

**11.2.6.14.1. Purpose**

The command provides an interface from OpenMES to the MS-DOS operating system.

**11.2.6.14.2. Function**

The *MSDOS()* command launches the MS-DOS command interpreter with the string specified at the function’s input.

**11.2.6.14.3. Examples**

```
MSDOS (V1)
MSDOS (P1)
MSDOS ("LOADER.BAT FILE.DAT")
```

**11.2.6.15. MSWINDOWS()**

<b>MSWINDOWS()</b>		<i>Launches any MS-WINDOWS executable file</i>	
<b>Name:</b>	MSWINDOWS( <i>String</i> )		
<b>Inputs:</b>	<i>String</i>	<ul style="list-style-type: none"> <li>Any valid MS-Windows command line.</li> </ul>	<ul style="list-style-type: none"> <li>Any valid MS-Windows command line.</li> </ul>

**11.2.6.15.1. Purpose**

The command provides an interface from OpenMES to the MS-WINDOWS operating system.

**11.2.6.15.2. Function**

The *MSWINDOWS()* command launches the MS-WINDOWS executable file according to the string specified at the function’s input.

**11.2.6.15.3. Examples**

```
MSWINDOWS (V1)
MSWINDOWS (P1)
MSWINDOWS("[default system drive (for example
C:)]\WINDOWS\notepad.exe
C:\Users\Public Documents\Intelitek\OpenCIM\WSn\filename")
```



## 11.2.6.16. ABORT( )

<b>ABORT( )</b>	Unconditionally aborts the current CNC Device Driver program
<b>Name:</b>	ABORT ( )

## 11.2.6.16.1. Purpose

Using this command is the only way to abort a CNC Device Driver program without the OpenMES Manager.

## 11.2.6.16.2. Function

The ABORT( ) command unconditionally aborts the current CNC Device Driver program.

## 11.2.6.16.3. Examples

ABORT( )

## 11.3. ROBOT AND CNC INTERFACE

When a robot inserts a part into a CNC machine, it must coordinate its movements with the operation of the machine using a *CNC synchronization mechanism*. This mechanism is used when a robot sends a command message to a CNC machine telling it to perform a certain function. The robot then waits for a response. Only after the CNC responds does the robot's ACL program continue execution.

The following scenario describes how a typical robot and CNC machine interact when the robot inserts and removes a part from the machine:

- The robot waits while the CNC machine opens its door and vise.
- The robot enters the machine. It holds the part in place while the machine clamps the part in its vise.
- The robot exits the machine and signals the OpenMES Manager that the CNC machine is ready to be activated.
- The robot waits outside the machine until it receives a signal from the OpenMES Manager that the machine is finished.
- The CNC opens its door and waits until the robot has grasped the part before it opens its vise.
- The robot removes the part and takes it to the next location.

While the OpenMES Manager could conceivably coordinate the above interaction between a robot and a CNC machine, it is more efficient for the ACL controller to do this. This section describes how to write ACL programs that communicate with script programs found in the CNC device driver. (You should already be familiar with OpenMES ACL programming before continuing. See ACL Programming for OpenMES for more information.)

The CNC synchronization mechanism is actually a specific case of how you can send command and status messages to perform OpenMES operations.

1. It is possible to have two robots attached to a single ACL controller. In this case, you would use the ACL system file, CIMSYSM instead of CIMSYS. You would also need to adjust the sample code presented in this section to distinguish between the two robots. These changes are beyond the scope of this discussion.

The following diagram illustrates the sequence of commands that are executed when a robot inserts a part into a CNC machine. The commands shown in step 2 below are generated by the robot's PUT program for the CNC machine.




Figure 12-8: Sequence of Commands when a Robot Tends a CNC Machine

The following table describes the dialog that occurs between a robot and its CNC machine. This table shows the sequence of CNC commands generated by the PUT and GET programs that insert and remove a part from a machine.

Robot Action	Robot Request	CNC Response
<b>PUT Part into CNC Machine</b>		
Robot brings part to entrance of CNC machine and waits for door to open.	<b>Open Door</b>	Door Open
Robot enters CNC machine with part and waits for vise to open.	<b>Open Vise</b>	Vise Open
Robot places part in vise and waits for vise to close.	<b>Close Vise</b>	Vise Closed
Robot releases part, withdraws from CNC, and waits for door to close.	<b>Close Door</b>	Door Closed
Robot signals OpenMES Manager that part is ready to be machined. The OpenMES Manager turns on the CNC machine.		
(The robot does NOT directly turn on the CNC machine by sending an activate command. Instead, the OpenMES Manager sends the activate CNC command message to the machine so that it can take care of downloading the G-code needed to process this part.)		
<b>GET Part from CNC Machine</b>		
Robot moves to entrance of CNC and waits for door to open.	<b>Open Door</b>	Door Open
Robot enters CNC, grasps part, and waits for vise to open.	<b>Open Vise</b>	Vise Open
Robot removes part from CNC machine.		

### 11.3.1. Writing Scorbse Programs for the CNC Machine

This section describes briefly how to write Scorbse programs for the CNC machine and displays various examples. It includes the following:

- Receiving Strings from an OpenMES Device Driver
- Receiving Notifications from the CNC Machine and Sending Messages to the CNC Device Driver

#### 11.3.1.1. Receiving Strings from an OpenMES Device Driver

The Scorbse software automatically recognizes and executes the following two string formats, for example:

- SET PRGNM=301: In this string format, PRGNM is the name of the Scorbse variable and this statement is equivalent to the Set Variable PRGNM = 301 instruction in the Scorbse program. This string is generally defined in the **Program** column of the CIM Machine Definition utility in the OpenMES Manager application.
- Run STRTM: In this string format, STRTM is the Scorbse subroutine name and the string is equivalent to the Call STRTM instruction in the Scorbse program. The Scorbse program should contain the STRTM subroutine, as shown in the following example:

Set Subroutine STRTM

Print to Screen: STRTM.PRGNM = 'PRGNM'

Call Subroutine SCRIPT.OPENPORT (2)

Call Subroutine SCRIPT.SENDFILE(2, PRGNM)

Call Subroutine SCRIPT.CLOSEPORT(2)

Return from Subroutine

- ❗ *The STRTM subroutine is executed in parallel to the Pick and Place operation of the robot*
- ❗ *The STRTM subroutine does not contain axis control Scorbse commands.*
- ❗ *The Run STRTM string is generally defined in the CNC device driver script file.*

### 11.3.1.2. Receiving Notifications from the CNC Machine and Sending Messages to the CNC Device Driver

The USB controller's digital input can be connected to the CNC machine's digital output. The CNC machine's G-Code program may change the status of the digital output that is connected to USB controller.

The Scorbase program can recognize changes to the status of the digital input and then run a user defined subroutine (END\_LATHE23), which can be executed in parallel to the Pick and Place operation of the robot, as shown in the following example:

Set Subroutine PUT023

Print to Screen: PUT PART TO CNC MACHINE CHUCK (CNC22)

...

...

...

Enable Input Interrupt 1

On Input Interrupt 1 On Run Subroutine END\_LATHE23

Send Message \$Finish to MANAGER ID TASK\_ID

Send Message \$End to MANAGER ID TASK\_ID

Return from Subroutine

Set Subroutine END\_LATHE23

Send Message ENDLATHE to Device Driver ID 23

Disable Input Interrupt 1

Return from Subroutine

**i** Pay attention to the Enable/Disable Input Interrupt instructions to ensure system safety.

### 11.3.2. Writing ACL Programs for the CNC Machine

The CNC synchronization mechanism is used when a robot must order a CNC machine to perform an operation and wait until the machine signals that it has completed the operation. The previous table shows the sequence of events in a set of PUT and GET programs that communicate with a CNC machine. The sample ACL code shown in this section demonstrates how to write these programs and implement the CNC synchronization mechanism.

You must code this synchronization mechanism into each of the following programs. Note the order in which programs are activated as shown in the figure below.

- ACL Controller**      The PUT and GET programs which tell the robot how to insert and remove parts from a CNC machine.
  
- CNC Device Driver**      CNC script programs (executed by the CNC device driver) which are activated by a robot request. For example:  
 OPEN DOOR, CLOSE DOOR, OPEN VISE, CLOSE VISE
  
- ACL Controller**      A group of short ACL programs which set a semaphore variable that announces that the CNC machine has completed the requested operation (e.g. DROPN - door open, DRCLS - door closed, VCOPN - vise open, VCCLS - vise closed).




Figure 12-9: Sequence of Program Activation During CNC Synchronization

**Sequence of Program Activation**

---

- |  |   |
|--|---|
| <p><b>1.</b> RUN GTxxx<br/>RUN PT001</p>       | <p>Pick-and-place command from the OpenMES Manager runs the ACL program PT001 to insert a part into the CNC machine. (The constant .CNC1 equals 001, the device ID of the machine.)</p> |
| <p><b>38.</b> .CNCREQ .CNC1<br/>OPEN DOOR</p>  | <p>Activates CNC script program OPEN DOOR in CNC device driver #1.</p>  |
| <p><b>39.</b> SENDSTR(V1,"RU<br/>N DROPN")</p> | <p>Sends an acknowledgment by running the ACL program DROPN. This line sends a run command to the ACL device driver whose address is specified in variable V1.</p>                      |
| <p><b>40.</b> SET<br/>DOOR = OPEN</p>          | <p>Causes the program PT001 to resume.</p>  |

The following ACL statement sends a command to a CNC machine:

```
.CNCREQ .CNC1 OPEN DOOR
```

The macro and symbolic constant in this statement expand to:

```
PRINTLN "%CNCREQ 001 OPEN DOOR "
```

Each item in this statement is explained below:

---

**ACL Statement that Requests a CNC Operation**

---

- |                  |  |
|------------------|--|
| <p>PRINTLN</p>   | <p>This ACL command sends a message to the robot's ACL device driver via a serial connection between the ACL controller and the Station Manager PC.</p>  |
| <p>%CNCREQ</p>   | <p>This string signals the ACL device driver that the rest of this message is a command intended for a CNC machine. The ACL device driver interprets and formats the message accordingly.</p>  |
| <p>001</p>       | <p>The device ID of the CNC machine that the robot is tending; used as part of the destination address.</p>  |
| <p>OPEN DOOR</p> | <p>This string is the name of the script program which the CNC device driver will execute. The robot waits until this script program sends a response message indicating that it has finished performing the requested CNC operation. You can check the name of CNC script programs by looking at the Command List on the CNC Control Panel.</p> |
-

When an ACL program needs to activate an operation on another device and wait for an acknowledgment, it can use the CNC synchronization mechanism. The sample ACL code below demonstrates an efficient way to implement this mechanism:

```
:
:
SET DOOR = 0
```

The global variable DOOR represents the status of the door on the CNC machine. It can have one of the following values:

0 - Door status is about to change. CNC request is pending.

OPEN - Door is open.

CLOSE - Door is closed.

The variable DOOR is used as a semaphore to signal that the CNC machine has completed the requested operation (i.e. when a response has been received from the CNC machine). This variable is reset to 0 here to indicate that a CNC request is pending.

```
.CNCREQ .CNC1 OPEN DOOR
```

This line uses an ACL macro (explained above) to send the command message "OPEN DOOR" to CNC machine #1.

```
WAIT DOOR = OPEN
```

This line suspends execution of this ACL program until an acknowledgment is received from the CNC machine. (Note that this line does NOT assign the value of OPEN to the variable DOOR. The string DOOR = OPEN is a logical condition which must be satisfied before the WAIT statement allows execution to continue.)

```
:
:
```

In this example, the CNC machine signals that the door is open by sending a command to the ACL device driver to run a short ACL program, DROPN. This program sets the global variable DOOR equal to OPEN. This assignment satisfies the WAIT condition and execution continues.

**Tip:** *The WAIT statement is more efficient than using a polling loop to continually check the value of the variable DOOR. Unlike a loop, this statement suspends execution of the program until the condition is satisfied. Suspending execution allows other active ACL programs to run faster.*



The following is a set of sample ACL programs: GET, PUT, DROPN, DRCLS, VCOPN, and VCCLS. These programs insert and remove a part from a machine using the CNC synchronization mechanism (the CNC synchronization code is highlighted):

```
.PROGRAM_GET .CNC1
.OPEN
.FAST
MOVED CIM[260]
MOVED CIMB[260]
MOVED CIM[260]
JAW 50
    SET DOOR = 0
    .CNCREQ .CNC1 OPEN DOOR
    WAIT DOOR = OPEN
.MEDIOM
MOVED CIM[261]
SPLINE CIM 262 263
.MEDIOM
MOVED CIM[288]
.SLOW
MOVED CIM[289]
.CLOSE
    SET VISE = 0
    .CNCREQ .CNC1 OPEN VISE
    WAIT VISE = OPEN
.MEDIOM
MOVED CIM[288]
.MEDIOM
MOVED CIM[262]
.FAST
.START
MOVED CIM[261]
MOVED CIM[260]
.END_GET
```

```
PROGRAM DROPN
SET DOOR = OPEN
END
```

```
PROGRAM DRCLS
SET DOOR = CLOSE
END
```

```
PROGRAM VCOPN
SET VISE = OPEN
END
```

```
PROGRAM VCCLS
SET VISE = CLOSE
END
.PROGRAM_PUT .CNC1
.SYNC
.FAST
MOVELD CIM[260]
IF PART = 2
    ORIF PART =4
    GOSUB GIJIN
ENDIF
MOVED CIM[260]
MOVED CIMB[260]
```

```
        SET          DOOR = 0 ;
        .CNCREQ      .CNC1 OPEN DOOR
        WAIT         DOOR = OPEN
.MEDIOM
MOVED   CIM[261]
SPLINE  CIM 262 263
        SET          VISE = 0
        .CNCREQ      .CNC1 OPEN VISE
        WAIT         VISE = OPEN
.MEDIOM
MOVED   CIM[268]
.SLOW
MOVED   CIM[269]
JAW 50
.MEDIOM
MOVED   CIM[270]
.SLOW
.CLOSE
MOVED   CIM[271]
        SET VISE = 0
        .CNCREQ      .CNC1 CLOSE VISE
        WAIT         VISE = CLOSE
.MEDIOM
MOVED   CIM[270]
MOVED   CIM[262]
.FAST
MOVED   CIM[261]
MOVED   CIM[260]
MOVED   CIMB[1]
        SET          DOOR = 1
        .CNCREQ      .CNC1 CLOSE DOOR
        WAIT         DOOR = CLOSE

.FINISH
.OPEN
.END
.END_PUT
```

### 11.3.3. Using CNC Script Programs for ACL Program Response

When a CNC script program has completed an operation requested by an ACL program, it must send back an acknowledgment to the ACL program. The following script statement sends this acknowledgment and is explained below:

```
SENDSTR (V1, "RUN DROPN")
```

SENDSTR	Sends the acknowledgment message to the robot's ACL device driver using the OpenMES network.
V1	A script parameter variable containing the destination address of the robot which is to receive this acknowledgment. This variable is assigned in a parameter file (e.g. CNC1.INI) when the CNC device driver starts up.
"RUN DROPN"	A command to run the ACL program DROPN which sets a semaphore variable indicating that the CNC door is open. This ACL program name corresponds to the operation being performed. For example: DRCLS - door closed VCOPN - vise open

The following sample CNC script program shows how this statement appears at the end of the script after the requested operation has completed:

```
PROGRAM OPEN DOOR
PULSBIT(PORT0,BV0,"00001000",600)
DRAW( --- OPENING THE DOOR --- )
WAITBIT( PORT0, "00000010", 20000 )
DRAW( --- DOOR IS NOW OPEN --- )
SENDSTR( V1, "RUN DROPN" )
END
```

Figure 12-10: Sample CNC Script Program that Sends an Acknowledgment to a Robot

### 11.3.4. Writing Portable CNC Script Programs

If you have multiple CNC machines which use the same commands, you can reuse the same CNC script file (e.g. CNC\_SCR.DBF) to control these machines. Follow the example below which shows how to write portable CNC scripts using a parameter variable to specify a destination address:

**Portable:** SENDSTR (V1, "DROPN")

**Not Portable:** SENDSTR(WS3 ACL43, "DROPN")

Use a text editor to assign V1 in a parameter file (e.g. CNC1.INI) as follows:

```
:
:
V1 = ACL43
:
:
```

The elements in this example are explained below:

WS3	The name of the Station Manager PC (as found in the file SETUP.CIM) running the CNC device driver. Substitute the appropriate workstation number for the 3 in this example.
ACL	The type of communication channel used to send messages to this device. Use <code>ACL</code> for any device attached to an ACL controller.
43	The device ID that indicates which device driver is to receive this message. Substitute the device ID of the robot which tends this machine for the 43 in this example.

### 11.3.5. Adjustments for Single Robots Tending Two Machines

If a single robot is tending two CNC machines, make the following adjustments to the sample programs shown in this section:

- In the ACL controller, use two separate global variables, `DOOR1` and `DOOR2`, for each machine (instead of the single variable `DOOR`).
- Use two separate ACL programs, `DRON1` and `DRON2`, to set these variables (instead of the single program `DROPN`).

The OPEN DOOR script programs on the CNC machines would call their associated ACL program, `DRON1` or `DRON2`.

### 11.3.6. ACL Controller Backup and Restore

Because there is always a chance that system files could be altered or destroyed, we recommend keeping backup files of your OpenMES system. Should your OpenMES system crash and need to be replaced, the backup files can be used to restore the system. These procedures should only be performed by the system supervisor.

The Backup procedure involves three stages:

1. Back up the ACL controllers to the Station Manager PCs
41. Back up the Station Manager PCs to the OpenMES Manager PC
42. Back up the OpenMES Manager PC.

- ❗ *Do not perform Backup procedures while the OpenMES is running because currently running programs may be aborted and data files may be in an unstable state.*
- ❗ *Always keep robot positions, ACL programs and parameters on disk.*
- ❗ *Back up and restore the entire system regularly to ensure good backup at all times.*

### 11.3.7. How to Back Up an ACL Controller

An entire backup of the ACL controller includes all robot parameters, positions and programs.

To back up the controller, do the following:

- ❶
- ❷
- ❸

Procedure

Backing Up the ACL  
Controllers

1. From the ATS main screen on the Station Manager PC, press [Shift + F10] for Backup. The Backup Manager screen appears.
2. Make sure the Backup Directory field is correct before proceeding.
3. Select "Parameter" in Backup/Restore.
4. Type Parameter in the File Name field and press [Enter].
5. Press [F3] for backup; a warning message appears stating that All running programs will be aborted. Are you sure (Y/N)?
6. Type Y; asterisks appear and move across the bottom of the screen representing a time bar. When the time bar lapses, Done appears on the screen confirming that the backup copy has been completed successfully.
7. Press [Enter] until the cursor selects "Positions" in Backup/Restore.
8. Type Position in the File Name field and press [Enter].
9. Repeat steps 5 and 6 for the backup of Positions.
10. Press [Enter] until the cursor selects "Programs" in Backup/Restore.
11. Type Programs in the File Name field and press [Enter].
12. Repeat steps 5 and 6 for the backup of Programs.
13. Press [Enter] until the cursor selects "All" in Backup/Restore.
14. Type All in the File Name field and press [Enter].
15. Repeat steps 5 and 6 for the backup of All.
16. Verify that all the backup files you copied can be found in the *WSn Robotn* directory. The backup file extension is .CBU (e.g. POSITION.CBU).

## 11.4. OPTIMIZATION ENHANCEMENT USING OPEN SOURCE

The Optimization Manager of OpenMES enables users to choose any combination of algorithms and weights for the machine queues, using the algorithms supplied in the installation.

Using Open Source in OpenMES, the advanced programmer can add new algorithms to the existing list. The new algorithms are automatically added to the OpenMES Optimization Manager. The user can then choose the new algorithms from the Algorithms drop down list in the Optimization Manager and test them by running the OpenMES Manager. The new algorithm can use any of the parameters that are included in the OpenMES database.

For detailed instructions on adding new algorithms refer to the ReadMe file that is provided with the source files of the QueAlgDef project.

## 11.5. EXPERIMENTING WITH PRODUCTION STRATEGIES USING THE A-PLAN

The A-Plan is a table of sequential instructions which the OpenMES Manager executes in order to produce the products being ordered. It is created when you submit an order. You can also edit this table manually with a z editor.

Just as you can compile and run a program without ever examining the associated assembly code, so you can submit an order and run the OpenMES production line without dealing with the A-Plan. However, advanced users may want to understand the mechanics of OpenMES production in order to optimize certain critical areas. This section explains the structure of the A-Plan and how to modify it.

The A-Plan is based on processes and operations that have been set up in the Part Definition table. For each ordered part, the A-Plan lists the procedures required to produce that part.

The relationship between the Part Definition table and the A-Plan is similar to the relationship between source code written in a high-level programming language and the resulting assembly language output after compilation. Dealing with the source code is the easiest way to understand and change a program. However, dealing with the assembly language output might be appropriate for advanced users who need to optimize certain critical areas or who want to understand more fully what is happening at the hardware level. Similarly, the Part Definition table provides an overview of the CIM production process while the A-Plan lists the underlying details.

In addition to user-defined processes, the A-Plan includes the intervening steps required to move parts from machine to machine and from station to station. When an order is submitted, the Order Entry module automatically creates the A-Plan by combining the appropriate material handling commands (described below) with the user-defined processes from the Part Definition table.

### 11.5.1. A-Plan Commands

The following discussion of the A-Plan assumes that:

- The default storage device is a single ASRS used to house empty templates, raw materials, and finished parts.
- The default assembly device is a jig machine which is used to hold parts that are in the process of being put together by a robot.

The list below shows each command that can appear in the A-Plan table. Related commands are grouped together. These groups are labeled in the Purpose column.

Purpose	A-Plan Command	Description
<b>Loop for Producing Multiple Parts of the Same Type</b>	MAKE	Defines the beginning of a loop used to produce the number of products ordered.
	NEXT	Marks the point at which production of the next ordered part begins. Note that production of the next part may begin before the current part has finished.
<b>Template Commands</b>	DELIVER	Tells the PLC to stop a specific template at a station.
	FREE	Releases an empty template so it can be returned to the ASRS.
<b>Assemble Two Parts</b>	BASE	Commands a robot to place the first part to be assembled in a jig. The OpenMES Manager waits for all subparts that belong to this assembly to arrive before placing the base part in the jig.
	PACK	Commands a robot to place a subsequent part to be assembled onto the base part in the jig. The OpenMES Manager waits for the Base command to finish before it starts executing a Pack command.
	ENDPACK	Signals the end of an assembly operation.
<b>Storage Commands</b>	GET	Reserves a part that is being stored in the ASRS.
	STORE	Sends a part to the ASRS (or other storage location) to be stored.
	RENAME	Assigns the name shown in the Part field to a finished part. This command appears in the A-Plan immediately after the last user-defined process from a Part Definition table has been performed.
<b>Robot Commands</b>	PLACE	Commands a robot to move a part or template from one location at a station to another (i.e. a pick-and-place operation). This command is used to insert parts into devices such as a laser scan meter or robot vision system. However, it is NOT used when placing a part in an assembly jig (see <i>Base/Pack above</i> ) or a CNC machine (see <i>Load below</i> ).

Purpose	A-Plan Command	Description
	LOAD	Uses a robot to insert a part into a CNC machine and downloads the appropriate G-code to the machine if required. The <code>Load</code> command is similar to the <code>Place</code> command with the added feature that it ensures the required G-code is downloaded..
	UNLOAD	Removes a part from a CNC machine. The <code>Unload</code> command is similar to the <code>Place</code> command.
<b>Comment Line</b>	NOP	This line is ignored. It can be used for adding comments or blank lines to the A-Plan.
<b>User-Defined Process</b>	<i>Process Name</i>	Executes the process as defined in the Machine Process table. Each user-defined process that appears in a Part Definition table for this product also appears in the A-Plan table.

The following A-Plan commands shown in detail are representative of how to interpret the other commands.

**MAKE**

<b>Format</b>	<code>MAKE &lt;ttl qty&gt; &lt;initial qty&gt; &lt;subsqnt qty&gt; &lt;priority type&gt; &lt;priority #&gt;</code>
<b>Description</b>	Defines the beginning of a loop used to produce the quantity ordered for each line in the Order table.
<b>SUBPART</b>	Name of the product being ordered. This name is made unique by a suffix which identifies the position of this part in the Part Definition tree.
<b>Target</b>	Sequential number that corresponds to a line number in the Order table. This number is incremented by one for each occurrence of a Make command in the A-Plan table.
<code>&lt;ttl qty&gt;</code>	Total number of products to be produced.
<code>&lt;initial qty&gt;</code>	Number of parts produced in parallel when production of this part first begins.
<code>&lt;subsqnt qty&gt;</code>	Number of parts produced in parallel after the initial quantity has been completed.



*<priority type>* Priority method used to determine which part order gets produced first. Valid methods are:  
P - Produce orders with the highest priority first.  
D - Try to finish all parts by their Due Time.  
B - Consider both priority and due time when determining the sequence of production.

*<priority #>* Priority of this order (1 - 9). A priority of 1 is most urgent, 9 is least urgent. When *<priority type>* is set to either P or B, the OpenMES Manager uses *<priority #>* to determine the sequence in which to produce orders.

**Example** MAKE COVERED\_BOX/1.1 1 1,1,1,P,1

**Note** See the NEXT command.

**GET**

**Format** GET <subpart> <storage location>

**Description** Reserves a part in a storage location that is needed to produce the current order. The default storage location is the ASRS. Parts can also be stored in a storage rack, a part feeder, or some other designated location. If no part is available, a warning message appears on the OpenMES Manager screen and a Wait status symbol on the Production screen.

<subpart> The subpart in a storage location that is being reserved.

<storage location> The place in the CIM cell from where you want to order the part. If this field is omitted, the ASRS is assumed.

**Example** GET BOX ASRS1

**Note** See also STORE and RENAME.

You can view/edit a table of A-Plan commands that is created when you submit an order. Parts that have a 1 in the # column can be produced in parallel (except for a part associated with an ONFAIL process). The commands in this table are executed from top to bottom.

Processes that have a blank entry in their Subpart column operate on the last subpart listed previously. For example, in the figure below, processes 3 and 4 operate on the BOX subpart shown in line 2. Process 6 operates on COVER/1.1 shown in line 5.

Robot pick-and-place operations are not shown in the A-Plan table. The OpenMES Manager implicitly performs these operations when it needs to move a part from one station location to another.

PART	#	PROCESS	SUBPART	TARGET	INDEX	DURAT	PARAMETER
COVERED_BOX/1	1	MAKE	COVERED_BOX/1.1		1		1,1,P,1,00:00:00
COVERED_BOX/1.1	1	GET	BOX	ASRS1			
COVERED_BOX/1.1	2	MILL2		EXPERTMILL		00:00:10	302.NC
COVERED_BOX/1.1	3	PLACE		RACK1			
COVERED_BOX/1.1	4	ASSY	COVER/1.1	JIG1		00:00:10	
COVERED_BOX/1.1	5	VIEW/FLEX				00:00:10	
COVERED_BOX/1.1	6	ONFAIL	REJECTED/1.1	TRASH1			
COVERED_BOX/1.1	7	NEXT					
COVERED_BOX/1.1	8	TARGET		ASRS1			
COVER/1.1	1	GET	COVER	ASRS1			
COVER/1.1	2	PLACE		RACK1			
COVER/1.1	3	FREE	TEMPLATE	ASRS1			
REJECTED/1.1	1	TARGET		TRASH1			
REJECTED/1.1	2	FREE	TEMPLATE	ASRS1			

SEQ	PART	QUAN	FIRST	NEXT	QUEU	PRIO	DUE TIME	N
0	COVERED_BOX	1	1		P	1		

Figure 12-11: A-Plan Table

You can track the current status of production by watching the Program View screen on the OpenMES Manager PC. This screen shows the commands that the OpenMES Manager executes to produce an order.




Figure 12-12: Program View Showing A-Plan Used to Produce an Order

The elements of the Program View screen are described in detail in Chapter 6, Operating OpenMES Manager.

## 12. Inside OpenMES

This chapter describes various OpenMES administration procedures for the advanced user. It includes the following sections

- **OpenMES Loader: DDLoader.EXE**, describes the OpenMES Loader that is used to start up all device drivers belonging to the same workstation on each Station Manager PC.
- **OpenMES Directory Structure**, describes default OpenMES directory structure of the CIM folders and files that is automatically created in the installation procedure.
- **OpenMES Database Structure**, displays lists of tables consisting of the files contained in the OpenMES database
- **Software Backup**, describes the OpenMES backup procedures.

### 12.1. OPENMES LOADER: DDLOADER.EXE

The OpenMES Loader automates the start-up of the Device Drivers under Windows. The Loader runs on each workstation PC in order to automatically start up the Device Drivers on these PCs:

OpenMES Device Drivers Started by the Loader	
Station Manager PCs	Each device driver running on this PC

You can set up the programs you want the Loader to run in an INI file that you specify on the Loader's command line. (In order to display the Path and Command Line columns of the Loader, select Show All Columns from the File drop-down menu.) Clicking on the Loader's icon on the Program Manager screen would thus start up all the programs listed in this INI file. The Loader should be used to start up all device drivers belonging to the same workstation on each Station Manager PC.




Figure 13-1: CIM Device Loader Sample

The name of this INI file typically corresponds to the station number as follows:

Workstation Naming Conventions	
WS1.INI	Settings for workstation No. 1.
WS2.INI	Settings for Workstation No. 2
⋮	

The Loader looks through the INI file for the section entitled *[Loading]* and runs the programs (maximum eight) specified. Use a text editor to edit the command line for each program in this INI file.

The following example of an INI file shows the command lines invoked by the Loader

```
[General]
CimSetupPath = ..\CIMCELL\SETUP\SETUP.CIM
⋮
[Loading]
Load1=..\BIN\BCRDRIVER.EXE BCRVD1.INI 13 /COM:2 /C
Load2=[default system drive (for example C:)]\Intelitek\Scorbase\Bin\Scorbase.EXE /I=SCBSVD1.INI
/N=11
```

#### Loader Command Lines

Each device (or controller) that is connected to a Station Manager PC requires a separate device driver running on that PC. It is possible to have a controller attached to a Station Manager PC that supports multiple devices (e.g. a robot and a bar code reader attached to a Scorbase controller). In this case, only one device driver is required (e.g. a Scorbase device driver). In this section, the term device can also refer to a controller with multiple devices.

The list below shows the name of the program that corresponds to each OpenMES device driver:

- ACL device driver: ACLDriver.EXE
- CNC device driver: CNCDriver.EXE
- Laser Scan Meter device driver: LSMDriver.EXE
- ROBOTVISIONpro device driver: RVPDriver.EXE
- PLC device driver: PLCDriver.EXE
- ULS device driver: ULSDriver.EXE
- ViewFlex device driver: ViewFlex.EXE
- Scorbase for Controller-USB Device Driver: Scorbase.EXE
- Scorbase NXC100 and XtraDrive

- Scorbace for Controller-USB PRO controller
- Hydraulic device driver HYDDriver.exe
- Pneumatic device driver PNEUDriver.exe
- Process device driver ProcDriver.exe
- BCR device driver BCRDriver.exe

The table below describes the command line switches you can specify when you invoke a device driver or program module. These switches let you specify the device, data files, and control mode that apply to a program.

All device drivers share the following command line format:

*xxx.EXE IniFile DevID /COM:n [/Simulation]*

(where *xxx* is the type of device driver).

<i>IniFile</i>	The name of the initialization file containing parameter definitions for this particular device. These parameter definitions override global values set in the file OPENMES.INI
<i>DevID</i>	<p>The unique ID number of the device as defined in the Setup program. This number is used to identify the device when communicating with the OpenMES Manager or with another CIM device (e.g. a CNC machine being tended by this robot).</p> <p>If more than one device is attached to a controller, you can specify the ID of any one of these devices (e.g. the robot's ID in the case of an ACL controller).</p>
<i>COM:n</i>	<p>The RS232 port on the Station Manager PC that the device driver uses to communicate with the device. Com ports 1 - 4 are supported. Com parameters (baud rate, parity, etc.) can be assigned in the initialization file <i>IniFile</i>, in the section for this device. For example:</p> <pre>[CNCDriverDefinitions]</pre> <p>A port value of 0 (zero) indicates that the device driver is to operate in Manual mode.</p>
<i>/Simulation</i>	This optional switch starts up the device driver in Simulation mode. In this mode, the device driver emulates a robot by automatically generating status messages in response to command messages.

You can invoke a device driver in any one of the following ways:

- Use the OpenMES Loader to automatically start up a set of device drivers listed in the [Loading] section of an INI file.
- In the Windows Program Manager, click on an icon which is defined to run the device driver.
- In the Windows Program Manager, select File, Run and enter the device driver command line.

## 12.2. OPENMES DIRECTORY STRUCTURE

Each PC on which the OpenMES software has been installed has the same directory structures.

The OpenMES software and the projects files are installed in separate locations. The file structures of the two are detailed below.

### 12.2.1. Installation Directory

The CIM software is installed in the programs files directory (for example: [default system drive (for example C:)]\Program Files\Intelitek\OpenCIM\).

Some of the subdirectories are described below:

Subdirectory	Description
Bin	OpenMES software files
Books	OpenMES software book
Sources	
QueAlgDef	Queue algorithm source dll to which you can add your own algorithms for the machine queue.
RW	Documentation on how to develop custom parts.
Converter	Application for converting a graphic module from Autocad or 3D studio to RWX.
Documentation	Documentation detailing how to work with the graphic modules.




Figure 13-2: OpenMES Installation Directory Structure

#### 12.2.1.1.1. Projects Directory

CIM projects are installed in the public user directory:

- C:\Users\Public\Documents\Intelitek\OpenCIM\

This directory contains the projects folders.

**Project Folder:** Contains all project folders and a lib directory which includes preconfigured setup files for common machines, robots and stations.

**WorkStation's Folders:** In every project folder you can find subfolders with data that is relevant only to a specific station (e.g. WS1, WS2). The project folders can be located on the OpenMES Manager PC (if you want to centralize the system data) or on that station PC. It is recommended to use the first structure, where the data is kept in a single location as it facilitates backup.

The figure below shows the OpenMES projects directory structure (path listing) before any OpenMES system is created using the Virtual OpenMES Setup.




Figure 13-3: OpenMES Projects Directory Structure



CIM\_CUSTOM\_PARTS: contains all the RWX files for parts provided by Intelitek. For information on modifying these parts and creating new ones, refer to Chapter 7: OpenMES Manager Utility Programs.

For every cell created by the Virtual OpenMES Setup, a subdirectory, which contains the following subdirectories, is created:

Subdirectory	Description
DATA	Contains data files that change during the normal operation of the CIM.
DOC	Contains all documentation relevant to this particular system.
LOG	Contains a log of the system.
SETUP	Contains all the files that change when setting up the CIM cell.
WS0	Workstation Manager.
WS $n$	Contains all data files that are unique to this station.
VC2_WM.DBF	OpenMES network messages file.
CIMCELL.INI	These files contain graphic information of the cell.
VC2.INI	
CIMCELL.O2B	
CIMCELL.O2C	
CIMCELL.O2P	

The WS $n$  subdirectories represent each of the workstations in the CIM cell.

The subdirectory is created in the OpenMES Manager for each specific WS $n$ . and is then shared via the network with the Station Manager. A subdirectory is created for each machine at that workstation.

A system with three workstations (WS1, WS2, WS3) may be set up as follows, for example:

- The WS1 subdirectory contains all INI files and DBF files that are unique to workstation #1. ROBOT 1 contains all of the robot programs specific to workstation #1.
- The WS2 subdirectory contains all INI files and DBF files that are unique to workstation #2. ROBOT 2 contains all of the robot programs specific to workstation #2. GCODE contains all the G-code programs necessary for the CNC machine.
- The WS3 subdirectory contains all INI files and DBF files that are unique to workstation #3.

The table below lists the files found in a typical OpenMES system, grouped by subdirectory. The subdirectory generically called *CIMCELL* represents a typical CIM cell.

File Type	Description
Projects Directory\LIB\ACL	Subdirectory containing a library of generic ACL source code, utility programs, and parameter files.
CIMSYS.DMC	Source code of standard ACL system programs for a single robot

File Type	Description
	attached to an ACL controller.
CIMSYSTEM.DMC	Source code of standard ACL system programs for multiple robots attached to the same ACL controller.
Projects Directory\LIB\ACL\ATS	
DOWNLOAD.EXE	ACLOff-line downloader utility program that sends DNL files to an ACL controller.
SEND.EXE	Utility program to send a command to an ACL controller.
TERM_ACL.EXE	ATS terminal emulation program used to interact with an ACL controller.
SETUP.DIR	A data file used by the TERM_ACL program.
ASRSB.PRB	ACL parameter files.
ASRSSQ.PRB	
BELT.PRB	
LSB100CM.PRB	
LSB150CM.PRB	
LSB20.PRB	
NOCONECG.PRB	
NOCONNECT.PRB	
ROTARY_B.PRB	
SERVOG_C.PRB	
XYTAB.PRB	
SCC_BELT.PRB	
SETUP.PAR	
ATS.BAT	Batch file to load the TERM_ACL.EXE.
TERM.MAC	
ONOFF.CBU	On/Off program for the controller.
PAR.CBU	File containing parameters for the controller.
PAR14.CBU	File containing parameters for Robot ER 14.
PAR9.CBU	File containing parameters for Robot ER 9.
PARMK2.CBU	File containing parameters for Robot MK2.
<b>BIN</b>	Subdirectory containing OpenMES program files (EXE, DLL, HLP, ICO, TRK, VBX).
C4DLL.DLL	Object code files containing a shared library of Windows programs.
DBCREATER.DLL	
QueAlgDef.dll	Machine queue algorithms Dll
VBC4DLL.DLL	

File Type	Description
OpenMES_Ver4.5.chm	Help file
ACLDRIVER.EXE	The ACL device driver.
APLAN.EXE	The A-Plan program.
BCRDriver.exe	The bar-code device driver
CHECKCOMMUNICATION. EXE	Utility program for testing TCP/IP communications.
CIMREPORT.EXE	Report Generator program
CIMSAF.EXE	OpenMES safety device driver
CIMSETUP.EXE	Virtual OpenMES Setup program
CIMSIMUL.EXE	Graphic Display Program Loader
CNCDRIVER.EXE	CNC device driver
DBTOOL.EXE	Edits database files
DDLLOADER.EXE	Loader program for device drivers
HYDDriver.exe	Hydraulic device driver
LSMDRIVER.EXE	Laser Scan Meter device driver
MACHINEDEFINITION. EXE	Machine Definition module
MANAGER.EXE	OpenMES Manager module
MRP.EXE	MRP module
Optimization.exe	Optimization Utility
PARTDEFINITION.EXE	Part Definition module
Performance.exe	Performance Utility
PLCDRIVER.EXE	PLC device driver
PNEUDriver.exe	Pneumatic device driver
ProcDriver.exe	Process device driver
ProjectManager.exe	Project Manager Program
RFIDDriver.exe	RFID Device Driver
RVPDRIVER.EXE	ROBOTVISIONPro Device Driver
SCHEDULER.EXE	Scheduler Module
SCRIPTER.EXE	Activates Graphic Display commands
STORAGEMANAGER.EXE	Storage manager module

File Type	Description
ULSDRIVER.EXE	Laser Engraver Device Driver
<b>CIMCELL</b>	Generic name for a subdirectory containing all data for one particular CIM cell, as created by the Virtual OpenMES Setup.
<b>CIMCELL</b> <b>/ DATA</b>	Subdirectory containing data files used by the OpenMES system. (*.DBF is a file in dBASE format).
ORDER.CFG	Internal configuration parameters used by the MRP.
APLAN.DBF	A-Plan commands generated by last order submitted.
BACK.DBF	The REF.BAT batch file uses this data file to restore STORAGE.DBF.
CSTORDER.DBF	Details of the customer order.
CUSTOMER.DBF	List of customers.
CIMREP.DBF	Report format specifications.
LEAFPART.DBF	Internal information used by the OpenMES Manager to display active production operations in Leaf View.
MACHINE.DBF	List of machines as defined in the Machine Definition.
OPT_MQUEUE.DBF	List of which algorithm to use for each machine queue.
ORDER.DBF	Records that appear in the Order table.
PART_DEF.DBF	Records that appear on the Part Definition screen.
PART_PRC.DBF	Records that appear in the Part Process table.
PERF_SUMM.DBF	System performance summary.
PROCESS.DBF	Records that appear in the Machine Process table in the Machine Definition module.
Performance.dbf	Machine performance summary.
REPORT.DBF	Records that appear in the Report table.
PROCESS.DBF	Machine process summary.
SCHEDULER.BDF	Information used by the scheduler.
PURCHASE.DBF	List of item parts for purchase.
STORAGE.DBF	Contents of all storage devices.
SCHEDULER.DBF	Machine task schedule summary.
SUPPLIER.DBF	List of Suppliers.
TEMPLATE.DBF.DBF	Conveyor template definitions as assigned in the Storage Definition module.
ANALYSIS.RPT	Listing of files for the Report Generator. Each file is named



File Type	Description
SETUP.CIM	Configuration data file; contains all devices and their associated parameters.
DEVICE.DMC	Assignment of device names to ACL program numbers.
OPENMES.INI	Default device driver parameters.
FDR1.INI	File detailing the files used by each storage device.
RACK1.INI	File containing the configuration of the rack.
PNEUST1FDR1	File containing the configuration of the pneumatic station.
CONPALET.INI	File containing the minimum number of empty pallets running in the conveyor.
<b><i>CIMCELL</i></b> <b><i>/ WSO</i></b>	Subdirectory containing files for the OpenMES Manager PC.
CIM.LOG	OpenMES network messages file for this station.
CIM.PRT	File containing a listing of all messages (LOG file).
WSO.INI	Parameters passed into the OpenMES Manager at initialization time.
CIM.PNP	Pick-and-place file.
CIM.LOG	File containing the leaf view (LOG file).
ERROR.LOG	Error graphic file
OLMT.TXT	List of Messages sent to Simulation (Log file).
<b><i>CIMCELL</i></b> <b><i>/ WSn</i></b>	Subdirectory containing files for a typical workstation.
ACLVD1.INI	ACL Virtual driver.
VC2_QC.INI	Format settings for quality control report.
BCRVD1.INI	BarCode Virtual driver.
SCBSVD1.INI	Scorbase Virtual driver
PNEUVD1.INI	Pneumatic Station Virtual driver
\$ACL_011.PRT	File containing ACL device driver protocol.
CNCVD1.INI	CNC Virtual driver.
ULSVD1.INI	ULS Virtual driver
HYDVD1.INI	Hydraulic Station Virtual driver
VFVD1.INI	ViewFlex Virtual driver
PROCVD1.INI	Process Virtual driver
\$LSM_009.PRT	File containing LSM device driver protocol.

File Type	Description
LSMVD1.INI	LSM Virtual device driver INI file.
\$PLC_001.PRT	File containing PLC device driver protocol.
PLCVD1.INI	PLC virtual device driver.
WS1.INI	Typically used to pass command line parameters to the Loader program used to start each device driver at this station in Real mode.
ACL_011.PNP	Pick-and-place file.

Every machine, robot or station directory in a workstation contains a number of preconfigured setup files.

The following is an example of a robot directory which contains files for the Robots in the stations.

<b>CIMCELL</b> <b>/ WS<math>n</math></b> <b>    / ROBOT<math>n</math></b>	Subdirectory containing files for the ACL controller at Station $n$ .
REPORT.DLD	Log file showing the commands executed during the last ACL download (see the <i>ACLOff-line</i> manual).
WS2.DNL TRASH1.DNL BFFR1.DNL RDR1.DNL RACK1.DNL CNV1.DNL EPILOG1.DNL PROLOG1.DNL FDR1.DNL ASMBUF.DNL ASRS.DNL	Listing of all the download robot programs for this station.
RVPCOM2V.QCL RVPCOMOV.QCL RVPCOM1V.QCL RVPCOM.QCL	Listing of all download Quality Control robot programs.
SETUP.DIR	Data file used by the TERM_ACL program.
<b>CIMCELL</b> <b>/ WS<math>n</math></b> <b>    / ROBOT<math>n</math></b>	Subdirectory containing files for controllers operated by Scorbace software
STN.WS	

File Type	Description
STN.SBP	
STN.PNT	
CIMCELL / WSn / ROBOTn	Subdirectory containing files for controllers operated by Scorbase software
STN.WS	
STN.SBP	
STN.PNT	
<b>LIB</b>	Subdirectory containing preconfigured setup files for common machines, ACL programs, etc. (library of ACL programs).  Located in the projects directory
<b>LIB</b> / ACL	Subdirectory containing a library of unique ACL source code, utility programs, and parameter files.
Projects Directory\LIB\ACL	Subdirectory containing a library of generic ACL source code, utility programs, and parameter files.
CIMSYS.DMC	Source code of standard ACL system programs for a single robot attached to an ACL controller.
CIMSYSTEM.DMC	Source code of standard ACL system programs for multiple robots attached to the same ACL controller.
Projects Directory\LIB\ACL\ATS	
DOWNLOAD.EXE	ACL off-line downloader utility program that sends DNL files to an ACL controller.
SEND.EXE	Utility program to send a command to an ACL controller.
TERM_ACL.EXE	ATS terminal emulation program used to interact with an ACL controller.
SETUP.DIR	A data file used by the TERM_ACL program.
ASRSB.PR ASRSSQ.PR BELT.PR LSB100CM.PR LSB150CM.PR LSB20.PR NOCONECG.PR NOCONNECT.PR ROTARY_B.PR SERVOG_C.PR XYTAB.PR	ACL parameter files.



<b>File Type</b>	<b>Description</b>
SCC_BELT.PRB	
SETUP.PAR	Location of the Robot parameters.
ATS.BAT	Batch file to load the TERM_ACL.EXE.
TERM.MAC	
ONOFF.CBU	On/Off program for the controller.
PAR.CBU	File containing parameters for the controller.
PAR14.CBU	File containing parameters for Robot ER 14.
PAR9.CBU	File containing parameters for Robot ER IX.
PARMK2.CBU	File containing parameters for Robot MK2.
<b>LIB/ Hydraulic</b>	Subdirectory containing hydraulic station files.
Load.pgm	
Press.pgm	
Unload.pgm	
<b>LIB/ QC</b>	Subdirectory containing examples of Quality Control INI files.
VC2_QC.INI	
<b>LIB/ SCR</b>	Subdirectory containing all the CNC script and BATCH file examples.
SCRLAB.DBF	
SCRILAB.DBF	
SCRTIL.DBF	
SCRSITIL.DBF	
SCRPRJ.DBF	
VC2_WM.EXP	
CNC_L.LAB	
EXAMPLE.DBF	
CNC_L.BAT	
CNC_SCR.DBF	
CNCSCRSI.DBF	
LIB/ ViewFlex	Subdirectory containing all the ViewFlex Scripts
CHECK_V.bas	
FIND_4_PINS.bas	
FIND_4_SCREWS.bas	

File Type	Description
Lower_Left_Pin.mod	
Lower_Left_Screw.mod	
Lower_Right_Pin.mod	
Lower_Right_Screw.mod	
Upper_Left.mod	
Upper_Left_Pin.mod	
Upper_Left_Screw.mod	
Upper_Right_Pin.mod	
LIB/ Vuniq40	Subdirectory containing required files to work with with Vuniq.

### 12.2.2. MAP.INI

The setup file MAP.INI performs the following functions:

- Contains the TCP/IP configuration of the manager and all device drivers in an OpenMES cell. This information is required by each OpenMES in order to enable communication with other OpenMES entities.
- Allows two or more devices to use the same device driver to send and receive messages

A typical MAP.INI has the following format:

```
[Redirect]
53=51
23=21
24=21
[COMMMANAGER]
RemoteIP=200.1.1.1
RemotePort=700

[COMMACL11]
RemoteIP=200.1.1.1
RemotePort=711

[COMMLSM13]
RemoteIP=200.1.1.1
RemotePort=713

[COMMACL21]
RemoteIP=200.1.1.1
RemotePort=721

[COMMACL24]
RemoteIP=200.1.1.1
RemotePort=724
```

When a device driver starts, it must access MAP.INI in order to be able to communicate with other device drivers and the OpenMES Manager. On each Station Manager PC the file path to MAP.INI is contained in the parameter variable *CimMapPath* in the *[Networking]* section of the INI file for this station.

- ❗ *To guarantee proper operation of OpenMES, be sure that the file MAP.INI is accessible to all device drivers. To be sure that the MAP.INI file is accessible, do the following:*
- ❗ *Open any device driver*
- ❗ *Check if the MAP.INI file is updated by editing the TCP/IP configurations of the DD opened*

You can use any ASCII text editor (e.g. Windows Notepad) to modify MAP.INI. The two types of entries in this file are described below.

Since only one device can be assigned to a device driver on a command line, an ID entry in MAP.INI is used to assign other devices to this device driver. For example, a bar code reader (device 13) and a robot (device 11) may be connected to the same ACL controller and thus share the same ACL device driver for passing OpenMES messages. The following command line assigns the robot to the ACL device driver:

```
ACLDriver.EXE ACLVD1.INI 11,13 /COM:2
```

The following MAP.INI entry allows the bar code reader to share the use of this device driver:

```
[REDIRECT]
```

```
13=11
```

```
13
```

A device that is sharing the use of a device driver.

```
11
```

The primary device that is assigned to a device driver on the command line that invokes the device driver.

### 12.2.3. SETUP.CIM

SETUP.CIM is an ASCII file which defines all devices found in the OpenMES system. The file is located in the path *Projects Directory\CIMCELL\SETUP*. The fields in this file are separated by a space.

The SETUP.CIM file for the CIMLAB4 Virtual CIM is shown below.

```
5
51 1 ER5P ROBOT1 R 1 0 0 0 0
52 2 ER9 ROBOT2 R 1 0 0 0 0
53 3 ER5P ROBOT3 R 1 0 0 0 0
54 4 ER7 ROBOT4 R 1 0 0 0 0
00 PLANE PLANE 0. 0. 0.
1 2 CNV1 CNV1 C 4 0 0 0 4 ROBOT1 0 ROBOT2 0 ROBOT3 0 ROBOT4 0 0
55 4 ERXY XYJIG J 1 0 0 0 1 ROBOT4 0 0
2 1 RNDAS RNDAS1 A 54 0 0 0 1 ROBOT1 0 0
3 1 READER RDR1 Y 1 0 0 0 1 ROBOT1 0 0
4 2 MILL_S MILL1 M 1 0 0 0 1 ROBOT2 0 0
5 2 M2AS BFFR1 B 2 0 0 0 1 ROBOT2 0 0
6 2 M2AS BFFR2 B 2 0 0 0 1 ROBOT2 0 0
7 3 LATH_S LATHE1 M 1 0 0 0 1 ROBOT3 0 0
8 3 M2AS BFFR3 B 2 0 0 0 1 ROBOT3 0 0
9 4 M2AS BFFR4 B 2 0 0 0 1 ROBOT4 0 0
10 4 FEEDER FDR1 F 1 201 0 20 1 ROBOT4 0 0
11 4 RACK RACK1 K 9 101 0 0 1 ROBOT4 0 0
12 4 RACK RACK2 K 2 102 0 0 1 ROBOT4 0 0
13 4 TRASH TRASH1 X 1 0 0 0 1 ROBOT4 0 0
14 4 JIG JIG1 J 1 0 0 0 1 ROBOT4 0 0
17 4 VISION VSN1 V 1 0 0 0 1 XYJIG 0 0
16 4 SCREWD SDRV1 D 1 0 0 0 1 XYJIG 0 0
51 1 ER5P ROBOT1 R 1 0 0 0 0
52 2 ER9 ROBOT2 R 1 0 0 0 0
53 3 ER5P ROBOT3 R 1 0 0 0 0
54 4 ER7 ROBOT4 R 1 0 0 0 0
60 0 SPARE CONPALET O 16 1 0 0 0 0
60 0 SPARE CONPALET O 16 1 0 0 0 0
```



The following is an example of a SETUP.CIM file.

```

1
11 1 SQRAS SQRAS1 R 1 0 0 0 0
211 1 ASRS ASRS1 A 72 0 0 0 1 SQRAS1 0 0
21 2 ER9 ROBOT5 R 1 0 0 0 0
31 3 MK3 ROBOT3 R 1 0 0 0 0
41 4 ER14 ROBOT4 R 1 0 0 0 0
0 0 PLANE PLANE 0. 0. 0.
1 1 CNV1 CNV1 C 4 0 0 0 4 SQRAS1 0 ROBOT5 0 ROBOT3 0 ROBOT4 0 0
12 1 READER RDR1 Y 1 0 0 0 1 SQRAS1 0 0
24 2 PCMILL PCMILL1 M 1 0 0 0 1 ROBOT5 0 0
23 2 PCTURN PCTURN1 M 1 0 0 0 1 ROBOT5 0 0
33 3 WELDST WELDST1 D 1 0 0 0 1 ROBOT3 0 0
49 4 CMM CMM1 Q 1 0 0 0 1 ROBOT4 0 0
47 4 VISION VSN1 V 1 0 0 0 1 ROBOT4 0 0
44 4 RACK RACK1 K 1 101 0 0 1 ROBOT4 0 0
45 4 RACK RACK2 K 1 102 0 0 1 ROBOT4 0 0
43 4 JIG JIG1 J 1 0 0 0 1 ROBOT4 0 0
48 4 TRASH TRASH1 X 1 0 0 0 1 ROBOT4 0 0
22 2 M2AS BFFR1 B 2 0 0 0 1 ROBOT5 0 0
32 3 M2AS BFFR2 B 2 0 0 0 1 ROBOT3 0 0
42 4 M2AS BFFR3 B 2 0 0 0 1 ROBOT4 0 0
46 4 FEEDER FDR1 F 1 103 0 0 1 ROBOT4 0 0
50 0 SPARE CONPALET O 16 1 0 0 0 0

```

#### 12.2.4. DEVICE.DMC

The DEVICE.DMC file in the SETUP directory defines numbers for the ACL logical name of every device in the system.

The DEVICE.DMC file for the CIMLAB4 Virtual CIM is shown below.

```

#IFNDEF _DEVICE_DMC
#DEFINE _DEVICE_DMC
#DEFINE CNV1      001
#DEFINE RNDAS1   002
#DEFINE BFFR1    005
#DEFINE BFFR2    006
#DEFINE BFFR3    008
#DEFINE BFFR4    009
#DEFINE FDR1     010
#DEFINE RACK1    011
#DEFINE RACK2    012
#DEFINE TRASH1   013
#DEFINE ROBOT1   051
#DEFINE ROBOT2   052

```

```
#DEFINE ROBOT3    053
#DEFINE ROBOT4    054
#DEFINE ROBOT5    055
#DEFINE MILL1     004
#DEFINE LATHE1    007
#DEFINE JIG1      014
#DEFINE SDRV1     016
#DEFINE VSN1      015
#DEFINE RDR1      003
#ENDIF
```

For an explanation of this file and how to edit it, refer to Writing ACL Source Code in Chapter 12, OpenMES Programming.

### 12.2.5. INI Files

OpenMES uses a set of INI files to set configuration parameters for the following programs:

- Each OpenMES device driver
- The OpenMES Manager
- The OpenMES Loader
- The Storage Definition module

OpenMES parameter settings for the above programs are stored in a set of text files: \*.INI. These files use the same structure as standard Windows INI files such as WIN.INI. These programs read their respective INI files at initialization time. If you make a change to a program's INI file after it has started, you must end the program and restart it for the change to take effect.

Default values for all devices are stored in the file OPENMES.INI. Settings for individual devices can be made in a local INI file which is specified on the device driver loader's command line. If the same parameter appears in both OPENMES.INI and a device driver's local INI file, the local setting takes precedence. All parameters must appear in either OPENMES.INI or in a local INI file.

The (OPENMES32\CIMLAB4\SETUP\) OPENMES.INI file for the CIMLAB4 setup is shown below.

```
[General]
CimSetupPath=..\SETUP\SETUP.CIM
CimSetupDir=..\SETUP
CimLibDir=..\LIB
CimDataDir=..\DATA
CimWorkDir=..\data
CimReportDir=..\DATA

[Networking]
CimMapPath=..\SETUP\MAP.INI
Timer=300
AttemptsCount=3
PassCount=3
OffDelay=3
```

```
EchoFilter=1124

[Simulation]
PCPLC=20,7,15

[ASRS1]
NumberOfRows=6
NumberOfCols=6
NumberOfGrids=2
FirstGridWithMinIndex=Bottom
LocationMinIndexGrid=LeftBottom
DirectionInIndexGrid=Right

[WndStatus]
PROGDEF=0
ORDERDER=0
STRGDEF=0
DEVICEDEF=0
LOGDEF=0
PALLETEDEF=0
LEAFDEF=0
EVENTDEF=0
MANAGERDEF=0
HYSTORYDEF=0

[CIMMODES]
TRACKINGMODE=0
UPDATEDURATION=0
SENDTOGRAPH=0
SIMULATION=1
CIMSPEED=1

[DDFileName]
CNV1=..\CIMLAB4\WS1\PLCVD1.INI
SQRAS1=..\CIMLAB4\WS1\ACLVD1.INI
RDR1=..\CIMLAB4\WS1\LSMVD1.INI
ROBOT5=..\CIMLAB4\WS2\ACLVD5.INI
PCTURN1=..\CIMLAB4\WS2\CNCVD1.INI
PCMILL1=..\CIMLAB4\WS2\CNCVD2.INI
ROBOT3=..\CIMLAB4\WS3\ACLVD3.INI
ROBOT4=..\CIMLAB4\WS4\ACLVD4.INI
VSN1=..\CIMLAB4\WS4\RVPVD1.INI
CMM1=..\CIMLAB4\WS4\LSMVD2.INI
```

You can use some combination of the parameter file strategies listed below when deciding how to organize INI files for your system:

Put all default parameter settings in OPENMES.INI. Then write a separate INI file for each device driver that contains only those parameters that deviate from the default.



Have a separate INI file for each device driver containing all the parameters for that device. Use OPENMES.INI only for global parameters.

Have a separate INI file for each Station Manager PC (e.g. WS1.INI) which contains the parameters for all devices at that station. These files would also contain the command lines used by the Loader to start each device driver at a station. Use OPENMES.INI only for global parameters.

To set up or edit an INI file, use a text editor (e.g. Windows Notepad) that can save files in ASCII format. The file is divided into sections with the title of each section enclosed in brackets, for example [Networking]. A program searches for the sections that apply to it and reads the associated parameter settings. Keep the following considerations in mind when editing an INI file:

Only lines that begin with valid parameter names are read (i.e. only parameters that belong in that section), all other lines are ignored. If you misspell a parameter name, it will be ignored.

A leading space at the beginning of a line will cause that line to be ignored.

Do not insert the same parameter more than once in a section (there is no guarantee as to which value will be used).

You can insert blank lines in an INI file to group related parameters and to set off sections.

You can create a comment line by inserting an extra character at the beginning of a line (by convention the semicolon, ;). For example, if you want to try a new text color but also keep the original value for reference, you could do the following:

```
;MainWindowTextColors = 0,255,0
MainWindowTextColors = 0,255,255
```

The table below lists all OpenMES parameters that you can set. Note that some of the values in the table are internal system parameters which should only be changed under the direction of Intelitek technical support. The table is divided into the following sections:

INI Parameter	Description
<b>Default Settings (OPENMES.INI)</b>	
[General]	The parameters in this section define the OpenMES directory structure on the central server PC.
CimLibDir=..\LIB	Location of the original OpenMES data and program files. These data files can be copied to the SETUP directory to restore the system to its original state.
CimDataDir = ..\DATA	Location of data files which define the OpenMES configuration (e.g. machine processes, part definitions, etc.).
CimWorkDir = ..\DATA	Location of data files, including log files, which are updated during OpenMES production.
CimReportDir = ..\DATA	Location of report output. Other software applications can interface here to pick up OpenMES production data.
[Networking]	
CimMapPath = ..\SETUP\MAP.INI	The location of the OpenMES map file which contains:  The name of all workstation PCs.  A list of all devices which share the use of a device driver (e.g. a robot, and an automatic screwdriver all connected to the same ACL controller).

INI Parameter	Description
Timer = 1000	<p>The frequency at which a program checks its mailslot for messages to transmit or receive. The OpenMES Manager must check its mailslot more frequently than the programs with which it communicates (device drivers or Storage Definition module).</p> <p>OpenMES Manager: 200 - 600 ms</p> <p>Device drivers: 400 - 1000 ms</p> <p>Reserved for Intelitek technical support use only.</p>
PassCount = 3	<p>Number of Timer intervals to wait before a retry is sent. For example:</p> <p>Timer = 1000, PassCount = 3 → delay before retry is 3000 ms</p> <p>Reserved for Intelitek technical support use only.</p>
OffDelay = 3	<p>Number of milliseconds a device driver waits for confirmation from the OpenMES Manager that it has received a shutdown notification message. A value of 0 (zero) causes the device driver not to send a shutdown message.</p>

### ASRS Device Driver Settings

[Structure]

NumberOfRow = 6

NumberOfCols = 6

NumberOfGrids = 2

FirstGridWithMinIndex = Bottom

LocationMinIndexGrid = LeftUp

DirectionInIndexGrid = Right

---

**ACL Device Driver Settings**

---

## [General]

CimSetupPath =..\CIMCELL\SETUP\SETUP.CIM

Tells the device driver where to find the following important OpenMES setup files:

- OPENMES.INI: Contains default parameter settings for all device drivers. The file OPENMES.INI must appear in the same directory as the setup file named in this setting.
- SETUP.CIM: Lists all physical devices and their IDs. The name SETUP.CIM is the default name for this file.

This parameter setting must appear in each local INI file. It is not needed in OPENMES.INI.

## [ACLDriverDefinitions]

ACLDriverPromptNum = 3

Number of times the device driver sends a query to an ACL controller to invoke the controller's command prompt, ">". Reserved for Intelitek technical support use only.

BaudRate = 9600

Parity = None

DataBits = 8

StopBits = 1

XonXoff = Yes

These are the standard RS232 settings for communicating with an ACL controller. They should not be changed since they match the fixed settings in the controller.

MainWindowBkgndColors = 0,0,0  
 MainWindowTextColors = 0,255,0

MainWindowBkgndColors = 0,0,0  
 MainWindowTextColors = 0,255,0  
 Color settings for the background and text colors in the device driver's Status window. When a Station Manager PC is running several device drivers simultaneously, these parameters allow you to set each one to a different color in order to distinguish between them.

The three numbers represent a color using the RGB color scheme (Red, Green, Blue). Values range from 0–255. A 0 (zero) indicates the absence of red, green, or blue, respectively, and 255 signifies a primary color at full intensity. For example:

Green = 0,255,0  
 White = 255,255,255  
 Black = 0,0,0

Do not set the text color to the same value as the background color. This combination would cause the text to become invisible.

---

### CNC Device Driver Settings

---

#### [General]

CimSetupPath= ..\CIMCELL\SETUP\SETUP.CIM See this parameter in the ACL section above.

#### [CNCDeviceDefinitions]

QCReport = No

Enables/disables creation of a log file for capturing results from this quality control device. If set to No, all other QC report parameters below are ignored.

QCReportTemplateFile = VC2\_QC.INI

Name (including path) of the file that defines the format of the quality control log file.

QCReportFileName =

Name (including path) of the quality control log file itself.

QCReportFileMarker =

A flag file (including path) which indicates that the quality control log file has been updated. A user application can delete this flag file after processing the log file. The next time the flag file appears, the application knows that there is new log file data to process.

QCReportFileDeleteOnStart =	This switch controls whether a new quality control log file will be created each time this device driver starts up. If Yes, the previous log file is deleted. If No, results are appended to the existing log file.
SimulationFailPercent = 20	When the device driver is operating in simulation mode, this value determines what percentage of the simulated quality control tests are randomly reported as failures. This setting provides the default value that appears in the Fail % box on the QC Control Panel. The range is 0–100 (0 = test always passes, 100 = test always fails).
BaudRate=9600 Parity=None DataBits=8 StopBits=1 XonXoff=No	RS232 parameters used by the QC device driver when it communicates with the controller for the quality control device. You must set these parameters to match the RS232 settings on the device's controller.
MainWindowBkgndColors=40,150,100 MainWindowTextColors=100,50,200	See these parameters in the ACL section above.

---

### RFID Device Driver Settings

---

[General]	See these parameters in the ACL section above.
CimSetupPath=..\CIMCELL\SETUP\SETUP.CIM	
[Networking]	Contains the TCP/IP configuration of the manager and all device drivers in an OpenMES cell.
CimMapPath=..\CIMCELL\SETUP\MAP.INI	
[RFIDDriverDefinitions]	RS232 parameters used by the RFID device driver for communication with the RFID reader.
BaudRate=9600 Parity=None DataBits=8 StopBits=1 XonXoff=No	

---

### ROBOTVISIONpro Device Driver Settings

---

[General]	
CimSetupPath== ..\CIMCELL\SETUP\SETUP.CIM	See this parameter in the ACL section above.
[RVPDriverDefinitions]	

Frame=1	Frame number as defined on the Frame Definition screen in the Setup menu of the ROBOTVISIONpro software. See the ROBOTVISIONpro documentation for details.
Snap=No	For older versions (prior to v2.3) of the ROBOTVISIONpro software, set this value to Yes. For v2.3 and later, set it to No. For best results, use only v2.3 and later.
BaudRate=9600 Parity=None DataBits=8 StopBits=1 XonXoff=No	RS232 parameters used by the QC device driver when it communicates with the controller for the quality control device. You must set these parameters to match the RS232 settings on the device's controller.
MainWindowBkgndColors=150,150,150 MainWindowTextColors=255,255,255	See these parameters in the ACL section above.
SimulationFailPercent=50	See this parameter in the Laser Scan Meter section above.
QCReport=Yes QCReportTemplateFile=VC2_QC.INI QCReportFileName= QCReportFileMarker= QCReportFileDeleteOnStart=	See these parameters in the Laser Scan Meter section above.

---

### ViewFlex Device Driver Settings

---

[General]

ScriptPath= project directory\cimcell\ws3

---

### ULS Device Driver Settings

---

[General]

CimSetupPath=..\CIMCELL\SETUP\SETUP.CIM

[Networking]

CimMapPath=..\CIMCELL\SETUP\MAP.INI

[CNCDeviceDefinitions]

BaudRate = 9600

Parity = None

DataBits = 8

StopBits = 1

XonXoff = No

; --- CNC Variables ---

RS232 parameters used by the CNC device driver when it downloads G-code to a CNC machine. You must set these parameters to match the RS232 settings on the CNC machine.

V1 = ACL71  
 V2 =  
 V3 =  
 V4 =  
 V5 =  
 V6 =  
 ⋮  
 V16 =  
 BV0 = 0  
 BV1 = 0

PORT0 = 0x500  
 PORT1 = 0x501

[DEBUG]  
 Protocol=YES

Parameter variables used by CNC script programs. These variables are used to write portable CNC script programs. For further information, see “ULS Device Driver” in Chapter 8.

These 8-bit values, which range from 0-255, are assumed to be the initial state of the control lines of a CNC machine when the system is turned on.

I/O port addresses on a Station Manager PC that are mapped to the status and control lines of a CNC machine using a special interface card. These values should match the jumper settings on the I/O card.

### PLC Device Driver Settings

---

[General]

CimSetupPath=..\CIMCELL\SETUP\SETUP.CIM See this parameter in the ACL section above.

[PLCDeviceDefinitions]

Type = OMRON The type of PLC being used. This value determines what communications protocol is used between the device driver and the PLC.

SimulationStations = 3,6,1,2,4,5,7 In Simulation or Manual mode, this parameter sets the order in which the stations appear.

SimulationPallets = 8 In Simulation mode or Manual mode, this parameter specifies the number of pallets traveling on the simulated conveyor.



SimulationPosPerStation = 3,3,3,3,3,3,3

In Simulation or Manual mode, this parameter specifies the distance between each station as measured in pallet lengths, i.e. the number of pallets that would fit on the simulated conveyor between two stations. The position of each number here corresponds to the order of stations as listed in the parameter `SimulationStations`. For example, the distance between stations 4 and 5 below is 8 pallets long:

SimulationStations = 3,6,1,2,4,5,7

SimulationPosPerStation = 3,5,7,4,8,3,5

SimulationDirection = L

In Simulation or Manual mode, this parameter specifies the direction in which the simulated conveyor travels.

L = Clockwise

R = Counter-clockwise

BaudRate = 9600

Parity = Even

DataBits = 7

StopBits = 2

XonXoff = No

RS232 parameters used by this device driver when it communicates with the PLC. You must set these parameters to match the RS232 settings on the PLC.

MainWindowBkgndColors = 150,0,170

MainWindowTextColors = 0,0,0

See these parameters in the ACL section above.

### 12.2.6. VC2\_WM.DBF

The VC2\_WM.DBF (Virtual Controller Series 2, Windows Messages Database File) contains the following fields:

DDE_CHNNL	The type of device driver that sends this message. This value must be one of the following (in lower case): <ul style="list-style-type: none"> <li>• dde_acl</li> <li>• dde_cnc</li> <li>• dde_plc</li> <li>• dde_cim</li> <li>• dde_rvp</li> <li>• dde_olmt</li> <li>• dde_asrs</li> <li>• dde_lsm</li> </ul>
WM_INPUT	The ID of the message to be sent.
NAME_WS	Name of destination workstation that is to receive this message (as specified in the file MAP.INI).
NAME_DDE	The type of device that receives this message (e.g. dde_cim for the OpenMES Manager).
WM_	This number identifies the type of message being sent.
ID_DEVICE	Device ID of the receiver as specified in the file SETUP.CIM. If a device does not appear in SETUP.CIM, this value will be 0 (e.g. the OpenMES Manager, the Graphic Tracking Module, an ASRS).
NOTE	A description of this message (free text).

**i** The term DDE stands for MS-Windows Dynamic Data Exchange. OpenMES device drivers do not currently use DDE but this term remains in the above field names for backward compatibility.

The following table shows the standard OpenMES messages contained in VC2\_WM.DBF:

External CIM Message	Message Description
2225	Robot Start from ACL
2226	Robot Finish from ACL
2230	Robot End from ACL

External CIM Message	Message Description
2335	Pallet Stop from PLC
2336	Pallet Pass from PLC
2337	Error from PLC
2338	Arrive Free Pallet from PLC
2229	Error from ACL
2339	Complex Pass Message from PLC to OLMT
2580	CNC End from CNC
2576	CNC Error from CNC
2581	CNC Start from CNC
2582	CNC Finish from CNC
2138	ACL to CNC Request
2137	ACL to CNC String
2195	QC Result
2358	Device is ready
2583	CNC Task is loaded
2359	Device is unavailable

### 12.3. OPENMES DATABASE STRUCTURE

The OpenMES database is compatible with the Xbase database management programs (e.g. dBASE, FoxPro and Clipper).

The OpenMES database consists of the following files:

File	Description
PART_DEF.DBF PART_PRC.DBF	Created by the Part Definition program.
MACHINE.DBF PROCESS.DBF	Created by the Machine Definition program.
TEMPLATE.DBF	Created by the Storage Definition program.
STORAGE.DBF	Created by the OpenMES Manager and is maintained by the Storage Definition program.
ORDER.DBF	Created by the Order Entry program.
APLAN.DBF	Created by the Order Entry program through the APLAN.EXE program.

CIMREP.DBF	Created by the OpenMES Manager.
LEAFPART.DBF	
SCHEDULER.DBF	Created by the CIM Scheduler program
PERFORMANCE.DBF	Created by the performance program
OPT_MQUEUE.DBF	Created by the Optimization program
PURCHASE.DBF	Created by the Order Entry program
CUSTOMER.DBF	
SUPPLIER.DBF	

The following tables describe the structure of the files that compose the OpenMES database.

Fld #	Field Name	Type	Width
<b>PART_DEF.DBF File Structure</b>			
1	PART	Character	20
2	DESCRIPT	Character	40
3	ID	Numeric	4
4	TEMPLATES	Character	15
5	RACKS	Character	15
6	SETUPTIME	Numeric	8
7	LEADTIME	Numeric	8
8	PRODUCT	Logical	1
9	SUPLIED	Logical	1
10	PHANTOM	Logical	1
11	COST	Numeric	6
12	SUPLIER	Character	30
13	SUPTIME	Numeric	8
14	PCTLOST	Numeric	2
15	MINORDER	Numeric	4
16	CAPACITY	Numeric	2
17	CATNUMBER	Character	30
18	SAFSTOCK	Character	5

**PART\_PRC.DBF File Structure**

Fld #	Field Name	Type	Width
1	PART	Character	20
2	SEQNO	Numeric	2
3	SUBPART	Character	20
4	PROCESS	Character	20
5	PARAMETERS	Character	30
6	ORDERING	Logical	1

#### MACHINE.DBF File Structure

1	SERVER	Character	20
2	COST	Numeric	6
3	NBUFFER	Numeric	1
4	NRACK	Numeric	1
5	NCONVEYOR	Numeric	1
6	NMAX	Numeric	2
7	QUETYPE	Character	4
8	QUEVEC1	Numeric	4
9	QUEVEC2	Numeric	4
10	QUEVEC3	Numeric	4
11	QUEVEC4	Numeric	4
12	QUEVEC5	Numeric	4
13	QUEVEC6	Numeric	4
14	NPRELOAD	Numeric	2
15	PRG1	Character	80
16	DATE1	Date	8
17	PRG2	Character	80
18	DATE2	Date	8
19	PRG3	Character	80
20	DATE3	Date	8
21	PRG4	Character	80
22	DATE4	Date	8
23	PRG5	Character	80
24	DATE5	Date	8

Fld #	Field Name	Type	Width
25	LASTLOADED	Numeric	1
PROCESS.DBF File			
1	SERVER	Character	20
2	ACTIONYPE	Character	12
3	PROCESS	Character	20
4	FILE	Character	80
5	PROGRAM	Character	20
6	ARGCNT	Character	20
7	PARAMETERS	Character	40
8	FAILPRCNT	Numeric	2
9	DURATION	Character	8
10	NEED ROBOT	Character	3

#### TEMPLATE.DBF File Structure

1	BAR_CODE	Character	6
---	----------	-----------	---

#### STORAGE.DBF File Structure

1	SERVERID	Numeric	4
2	SERVER	Character	20
3	INDEX	Numeric	3
4	TYPE	Character	1
5	SUBTYPE	Numeric	3
6	STATUS	Numeric	1
7	PARTID	Numeric	4
8	PARTNAME	Character	20
9	PARTPOS	Numeric	4
10	TEMPLTID	Numeric	4
11	TEMPLATE	Character	20
12	TEMPLTPOS	Numeric	4

#### ORDER.DBF File Structure

1	SEQNO	Numeric	2
2	PART	Character	20
3	ITEMS	Numeric	3

Fld #	Field Name	Type	Width
4	FIRSTDO	Numeric	

---

**ULS Device Driver Settings**

---

[General]

CimSetupPath=..\CIMCELL\SETUP\SETUP.CIM

[Networking]

CimMapPath=..\CIMCELL\SETUP\MAP.INI

[CNCDriverDefinitions]

BaudRate = 9600

Parity = None

DataBits = 8

StopBits = 1

XonXoff = No

RS232 parameters used by the CNC device driver when it downloads G-code to a CNC machine. You must set these parameters to match the RS232 settings on the CNC machine.

; --- CNC Variables ---

V1 = ACL71

V2 =

V3 =

V4 =

V5 =

V6 =

:

V16 =

Parameter variables used by CNC script programs. These variables are used to write portable CNC script programs. For further information, see "ULS Device Driver" in Chapter 8.

BV0 = 0

BV1 = 0

These 8-bit values, which range from 0-255, are assumed to be the initial state of the control lines of a CNC machine when the system is turned on.

PORT0 = 0x500

PORT1 = 0x501

I/O port addresses on a Station Manager PC that are mapped to the status and control lines of a CNC machine using a special interface card. These values should match the jumper settings on the I/O card.

[DEBUG]

Protocol=YES

**PLC Device Driver Settings**

---

[General]

CimSetupPath=..\CIMCELL\SETUP\SETUP.CIM      See this parameter in the ACL section above.

[PLCDriverDefinitions]

Type = OMRON

The type of PLC being used. This value determines what communications protocol is used between the device driver and the PLC.

SimulationStations = 3,6,1,2,4,5,7

In Simulation or Manual mode, this parameter sets the order in which the stations appear.

SimulationPallets = 8

In Simulation mode or Manual mode, this parameter specifies the number of pallets traveling on the simulated conveyor.

SimulationPosPerStation = 3,3,3,3,3,3,3

In Simulation or Manual mode, this parameter specifies the distance between each station as measured in pallet lengths, i.e. the number of pallets that would fit on the simulated conveyor between two stations. The position of each number here corresponds to the order of stations as listed in the parameter `SimulationStations`. For example, the distance between stations 4 and 5 below is 8 pallets long:

SimulationStations = 3,6,1,2,4,5,7

SimulationPosPerStation = 3,5,7,4,8,3,5

SimulationDirection = L

In Simulation or Manual mode, this parameter specifies the direction in which the simulated conveyor travels.

L = Clockwise

R = Counter-clockwise

BaudRate = 9600

Parity = Even

DataBits = 7

StopBits = 2

XonXoff = No

RS232 parameters used by this device driver when it communicates with the PLC. You must set these parameters to match the RS232 settings on the PLC.

MainWindowBkgndColors = 150,0,170

MainWindowTextColors = 0,0,0

See these parameters in the ACL section above.



### 12.3.1. VC2\_WM.DBF

The VC2\_WM.DBF (Virtual Controller Series 2, Windows Messages Database File) contains the following fields:

DDE_CHNNL	The type of device driver that sends this message. This value must be one of the following (in lower case): <ul style="list-style-type: none"> <li>dde_acl</li> <li>dde_cnc</li> <li>dde_plc</li> <li>dde_cim</li> <li>dde_rvp</li> <li>dde_olmt</li> <li>dde_asrs</li> <li>dde_lsm</li> </ul>
WM_INPUT	The ID of the message to be sent.
NAME_WS	Name of destination workstation that is to receive this message (as specified in the file MAP.INI).
NAME_DDE	The type of device that receives this message (e.g. dde_cim for the OpenMES Manager).
WM_	This number identifies the type of message being sent.
ID_DEVICE	Device ID of the receiver as specified in the file SETUP.CIM. If a device does not appear in SETUP.CIM, this value will be 0 (e.g. the OpenMES Manager, the Graphic Tracking Module, an ASRS).
NOTE	A description of this message (free text).

**i** *The term DDE stands for MS-Windows Dynamic Data Exchange. OpenMES device drivers do not currently use DDE but this term remains in the above field names for backward compatibility.*

The following table shows the standard OpenMES messages contained in VC2\_WM.DBF:

External CIM Message	Message Description
2225	Robot Start from ACL
2226	Robot Finish from ACL
2230	Robot End from ACL
2335	Pallet Stop from PLC
2336	Pallet Pass from PLC
2337	Error from PLC
2338	Arrive Free Pallet from PLC
2229	Error from ACL
2339	Complex Pass Message from PLC to OLMT
2580	CNC End from CNC
2576	CNC Error from CNC
2581	CNC Start from CNC
2582	CNC Finish from CNC
2138	ACL to CNC Request
2137	ACL to CNC String
2195	QC Result
2358	Device is ready
2583	CNC Task is loaded
2359	Device is unavailable

## 12.4. OPENMES DATABASE STRUCTURE

The OpenMES database is compatible with the Xbase database management programs (e.g. dBASE, FoxPro and Clipper).

The OpenMES database consists of the following files:

File	Description
PART_DEF.DBF PART_PRC.DBF	Created by the Part Definition program.
MACHINE.DBF PROCESS.DBF	Created by the Machine Definition program.
TEMPLATE.DBF	Created by the Storage Definition program.

STORAGE.DBF	Created by the OpenMES Manager and is maintained by the Storage Definition program.
ORDER.DBF	Created by the Order Entry program.
APLAN.DBF	Created by the Order Entry program through the APLAN.EXE program.
CIMREP.DBF LEAFPART.DBF	Created by the OpenMES Manager.
SCHEDULER.DBF	Created by the CIM Scheduler program
PERFORMANCE.DBF	Created by the performance program
OPT_QUEUE.DBF	Created by the Optimization program
PURCHASE.DBF	Created by the Order Entry program
CUSTOMER.DBF	
SUPPLIER.DBF	

The following tables describe the structure of the files that compose the OpenMES database.

Fld #	Field Name	Type	Width
<b>PART_DEF.DBF File Structure</b>			
1	PART	Character	20
2	DESCRIPT	Character	40
3	ID	Numeric	4
4	TEMPLATES	Character	15
5	RACKS	Character	15
6	SETUPTIME	Numeric	8
7	LEADTIME	Numeric	8
8	PRODUCT	Logical	1
9	SUPLIED	Logical	1
10	PHANTOM	Logical	1
11	COST	Numeric	6
12	SUPLIER	Character	30
13	SUPTIME	Numeric	8
14	PCTLOST	Numeric	2
15	MINORDER	Numeric	4

Fld #	Field Name	Type	Width
16	CAPACITY	Numeric	2
17	CATNUMBER	Character	30
18	SAFSTOCK	Character	5

#### **PART\_PRC.DBF File Structure**

1	PART	Character	20
2	SEQNO	Numeric	2
3	SUBPART	Character	20
4	PROCESS	Character	20
5	PARAMETERS	Character	30
6	ORDERING	Logical	1

#### **MACHINE.DBF File Structure**

1	SERVER	Character	20
2	COST	Numeric	6
3	NBUFFER	Numeric	1
4	NRACK	Numeric	1
5	NCONVEYOR	Numeric	1
6	NMAX	Numeric	2
7	QUETYPE	Character	4
8	QUEVEC1	Numeric	4
9	QUEVEC2	Numeric	4
10	QUEVEC3	Numeric	4
11	QUEVEC4	Numeric	4
12	QUEVEC5	Numeric	4
13	QUEVEC6	Numeric	4
14	NPRELOAD	Numeric	2
15	PRG1	Character	80
16	DATE1	Date	8
17	PRG2	Character	80
18	DATE2	Date	8
19	PRG3	Character	80
20	DATE3	Date	8

Fld #	Field Name	Type	Width
21	PRG4	Character	80
22	DATE4	Date	8
23	PRG5	Character	80
24	DATE5	Date	8
25	LASTLOADED	Numeric	1

**PROCESS.DBF File**

1	SERVER	Character	20
2	ACTIONYPE	Character	12
3	PROCESS	Character	20
4	FILE	Character	80
5	PROGRAM	Character	20
6	ARGCNT	Character	20
7	PARAMETERS	Character	40
8	FAILPRCNT	Numeric	2
9	DURATION	Character	8
10	NEED ROBOT	Character	3

**TEMPLATE.DBF File Structure**

1	BAR_CODE	Character	6
---	----------	-----------	---

**STORAGE.DBF File Structure**

1	SERVERID	Numeric	4
2	SERVER	Character	20
3	INDEX	Numeric	3
4	TYPE	Character	1
5	SUBTYPE	Numeric	3
6	STATUS	Numeric	1
7	PARTID	Numeric	4
8	PARTNAME	Character	20
9	PARTPOS	Numeric	4
10	TEMPLTID	Numeric	4
11	TEMPLATE	Character	20
12	TEMPLTPOS	Numeric	4

Fld #	Field Name	Type	Width
<b>ORDER.DBF File Structure</b>			
1	SEQNO	Numeric	2
2	PART	Character	20
3	ITEMS	Numeric	3
4	FIRSTDO	Numeric	
5	NEXTDO	Numeric	2
6	PRIORITY	Numeric	2
7	TARGET	Character	20
8	NOTE	Character	40
9	DUEDATE	Date	8
10	DUETIME	Character	8
11	DONE	Numeric	3
12	FAIL	Numeric	3
13	INPROCESS	Numeric	3
14	EXPDATE	Date	8
15	EXTIME	Character	8

**APLAN.DBF File Structure**

1	PART	Character	20
2	SEQNO	Numeric	2
3	PROCESS	Character	20
4	SUBPART	Character	20
5	TARGET	Character	20
6	INDEX	Character	20
7	DURATION	Character	8
8	PARAMETER	Character	80

**CStOrder.DBF File Structure**

1	CUSTNAME	Character	20
2	PART	Character	20
3	ITEMS	Numeric	3
4	DONE	Numeric	3
5	PRIORITY	Numeric	2

Fld #	Field Name	Type	Width
6	DUEDATE	Date	10
7	DUEPERIOD	Character	8
8	MANINDEX	Numeric	8

#### Customer.DBF File Structure

1	CUSTNAME	Character	20
2	DESC	Character	80
3	ADDRESS	Character	40
4	PHONE	Character	25
5	FAX	Character	25
6	EMAIL	Character	25

#### Orderlist.DBF File Structure

1	SEQNO		2
2	PCONTROL	Character	1
3	DESC	Character	80

#### PURCHASE.DBF File Structure

1	SUPPLIER	Character	20
2	PART	Character	20
3	SPART	Character	20
4	ITEMS	Numeric	3
5	COST	Numeric	6
6	DUEDATE	Numeric	6
7	SENDDATE	Numeric	6

**SUPPLIER.DBF File Structure**

1	SUPPLIER	Character	20
2	DESC	Character	80
3	ADDRESS	Character	40
4	PHONE	Character	25
5	FAX	Character	25
6	EMAIL	Character	25

**REPORT.DBF File Structure**

1	NAME	Character	20
2	REPORTNAME	Character	120
3	DESTINATION	Character	30
4	NOTE	Character	80

**SCHEDULER.DBF File Structure**

1	PART	Character	20
2	PROCESS	Character	20
3	MACHINE	Character	20
4	ORDERNUMB	Numeric	3
5	PLNSTART	Character	8
6	PLNFINISH	Character	8
7	PLDURATION	Character	8
8	ACTSTART	Character	8
9	ACTFINISH	Character	8
10	ACTDURATION	Character	8
11	STATUS	Numeric	2

**LEAFPART.DBF File Structure**

1	ID	Numeric	2
2	NAME	Character	20
3	ORDER_NO	Numeric	3
4	IDLIST	Character	80
5	ACTION_POS	Numeric	3
6	ACTION_SUB	Numeric	3
7	ACTION_TYPE	Numeric	3
8	STATUS	Numeric	1



**CIMREP.DBF File Structure**

1	CODE	Character	20
2	ORDER	Character	20
3	ORDERSEQ	Character	20
4	PART	Character	20
5	PARTID	Numeric	4
6	DEVICE	Character	20
7	DEVICEID	Numeric	4
8	ACTION	Character	20
9	ACTIONID	Numeric	4
10	SUBPART	Character	20
11	SUBPARTID	Numeric	4
12	WHICYH	Character	20
13	INDEX	Numeric	3
14	STATION	Character	20
15	TIME	Character	8
16	DATE	Date	10
17	DURATION	Character	8

**PERFORMANCE.DBF File Structure**

1	SERVER	Character	30
2	ORDERID	Character	5
3	TOTALTIME	Character	17
4	PROCTIME	Character	17
5	EFFICIENCY	Character	10
6	MAXQUELEN	Character	4
7	COST	Character	15
8	SETUPS	Character	4
9	FAILPRCNT	Character	10
10	NOTE	Character	80

**OPT\_MQUEUE.DBF Structure**

1	SERVER	Character	30
2	ALGNAME	Character	30
3	ALGWEIGHT	Character	3

4	ACTIVE	Character	3
5	FIN2FIN	Character	
6	Note	Character	80

### 12.4.1. Application to Report File Cross Reference

The following table links the specific OpenMES application to the database file name, the report name and the report template file name.

Application	Database File Name	Report Name	Report Template File Name
Part Definition	PART_DEF.DBF	Part Report	part.rpt
	PART_PRC.DBF	PProcess Report	proces.rpt
		Product Tree	partprocess.rpt
Machine Definition	MACHINE.DBF	Machine Definition Report	machine.rpt
Storage Definition (ASRS)	STORAGE.DBF	AS/RS Report	ASRS.rpt
OpenMES Manager (Created by)	CIMREP.DBF	Analysis Report	Analysis.rpt
OpenMES Manager and ASRS	STORAGE.DBF	Location Status Report	Location.rpt
MRP	APLAN.DBF	Aplan Report	Aplan.rpt
	ORDER.DBF	Order Report	order.rpt
	PURCHASE.DBF	Purchase report	Purchase.rpt
Performance	Performance*.DBF	Performance Report	performance.rpt
Optimization	OPT_MQUEUE*.DBF	Optimization Settings Report	Optimization.rpt
Report Generator	PART_DEF.DBF	Part Definition	Part.rpt
	PART_PRC.DBF	Sub. part	Subpart.rpt
	PART_PRC.DBF	Process	Process.rpt
	MACHINE.DBF	Machine Definition	Machine.rpt
	STORAGE.DBF	Storage Definition	asrs.rpt

PURCHASE.DBF	Purchase	purchase.rpt
ORDER.DBF	Manufacturing Order	order.rpt
APLAN.DBF	Aplan	aplan.rpt
CIMREP.DBF	Analysis	analysis.rpt
STORAGE.DBF	Location	location.rpt

## 12.5. SOFTWARE BACKUP

Since system files could be altered or destroyed, it is recommended that you keep backup files of your OpenMES system. The backup files can be used to restore the system if necessary.

The backup procedure involves three stages:

Back up the ACL controllers to the Station Manager Pcs (detailed in Chapter 8).

Back up the Station manager PCs to the OpenMES Manager PC.

Back up the OpenMES Manager PC to a backup disk.

ⓘ *These procedures should be performed by the system supervisor only.*

*Do not perform Backup procedures while the OpenMES is running because currently running programs may be aborted and data files may be in an unstable state.*

*Always keep robot positions, ACL programs and parameters on disk.*

*Backup and restore the entire system regularly to ensure good backup at all times.*

The following procedure backs up a CIM cell directory.

❶  
❷  
❸  
Procedure  
Backing up the  
OpenMES System

1. Back up the ACL controllers to a backup folder in each WSn folder in the Manager PC.
2. Place all relevant data of a CIM cell under its folder in the Manager PC.
3. Compress the CIM cell folder using Winzip.
4. Make copies of the compressed folder to your backup disk

It is recommended that you also make separate backup files of the following items:

Robot Points	Robot point coordinates are associated with the station PC connected to an ACL controller. These points can change whenever a new product is defined, an existing product definition changes, or a robot (or any other device) is moved.
Gcode and process programs files	These files contain the process program of the CNC machines or/and other processing machines.
QC script files	These files contain the Quality Control procedures.

# 13. Errors and Troubleshooting

This chapter describes how to handle device errors, troubleshooting and so on. It includes the following sections:

- Device Error Handling, describes the device error window that appears whenever a problem is detected with a specific machine or a robot as well the information referring to occurring problems.
- Troubleshooting, describes various trouble shooting procedures enabling you to identify the problems.
- Error Messages, lists the OpenMES error messages.
- Contacting Technical Support, describes how to contact Intelitek or your local distributor for assistance and displays the problem report form.

## 13.1. DEVICE ERROR HANDLING

The Device Error screen appears whenever a problem is detected with a specific machine or a robot. This screen allows you to determine how to deal with an error without having to reset the entire CIM.

The screenshot shows a window titled "Error Screen" with the following fields and controls:

- Station: WS 1
- Machine: ROBOT1
- Order: CIM ORDER
- Action: PLACE
- Part: LATHE SUP
- Next Process: CNC
- Next Machine: PLT3000\_1
- \*\*\* Manual Stop \*\*\*
- Error No.: 2
- Program: [empty]
- Prg Id: 1
- Line: 100
- Source: GFDR2
- Target: PLT3000\_1
- Buttons: IGNORE ERROR, CONTINUE ON TARGET
- FAIL OPTIONS:
  - Total Lost of Part
  - Process Unoperative
  - Machine Unoperative
  - FAIL

Figure 154: Device Error Screen

Device errors can be caused by various factors, including:

- Robot collision
- Device breakdown
- Defective part which does not properly fit into a machine or robot
- Machine running out of supplies for a given process

The Device Error screen gives you complete information about what was happening at the time that the problem occurred. It identifies the current part that was being processed (current process) when the error occurred. You can then choose what to do in order to recover from the error.

This screen is divided into the following sections:

- Where the problem occurred (top)
- What the problem is (middle)
- How to proceed (bottom)

### 13.1.1. Where the Problem Occurred

The following table describes information referring to a problem that occurred in OpenMES. This includes the station where the problem occurred, the part that was being processed when the problem occurred and so on.

Station	The name of the workstation PC where the problem occurred (e.g. WS 03).
Part	The ID of the current part that was being processed when the error occurred.
Device	The name of the robot or machine that experienced the problem.
Next Process	The name of the process that was to be performed on the Next Machine (described below). By examining the Process table for the current part, you can determine exactly where the production process was interrupted (select the current part on the Part Definition form).
Order ID	The entry in the Order table that was interrupted by the error.
Next Machine	The name of the next machine that was to process the current part. This information is especially useful when a robot error occurs. The Next Machine field tells you where the robot was supposed to deliver the current part when the error occurred.
Action	The CIM production command (A-plan action) that was being carried out when the error occurred.

### 13.1.2. What the Problem Is

All fields described in this section are optional. For a given error message, only those fields for which information is available will display.

Error Message	The text of the error message generated by the control program (e.g. robot program, G-code, etc.) that was running when the error occurred.
Error No.	The error code returned by the control program.
Program Name	The name of the program that was running when the error occurred.
Program ID	The ID number of the control program.
Program Line #	The line in the control program that generated the error.

- Source Location    The place where the current part resided prior to the error. This field consists of a location ID followed by an index number if appropriate (e.g. a slot number in a rack).
- Target Location    The place where the current part was to go next if the error had not occurred. This field consists of a location ID followed by an index number if appropriate (e.g. a slot number in a rack).

### 13.1.3. How to Proceed

In order to continue operation, two tasks must be accomplished:

- The part should be placed where the next process assumes the part is to be found.
- The proper messages must be sent to the OpenMES Manager so that it can activate the next process.

In most cases, the safest and easiest way to accomplish these tasks is to:

1. Remove the source of the problem.
5. Cause the device to repeat the operation. This is done by sending the device the appropriate command from the device driver. Then the OpenMES Manager ignores the reported error because the problem for the device has already been corrected.

**Ignore**            Process successfully completed; ignore the error and resume production.  
 If the current process was successfully completed (with or without help from the operator), clicking the Ignore button causes the OpenMES Manager to ignore the cause of the error and proceed with normal processing of the current part.



*Before you select ignore, make sure that:  
 The current part has not been damaged as a result of the error.  
 The cause of the error will not recur.  
 The current part is in the proper position to be handled by the next process.*

**Retry**            Reserved for future use.

**Fail**              Reserved for future use.

### 13.1.4. How to Recover a Failed Device

If a device fails to operate (for example a CNC machine), the CIM-Device Error! screen appears. To recover:

- 1
  - 2
  - 3
- Procedure

1. Go to the device that has failed (CNC, Robot, QC or PLC) and abort all programs.

## Recovering a Failed Device

2. Find the problem and correct it.
3. Return to the CIM Manager PC and select “Ignore” in the CIM Device Error! screen. The manager assumes that the last operation was completed and continues on to the next operation.

**Example 1:** While running the application, a robot goes into impact protection and the CIM-Device Error! screen appears on your CIM Manager PC.

1. Refer to the Robot user manual and take corresponding actions to abort the current program.
2. If appropriate (depending on specific robot controller type), initialize the controller.
3. Verify that the robot is in free space and then type Run Homes. Wait until the robot has finished homing.
4. Return to the CIM Manager PC and select “Ignore” in the CIM Device Error! screen.
5. According to the type of controller, try to run the last submitted Pick and Place sequence.

**Example 2:** While running the application, the CNC fails and the CIM-Device Error! screen appears on your CIM Manager PC.

1. Go to the CNC device driver.
2. Find the problem in the CNC machine and correct it.
3. Load the machine again (manually) with its supplied part.
4. Prepare the machine for Cycle Start.
5. Return to the CIM Manager PC and select “Ignore” in the CIM Device Error! screen
6. Using the CNC device driver, return to the last operation (normally Operate0). Wait until the CNC finishes its G-code.
7. Return manually to the last OpenMES operation using that device driver.



## 13.2. TROUBLESHOOTING

If the installation and startup procedures detailed in your system user manual were closely followed, your OpenMES system will give you reliable service. If a problem should occur, the first step in the troubleshooting procedure is to identify the problem and its source.

If you encounter problems accessing the Web Viewer, verify that the Internet Explorer Security Settings are set to the default settings.

The OpenMES system has been designed to simplify troubleshooting procedures by using the CIM-Device Error! dialog box.

When troubleshooting, pay careful attention to the following general warnings:



*Warning*

*Have all personnel remain clear of the robot envelope, CNC machines, Quality Control machines, and all other equipment when power is applied. The problem may be intermittent and sudden unexpected robot or equipment motion could result in injury.*

*Have someone ready to operate an emergency “Stop” switch in case it becomes necessary to shut off power to the robot’s CNC machines, QC machines, etc.*

*Never reach into a machine or robot to actuate a switch because unexpected machine or robot motion could occur, causing injury.*

*Remove all electrical power at the main, and turn off all switches before checking electrical connections or any inputs/outputs which could cause robot or machine motion.*

There are several cases of alteration that can occur to the OpenMES programs, including extreme environmental conditions, electromagnetic interference, improper grounding, improper wiring connection and unauthorized tampering. If you suspect the memory of the PC has been altered, scan the disk with the appropriate utility.

Problem	Solution
<p>1. If you receive one of the following messages:                      General Protection Error...                      Assertion Failed...                      An Error has occurred in your application...</p>	<p>Reset your PC, and perform a disk scan.</p>
<p>2. OpenMES tells you that it has received an unknown message.</p>	<p>This is not a real problem. This occurs when someone clicks the mouse on one of the OpenMES device drivers and activates a procedure.</p>

Problem	Solution
<p>8. The system is running but the robot Device Driver is not responding to OpenMES Manager.</p>	<p>ACL:</p> <ul style="list-style-type: none"> <li>• Verify that the ACL controller is in CON mode.</li> <li>• Verify that ACL Controller-A is in Motors ON.</li> <li>• Try to run the failed command again from the control panel of the ACL device driver.</li> <li>• Verify that your MAP.INI is correct.</li> <li>• Review the robot and controller user manuals, and check if the robot system is operational and is communicating with OpenMES.</li> </ul> <p>Scorbase:</p> <ul style="list-style-type: none"> <li>• Verify that you have a single Network Connection in the System Network Connections Window.</li> <li>• Verify that your MAP.INI is correct.</li> <li>• Verify that you are working in StandAlone mode.</li> <li>• Verify that your TCP/IP status is enabled. To do so:</li> <li>• Click the TCP/IP icon on the toolbar and select <b>Enable TCP/IP</b> if it is disabled.</li> </ul>
<p>9. While the system is running, a pallet stops in the wrong destination or does not stop in the correct position.</p>	<ul style="list-style-type: none"> <li>• Turn the PLC off and then turn it on again. Verify for each pallet, that it stops and releases at each station.</li> <li>• Start the PLC device driver. Place only one pallet on the conveyor and follow the report on the PLC device driver control panel. Verify that the correct pallet ID is reported for each station as the pallet passes. Repeat the same test for each pallet.</li> <li>• Using the control panel, deliver one of the pallets to one of the stations and release it (refer to “The PLC Device Driver” for more details on operating the PLC device driver).</li> </ul>
<p>10. The system is running but the PLC is not responding.</p>	<ul style="list-style-type: none"> <li>• Verify that the PLC is on.</li> <li>• Verify that you are able to operate the PLC from the control panel.</li> <li>• Verify that your MAP.INI is correct.</li> </ul>

Problem	Solution
<p><b>11.</b> The system is running but the RVP is not responding.</p>	<ul style="list-style-type: none"> <li>• Verify that your MAP.INI is correct.</li> <li>• Verify that the RVP is in the automatic mode and you received the prompt &gt;.</li> </ul>
<p><b>12.</b> The system is running but the CNC does not respond.</p>	<ul style="list-style-type: none"> <li>• Try to operate the CNC machine from own board.</li> <li>• Verify that the CNC is in the mode designated by your system user's manual.</li> <li>• Try to operate the CNC machine from the CNC device driver.</li> <li>• Verify that your MAP.INI is correct.</li> </ul>
<p><b>13.</b> You try to run the system and the yellow Wait message appears (after waiting there is still no change).</p>	<ul style="list-style-type: none"> <li>• Verify that your MAP.INI is correct.</li> <li>• Check the OpenMES Debug dialog box. If "Error 8" is displayed, reboot your PC.</li> </ul>
<p><b>14.</b> One of the OpenMES applications is unable to locate one of its source files in the setup directory.</p>	<ul style="list-style-type: none"> <li>• Using the File Manager, verify that the project directory (on the main PC) is a shared directory.</li> <li>• Verify that your PC is connected to the main PC according to your identification in all your local INI files.</li> </ul>
<p><b>15.</b> The barcode fails a good template.</p>	<ul style="list-style-type: none"> <li>• If your barcode is operated by an ACL controller, verify that in your Part Definition form you entered the following: PROCESS column : READC PARAMETERS column: \$TEMPLATETYPE</li> </ul>
<p><b>16.</b> The OpenMES Manager is running, but gets stuck after the CNC process.</p>	<ul style="list-style-type: none"> <li>• In the Machine Definition form, verify that the field "List of Preloaded Programs" is not empty.</li> </ul>

Problem	Solution
<p><b>17.</b> The ACL driver can not establish communication with the robot.</p>	<ul style="list-style-type: none"> <li>• Verify that the ACL controller is on.</li> <li>• Verify that the motors are on.</li> <li>• Verify that no other application is using the same COM port (e.g. ATS, ACL Off line).</li> <li>• Exit Windows and start the ATS using the correct COM port. If the problem still exists, refer to the ATS manual.</li> <li>• Start Windows and then start the ACL device driver.</li> <li>• If the problem still exists, exit the device driver and verify the COM port in the ACL.INI file.</li> </ul>
<p><b>18.</b> The following communication error message appears while operating the robot from a PC with Scorbase: No communication between Controller-USB and computer. The Power LED is orange.</p>	<ul style="list-style-type: none"> <li>• Change to On-line mode.</li> <li>• Make sure the connecting cable is properly connected to the Controller-USB and to the computer.</li> <li>• If the problem persists, replace the USB cable.</li> <li>• Reinstall the USB driver. Refer to the section “USB Driver Installation” below.</li> </ul>
<p><b>19.</b> A device driver is unable to open an RS232 port in order to communicate with its device, and displays the following message in the Control Mode box: Cannot Open Com : n</p>	<ul style="list-style-type: none"> <li>• This error message indicates that the device driver could not open the serial port on the Station Manager PC. Possible causes include:</li> <li>• The port is in use by another application.</li> <li>• The port number is invalid.</li> <li>• One of the serial port parameters is invalid.</li> </ul>
<p><b>20.</b> The ViewFlex device driver can not establish communication with the Manager</p>	<ul style="list-style-type: none"> <li>• Verify that your MAP.INI is correct.</li> <li>• Verify that script file directory is defined correctly in the VFVD.INI file.</li> <li>• Verify that ViewFlex device driver is in On line mode.</li> </ul>

### 13.3. ERROR MESSAGES

Several errors shown in the list below are related to setup problems. The Virtual OpenMES Setup stores its information in the file SETUP.CIM.

Code	Description and Solution
9001	Undefined Part Set up this part using the Part Definition module.
9002	Internal Error <ul style="list-style-type: none"> <li>Call Intelitek technical support.</li> </ul>
9003	A Start Operation message was received when no operation was requested.
9004	A Finish Operation message was received when no operation was requested.
9005	An End Operation message was received when no operation was requested. <ul style="list-style-type: none"> <li>Check the ACL program or CNC or Scorbace script associated with the current process that may be sending an erroneous Start, Finish, or End message. OR</li> <li>Someone has manually triggered a Start, Finish, or End message by running a program from the Control Panel of either the ACL or CNC device driver.</li> </ul>
9006	Unrecognized device, location, or part. <ul style="list-style-type: none"> <li>Define the unrecognized device or location using the Setup module. OR</li> <li>Define an unrecognized part using the Part Definition module.</li> </ul>
9007	Cannot perform this process. Either the process definition or device definition is missing. <ul style="list-style-type: none"> <li>Define the unrecognized process using the Machine Definition module. OR</li> <li>Define the unrecognized device using the Setup module.</li> </ul>
9008	Start message received from an unrecognized device.
9009	Finish message received from an unrecognized device.
9010	End message received from an unrecognized device.
9011	Error message received from an unrecognized device.

Code	Description and Solution
	<ul style="list-style-type: none"> <li>Someone has manually triggered a Start, Finish, End or Error message by running a program from the Control Panel of either the ACL or CNC device driver. OR</li> <li>Check if the ACL program or CNC script that sent the message is using an invalid device ID (\$ID). OR</li> <li>Incorrect assignment of a device to a device driver in the file VC2.MAP. OR</li> <li>The device ID on the device driver command line is incorrect. OR</li> <li>Define the unrecognized device using the Setup module. OR</li> </ul>
9012	<p>This location has not been assigned to a robot.</p> <ul style="list-style-type: none"> <li>Use the Setup program to make this assignment.</li> </ul>
9013	<p>The file SETUP.CIM is missing from the working directory.</p> <ul style="list-style-type: none"> <li>Copy a backup version of this file to the working directory. OR</li> <li>Run the Setup module to create a new setup file from scratch.</li> </ul>
9014	<p>Unable to transfer this part to its next destination.</p> <ul style="list-style-type: none"> <li>No path has been defined between the part's current location and its next destination. Use the Setup module to link these two locations. OR</li> <li>Internal Error. Call Intelitek technical support.</li> </ul>
9015	<p>Cannot move part because its destination location is already occupied.</p> <ul style="list-style-type: none"> <li>Internal Error. Call Intelitek technical support.</li> </ul>
9016	<p>The robot has received a command to continue an operation that it has not started.</p> <ul style="list-style-type: none"> <li>Add the Move command to the Part Definition table to have the robot grab the part first.</li> </ul>
9017	<p>Invalid Storage Device. A request was received to retrieve a part from a location that is not a storage device.</p> <ul style="list-style-type: none"> <li>Use the Setup module to define the target device as a storage device. OR</li> <li>Use the Part Definition module to change the target device to be a valid storage device.</li> </ul>
9018	<p>This part is not available to the current process.</p> <p>Check the Part Definition table.</p>
9019	<p>A quality control result was received when no QC test was requested.</p>

Code	Description and Solution
	<ul style="list-style-type: none"> <li>• Check if an ACL program or CNC script is sending an incorrect message. OR</li> <li>• Someone has manually triggered a quality control result by running a program from the Control Panel of either the ACL or CNC device driver.</li> </ul>
9020	Reserved for future use.
9021	<p>An unexpected status message was received. There was no corresponding command message sent.</p> <ul style="list-style-type: none"> <li>• Check if an ACL program has assigned an invalid value to the variable \$ID (the task ID). OR</li> <li>• Check if a CNC program has assigned an invalid value to the variable \$ID. OR</li> <li>• Device driver internal error. Call Intelitek technical support.</li> </ul>
9022	Reserved for future use.
9023	<p>Invalid storage index.</p> <ul style="list-style-type: none"> <li>• Use the Setup module to increase the value of the Capacity field for this storage device. OR</li> <li>• Use the Part Definition module to ensure that the storage index specified in the Parameter field of the Part Definition table is within the range of the Capacity field for this device.</li> </ul>
9024	<p>Part is not available at this storage location.</p> <ul style="list-style-type: none"> <li>• Use the Storage Definition module to update the storage contents. OR</li> <li>• Abort this order if there are not enough parts to complete it.</li> </ul>
9025	<p>Invalid location index for a machine.</p> <ul style="list-style-type: none"> <li>• Use the Setup module to increase this machine's part capacity. OR</li> <li>• Internal Error. Call Intelitek technical support.</li> </ul>
9026	<p>Undefined process.</p> <ul style="list-style-type: none"> <li>• Add this process to a suitable machine using the Machine Definition module. OR</li> <li>• Modify the Part Definition table to use a valid process.</li> </ul>
9027	<p>No template buffer has been defined for this station.</p> <ul style="list-style-type: none"> <li>• Use the Setup module to add a buffer.</li> </ul>
9028	<p>Process cannot be performed because the machine is not defined in the file SETUP.CIM.</p>

Code	Description and Solution
	<ul style="list-style-type: none"> <li>Use the Part Definition module to specify a different process in the Part Definition table. OR</li> <li>Use the Setup module to define this machine.</li> </ul>
9029	<p>Inconsistent value in the inventory database file STORAGE.DBF.</p> <ul style="list-style-type: none"> <li>Rebuild the storage data by adding the “/INIT” switch to the OpenMES Manager command line (CIM.EXE). OR</li> <li>Check the OpenMES Manager’s INI file (usually OPENMES.INI) to ensure that the parameter <i>CimDataDir</i> in the [General] section is the same as that in the INI file for the Storage Definition module.</li> <li>If you want to restore a known good copy of the file STORAGE.DBF, click on the Refresh Storage icon on the Program Manager screen (or manually copy this file from a backup).</li> </ul>
9030	<p>Machine not defined in file SETUP.CIM.</p> <ul style="list-style-type: none"> <li>Use the Machine Definition module to set up this machine.</li> </ul>
9031	<p>The requested G-code task has not been assigned to a CNC machine.</p> <ul style="list-style-type: none"> <li>Use the Machine Definition module to assign this task to this CNC machine.</li> </ul>
9032	Reserved for future use.
9033	Reserved for future use.
9034	<p>Unexpected ONFAIL process.</p> <ul style="list-style-type: none"> <li>Use the Part Definition module to edit the Part Definition table so that ONFAIL only appears immediately after a quality control process.</li> </ul>
9035	<p>No ONFAIL process immediately after a quality control test.</p> <ul style="list-style-type: none"> <li>Use the Part Definition module to edit the Part Definition table so that ONFAIL appears immediately after this quality control process.</li> </ul>
9036	Reserved for future use.
9037	<p>Error in A-Plan Place command.</p> <ul style="list-style-type: none"> <li>Internal Error. Call Intlitek technical support.</li> </ul>
9038	<p>Error in A-Plan Next command.</p> <ul style="list-style-type: none"> <li>Internal Error. Call Intelitek technical support.</li> </ul>
9039	Reserved for future use.



Code	Description and Solution
9040	The parameter <i>ConPallet</i> (maximum # of pallets) is not defined in the file SETUP.CIM. <ul style="list-style-type: none"> <li>Add <i>ConPallet</i> assignment to SETUP.CIM.</li> </ul>
9041	Cannot start the OpenMES Manager because it is already running on this PC. <ul style="list-style-type: none"> <li>Switch to the window in which the OpenMES Manager is running.</li> </ul>
9042	Reserved for future use.
9043	Invalid status message. Received an unexpected quality control result from a non-QC device. <ul style="list-style-type: none"> <li>Check an ACL program or CNC script that might be sending an incorrect message.</li> </ul>
9044	Reserved for future use.
9045	Invalid status message. A bar code result was received when no operation was requested. Result ignored. <ul style="list-style-type: none"> <li>Someone has manually triggered a bar code result by running a bar code program from an ACL Control Panel. OR</li> <li>Check an ACL program or CNC script that might be sending an incorrect message.</li> </ul>
9046	Machine queue overflow - Too many parts are waiting to use this machine. Use the Order Entry module to decrease the initial quantity ordered for parts that use this machine.
9047	Reserved for future use.
9048	No status message was received after a command was sent because this device driver was reset. <ul style="list-style-type: none"> <li>Select how you would like to continue from the options shown on the Device Error screen.</li> </ul>
9049	No status message was received after a command was sent because this device driver is not running. <ul style="list-style-type: none"> <li>Select how you would like to continue from the options shown on the Device Error screen.</li> </ul>
9050	DBF handler error - Request to use an inactive field. <ul style="list-style-type: none"> <li>Internal Error. Call Intelitek technical support.</li> </ul>
9051	DBF handler error - Record number less than 1.

---

Code	Description and Solution
	<ul style="list-style-type: none"><li>• Internal Error. Call Intelitek technical support.</li></ul>

---

## 13.4. CONTACTING TECHNICAL SUPPORT

If you need to contact Intelitek or your local distributor for assistance, go to <https://intelitek.com/contact-us/>.

### 13.4.1. Problem Report Form

When contacting Intelitek support, include the information listed here:

- Product name
- Location of installation
- Serial numbers of all relevant Intelitek elements
- Date of purchase or invoice number
- Version number and date of every Intelitek software used (the information appears on the first screen of every software supplied, and through the ACL command VER regarding EPROMs)
- Detailed descriptions of the problem, including (but not only) all the steps which led up to the problem arising, since the start-up of the system (attach more pages if necessary)
- Error messages as they appear on the display (PC screen, TP LCD, PLC LEDs, etc.)
- List all changes introduced to the system since the last time the system worked properly
- **For robots:**
  - List of accessories and I/Os connected to controller and type of gripper attached to arm
  - Attach a printout of all the control parameters
- **For computers**
  - Computer type, DOS version and manufacturer
  - List of cards added (LAN, modem, etc)
  - Attach a printout of the AUTOEXEC.BAT and CONFIG.SYS file.

# 14. Glossary

This chapter contains the various abbreviations and terminology used in OpenMES. It includes the following sections:

- Abbreviations, contains a list of the acronyms used in OpenMES, as well as their descriptions.
- Terminology, contains a list of the OpenMES terminology, as well as their descriptions.

## 14.1. ABBREVIATIONS

Abbreviation	Explanation
ACK	Acknowledge
ACL	Advanced Control Language
AGV	Autonomous Guided Vehicle
ASRS	Automated Storage and Retrieval System
ATS	Advanced Terminal Software
BMP	BitMaP (the file extension representing the Windows native bitmap picture format)
bps	bits per second
CIM	Computer Integrated Manufacturing
CNC	Computer Numerically Controlled
DBF	Database File (in dBASE format)
DD	Device Driver
FIFO	First In, First Out
FMS	Flexible Manufacturing System
GT	Get part (robot operation)
LAN	Local Area Network
LIFO	Last In, First Out
LSM	Laser Scan Meter
MRP	Material Resource Planning
NACK	Negative Acknowledgment
PLC	Programmable Logic Controller
PP	Pick-and-Place (robot operation)
PT	Put Part (robot operation)

Abbreviation	Explanation
QC	Quality Control
RV	Robot Vision
TCP/IP	Transmission Control Protocol - Internet Protocol
WMF	Windows Meta Format (the file extension representing the Windows native vector picture format)
WS	Workstation

## 14.2. TERMINOLOGY

Term	Explanation
ACL	Robotic programming language used to control robots and peripheral equipment attached to Intelitek's ACL controllers (Advanced Control Language).
ACL Controller	A multitasking computer used to direct the operations of a robot(s) and peripheral devices in real-time.
ASRS	A robotic storage device used to store and dispense parts in a CIM cell.
Assembly	A part which has been put together from two or more subparts.
ATS	A PC based terminal emulation program used to program an ACL controller (Advanced Terminal Software).
Baud Rate	An RS232 parameter specifying the speed of the serial connection.
Bill of Materials	A structured list of all the materials or parts needed to produce a particular finished product or subpart.
Buffer	A buffer is a tray designed to hold a template when it is removed from the conveyor. It is attached to the outer rim of the conveyor at a station.
OpenMES Manager	The central control program of OpenMES. This program directs production in the CIM cell using a variety of communication networks. It also allows the user to set up and define CIM elements.
Com Port	See RS232.

Term	Explanation
Control Program	A program which manages the operation of a CIM device such as a robot (ACL program), a CNC machine (G-code), a camera (ROBOTVISIONpro program), etc. A control program communicates with the OpenMES system via a device driver at a Station Manager PC. The computer which executes a control program can reside in: A separate controller unit (e.g. an ACL controller) In the device itself (e.g. a CNC machine with embedded controller) A separate PC controlling the device (e.g. a PC attached to a ROBOTVISIONpro camera)
DBF	A file extension indicating “Data Base File” (i.e. in dBASE format).
Device Driver	A program which knows how to communicate with a given piece of equipment that is connected to a PC. It translates commands from other programs into a format understood by the device. It also translates information coming from the device into a format understood by other programs. OpenMES uses device drivers to communicate with robot controllers, CNC machines, and quality control devices.
Download	The act of sending a file(s) from one computer system to another.
Feeder	A device which dispenses parts at station (typically to a robot).
FMS	Flexible Manufacturing System; refers to either a CIM cell or a station in a CIM cell.
Free Movement Zone	A region approximately ½ meter above the work surface in which the robot can move freely and quickly between locations without encountering any obstacles. See also <i>Pick-and-Place</i> .
G-Code	A program that directs the operation of a CNC machine. See also <i>Control Program</i> .
Group A, B	Used in the context of programming robot positions using ACL. A group refers to a set of axes of movement that apply to a device (e.g. robot, X-Y table). The device can move along all axes in its group simultaneously.
GT	The name of a generic ACL program used to direct a robot to pick up a part at a designated location.
Home a Robot	A procedure used to reset a robot to known starting position.
INI File	A text file containing settings for various OpenMES parameters. Parameters are grouped into sections. The structure of OpenMES INI files is similar to that of other standard Windows INI files such as WIN.INI.
I/O (Input / Output)	A low voltage connection used for binary signaling between devices (i.e. on or off). An input is used to read the status of a device. An output is used to turn a designated operation on or off.

Term	Explanation
Load	An operation which uses a robot to insert a part into a CNC machine.
Loader	A program which automates the start-up of the OpenMES system under Windows based on command line parameters found in an INI file.
Machine	A CIM device (other than a robot) which performs production processes (e.g. CNC machine, laser scan meter, etc.).
Machine Tending	A device (e.g. a robot) which delivers and retrieves parts from a machine.
Material	See <i>Part</i> .
Order	Instructs the CIM system which part(s) to produce and in what quantity.
Pallet	A tray which travels on the conveyor and is designed to carry a template.
Part	An entity which moves between stations and machines according to a predefined path, or process. Three types of parts can be defined: supplied, phantom, and final product.
Part Family	A group of parts which are handled the same way by a robot (i.e. the same ACL program can be used to <i>pick-and-place</i> parts in the same family).
Pick-and-Place	The primary robot function which involves taking a part from one location (source) and placing it at another location (destination). The pick-and-place strategy minimizes the number of ACL programs required to move parts between two locations at a station. Each location has a GET and PUT program associated with it. The GET program “picks” up a part from the location. The PUT program “places” a part at this location. All GET and PUT programs for a robot are designed to work together to transfer a part from any location to any other location.
PLC	A device having several electrical inputs and outputs. A PLC switches its outputs on and off in response to the state of its inputs and the programming of its embedded computer. In the OpenMES system, a PLC is used to control the conveyor.
Points	See Position.
Position	The path a robot follows is made up of a set of predefined points. Each point along this path is called a robot position. The coordinates of each point are “taught” by using a <i>teach pendant</i> or by running a special ACL program while leading the robot “by the nose” and recording each stopping point along the path.
Process	A production activity (e.g. lathing, milling, assembly, QC check, etc.) performed by a machine on a part.

Term	Explanation
Processed Material	A part which results from the processing of a raw material.
Product	Something that is manufactured by the CIM cell. The CIM begins production in response to orders placed for products.
PT	The name of a generic ACL program used to direct a robot to place a part at a designated location.
Quality Control	Any process used to check whether a part is satisfactory or not.
Rack	A set of storage compartments used at some stations to store parts either before or after they are processed at that station. Each type of rack is assigned an ID number. Each compartment in a rack is identified by a unique number.
Raw Material	See Supplied Part.
RS232	A common, low speed communication protocol which allows a wide variety of devices to communicate with each other (typically in the range of 300 - 19,200 bps). On a PC, RS232 ports are referred to as COM1 - COM4.
Robot	A device that moves parts from place to place at a station. Some robots are also capable of assembling parts.
Robot Vision	A quality control device which optically scans a part to determine if it is satisfactory.
Serial Port	See <i>RS232</i> .
Slidebase	A peripheral device which enlarges the working envelope of a robot by allowing it to move along a rail. The slide base gives the robot an additional degree of freedom.
Station	A location adjacent to the CIM conveyor which contains production and/or storage equipment.
Subpart	A part which undergoes some sort of processing in order to be included in a higher level part.
Supplied Part	A part which is the starting point for making a product. This part (or material) is purchased and inserted into a CIM storage location. It will later be processed by the CIM cell.
Template	Plastic trays which can hold various types of parts. They allow parts to be transported on the conveyor.
Unload	An operation which uses a robot to remove a part from a CNC machine.
Working Envelope	The entire area in which a robot can reach.

<b>Term</b>	<b>Explanation</b>
Xbase	Any database management program that is compatible with the dBASE standard for file formats and commands.



# 15. Intelitek Software Licensing

OpenMES software is protected by a licensing agreement. Full details on Intelitek software licensing are provided in the Intelitek Software Licensing Guide.