

ACL

for Controller-AC

Advanced Control Language

Version AC30.25

Reference Guide

Catalog #100122 Rev.02



Copyright © 1996, 1998 by Eshed Robotec (1982) Limited.

October 1998 (PDF version)

Catalog #100122 Rev.02

All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system or translated into any language in any form without the written permission of Eshed Robotec (1982) Ltd. Program listings may be entered, stored, and executed in a computer system, but they may not be reproduced for publication.

Every effort has been made to make this book as complete and accurate as possible. However, no warranty of suitability, purpose, or fitness is made or implied. Eshed Robotec (1982) Ltd. is not liable or responsible to any person or entity for loss or damage in connection with or stemming from the use of the equipment and/or the information contained in this publication.

Eshed Robotec (1982) Ltd. bears no responsibility for errors which may appear in this publication and retains the right to make changes to the hardware, software and manual without prior notice.

Table of Contents

Introduction

CHAPTER 1

ACL Programming Language: Quick Reference

Command Modes	1-2
Coordinate Systems	1-2
Data Types	1-3
Variables	1-3
Strings (Comments)	1-3
Positions	1-3
Parameters	1-3
Axis Control Commands	1-4
I/O Control Commands	1-9
Program Control Commands	1-11
Position Definition and Manipulation Commands	1-13
Variable Definition and Manipulation Commands	1-16
Program Flow Commands	1-17
Configuration Commands	1-18
Report Commands	1-20
User Interface Commands	1-22
Program Manipulation Commands	1-24
Editing Commands	1-25
RS232 Communication Commands	1-26
Backup/Restore Commands	1-27

CHAPTER 2

Command Modes and Formats

Command Modes	2-1
DIRECT Mode	2-1
Manual Keyboard Control	2-2
Teach Pendant Control	2-2
Direct Teach	2-2
EDIT Mode	2-2
Editing Functions	2-3
PRIVILEGE Mode	2-4
Run Modes	2-4
Normal Run	2-4
Step	2-4
Coordinate Systems	2-5
Joint Coordinates	2-5
Cartesian (XYZ) and Tool Coordinates	2-5
World (XYZ) Space	2-6
Invalid XYZ Space	2-7

Data Types	2-8
Variables	2-8
User Variables	2-8
System Variables	2-9
Variable Lists	2-10
Strings (Comments)	2-10
Positions	2-11
Types of Positions	2-11
Defining Positions	2-12
Recording Positions	2-13
Position Lists	2-14
Parameters	2-14
Notational Conventions Used in this Manual	2-15
Additional Notes	2-15

CHAPTER 3 The ACL Commands

A / <Ctrl>+A	3-2
ANDIF	3-3
APPEND	3-4
ATTACH	3-5
AUTO	3-6
BRAKE	3-7
BREAK	3-8
CLOSE	3-9
CLR	3-10
CLRBUF	3-11
CLRCOM	3-12
COFF	3-13
CON	3-14
CONFIG	3-15
CONTINUE	3-18
COPY	3-19
DEFINE	3-20
DEFP	3-21
DEL	3-22
DELAY	3-23
DELETE	3-24
DELP	3-25
DELVAR	3-26
DIM	3-27
DIMG	3-28
DIMP	3-29
DIR	3-30
DISABLE	3-31
DO	3-32

DOWNLOAD	3-33
ECHO	3-34
EDIT	3-35
ELSE	3-36
EMPTY	3-37
ENABLE	3-38
END	3-39
ENDFOR	3-40
ENDIF	3-41
ENGLISH	3-42
EXACT	3-43
EXIT	3-44
FOR	3-45
FORCE	3-46
FREE	3-47
GACCEL	3-48
GET	3-49
GETCOM	3-50
GLOBAL	3-51
GOSUB	3-52
GOTO	3-53
GSPEED	3-54
HELP	3-56
HERE / HEREC	3-57
HERER [C / T]	3-58
HOME / HHOME	3-60
IF	3-62
INIT	3-63
INSERT	3-64
JAPANESE	3-65
JOINT	3-66
L	3-67
LABEL	3-68
LET PAR	3-69
LINEAR	3-70
LIST	3-71
LISTP	3-72
LISTPV	3-73
LISTVAR	3-74
MODULO [ROLL]	3-75
MOVE / MOVED	3-76
MOVEC / MOVECD	3-79
MOVEL / MOVELD	3-80
MOVES / MOVESD	3-81
NOBREAK	3-82

NOECHO	3-83
NOQUIET	3-84
NOSTEP	3-85
OPEN	3-86
ORIF	3-87
P	3-88
PANEL	3-89
PASSWORD	3-90
PEND / POST	3-91
PRCOM	3-92
PRINT	3-93
PRINTLN	3-94
PRIORITY	3-95
PRIV[ILEGE]	3-96
PRLNCOM	3-97
PSTATUS	3-98
PURGE	3-99
PVAL / PVALC	3-100
QPEND / QPOST	3-101
QUIET	3-102
READ	3-103
READCOM	3-104
RECEIVE	3-105
REMOTE	3-107
REMOVE	3-108
RENAME	3-109
RUN	3-110
S	3-111
SEND	3-112
SENDCOM	3-113
SET	3-114
SETP	3-117
SETPV	3-118
SETPVC	3-120
SHIFT / SHIFTC	3-121
SHOW	3-122
SPEED	3-125
SPEEDL	3-126
SPLINE / SPLINED	3-127
SPLINEL / SPLINELD	3-128
STAT[US]	3-129
STEP	3-130
STOP	3-131
SUSPEND	3-132
TEACH	3-133

TEACHR[T]	3-134
TOOL	3-136
TRIGGER	3-137
UNDEF	3-138
UPLOAD	3-139
VER	3-140
WAIT	3-141
ZSET	3-142
<Enter>	3-143
*	3-144
@	3-145
~ (Manual Control)	3-146

CHAPTER 4 **Predefined System Elements**

System Procedures	4-1
HOME	4-1
Reserved Program Names	4-1
AUTO	4-1
BACKG	4-2
CRASH	4-3
EMERG	4-3
RECOV	4-3
START	4-3
Position POSITION	4-5
System Variables	4-6
IN[n]	4-6
ENC[n]	4-7
LSCW[n] and LSCCW[n]	4-7
CPOS[n]	4-8
POSER[n]	4-8
JTARG[n] and XTARG[n]	4-8
TQ[n]	4-8
INDEX[n]	4-9
TIME	4-9
LTIME[n]	4-1
CONST	4-10
MFLAG	4-11
HOMED	4-12
ERROR, ERRPR and ERRLI	4-13
OUT[n]	4-14
JOG[n]	4-14
TQMAX[n] and TQMIN[n]	4-15

CHAPTER 5 System Messages

CHAPTER 6 Parameters

Warnings	6-1
Parameter Protection	6-2
Parameter Commands	6-2
Parameter Descriptions	6-3

Introduction

ACL, Advanced Control Language, is an advanced, multi-tasking robotic programming language, which is programmed onto a set of EPROMs within **Controller-AC**. **ACL** can be accessed from any standard terminal or PC computer by means of an RS232 communication channel.

ACL features include the following:

- Direct user control of robotic axes.
- User programming of robotic system.
- Input/output data control.
- Simultaneous and synchronized program execution (full multi-tasking support).
- Simple file management.

This *Reference Guide* is a complete guide to **ACL**.

ATS, Advanced Terminal Software, is the user interface to **Controller-AC**. **ATS** is supplied on diskette and operates on any PC host computer. This software enables access to **ACL** from a PC computer. The *ATS Reference Guide for Controller-AC* fully describes the **ATS** software.

ACLOff-line is a preprocessor software utility, which lets you access and use your own text editor to create and edit **ACL** programs even when the controller is not connected or not communicating with your computer. After communication is established, the **Downloader** utility lets you transfer your program to the controller. The **Downloader** detects the preprocessor directives, and replaces them with a string or block of **ACL** program code. **ACLOff-line** also enables activation of **ATS** for on-line programming and system operation. **ACLOff-line** is described fully in the *ACLOff-line User's Manual*.

The **teach pendant**, an optional device, is a hand-held terminal which is used for controlling the robot and peripheral equipment connected to the robot controller. The teach pendant is most practical for moving the axes, recording positions, sending the axes to recorded positions and activating programs. Other functions can also be executed from the teach pendant. The *Teach Pendant for Controller-AC User's Manual* fully describes the various elements and functions of the teach pendant.

This page intentionally left blank.

ACL Programming Language: Quick Reference

This chapter presents a brief summary of the command modes and data types used by **ACL**. These topics are described fully in other chapters of this manual.

In addition, this chapter includes brief descriptions of the **ACL** commands grouped according to the categories listed below. These lists will help you compare and select the command most suitable for your specific programming and operating requirements.

- Axis Control Commands
- I/O Control Commands
- Program Control Commands
- Position Definition and Manipulation Commands
- Variable Definition and Manipulation Commands
- Program Flow Commands
- Configuration Commands
- Report Commands
- User Interface Commands
- Program Manipulation Commands
- Editing Commands
- RS232 Communication Commands
- Backup/Restore Commands

For more detailed descriptions of individual commands, refer to Chapter 3.

Command Modes

ACL has two types of commands:

- DIRECT commands are executed as soon as they are entered at the terminal/computer keyboard.
- EDIT, or indirect, commands are executed during the running of the programs and routines in which they are used.

Some commands can be issued in both the DIRECT and EDIT modes, as indicated throughout this manual.

Some commands are password-protected, and can be issued only when the PRIVILEGE mode is active.

ACL provides two modes for program operation:

- RUN mode: programs are executed normally.
- STEP mode: allows user control of step-by-step program execution.

Refer to Chapter 2 for a detailed explanation of these command modes.

Coordinate Systems

ACL allows robotic systems to be operated and programmed in three different coordinate systems:

- JOINT (resolver) values.
- XYZ (Cartesian) coordinates.
- Tool coordinates.

Refer to Chapter 2 for a detailed explanation of the coordinate systems.

Data Types

Variables

ACL uses two types of variables:

- User variables:
 - User defined **GLOBAL** variables can be used in all programs.
 - User defined **PRIVATE** variables can only be used in the program which was being edited at the time the variable was defined.

- System variables.

System defined variables contain values which indicate the status of inputs, outputs, resolvers, and other control system elements.

Refer to Chapter 4 for a detailed explanation of variables.

Strings (Comments)

Some **ACL** command lines include comments or textual strings. Strings of up to 40 characters and spaces are recognized.

Refer to Chapter 2 for a detailed explanation of strings.

Positions

ACL uses eight types of positions:

- Absolute Joint
- Absolute XYZ
- Relative to Another Position by Joint
- Relative to Another Position by XYZ
- Relative to Another Position by Tool
- Relative to Current by Joint
- Relative to Current by XYZ
- Relative to Current by Tool

Refer to Chapter 2 for a detailed explanation of positions.

Parameters

ACL parameters define the values of physical constants which adapt the controller to a particular robotic system.

Parameters are referred by their numbers (1 to 2048).

Refer to Chapter 6 for detailed descriptions of parameters.

Axis Control Commands

MOVE	OPEN	CON
MOVED	CLOSE	COFF
MOVEC		BRAKE
MOVECD	CLRBUF	
MOVEL		HOME
MOVELD	SPEED	
MOVES	SPEEDL	CLR
MOVESD	GSPEED	ZSET
SPLINE	GACCEL	MODULO ROLL
SPLINED	SHOW SPEED	
SPLINE		~
SPLINED	EXACT	<Alt>+M
SPLINEL		AUTO
SPLINELD	JOINT	
	LINEAR	

COMMAND	FORMAT	DESCRIPTION	MODE	NOTES
MOVE				
	MOVE <i>pos</i>	Moves axes to target position at current joint speed.	DIRECT, EDIT	
	MOVE <i>pos duration</i>	Moves axes to target position within time specified.	DIRECT, EDIT	
	MOVED <i>pos [duration]</i>	Same as MOVE, and suspends program until axes accurately reach target position.	EDIT	Execution is affected by EXACT command.
MOVEC				
	MOVEC <i>pos1 pos2</i>	Moves robot's TCP to position 1, along a circular path through position 2, at current linear speed.	DIRECT, EDIT	
	MOVECD <i>pos1 pos2</i>	Same as MOVEC, and suspends program until axes have accurately reached position 2.	EDIT	Execution is affected by EXACT command.
MOVEL				
	MOVEL <i>pos</i>	Moves robot's TCP to target position, along a linear path, at current linear speed.	DIRECT, EDIT	
	MOVEL <i>pos duration</i>	Moves robot's TCP to target position, along a linear path, within time specified.	DIRECT, EDIT	
	MOVELD <i>pos [duration]</i>	Same as MOVEL, and suspends program until axes accurately reach target position.	EDIT	Execution is affected by EXACT command.

COMMAND	FORMAT	DESCRIPTION	MODE	NOTES
MOVES				
MOVES	<i>pvect pos1 posn</i>	Moves axes smoothly through all consecutive vector positions between position 1 and position <i>n</i> , at current joint speed. Constant time between consecutive positions.	DIRECT, EDIT	
MOVES	<i>pvect pos1 posn duration</i>	Same as MOVES, except average speed determined by time definition.	DIRECT, EDIT	
MOVESD	<i>pvect pos1 posn</i>	Same as MOVES, and suspends program until axes accurately reach position <i>n</i> .	EDIT	Execution is affected by EXACT command.
SPLINE				
SPLINE	<i>pvect pos1 posn</i>	Moves axes smoothly through <i>or near</i> all consecutive vector positions between position 1 and position <i>n</i> . Constant speed between consecutive positions. axes move at current joint speed.	DIRECT, EDIT	
SPLINE	<i>pvect pos1 posn duration</i>	Same as SPLINE, except average speed determined by time definition.	DIRECT, EDIT	Execution is affected by EXACT command.
SPLINED	<i>pvect pos1 posn [duration]</i>	Same as SPLINE, and suspends program until axes accurately reach target position.	DIRECT, EDIT	Execution is affected by EXACT command.
SPLINEL	<i>pvect pos1 posn</i>	Same as SPLINE, except robot's TCP moves at currently linear speed.	DIRECT, EDIT	
SPLINEL	<i>pvect pos1 posn duration</i>	Same as SPLINEL, except average speed determined by time definition.	DIRECT, EDIT	Execution is affected by EXACT command.
SPLINELD	<i>pvect pos1 posn [duration]</i>	Same as SPLINEL, and suspends program until axes accurately reach target position.	DIRECT, EDIT	Execution is affected by EXACT command.
OPEN				
OPEN		Opens gripper.	DIRECT, EDIT	
CLOSE				
CLOSE		Closes gripper.	DIRECT, EDIT	
CLRBUF				
CLRBUF		Empties movement buffer of all axes.	DIRECT, EDIT	
CLRBUFA/B		Empties movement buffer of group A or group B.	DIRECT, EDIT	
CLRBUF	<i>axis</i>	Empties movement buffer of specific axis.	DIRECT, EDIT	\

COMMAND	FORMAT	DESCRIPTION	MODE	NOTES
SPEED				
	SPEED <i>var</i>	Sets speed for group A axes. Determines speed of MOVE, MOVES and SPLINE movements.	DIRECT, EDIT	$1 \leq var \leq 100$. Default is 50.
	SPEED{A/B} <i>var</i>	Sets speed for group A or group B.	DIRECT, EDIT	
	SPEEDC <i>var axis</i>	Sets speed for axis in group C.	DIRECT, EDIT	
SPEEDL				
	SPEEDL <i>var</i>	Sets speed for robot (group A) axes. Determines speed of MOVEL, MOVEC and SPLINEL movements.	DIRECT, EDIT	<i>var</i> = mm/second
GSPEED				
	GSPEED [A/B] <i>var</i>	Applies global speed factor to movement of all axes, or group A or group B axes.	DIRECT, EDIT	$-100 \leq var \leq 100$. Default is 100.
	GSPEEDC <i>var axis</i>	Applies a global speed factor to movement of an axis in group C.	DIRECT, EDIT	$-100 \leq var \leq 100$. Default is 100.
GACCEL				
	GACCEL [A/B] <i>var</i>	Applies global acceleration factor to movement of all axes, or group A or group B axes.	DIRECT, EDIT	$1 \leq var \leq 100$. Default is 70.
	GACCELC <i>var axis</i>	Applies a global acceleration to movement of an axis in group C.	DIRECT, EDIT	$1 \leq var \leq 100$. Default is 70.
SHOW SPEED				
	SHOW SPEED	Displays the current speed settings.	DIRECT	
EXACT				
	EXACT {A/B/C}	Ensures movement reaches target position accurately; disregards <i>duration</i> if specified in movement command. Defined separately for group A, B and C. Only affects commands with the 'D' suffix: MOVED, MOVELD, MOVECD, MOVESD, SPLINED, SPLINELD.	DIRECT, EDIT	EXACT is default mode.
	EXACT OFF{A/B/C}	Movement reaches target position according to <i>duration</i> ; accuracy not guaranteed. Only affects movement commands with the 'D' suffix.	DIRECT, EDIT	

COMMAND	FORMAT	DESCRIPTION	MODE	NOTES
JOINT				
JOINT		Sets mode of robot arm movement to Joints.	DIRECT, EDIT	
LINEAR				
LINEAR		Sets mode of robot arm movement to Linear.	DIRECT, EDIT	
CON				
CON[A/B]		Enables servo control of all axes, or specifically of group A or B.	DIRECT	
CON <i>axis</i>		Enables servo control of a specific axis.	DIRECT	
COFF				
COFF[A/B]		Disables servo control of all axes, or specifically of group A or B.	DIRECT	
COFF <i>axis</i>		Disables servo control of a specific axis.	DIRECT	
BRAKE				
BRAKE <i>n</i>		Releases brake on a specific axis.	DIRECT	For maintenance purposes only.
HOME				
HOME [<i>n</i>]		Searches for microswitch home position, for all robot axes, or specific axis.	DIRECT, EDIT	From teach pendant, key in: RUN 0. TP homes robot only.
HHOME <i>n</i>		Searches for hard stop home for specific axis.	DIRECT, EDIT	
CLR				
CLR <i>n</i>		Sets the number of turns of a specific resolver to 0.	DIRECT, PRIV	$1 \leq n \leq 8$
CLR *		Sets the number of turns of all resolvers to 0.	DIRECT, PRIV	
ZSET				
ZSET		Initializes (sets to 0) the parameters used for homing.	DIRECT	<i>Use with caution. May alter current home position.</i>
MODULO ROLL				
MODULO MODULO ROLL		Returns the value of the roll axis to a value within $\pm 360^\circ$ range, without moving the axis.	DIRECT	

COMMAND	FORMAT	DESCRIPTION	MODE	NOTES
~ ~ or <Ctrl>+M		Activates and deactivates Manual mode, for direct control of axes from terminal or computer keyboard .	DIRECT	
AUTO AUTO		Transfers control to the keyboard after the Auto/Teach switch on the teach pendant is switched to Auto.	DIRECT	

I/O Control Commands

DISABLE	SHOW DIN	REMOTE
ENABLE	SHOW DOUT	PANEL
FORCE	SET OUT[<i>n</i>]	
	IF IN[<i>n</i>]	
	TRIGGER	

COMMAND	FORMAT	DESCRIPTION	MODE	NOTES
DISABLE				
DISABLE	{IN/OUT} <i>n</i>	Disconnects the physical input or output from normal system control.	DIRECT	$1 \leq n \leq 16$
DISABLE	?	Displays a list of all disabled inputs and outputs.	DIRECT	
ENABLE				
ENABLE	{IN/OUT} <i>n</i>	Reconnects a disabled input or output to normal system control.	DIRECT	$1 \leq n \leq 16$ ENABLE is default mode.
FORCE				
FORCE	{IN/OUT} <i>n</i> {0/1}	Forces a disabled input or output to a different state.	DIRECT	$1 \leq n \leq 16$ 0=OFF; 1=ON
FORCE	?	Displays the state of all forced inputs and outputs.	DIRECT	Display: 1=ON; 0=OFF
SHOW				
SHOW	DIN	Displays the state of all 16 inputs.	DIRECT	Display: 1=ON; 0=OFF
SHOW	DOUT	Displays the state of all 16 outputs.	DIRECT	Display: 1=ON; 0=OFF
SET				
SET	OUT[<i>n</i>]={0/1}	Sets the state of an output port.	DIRECT, EDIT	$1 \leq n \leq 16$ 0=OFF; 1=ON
IF				
IF	IN[<i>n</i>]={0/1}	Checks the state of an input.	EDIT	$1 \leq n \leq 16$ 0=OFF; 1=ON
TRIGGER				
TRIGGER	<i>prog</i> BY {IN/OUT} <i>n</i> {0/1}	Executes a program, conditional upon a change in the state of an input or output.	EDIT	$1 \leq n \leq 16$ 0=OFF; 1=ON

COMMAND	FORMAT	DESCRIPTION	MODE	NOTES
REMOTE				
REMOTE		Transfers control of some controller functions to external switches and indicators.	DIRECT EDIT	Parameters must be properly set.
PANEL				
PANEL		Cancels REMOTE. Returns control of switch functions to controller panel.	DIRECT EDIT	

Program Control Commands

RUN	SUSPEND	DELAY
STEP	CONTINUE	WAIT
NOSTEP		TRIGGER BY IN/OUT
BREAK	PRIORITY	
NOBREAK		PEND
	SET var TIME	POST
A		QPEND
STOP		QPOST

COMMAND	FORMAT	DESCRIPTION	MODE	NOTES
RUN				
	RUN <i>prog</i>	Runs the specified program.	DIRECT, EDIT	
	RUN <i>prog priority</i>	Runs the specified program, per priority.	DIRECT, EDIT	
STEP				
	STEP <i>prog</i>	Marks a break point at start of specified program. Execution will be halted at first line of program; user may resume continuous execution or to proceed one line at a time.	DIRECT	
NOSTEP				
	NOSTEP <i>prog</i>	Cancels the break point at start of specified program.	DIRECT	
BREAK				
	BREAK <i>n</i>	Same as STEP, but marks a break point at a specific line number in program.	DIRECT	
	BREAK	Lists all break points currently in use.	DIRECT	
NOBREAK				
	NOBREAK <i>n</i>	Cancels the break point at the specified line.	DIRECT	
	NOBREAK	Cancels all break points	DIRECT	
A				
	A or <Ctrl>+A	Immediately aborts all running programs, and stops axes movement.	DIRECT	
	A <i>prog</i>	Aborts the specified program.	DIRECT	
STOP				
	STOP	Aborts all running programs and stops all axis movement.	EDIT	
	STOP <i>prog</i>	Aborts a specific running program.	EDIT	

COMMAND	FORMAT	DESCRIPTION	MODE	NOTES
SUSPEND				
	SUSPEND <i>prog</i>	Halts execution of a program.	DIRECT, EDIT	
CONTINUE				
	CONTINUE <i>prog</i>	Resumes execution of a program previously halted by SUSPEND.	DIRECT, EDIT	
PRIORITY				
	PRIORITY <i>prog var</i>	Sets a program's run time priority to <i>var</i> . Programs with a higher priority have precedence when the CPU is loaded.	EDIT	$1 \leq var \leq 10$. Default is 5.
SET				
	SET <i>var</i> =TIME	Assigns the value of system variable TIME to <i>var</i> .	DIRECT, EDIT	
DELAY				
	DELAY <i>var</i>	Suspends program execution for the time specified by <i>var</i> .	EDIT	<i>var</i> defined in hundredths of a second.
WAIT				
	WAIT <i>var1 oper var2</i>	Suspends program execution until condition is satisfied (true).	EDIT	<i>Cond</i> can be: <, >, =, <=, >=, <>
TRIGGER				
	TRIGGER <i>prog</i> BY {IN/OUT} <i>n</i> {0/1}	Executes a program, conditional upon a change in the state of an input or output.	EDIT	$1 \leq n \leq 16$ 0=OFF; 1=ON
PEND				
	PEND <i>var1</i> FROM <i>var2</i>	Suspends program execution until another program posts a non-zero value to <i>var2</i> .	EDIT	Used with POST to synchronize programs.
POST				
	POST <i>var3</i> TO <i>var2</i>	Assigns the value of <i>var3</i> to <i>var2</i> .	EDIT	Used with PEND to synchronize programs.
QPEND				
	QPEND <i>var1</i> FROM <i>array</i>	Same as PEND, but value is taken from a queue (a variable array).	EDIT	Used with QPOST to synchronize programs.
QPOST				
	QPOST <i>var3</i> TO <i>array</i>	Same as POST but value is put into a queue (a variable array).	EDIT	Used with QPEND to synchronize programs.

Position Definition and Manipulation Commands

DEFP	HERER	SHIFT
DIMP	HERERC	SHIFTC
	HERERT	
DELP		SETP
UNDEF	TEACH	
	TEACHR	TOOL
DELETE	TEACHRT	
INSERT		ATTACH
	SETPV	
HERE	SETPVC	SET var=PVAL
HEREC		SET var=PVALC
		SET var=PSTATUS

COMMAND	FORMAT	DESCRIPTION	MODE	NOTES
DEFP				
	DEFP[A/B] <i>pos</i>	Defines (creates) a position for group A or B or for axis in group C.	DIRECT,	$1 \leq axis \leq 8$
	DEFP[C] <i>pos axis</i>		EDIT	
DIMP				
	DIMP[A/B] <i>vect[n]</i>	Defines (creates) a vector of <i>n</i> positions for group A or B or for axis in C.	DIRECT,	$1 \leq axis \leq 8$
	DIMP[C] <i>vect[n] axis</i>		EDIT	
DELP				
	DELP <i>pos</i>	Deletes positions and position vectors from user RAM.	DIRECT,	
	DELP <i>pvect</i>		EDIT	
UNDEF				
	UNDEF <i>pos</i>	Deletes position coordinate values, but <i>position is still defined.</i>	DIRECT,	
	UNDEF <i>pvect</i>	Deletes coordinate values of all positions in the vector, but <i>vector is still defined.</i>	EDIT	
DELETE				
	DELETE & <i>pvect[n]</i>	Deletes coordinates for position <i>n</i> in vector & <i>pvect</i> ; all recorded positions above <i>n</i> are moved down one place until an unrecorded position is encountered.	DIRECT, EDIT	Vector name must have prefix &.
INSERT				
	INSERT & <i>pvect[n]</i>	Records current coordinates of axes, and inserts them into vector & <i>pvect</i> at position <i>n</i> ; all recorded positions above <i>n</i> are moved up one place until an unrecorded position is encountered.	DIRECT, EDIT	Vector name must have prefix &.
COMMAND	FORMAT	DESCRIPTION	MODE	NOTES

HERE

HERE <i>pos</i>	Records joint coordinates for current position of axes.	DIRECT, EDIT	Joint coordinates = resolver counts.
HEREC <i>pos</i>	Records Cartesian coordinates for current position of robot.	DIRECT, EDIT	Cartesian coordinates: XYZ in linear units; pitch/roll in angular units.

HERER

HERER <i>pos2 pos1</i>	Records joint offset coordinates for a position relative to another position.	DIRECT, EDIT	
HERERC <i>pos2 pos1</i>	Records Cartesian offset coordinates for a position relative to another position.	DIRECT EDIT	
HERERT <i>pos2 pos1</i>	Records Tool offset coordinates for a position relative to another position.	DIRECT EDIT	
HERER <i>pos</i>	Records joint offset coordinates entered from keyboard for a position relative to current position.	DIRECT	

TEACH

TEACH <i>pos</i>	Records Cartesian coordinates entered from keyboard for a robot position.	DIRECT	
------------------	---	--------	--

TEACHR

TEACHR <i>pos2 pos1</i>	Records Cartesian offset coordinates entered from keyboard for a robot position relative to another robot position.	DIRECT	
TEACHRT <i>pos2 pos1</i>	Records Tool offset coordinates entered from keyboard for a robot position relative to another position.	DIRECT	
TEACHR <i>pos</i>	Records Cartesian offset coordinates entered from keyboard for a robot position relative to the current robot position.	DIRECT	
TEACHRT <i>pos</i>	Records Tool offset coordinates entered from keyboard for a robot position relative to current position.	DIRECT	

COMMAND	FORMAT	DESCRIPTION	MODE	NOTES
SETPV				
SETPV	<i>pos</i>	Records joint coordinates for a position.	DIRECT	
SETPV	<i>pos axis var</i>	Changes one joint coordinate of a previously recorded position.	DIRECT, EDIT	$1 \leq axis \leq 8$
SETPVC				
SETPVC	<i>pos coord var</i>	Changes one Cartesian coordinate of a previously recorded robot position.	DIRECT, EDIT	<i>coord</i> ={X/Y/Z/P/R}
SHIFT				
SHIFT	<i>pos BY axis var</i>	Changes one joint coordinate of a previously recorded position <i>by an offset value</i> .	DIRECT, EDIT	$1 \leq axis \leq 8$
SHIFTC	<i>pos BY coord var</i>	Changes one Cartesian coordinate of a previously recorded robot position <i>by an offset value</i> .	DIRECT, EDIT	<i>coord</i> ={X/Y/Z/P/R}
SETP				
SETP	<i>pos2=pos1</i>	Copies the coordinates and type of <i>pos1</i> to <i>pos2</i> .	DIRECT, EDIT	
TOOL				
TOOL	<i>length offset angle</i>	Defines the position of the tool center point (TCP) relative to the robot's flange.	DIRECT, EDIT	
ATTACH				
ATTACH	<i>pvect</i>	Attaches a position vector to the teach pendant according to group for which the vector is defined. Vector positions can now be accessed from TP by means of their index numbers.	DIRECT	
ATTACH	OFF{A/B/C}	Detaches the position vector which is currently attached to the TP. Group A, B or C must be specified.	DIRECT	
ATTACH	?	Displays current ATTACH status.	DIRECT	
SET				
SET	<i>var=PVAL pos axis</i>	Assigns <i>var</i> the value of one joint coordinate of a recorded position.	DIRECT, EDIT	$1 \leq axis \leq 8$
SET	<i>var=PVALC pos coord</i>	Assigns <i>var</i> the value of one Cartesian coordinate of a recorded position.	DIRECT, EDIT	<i>coord</i> ={X/Y/Z/P/R}
SET	<i>var=PSTATUS pos</i>	Assigns <i>var</i> a value according to the type of the position.	DIRECT, EDIT	

Variable Definition and Manipulation Commands

DEFINE	DIM	DELVAR
GLOBAL	DIMG	PURGE
		SET <i>var</i>

COMMAND	FORMAT	DESCRIPTION	MODE	NOTES
DEFINE				
	DEFINE <i>var1...var12</i>	Creates (defines) private variables. Up to 12 variables can be defined in one command.	EDIT	A private variable is recognized only by the program in which it is defined.
GLOBAL				
	GLOBAL <i>var1...var12</i>	Creates (defines) a global variable. Up to 12 variables can be defined in one command	DIRECT, EDIT	Global variables can be used by any program.
DIM				
	DIM <i>var[n]</i>	Creates (defines) an array of <i>n</i> private variables.	EDIT	
DIMG				
	DIMG <i>var[n]</i>	Creates (defines) an array of <i>n</i> global variables.	DIRECT, EDIT	
DELVAR				
	DELVAR <i>var</i>	Deletes variable from user RAM.	DIRECT, EDIT	
PURGE				
	PURGE	Deletes all unused variables from user RAM.	DIRECT	
SET (mathematical and logical functions)				
	SET <i>var1=var2</i>	Assigns the value of <i>var2</i> to <i>var1</i> .	DIRECT, EDIT	
	SET <i>var1=oper var2</i>	Performs operation on <i>var2</i> and assigns result to <i>var1</i> .	DIRECT, EDIT	<i>oper</i> : ABS, NOT
	SET <i>var1=var2 oper var3</i>	Performs operation on <i>var2</i> and <i>var3</i> and assigns result to <i>var1</i> .	DIRECT, EDIT	<i>oper</i> : +, -, *, /, AND, OR, EXP, LOG, MOD, SIN, COS, TAN, ATAN,
	SET <i>var1=COMPLEMENT var2</i>	Inverts each binary bit of <i>var2</i> and assigns the result to <i>var1</i> .	DIRECT, EDIT	
	SET <i>var=PAR n</i>	Assigns the value of the specified parameter to <i>var</i> .	DIRECT, EDIT	

Program Flow Commands

IF	FOR	LABEL
ANDIF	ENDFOR	GOTO
ORIF		
ELSE		GOSUB
ENDIF		

COMMAND	FORMAT	DESCRIPTION	MODE	NOTES
IF	IF <i>var1 oper var2</i>	Checks the conditional relation of two variables.	EDIT	<i>oper</i> can be: <, >, =, <=, >=, <>
ANDIF	ANDIF <i>var1 oper var2</i>	Logically combines a condition with other IF commands.	EDIT	
ORIF	ORIF <i>var1 oper var2</i>	Logically combines a condition with other IF commands.	EDIT	
ELSE	ELSE	Follows IF and precedes ENDIF. Begins subroutine when IF is false.	EDIT	
ENDIF	ENDIF	End of IF subroutine.	EDIT	
FOR	FOR <i>var1=var2 TO var3</i>	Loop command. Executes subroutine for all values of variable.	EDIT	
ENDFOR	ENDFOR	End of FOR loop.	EDIT	
LABEL	LABEL <i>n</i>	Marks a program subroutine to be executed by GOTO command.	EDIT	$0 \leq n \leq 9999$
GOTO	GOTO <i>n</i>	Continues program execution at line following specified LABEL.	EDIT	
GOSUB	GOSUB <i>prog</i>	Transfers control to another program. Main program is suspended until subroutine is completed.	EDIT	

Configuration Commands

CONFIG	INIT EDITOR	REMOTE
LET PAR	INIT CONTROL	PANEL
SHOW PAR	PASSWORD	DOWNLOAD
	PRIV[ILEGE]	UPLOAD

COMMAND	FORMAT	DESCRIPTION	MODE	NOTES
CONFIG				
CONFIG		Activates procedure for configuring the controller configuration.	DIRECT	Automatically followed by INIT EDITOR; erases user RAM.
CONFIG ?		Displays the current controller configuration.	DIRECT	
LET PAR				
LET PAR <i>n=var</i>		Changes the value of system parameters.	DIRECT PRIV	Must be followed by INIT CONTROL. <i>Use with caution.</i>
SHOW				
SHOW PAR <i>n</i>		Displays the value of parameter <i>n</i> .	DIRECT	
INIT				
INIT EDITOR		Erases all user programs, positions and variables in user RAM.	DIRECT	<i>Use with caution.</i>
INIT CONTROL		Resets system parameters according to LET PAR values.	DIRECT	Must be executed after changing parameter values.
PASSWORD				
PASSWORD		Activates procedure for changing the password which protects the PRIVILEGE mode.	DIRECT	
PRIV[ILEGE]				
PRIV ON PRIV OFF		Activates and cancels the PRIVILEGE mode.	DIRECT	Requires password.
REMOTE				
REMOTE		Transfers control of some controller functions to external switches and indicators.	DIRECT EDIT	Parameters must be properly set.
PANEL				
PANEL		Cancels REMOTE. Returns control of controller functions to controller panel.	DIRECT EDIT	

COMMAND	FORMAT	DESCRIPTION	MODE	NOTES
DOWNLOAD				
DOWNLOAD		Copies servo control parameters from controller BBRAM to DDC card EEPROM.	DIRECT	
UPLOAD				
UPLOAD		Copies servo control parameters from DDC card EEPROM to controller BBRAM, thus allowing backup to disk.	DIRECT	

Report Commands

ATTACH ?	SHOW	BREAK
CONFIG ?	STAT	DIR
DISABLE ?	VER	LIST
FORCE ?	FREE	SEND

COMMAND	FORMAT	DESCRIPTION	MODE	NOTES
ATTACH				
ATTACH ?		Displays current ATTACH status.	DIRECT	
CONFIG				
CONFIG ?		Displays the current controller configuration.	DIRECT	
DISABLE				
DISABLE ?		Displays a list of all disabled inputs and outputs.	DIRECT	
FORCE				
FORCE ?		Displays a list of all forced inputs and outputs.	DIRECT	
SHOW				
SHOW DIN		Displays status of all 16 inputs.	DIRECT	Display: 1=Input ON 0=Input OFF
SHOW DOUT		Displays status of all 16 outputs.	DIRECT	Display: 1=Output ON 0=Output OFF
SHOW ENCO		Displays the values of all resolvers every 0.5 seconds	DIRECT	<Ctrl>+C cancels the display.
SHOW PAR <i>n</i>		Displays the value of parameter <i>n</i> .	DIRECT	
SHOW SPEED		Displays the current speed settings.	DIRECT	
STAT				
STAT		Displays a list of active user programs: name, priority, status, current line number and command being executed.	DIRECT	
VER				
VER		Displays ACL EPROM version.	DIRECT	
FREE				
FREE		Displays a list of available user memory.	DIRECT	

COMMAND	FORMAT	DESCRIPTION	MODE	NOTES
BREAK				
BREAK		Lists all break points currently in use.	DIRECT	
DIR				
DIR		Displays a list of the names and ID numbers of all user programs.	DIRECT	
LIST				
LIST [prog]		Displays all lines of all user programs or a specific program.	DIRECT	
LISTP		Displays a list of all defined positions.	DIRECT	
LISTPV pos		Displays the type of position and joint coordinates of the specified position. Cartesian coordinates also displayed for robot positions.	DIRECT	
LISTPV POSITION		Displays current coordinates of robot arm.	DIRECT	
LISTVAR		Displays a list of all user and system variables.	DIRECT	
SEND				
SEND		Displays all user programs, variables and positions, and parameters in RECEIVE/APPEND format.	DIRECT	
SEND prog		Displays the specified user program in RECEIVE prog format.	DIRECT	
SENDPROG		Displays all user programs, variables, and positions in RECEIVE/APPEND format.	DIRECT	
SENDPOINT		Displays all user defined positions in RECEIVE/APPEND format.	DIRECT	
SENDVAR		Displays all user defined variables in RECEIVE/APPEND format.	DIRECT	
SENDPAR		Displays all system parameters in RECEIVE/APPEND format.	DIRECT	
SEND prog > PRN: SENDPROG > PRN: SENDPOINT > PRN: SENDVAR > PRN: SENDPAR > PRN:		Prints list at a printer connected to controller's parallel port.	DIRECT	

User Interface Commands

QUIET	PRINT	HELP
NOQUIET	PRINTLN	
		DO
ECHO	READ	
NOECHO	GET	ENGLISH
		JAPANESE

COMMAND	FORMAT	DESCRIPTION	MODE	NOTES
QUIET				
	QUIET	DIRECT commands sent by a program using the @ command are not displayed on screen.	DIRECT	
NOQUIET				
	NOQUIET	DIRECT commands sent by a program using the @ command are displayed on screen.	DIRECT	NOQUIET is default mode.
ECHO				
	ECHO	Displays on screen all characters that are transmitted to controller.	DIRECT	ECHO is default mode.
NOECHO				
	NOECHO	Keyboard entries are not displayed on screen.	DIRECT	
PRINT				
	PRINT " <i>string</i> "	Displays <i>string</i> on screen.	DIRECT, EDIT	
	PRINT <i>var1...var4</i>	Displays value(s) of specified variable(s).	DIRECT, EDIT	
PRINTLN				
	PRINTLN	Same as PRINT, but starts a new line before displaying text.	EDIT	
READ				
	READ " <i>string</i> " <i>var</i>	Displays the <i>string</i> and waits for value of <i>var</i> from keyboard.	EDIT	
GET				
	GET <i>var</i>	Waits for one keyboard character to be pressed. ASCII value of character is assigned to <i>var</i> .	EDIT	

COMMAND	FORMAT	DESCRIPTION	MODE	NOTES
HELP				
HELP		Provides on-line help for EDIT commands.	EDIT	
HELP		Provides on-line help for DIRECT commands.	DIRECT	
DO HELP		Provides on-line help for EDIT commands.	DIRECT	
DO				
DO	<i>editcom</i>	Executes certain EDIT mode commands when controller in DIRECT mode.	DIRECT	
ENGLISH				
ENGLISH		Causes controller messages to be displayed in English on screen.	DIRECT	
JAPANESE				
JAPANESE		Causes controller messages to be displayed in Japanese on screen.	DIRECT	

Program Manipulation Commands

	COPY	REMOVE	EDIT	
	RENAME	EMPTY		
COMMAND	FORMAT	DESCRIPTION	MODE	NOTES
COPY				
	<code>COPY prog1 prog2</code>	Copies program <i>prog1</i> to a new program <i>prog2</i>	DIRECT	
RENAME				
	<code>RENAME prog1 prog2</code>	Changes name of user program from <i>prog1</i> to <i>prog2</i> .	DIRECT	
REMOVE				
	<code>REMOVE prog</code>	Deletes program from user RAM.	DIRECT	
EMPTY				
	<code>EMPTY prog</code>	Deletes all program lines, but leaves program existent and valid.	DIRECT	
EDIT				
	<code>EDIT prog</code>	Activates EDIT mode for program creation and editing.	DIRECT	

Editing Commands

S * END
 P @
 L EXIT
 DEL
 <Enter>

COMMAND	FORMAT	DESCRIPTION	MODE	NOTES
S				
S		Goes to the first line of the program being edited.	EDIT	
S	<i>n</i>	Goes to line <i>n</i> of program being edited.	EDIT	
P				
P		Goes to previous line of program.	EDIT	
L				
L	<i>n1 n2</i>	Displays program lines, from line <i>n1</i> to line <i>n2</i> .	EDIT	
DEL				
DEL		Erases the current line of program.	EDIT	
<Enter>				
<Enter>		Goes to next line in program and displays its number.	EDIT	
*				
*	<i>string</i>	* precedes user comment line.	EDIT	
@				
@	<i>DIRECTcom</i>	Allows the execution of a DIRECT command from a running user program.	EDIT	
EXIT				
EXIT		Quits EDIT and checks program validity.	EDIT	
END				
END		End of program. Automatically written by system at end of program		Not a user command.
(END)		End of listing. Automatically displayed by system.		Not a user command.

RS232 Communication Commands

SENDCOM PRCOM CLRCOM
 GETCOM PRLNCOM
 READCOM

COMMAND	FORMAT	DESCRIPTION	MODE	NOTES
SENDCOM				
	SENDCOM <i>n var</i>	Transmits one byte, whose value is specified by a variable or constant, to the specified RS232 port.	EDIT	<i>n</i> =RS232 COM port; 0 ≤ <i>n</i> ≤ 8
GETCOM				
	GETCOM <i>n var</i>	Receives one byte from the specified RS232 port, and stores its value in the specified variable.	EDIT	0 ≤ <i>n</i> ≤ 8
PRCOM				
	PRCOM <i>n arg1</i> [<i>arg2 arg3</i>]	Transmits <i>arg</i> (strings and/or variable values) to the specified RS232 port.	EDIT	0 ≤ <i>n</i> ≤ 8
PRLNCOM				
	PRLNCOM <i>n arg1</i> [<i>arg2 arg3</i>]	Transmits <i>arg</i> (strings and/or variable values) to the specified RS232 port, and adds carriage return.	EDIT	0 ≤ <i>n</i> ≤ 8
READCOM				
	READCOM <i>n var</i>	Receives ASCII character(s) followed by a carriage return (↵) from the specified RS232 port and assigns the ASCII numeric value to <i>var</i> .	EDIT	0 ≤ <i>n</i> ≤ 8
CLRCOM				
	CLRCOM <i>n</i>	Clears the buffer of the specified RS232 port, or all ports.	EDIT	0 ≤ <i>n</i> ≤ 8; 0 = all ports

Backup/Restore Commands

SEND DOWNLOAD
RECEIVE UPLOAD
APPEND

COMMAND	FORMAT	DESCRIPTION	MODE	NOTES
SEND				
SEND		Generates a listing of all user programs, variables and positions, and parameters in a format compatible with the RECEIVE and APPEND commands.	DIRECT	
SEND <i>prog</i>		Generates a listing of the specified user program in a format compatible with the RECEIVE <i>prog</i> command.	DIRECT	
SENDPROG		Generates a listing of all user programs, variables, and positions in a format compatible with the RECEIVE and APPEND commands.	DIRECT	
SENDVAR		Generates a listing of all user defined variables in a format compatible with the RECEIVE and APPEND commands.	DIRECT	
SENDPOINT		Generates a listing of all user defined positions in a format compatible with the RECEIVE and APPEND commands.	DIRECT	
SENDPAR		Generates a listing of all system parameters in a format compatible with the RECEIVE and APPEND commands.	DIRECT	
RECEIVE				
RECEIVE		Loads programs, positions and variables from external backup file to user RAM.	DIRECT	Erases current contents of user RAM
RECEIVE <i>prog</i>		Loads contents of one program from backup file.	DIRECT	Does not affect other data in user RAM.
APPEND				
APPEND		Adds user programs from external file to user RAM.	DIRECT	Does not affect other data in user RAM.
DOWNLOAD				
DOWNLOAD		Copies servo control parameters from controller BBRAM to DDC card EEPROM.	DIRECT	
UPLOAD				
UPLOAD		Copies servo control parameters from DDC card EEPROM to controller BBRAM, thus allowing backup to disk.	DIRECT	

This page intentionally left blank.

Command Modes and Formats

This chapter describes the various modes of **ACL** programming and operation, as well as the types and formats of commands and data used in the **ACL** programming language.

Command Modes

Once **ATS** has been loaded, you can communicate with the controller from your computer keyboard. You may now create or edit your programs, or assume direct control of the robot and peripheral axes, depending on the active mode of operation.

ACL has two types of commands:

- **DIRECT** commands, which are executed as soon as they are entered at the terminal/computer keyboard.
- Indirect, or **EDIT** commands, which are executed during the running of the programs and routines in which they are used.

Some commands are available in both the **DIRECT** mode and the **EDIT** mode.

In addition, the controller has a password-protected **PRIVILEGE** mode. Most of the system parameters, and some commands, can be accessed only when the **PRIVILEGE** mode is active.

DIRECT Mode

When **DIRECT** mode is active, all commands entered from the keyboard are immediately executed by the controller.

Whenever the **DIRECT** mode is active, the screen shows the following cursor prompt:

```
>_
```

DIRECT mode commands can be included in programs for execution from a running program by prefacing them with the character **@**. The **@** signals to the controller that the string be read as a **DIRECT** mode command, and activated from a running program.

Once the **@** command has been transmitted, and its execution has begun, the program continues running regardless of the **@** command's status. Use the

DELAY command to ensure completion of a @ command.

Some EDIT mode commands can be executed in the DIRECT mode when preceded by the command DO.

Refer to the command descriptions for @, DELAY, and DO in Chapter 3.

Manual Keyboard Control

When a teach pendant is not available, you can assume direct control of the robot and peripheral axes from the keyboard by activating Manual mode. Manual mode can be activated only when the system is operating in DIRECT mode.

To activate the Manual mode, type either of the following:

<Alt>+M	(when using ATS)
~	(usually by pressing <Shift>+ `)

Refer to the command ~ (Manual Control) at the end of Chapter 3 for a complete description of the functions available in Manual mode.

Teach Pendant Control

The teach pendant is a hand-held terminal which permits the operator direct control of the robot and peripheral axes. In addition to controlling movement of the axes, the teach pendant is used for recording positions, sending axes to recorded positions, activating programs, and other functions.

The teach pendant provides direct control of the axes even when the controller is in EDIT mode.

Teach pendant operation is described fully in the *Teach Pendant for Controller-AC User's Manual*.

Direct Teach

The Performer-MK3 robot can be equipped with an optional pair of Direct Teach handles. When these handles are installed, they are used to manually move the robot arm along a path and record positions.

Instructions for operating the robot by means of the Direct Teach handles are provided with the handles, and in the *Controller-AC User's Manual*.

EDIT Mode

The *EDIT* mode is used to create and edit **ACL** programs.

Whenever the EDIT mode is active, the screen shows the current program line number and a cursor prompt, indicating that a command can be inserted. For example:

```
143: ?_
```

The controller assigns the line numbers; they are not user definable.

The EDIT mode is activated by typing the command EDIT and the name of a program. For example:

```
>edit pack1
```

The system will respond:

```
PACK1 NEW PROGRAM
DO YOU WANT TO CREATE THAT PROGRAM (Y/N)>
```

Type:

```
y <Enter>
```

The system will respond:

```
PROGRAM    PACK1
*****
36: ?_
```

If you do not specify the name of a program after the EDIT command, you will be prompted to provide one.

If you have specified the name of an existing program after the EDIT command, you will be prompted as follows:

```
WELCOME TO ACL EDITOR, TYPE HELP WHEN IN TROUBLE.
PROGRAM    PACK1
*****
36: ?_
```

The cursor is located at the first line of program PACK1.

Names used to define programs may be a combination of up to five alphanumeric characters. For example:

```
RUN MILL3           Executes the program MILL3.
GOSUB 20            Execution goes to first line of program named 20.
```

Editing Functions

ACL provides the following EDIT mode commands for program editing:

S	Goes to the first line of the program.
S n	Goes to a specified line in the program.
P	Goes to the preceding line.
L n1 n2	Displays program lines, from the first line specified, to the last line specified.
DEL	Erases the current line of the program.
<Enter>	Goes to the next line in the program and displays the line number and a cursor prompt (EDIT mode). Or, checks and inserts the currently typed command line (DIRECT mode).

EXIT Quits EDIT mode, and checks program validity.

Refer to the complete descriptions for each of these commands in Chapter 3.

ATS utilizes the following keys for editing commands. Note that these keys can be used in both EDIT and DIRECT mode.

←	(or backspace) Removes characters.
→	Restores characters.
<Ins>	Inserts characters.
	Erases characters.
<Esc>	Erases the currently typed command.
<Ctrl>+→	Restores the currently erased command.
↑ and ↓	Repeats the last command(s) entered.

PRIVILEGE Mode

Most of the parameters and some **ACL** commands for the controller can be accessed only when the controller's PRIVILEGE mode is active.

The status of parameter 19 indicates whether or not the PRIVILEGE mode is active. If PAR 19=0, a password is required to access the protected parameters and commands; if PAR 19=1, no password is required.

Refer to the commands PASSWORD and PRIV[ILEGE] in Chapter 3 for more information on the PRIVILEGE mode.

Run Modes

ACL programs can be executed in Normal Run mode. In Step mode, the user can suspend and resume program execution one line at a time.

Normal Run

To execute a program normally, use the command:

```
RUN prog
```

Step

To execute a program manually one line at a time (“step-by-step”), set a “break” point by using either of the following commands:

STEP prog	The program will run in Step mode, from the first line of the program.
BREAK line#	The program will switch to Step mode at the specified line number.

Refer to the commands RUN, STEP, BREAK, NOSTEP and NOBREAK in Chapter 3 for more information.

Coordinate Systems


ACL allows robotic systems to be operated and programmed in three different coordinate systems: **Joint** coordinates, **Cartesian (XYZ)** coordinates and **Tool** coordinates. Refer to the command ~ (Manual mode) in Chapter 3 for a complete description of axes movements in each of these modes.

Joint Coordinates

Joint coordinates specify the location of each axis in resolver counts.

When the coordinate system is set to the **Joint** mode, manual movement commands cause the robot to move one joint.

The position of any peripheral devices which are connected to the system is always according to resolver counts.



Joint Coordinates

Other than the limitations of the robot's working envelope, no restriction apply when recording joint position coordinates and when programming and executing joint movement commands (MOVE, MOVES and SPLINE).

Cartesian (XYZ) and Tool Coordinates


The Cartesian, or XYZ, coordinate system is a geometric system used to specify the position of the robot's TCP (tool center point) by defining its distance, in linear units, from the point of origin (the center bottom of the robot base), along three linear axes.

To complete the position definition, the pitch and roll of the gripper are specified in angular units.


The TOOL command (or parameters 308, 309 and 310) defines the exact location of the TCP.

When the coordinate system is set to the **XYZ or Tool** mode:

- Manual movement commands to the X, Y or Z axis result in a linear motion of the **tool center point (TCP)** along the respective axis, while maintaining a constant orientation of the tool.
- Manual movement commands to the pitch or roll axis will change the orientation of the tool, while maintaining a constant TCP position.



Cartesian Coordinate System



Tool Coordinate System

When the coordinate system is set to the **Tool** mode, the X, Y and Z axes are defined as follows.

- The Z-axis is the axis which intersects the flange at its center point, and is perpendicular to it.
- The X-axis is horizontal and perpendicular to the Z-axis.
- The Y-axis is vertical and perpendicular to both the Z and X axes.


World (XYZ) Space

Certain restrictions apply when recording Cartesian position coordinates and when programming and executing XYZ movement commands (MOVEL, MOVEC and SPLINEL). The validity of these positions and movements is determined by three areas of world (XYZ) space. Refer to the following diagrams.


- World Space A: Positions in which link 3 is at a negative angle relative to link 2 of the robot arm.
- World Space B: Positions in which link 3 is at a positive angle relative to link 2 of the robot arm.

All position within World Space A and B can be recorded in Cartesian coordinates, and reached by the robot's TCP.

The XYZ movement commands (MOVEL, MOVEC and SPLINEL) are allowed within both World Space A and B. However, all positions referenced in the command must belong to *either* World Space A or World Space B. If the command implies a movement from one space to the other, an error message is displayed, and the command is aborted.



World Space A




World Space B

Invalid XYZ Space

Positions in which axis 4 or the TCP is behind the line of axis 1 cannot be recorded in Cartesian coordinates and cannot be reached by the robot's TCP by means of XYZ movement commands (MOVEJ, MOVEC and SPLINEL). These positions can, however, be recorded and reached in the Joint mode.

This invalid posture is termed World Space C.



World Space C

Data Types

The **ACL** programming language uses four data types:

- Variables
- Strings
- Positions
- Parameters

Variables

Variables are reserved memory locations which hold integer values in the range: -2147483647 to +2147483647 (long integer, 32 bits).

ACL uses two types of variables: user variables and system variables.

User Variables

User variables may be either global or private.

- **Global Variables**

Global variables can be defined in either **DIRECT** or **EDIT** mode, and can be used in all programs.

- The command **GLOBAL** is used to define a global variable.
- The command **DIMG** is used to define an array of global variables.

- **Private Variables**

Private variables can be defined only in **EDIT** mode, and can only be used in the program which was being edited at the time the private variable was defined.

- The command **DEFINE** is used to define a private variable.
- The command **DIM** is used to define an array of private variables.

Up to 12 variables can be defined in one command.

Names used to define variables may be a combination of up to five alphanumeric characters. The first character of a variable name must be a letter. Names of variable arrays also include an index (a number within square brackets) which defines the number of variables in the array.

The following are examples of commands with variables:

<code>DEFINE X</code>	Defines private variable X.
<code>GLOBAL VAR99</code>	Defines global variable VAR99.
<code>DIM A[20]</code>	Defines an array named A containing 20 private variables.
<code>SET Z=10</code>	Variable Z is assigned a value of 10.

SET X=CPOS[n]-ENC[n]	(where <i>n</i> is an axis number) The value of the position error of the specified axis is the difference between system variables CPOS and ENC; this value is assigned to the variable X.
SET OUT[3]= Y	The state of output 3 is determined by the value of variable Y.
SET Y=IN[1]	The value of variable Y is determined by the status of input 1.
WAIT IN[J]=1	Condition for variable input J.

User variables have a read/write attribute. You can perform operations on these variables and change their values, using all available **ACL** commands.

The maximum number of user variables is defined by the controller configuration.

System Variables

System defined variables contain values which indicate the status of inputs, outputs, resolvers, and other control system elements. The **ACL** system variables enable you to perform diagnostic tests and recovery programs, and to execute applications which require real-time information about the system status.

System variables can be used in the same manner as user variables. However, system variables cannot be deleted.

ACL contains 22 system variables:

IN[16]	TQ[5]	ERROR
ENC[5]	INDEX[5]	ERRPR
LSCW[5]	LTIME[5]	ERRLI
LSCCW[5]	TIME	OUT[16]
CPOS[12]	MFLAG	JOG[5]
POSER[5]	HOMED	TQMAX[5]
JTARG[5]	CONST	TQMIN[5]
XTARG[5]		

The indices indicate the dimensions of the array variables.

- IN, ENC, LSCW, LSCCW, CPOS, POWER, JTARG, XTARG, TQ, INDEX, TIME, CONST, LTIME, MFLAG, and HOMED are read-only variables.
- ERROR, ERRPR, ERRLI, OUT, TQMAX and TQMIN are read-write variables.
- JOG is a read-write variable only in PRIVILEGE mode; otherwise it is read-only.

Refer to Chapter 4 for a complete description of system variables.

Variable Lists

The command LISTVAR displays a list of all system and user variables. The name of the program to which a private variable is dedicated appears in parentheses next to the variable.

The command SENDVAR produces a coded list for downloading the variable. The code format is as follows:

Prefix: type of variable (\$l for private; \$v for global)
Sequential number
Name of variable
Name of dedicated program (for private variable)
Value

Strings (Comments)

A string (comment) is an argument of up to 10 characters used in the following ACL commands:

```
PRINT " . . . . "  
PRINTLN " . . . . "  
PRCOM " . . . . "  
PRLNCOM " . . . . "  
@ command  
* comment
```

Up to 40 characters and spaces—that is, four strings— may comprise the text on these command lines.

If a string is longer than 10 characters, it is automatically divided into substrings, each of which is limited to 10 characters. For example:

```
PRINT "HELLO, HOW DO YOU FEEL THIS MORNING?"
```

This string is actually four arguments:

```
"HELLO, HOW" " DO YOU FE" "EL THIS MO" "RNING?"
```

The maximum number of strings (comments) is defined by the controller configuration.

Positions

Positions are reserved memory locations which hold position data. The position data include one integer value for each axis in the range -2147483647 to $+147483647$ to define the coordinates, and one word in the range -32668 to $+32767$ to indicate the type of position.

Types of Positions

ACL has eight types of positions, as listed below. The commands used to record each type of position appears in parentheses. Refer also to the chart of position recording commands later in this chapter.

- **Absolute Joint** (HERE, SETPV, SHIFT)
Position data are the coordinates of the position in resolver values.
- **Absolute XYZ** (HEREC, TEACH, SETPVC, SHIFTC)
Position data are the coordinates of the position in Cartesian values.
- **Relative to Another Position by Joint** (HERER *pos2 pos1*)
Position data are the differences between resolver values of one position and resolver values of another position.
- **Relative to Another Position by XYZ** (TEACHR *pos2 pos1*; HEREK *pos2 pos1*)
Position data are the differences between the Cartesian coordinate values of one position and the Cartesian coordinate values of another position.
- **Relative to Another Position by Tool** (HERERT *pos2 pos1*)
Position data are the differences between the Tool coordinate values of one position and the Tool coordinate values of another position.
- **Relative to Current by Joint** (HERER *pos*)
Position data are calculated by adding the resolver values of one position to the resolver values of the current position.
The current position is the resolver values at time the command using the position is executed.
- **Relative to Current by XYZ** (TEACHR *pos*; HEREK *pos*)
Position data are calculated by adding the Cartesian coordinate values of one position to the Cartesian coordinate values of the current position.
The current position is the Cartesian coordinate values at time the command using the position is executed.
- **Relative to Current by Tool** (TEACHRT *pos*; HERERT *pos*)
Position data are calculated by adding the Cartesian coordinate values of one position to the Cartesian coordinate values of the current position.
The current position is the Tool coordinate values at time the command using the position is executed.

ACL permits relative positions to be linked to one another in a chain of up to 32 positions. This relative chain of positions must be anchored to one absolute (root) position.

Defining Positions

The commands DEFP, DEFPB, DEFPC are used to define positions, and the commands DIMP, DIMPB and DIMPC are used to define position vectors.

To define a position is to reserve a location in controller memory and give a name to the location.

Three types of position names are possible:

- Alphanumeric names (such as P, POS10, A2). The name may be a combination of up to five characters, and should begin with a letter. Non-vector positions with alphanumeric names cannot be accessed from the teach pendant.
- Vector names (such as PVEC[50] and PVEC[10]) of up to five characters and an index. A position vector—an array of positions—can be attached to the teach pendant by means of the **ACL** command ATTACH. The vector positions can then be accessed from the teach pendant by means of their index number.

Positions vectors must have alphanumeric names, which must begin with a letter. The definition also includes an index (a number within square brackets) which defines the number of positions in the vector.

- Numerical names (such as 3, 22, 101) of up to five digits. These positions can be accessed directly from the teach pendant. Robot (group A) positions with this type of name do not need to be defined before they are recorded; the position recording commands automatically define and record numerically named robot positions.

For more efficient programming, it is recommended that you define position vectors and record positions in the vector; that is, use vector indices rather than numerical names.

Position memory is allocated separately to each of the three axis control groups: group A, group B and group C (individual axes). The maximum number of positions for each group is defined by the controller configuration.

Once a position has been defined, it remains dedicated to a specific axis control group, and cannot accept coordinate values for another axis group. By default, positions are defined for group A.

The following are examples of position definition commands:

DEFP PA	Defines one position named PA for group A.
DIMP AA[10]	Defines a vector of 10 positions named AA for group A.
DEFPB PB	Defines one position named PB for group B.
DEFPC PC 8	Defines one position named PC for group C axis 8.
DIMPC AC[10] 8	Defines a vector of 10 positions named AC for group C axis 8.

Recording Positions

The commands HERE, HEREC, HERER, HERERT, TEACH, TEACHR, TEACHRT, SETPV, SETPVC, SHIFT and SHIFTC are used to record position coordinate values.

To record a position is to write its values in the reserved memory location.

The following chart summarizes the commands for position recording.

	Joint	Cartesian	Tool
Controller records current position of robot arm (available in DIRECT and EDIT modes)			
Absolute; current values.	HERE <i>pos</i>	HEREC <i>pos</i>	—
Relative to Another Position.	HERER <i>pos2 pos1</i>	HEREC <i>pos2 pos1</i>	HERERT <i>pos2 pos1</i>
User enters position coordinates from keyboard (available in DIRECT mode only)			
Absolute; user defined values.	SETPV <i>pos</i>	TEACH <i>pos</i>	—
Relative to Another Position.	—	TEACHR <i>pos2 pos1</i>	TEACHRT <i>pos2 pos1</i>
Relative to Current Position.	HERER <i>pos</i>	TEACHR <i>pos</i>	TEACHRT <i>pos</i>
Changes one coordinate of a recorded position (available in DIRECT and EDIT modes)			
Absolute; Changes value of recorded position. By one coordinate: By one offset value:	SETPV <i>pos axis var</i> SHIFT <i>pos BY axis var</i>	SETPVC <i>pos coord var</i> SHIFTC <i>pos BY axis var</i>	

Although positions values are recorded in the Joint, Cartesian or Tool coordinate system, the axes can be instructed to move to positions in any coordinate system. The controller converts the coordinate values according to the movement command which is issued.

If a position is defined but not recorded, attempts to execute commands which refer to that position will cause run time errors.

It is recommended that you define (but not necessarily record) positions before editing the program in which they are used.

The following are examples of position recording commands:

HERE 1	Records the current coordinates of the axes in resolver values, for position 1.
TEACH P1	Records Cartesian coordinates for position P1, according to user settings.

Position Lists

The command LISTP displays a list of all positions and the group to which each position is dedicated.

The command LISTPV displays the resolver and/or Cartesian coordinate values of a specified position.

The command SENDPOINT produces a coded list for downloading the position. The code format is as follows:

Prefix (\$p)
Sequential number
Group (1/2/3: respectively, group A, B, C)
Name of position
Coordinates values
Axis number (if group C)
Type of position

Parameters

Parameters are reserved memory locations which are used to set the values of physical constants needed to adapt the controller to a particular robotic system. Most parameters are password-protected.

Parameters are referred by their number (1 to 2048). For example:

SHOW PAR 300 Displays value of parameter 300.

LET PAR 294 8000 Sets value of parameter 294 to 8000.

Refer to Chapter 7 for a complete description of system parameters.

Notational Conventions Used in this Manual

The following notations are used in the command formats described and explained throughout this manual:

- { } Curly braces enclose a list from which you must choose an item.
- [] Square brackets encloses optional items.
Note, however, that the **ACL** format requires square brackets around the indices of position vectors, variable arrays and inputs/outputs.
- ... An ellipsis indicates you may repeat the preceding item zero or more times.
- / A slash separates alternative items in a list. For example, `ATTACH OFF {A/B/C}` means:

```
ATTACH OFFA    or
ATTACH OFFB    or
ATTACH OFFC
```

italics Italics represents a descriptive item that should be replaced with an actual item name or value. The most common items are as follows:

Program: <i>prog</i>	Position: <i>pos</i>
Variables: <i>var</i>	Position vector: <i>pvect</i>
Value: <i>value</i>	Duration (time): <i>duration</i>
Axis: <i>axis</i>	Argument: <i>arg</i>

>bold In some examples, bold text is used to indicate command entry; often followed by **:?bold** non-bolded text indicating the controller's response.

Additional Notes

- **ACL** is not case-sensitive. Characters may be entered in either lower case or upper case.
- <Enter> must be pressed following all but three **ACL** commands, and is therefore not usually shown in this manual.

The following commands do not require <Enter> for execution:

<Ctrl>+A	Abort.
~	Toggles Keyboard Manual mode on and off.
<Ctrl>+C	Cancels the display of data resulting from SHOW ENCO, LIST, SEND, and other commands.

This page intentionally left blank.

The ACL Commands

This chapter presents the **ACL** commands in alphabetical order.

Each entry includes the following information:

- Command name.
- Operative mode: DIRECT and/or EDIT, and PRIVILEGE.
- Command format.
- Complete description of the command.
- Examples of use.
- Additional notes, including references to related commands and subjects.

Note:

Controller-AC uses resolvers as positioning feedback devices, whereas **ACL** command formats refer to encoder or ENC values. Since the values received from resolvers are comparable to those received from encoders, references to these two types of feedback devices are interchangeable in the **ACL** language.

Format: A [*prog*]
<Ctrl>+A

Where: *prog* is a running program.

Description: A or <Ctrl>+A Immediately aborts all running programs and stops movement of axes.

<Ctrl>+A is the fastest software method for stopping program execution and halting the movement of all axes. It can be used at any moment, even while entering another command, in order to urgently stop programs and axes.

A *prog* Aborts the running of the specified program only.

Examples: ■ A Aborts all programs.

■ A NEW Aborts program NEW.

Notes: The command <Ctrl>+A does not require <Enter> for execution.
The command A requires <Enter> for execution.

Format: ANDIF *var1 oper var2*

Where: *var1* and *var2* are variables or constants;
oper can be: <, >, =, <=, >=, < >

Description: An IF type command, ANDIF logically combines a condition with other IF commands.

Example: ■ IF A=B If the values of A and B are equal,
 ANDIF C>2 and if the value of C is greater than 2,
 CLOSE close the gripper;
 ELSE If any of the conditions is not true,
 OPEN open the gripper.
 ENDIF End of conditional routine.

Notes: Refer to the IF command.

Format: APPEND

Description: APPEND loads data from a backup file in the host computer to the controller's user RAM, via the main RS232 channel (CONSOLE port).

APPEND is similar to the RECEIVE command, but does not erase or modify existing programs.

The file must be in the format generated by a SEND command.

When the APPEND command is executed, the following occurs:

- New programs are accepted.
- New variables are accepted.
- New positions are accepted.
- Coordinate values will be assigned to defined positions whose coordinate values have not yet been set.

Notes: The **ATS** Backup Manager performs the SEND, RECEIVE and APPEND procedures. Use that menu to backup and restore user RAM.

Refer to the chapter on the Backup Manager in the *ATS Reference Guide*

Also refer to the SEND and RECEIVE commands.

DIRECT

ATTACH

Format: `ATTACH pvect`
 `ATTACH OFF{A/B/C}`
 `ATTACH ?`
Where: *pvect* is a vector.

Description: `ATTACH pvect` Attaches the specified position vector to the teach pendant according to the group for which the position vector is defined.

When a vector is attached to the teach pendant, all references to that group refer to the positions in the attached vector.

Only one vector at a time may be attached to each group. Attaching another position vector cancels the previous attachment for this group.

`ATTACH OFFA` Detaches the position vector from teach pendant according to the group specified.

`ATTACH OFFB`

`ATTACH OFFC`

`ATTACH ?` Displays the current ATTACH status.

Examples: ■ `DIMP ALPHA[20]` Defines a position vector for group A named ALPHA containing 20 positions.
 `ATTACH ALPHA` Attaches vector ALPHA to teach pendant. A reference from teach pendant to position 15 will now actually refer to the position ALPHA[15].

 ■ `DIMPB &BETA[30]` Defines a position vector for group B named &BETA containing 30 positions.
 `ATTACH &BETA` The & prefix enables this vector to be manipulated by the DELETE and INSERT commands.

 ■ `ATTACH OFFB` Detaches from the teach pendant the currently attached group B position vector.

AUTO

DIRECT

Format: AUTO

Description: This command must be entered after the Auto/Teach switch on the teach pendant is moved from Teach to Auto.

AUTO transfers control from the teach pendant to the keyboard.

Format: BRAKE *n*

Where: *n* is an axis

Description: Releases the brake on the specified axis.

This command is useful when maintenance procedures or handling necessitates moving the robot by hand.

Use this command with caution. Releasing the brake may cause the robot arm to drop.

Use the command COFF to reapply the brake.

Note: Refer to the COFF command.

Format: BREAK *n*

BREAK

Where: *n* is a program line number

Description: BREAK *n*

When program execution reaches the line number specified by the BREAK *n* command, it will suspend execution, and display a prompt in the following format:

```
Break at task: DEMO in program: SUB1
  42: <Break> SET ERROR=0
(G/S/E)
```

The prompt displays the name of the task (e.g., program DEMO) which calls the routine (e.g., program SUB1) which contains the line number (e.g., 42) specified by the BREAK.

The prompt allows you to continue by doing one of the following:

- G <Enter> (Go) Program will resume continuous execution, unless it reaches another break point.
- S <Enter> (Step) Program will continue one line at a time, and display the (G/S/E) prompt after execution of each command.
- E <Enter> (Exit) Program will be aborted.

BREAK

Lists all break points currently set.

Example: BREAK 600

When program execution reaches line 600, it will halt and wait for an input from the keyboard.

Note: Refer to the NOBREAK, RUN and STEP commands.

Format: CLOSE

Description: The CLOSE command closes the gripper.
The CLOSE command activates the digital output which controls the gripper.
Parameter 274 defines the number of the output which controls the gripper.

Notes: Refer to the OPEN command.
Also refer to the gripper parameters in Chapter 6.

- Format:** CLR *n*
Where: *n* is a resolver, $1 \leq n \leq 8$, or *.
- Description:** CLR *n* Clears the value (in the range $0 \leq \text{resolver} < 2048$) of a specific resolver; number of resolver turns is set to 0.
- CLR * Clears the values of all resolvers.
- Resolver values can be cleared only when the PRIVILEGE mode is active.
- Warning! CLR spoils the robot arm's home reference, and alters all other positions as a result. Use with caution.*
- Example:** ■ CLR 3 Clears resolver 3.
- Notes:** Refer to the section on PRIVILEGE mode in Chapter 2.
Refer to the PRIV command.

Format: CLRBUF [A/B]

CLRBUF *n*

Where: *n* is an axis in group C.

Description: CLRBUF
 Empties the movement buffer of all axes, thereby aborting current and remaining movement commands. Can be used to stop the robot or axes upon event, and to continue the program with other commands.

CLRBUFA
 Empties the movement buffer of group A.

CLRBUFB
 Empties the movement buffer of group B.

CLRBUF *n*
 Empties the movement buffer of a specific axis in group C.

Examples: ■ CLRBUF
 Empties the movement buffer of all axes.

■ IF IN[3]=1
 STOP MAIN
 CLRBUFA

 MOVE HOME
 ENDIF
 If input 3 is on;
 stop program MAIN;
 clear all remaining MOVE commands from the
 buffer of group A;
 move to position HOME.

Format: CLRCOM [*n*]

Where: *n* is an RS232 communication port, $0 \leq n \leq 8$

Description: CLRCOM Clears the buffers of all the RS232 communication ports.

CLRCOM *n* Clears the buffers of the specified RS232 port.

This command can be used to reset the communication ports when an error, such as XOFF without a subsequent XON, interrupts or halts RS232 communication.

Examples: ■ CLRCOM 2 Clears the buffers of RS232 port COM2.

■ CLRCOM 0 Clears the buffer of the controller's RS232 port COM0.

Note: Refer to the SENDCOM command.

Format: COFF [A/B]

COFF *n*

Where: *n* is an axis in group C.

Description: COFF Disables servo control of all axes.
 COFFA Disables servo control of group A or group B.
 COFFB
 COFF *n* Disables servo control of a specific axis in group C.

COFF is activated when one of the following occurs:

- COFF is entered from the keyboard or Control Off is entered from the teach pendant.
- An EMERGENCY button is pressed. (After the button is released, CON must be entered to restore servo control.)
- The controller detects an impact or thermic error condition (as determined by parameter settings).

Once COFF has been entered, the axes cannot be operated and the following message appears on both the computer screen and the teach pendant display:

CONTROL DISABLED

You must activate CON before motion can resume.

Examples:

- COFF Control OFF for all axes.
- COFFA Control OFF for group A axes.
- COFF 10 Control OFF for axis 10 in group C.

Note: Refer to the CON command.

Format: CON[A/B]

CON *n*

Where: *n* is an axis in group C.

Description: CON Enables servo control of all axes.
CONA Enables servo control of group A or group B.
CONB
CON *n* Enables servo control of a specific axis in group C.

When either CON (from keyboard) or Control On (from the teach pendant) is activated, the following message appears on both the computer screen and the teach pendant display:

CONTROL ENABLED

The controller must be in the CON state for axis operation.

Entering the command CON has no effect if the axis is already enabled.

Examples:

- CON Control ON for all axes.
- CONA Control ON for group A axes.
- CONB Control ON for group B axes.
- CON 10 Control ON for axis 10 in group C.

Note: Refer to the COFF command.

Format: CONFIG [?]

Description: The CONFIG command allows you to perform a complete configuration of the controller. During the configuration the system displays the existing values [in brackets] and allows you to change them, as shown in the example below. If you do not want to change a setting, accept it by pressing <Enter>.

Warning! This command erases all programs, variables and positions in user RAM! Also erases current password and resets to factory-set default.

CONFIG	Activates the file used for configuring the controller. Allows you to define: number of inputs and outputs; number of servo axes; type of robot; size of memory reserved for user defined programs and program lines, and user defined variables, positions and comments.
CONFIG ?	Displays the current configuration.

Example: ■ >config <Enter>

```
(239) SYSTEM CONFIGURATION
!!!WARNING ALL USER PROGRAMS WILL BE ERASED.
ARE YOU SURE ??? [YES/NO/DEFAULT] (DEFAULT)> <Enter>
JOB KILLING PHASE .....>
ENTER NUMBER OF INPUTS [16] (0-16) > <Enter>
ENTER NUMBER OF OUTPUTS [16] (0-16) > <Enter>
ENTER NUMBER OF AXIS DRIVERS INSTALLED [5] (0-8)>8 <Enter>
ENTER NUMBER OF AUXILIARY RS232 PORTS [0] (0-8) > <Enter>
WHICH TYPE OF ROBOT (0-NONE,2-MK2,3-MK3) [3](0-3)> <Enter>
ENTER NUMBER OF SERVO LOOPS, GROUP A [5] (5-5)> <Enter>
ENTER NUMBER OF FIRST AXIS OF GROUP B [6] (6-8) 7<Enter>
ENTER NUMBER OF SERVO LOOPS, GROUP B [0] (0-3)> 1<Enter>
ENTER NUMBER OF USER PROGRAMS [400] > <Enter>
ENTER NUMBER OF USER PROGRAM LINES [5000] > <Enter>
ENTER NUMBER OF USER VARIABLES [3000] > <Enter>
ENTER NUMBER OF USER POINTS , GROUP A [5000] > <Enter>
ENTER NUMBER OF USER POINTS , GROUP B [0] > 1000<Enter>
ENTER NUMBER OF USER POINTS , GROUP C [0] > 1000<Enter>
ENTER NUMBER OF USER COMMENTS [3000] > <Enter>

Performing configuration, please wait 10 seconds

Available workspace 366012 (Bytes) 100%
Assigned workspace 280511 (Bytes) 76%
Unused workspace 85501 (Bytes) 23%
O.K.
>
```

The system displays the existing (default or currently defined) values, which you may change according to the options displayed. The factory-set default configuration for Controller-AC defines the 5 axes of the PERFORMER-MK3 and no peripheral axes but loads control parameters for a A3A motor or Axis 6 and A8A motors for Axes 7 and 8.

- The maximum number of inputs and outputs is 16.
- The maximum number of axis drivers is 8; default is 5.
Normally the slot for axis driver 6 remains empty, but the software assumes a card is installed. If a driver card for axes 7 and 8 is installed the configuration must define 8 axes.
- The maximum number of auxiliary (optional) RS232 ports is 8.
- When prompted for the type of robot, your options are as follows:
 - 0: Separate axes, kinematics of the arm unknown, no XYZ calculations, no HOME routine.
 - 3: Compatible with **PERFORMER-MK3** kinematics.
- The number of axes for group A is restricted to 5 axes.
- By default, no servo gripper is installed at axis 6. This (gripper) axis can be used for driving other servo devices. If an electric servo gripper is being used, it must be installed as the next available axis following group A; for example, if group A includes 5 axes, the gripper must be installed as axis 6.
- The total number of servo loops cannot be less than the number of axes defined for groups A and B and gripper. Any remaining axes are assigned to group C, which always contains independent axes. In this example the default settings are: 5 axes in group A, 2 axes in group B, and 1 axis in group C, totalling 8 axes.
- The number of user defined programs, program lines, variables, positions, and comments depends upon the memory size and the allocation of all these items.

It will take about 30 seconds for the DEFAULT configuration to be performed; other configurations will take about 10 seconds.

The workspace allocations are as follows:

- Available Workspace: Memory remaining available to user after memory allotted to controller.
- Assigned Workspace: Percentage of the Available Workspace. Calculated according to the settings you entered during the configuration.
- Unused Workspace: Percentage of the Available Workspace not allotted.

Note that there is a delay of several second before the controller displays OK.

The system is reset at the end of the configuration. INIT EDITOR is also executed automatically.

- The following is an example of a configuration report. The values in this example result from the configuration in the example shown above.

>CONFIG ?

```
***** CURRENT CONFIGURATION IS :
MK3 ROBOT TYPE
GRIPPER IS CONNECTED TO OUTPUT 16
16 INPUTS          | 400  PROGRAMS
16 OUTPUTS         | 5000 PROGRAM LINES
8 AC SERVO MOTORS  | 3000 VARIABLES
0 AUXILIARY PORTS  | 3000 COMMENTS
5 AXES IN GROUP A  | 5000 POINTS IN GROUP A
7 FIRST AUX. AXI   | 1000 POINTS IN GROUP B
1 AXES IN GROUP B  | 1000 POINTS IN GROUP C
1 INDIVIDUAL AXES  | 512  KB BACKED-UP MEMORY
DIRECT TEACH OPTION: INSTALLED

Available workspace 366012 (Bytes) 100%
Assigned workspace  280511 (Bytes) 76%
Unused workspace    85501 (Bytes) 23%
```

Format: CONTINUE *prog*
 Where: *prog* is a suspended program.

Description: Resumes execution of program *prog* from the point where it was previously suspended by the SUSPEND command.

Example: ■ CONTINUE ALPHA Resumes execution of program ALPHA.

Note: Refer to the SUSPEND command.

Format: `COPY prog1 prog2`

Where: *prog1* is an existing user program.

Description: Copies *prog1* to a new program named *prog2*.

Two copies of the same program now exist under different names.

If the name *prog2* is already in use, a warning message is displayed.

Example: ■ `COPY ALPHA BETA` Copies user program ALPHA to program BETA.

Format: DEFINE *var1* [*var2* ... *var12*]
Where: *var1* , *var2* , ... *var12* are user variables.

Description: Defines a private variable. A private variable is recognized only by the specific program which was being edited when the DEFINE *var* command was entered.
Up to twelve variables can be defined in one command.

Examples:

- DEFINE I Creates a private variable named I.
- DEFINE L ALL KEY Creates private variables named L, ALL and KEY.

Note: This command does not create a program line.

Format: DEFP[A/B] *pos*

DEFPC *pos n*

Where: *pos* is a user defined name;
n is an axis in group C.

Description: Defines a position for a specific axis control group. When a position is defined, controller memory is reserved for the position's coordinate values which will subsequently be recorded or set.

DEFP *pos* Defines a position for axis control group A.

DEFPA *pos*

DEFPB *pos* Defines a position for axis control group B.

DEFPC *pos n* Defines a position for an axis in group C.

If a group is not specified for the position, group A is assumed. Once a position has been defined, it is dedicated to a specific axis control group, and cannot be used to record coordinates for a different axis control group.

The DEFP command is not required for *numerically* named positions for group A; these positions will be automatically defined when entered as part of a command.

- Examples:**
- DEFP S Defines a position named S for group A.
 - DEFPA BF3 Defines a position named BF3 for group A
 - DEFPB DD Defines a position named DD for group B.
 - DEFPC P85 9 Defines a position named P85 for group C axis 9.

Note: This command does not create a program line.

DEL

EDIT

Format: DEL

Description: Erases the last displayed line in a program which is being edited.

Example: ■ 190: LABEL 1
191: MOVE 10
192: ?**DEL** Erases the command in line 191.

Format: `DELAY var`

Where: `var` is a variable or constant.


Description: Delays the execution of a program.

`Var` is defined in hundredths of a second (0.01 second).

The DELAY command is used for the following purposes:

- To insert a specific time delay between the execution of any two commands in a program.
- To enable the control system to stabilize at a certain position during the execution of movement commands. This compensates for differences in motion conditions (such as speed, direction, payload) between the time positions are recorded, and when they are approached at run-time.

The diagram here suggests a point for delaying the execution of a program, before the robot inserts a pin into a hole.



Examples: ■ `DELAY 100`

Delays for
1 second.

■ `SET T=500`
`DELAY T`

Delays for 5 seconds.

Format: DELETE *pvect*[*n*]

Where: *pvect* is a vector;
 n is the index of one of the positions in the vector.

Description: Deletes position *n* in vector *pvect*; all positions above position *pvect*[*n*] are moved down one place until an empty (unrecorded) position is encountered.

DELETE can only be applied to a position for a robot or multi-axis device which is dedicated to group A or group B. The command is not applicable to positions for a single axis device.

You can delete a position only if it is not used by any program in the user RAM. The controller will warn you if you attempt to delete a position which is in use.

Example: ■ DELETE AA[4] Deletes position 4 in vector AA.

Note: Refer to the DIMP, UNDEF and INSERT commands.

Format: DELP *pos*
 DELP *pvect*

Where: *pos* is a position;
 pvect is a vector.

Description: Deletes positions and position vectors from user RAM.

You can delete a position or vector only if it is not used by any program in the user RAM. A warning will appear if you attempt to delete a position which is in use.

The DELP command cannot delete individual positions within a vector.

The DELETE command can delete individual positions within a vector, providing the vector name has the prefix .

The UNDEF command erases the coordinate values of a position, but keeps the position defined.

Examples:

- DELP A9 Deletes a position or a vector named A9.
- DELP DOD Deletes a position or a vector named DOD.
- DELP BB Deletes a vector named BB.

Notes: This command does not create a program line.
 Refer to the DELETE and UNDEF commands.

Format: DELVAR *var*

Where: *var* is a user variable or variable array.

Description: Erases a user defined variable or variable array from user RAM.

You can delete a variable only if it is not used by any program in the user RAM. A warning will appear if you attempt to delete a variable which is in use.

In DIRECT mode DELVAR deletes only global variables.

In EDIT mode DELVAR deletes private variables; it will delete a global variable only if a private variable with that name does not exist.

You cannot delete system variables.

- Examples:**
- DELVAR X Deletes variable X.
 - DELVAR PRESS Deletes variable PRESS.

Note: This command does not create a program line.

Format: DIM *var*[*n*]

Where: *var* is a user defined name;
[*n*] is the dimension of the array.

Description: Defines a private variable array of *n* elements. The elements created are named *var*[1], *var*[2], . . . *var*[*n*].

A private variable is recognized only by the program in which it is defined.

Example: ■ DIM PRGV[20] Creates a variable array named PRGV containing 20 private variables, PRGV[1] . . . PRGV[20].

Note: This command does not create a program line.

Format: `DIMG var[n]`

Where: *var* is a user defined name;
[n] is the dimension of the array.

Description: Defines a global variable array of *n* elements. The elements created are named *var[1]*, *var[2]* . . . *var[n]* .

A global variable can be used by any user program.

Example: ■ `DIMG GLOB[8]` Creates a variable array named GLOB containing 8 global variables, GLOB[1] . . . GLOB[8].

Note: This command does not create a program line.

Format: DIMP[A/B] *pvect*[*n*]
 DIMPC *pvect*[*n*] *axis*

Where: *pvect* is a user defined name;
 [*n*] is the dimension of the vector;
 axis is an axis in group C.

Description: Defines a vector containing *n* positions, named *pvect*[1], *pvect*[2], . . . *pvect*[*n*], for a specific axis control group. When a vector is defined, controller memory is reserved for the coordinate values of the positions which will subsequently be recorded or set.

DIMP *pvect*[*n*] Defines a vector for axis control group A.

DIMPA *pvect*[*n*]

DIMPB *pvect*[*n*] Defines a vector for axis control group B.

DIMPC *pvect*[*n*] *axis* Defines a vector for an axis in group C.

If a group is not specified for the vector, group A is assumed. Once a vector has been defined, it is dedicated to a specific axis control group, and cannot be used to record coordinates for a different axis control group.

The first character of the vector name must be a letter or the character .

When the first character of the vector name is , the vector can be manipulated by the DELETE and INSERT commands. Include the prefix in the vector name if you intend to use the vector for SPLINE or MOVES trajectories.

- Examples:**
- DIMP PICK[30] Creates a vector for group A containing 30 positions named PICK[1] . . . PICK[30].
 - DIMPB BETA[30] Creates a vector for group B containing 30 positions, named BETA[1] . . . BETA[30]. The prefix enables this vector to be manipulated by the DELETE and INSERT commands.
 - DIMPC CNV[25] 11 Creates a vector for axis 11 containing 25 positions named CNV[1] . . . CNV[25].

Notes: This command does not create a program line.

Format: DIR

Description: Displays a list of all current user programs. The four columns provide the following information:

- Program Name.
- Program Validity.
If the program contains a logic error, NOT VALID will be displayed.
- Program Identity Number.
This is a controller assigned program number; this is the number you need to use for accessing programs from the teach pendant.
Since certain controller operations will cause the ID number to change, it is recommended that you use the DIR command at the beginning of each working session to verify the ID numbers of the programs you will want to run from the teach pendant.
- Program Execution Priority.

Example: ■ `>DIR`

name	: validity	: identity	: priority
IO	:	: 2	: 5
IOA	:	: 3	: 5
TWOIO	:	: 4	: 5
INOUT	:	: 5	: 5
PICP	:	: 6	: 5

Notes: Validity: Refer to the EXIT command.

Priority: Refer to the PRIORITY and RUN commands.

Format: DISABLE {IN/OUT} n

DISABLE ?

Where: IN is an input;
 OUT is an output;
 n is the I/O index, $1 \leq n \leq 16$.

Description: DISABLE IN n Disconnects the physical input or output from normal system control.
 DISABLE OUT n

DISABLE ? Displays a list of all disabled inputs and outputs.

When an input or output is disabled, its last state remains unchanged. However, the FORCE command can be used to alter its state.

To restore normal system control of a disabled input or output, use the ENABLE command.

Examples: ■ DISABLE IN 8 Disconnects input 8 from normal system control.

■ DISABLE OUT 12 Disconnects output 12 from normal system control.

Note: Refer to the ENABLE and FORCE commands.

Format: DO *editcom*

Where: *editcom* is an EDIT mode command.

Description: Performs any of the following EDIT mode commands in DIRECT mode.

POST	CLRCOM
QPOST	PRCOM
PRINTLN	PRLNCOM
READ	READCOM
STOP	SENDCOM

Example: ■ DO CLRCOM 2 Immediately resets communication port 2.

■ DO PRINTLN Immediately inserts a carriage return and line feed.

Format: DOWNLOAD

Description: Servo control parameters for each axis are programmed onto an EEPROM on the DDC card for each axis. A copy of these parameters is contained in the ACL parameters (PAR 1000 – PAR 2048) in the controller's BBRAM.

Before executing this command, the system will display the message:

```
*** WARNING *** After downloading parameters to drivers,  
controller will be reset.  
Are you sure? <Yes/No>_
```

Type Yes (complete word) and [Enter] to accept the download and reset. Any other response is regarded as No (cancel).

DOWNLOAD copies the servo control parameters for all configured axes from the controller's BBRAM to the EEPROMs on the DDC cards.

A parameter (CBU) file on a disk can be loaded into the controller by means of the ATS Backup Manager (<Shift>+F10), and then copied to the DDC cards by means of the DOWNLOAD command.

Note: Refer to the UPLOAD command.

Format: ECHO

Description: In ECHO mode, all characters that are transmitted to the controller are displayed on the screen. This is the default mode.

In NOECHO mode the transmitted characters are not displayed.

Note: Refer to the NOECHO command.

Format: `EDIT prog`

Where: `prog` is any user program.

Description: Activates the EDIT mode and calls up a user program named `prog`.
If `prog` is not found, the system automatically creates a new program of that name.

To quit the EDIT mode, and return to DIRECT mode, use the command:

`EXIT`

Example: ■ `>edit ALPHA`

Welcome to ACL editor, type HELP when in trouble

`PROGRAM ALPHA`
`*****`

`127:?`

The editor is now ready to receive program lines.

Notes: Refer to the EXIT command.

Refer to Chapters 1 and 2 for descriptions of editing commands.

Refer to Chapter 4 for information on reserved names for user programs.

Format: ELSE

Description: The ELSE command follows an IF command and precedes ENDIF.
ELSE marks the beginning of a program subroutine which defines the actions to be taken when an IF command is false.

Example: ■ IF J>2
 ANDIF A=B
 SET OUT[1]=1
ELSE
 SET OUT[5]=1
ENDIF

If the value of J is greater than 2, and if the values of A and B are equal, the controller will turn on output 1; If any of the conditions is not true, the controller will turn on output 5.

Note: Refer to the IF command.

Format: EMPTY *prog*

Where: *prog* is a user program.

Description: Deletes all lines of a program, but leaves the program existent and valid.

The EMPTY command is useful when *prog* is an application subroutine which is called by another program.

Once a program has been emptied, you can alter its specific function without changing the main program. This is particularly useful in CIM applications, when you want to change a process at a given station without changing the CIM system programs.

Private variables assigned to this program are also deleted.

Example: ■

```
PROGRAM MAIN
*****
[program line]
[program line]
[program line]
```

```
.
GOSUB USER
```

```
.
[program line]
[program line]
[program line]
```

```
.
END
```

```
PROGRAM USER
*****
[program lines which]
[can be removed and]
[rewritten by means of]
[the EMPTY command]
```

```
END
```

Use the command EMPTY USER to erase all program lines. Then EDIT program USER to alter the contents of the program.

Format: ENABLE {IN/OUT} *n*

Where: IN is an input;
 OUT is an output;
 n is the I/O index, $1 \leq n \leq 16$.

Description: ENABLE IN *n* Restores normal system control of an input or
 ENABLE OUT *n* output which has been disconnected by means of
 the DISABLE command.

By default, all the inputs and outputs are enabled.

Examples: ■ ENABLE IN 8 Reconnects input 8 to normal system control.
 ■ ENABLE OUT 12 Reconnects output 12 to normal system control.

Note: Refer to the DISABLE command.

EDIT

END

Description: The system automatically writes END as the last line of a program.
The system automatically writes (END) at the end of a listing.
END is not a user command.

Format: ENDFOR

Description: Required companion to FOR command.
 Ends the subroutine to be executed by the FOR command.

Example: ■ FOR I=1 TO 16 This loop is performed 16 times,
 SET OUT[I]=1 and turns on all 16 outputs
 ENDFOR

Note: Refer to the FOR command.

Format: ENDIF

Description: Required companion to IF command.
Ends the subroutine to be executed by the IF command.

Example: ■ IF XYZ=1 If the first condition and the second condition are true,
 ANDIF Z[1]=X or if the third condition is true,
 ORIF B<C execute the move;
 MOVE POS[1] otherwise,
ELSE execute a different move.
 MOVE POS[2]
ENDIF

Note: Refer to the IF command.

Format: ENGLISH

Description: Causes the controller messages to be displayed in English.

If garbled text appears on the screen, it means the PC does not support work in Japanese. Use the ENGLISH command to make the system communicate in English.

The language definition is saved when the controller is switched off.

Note: Refer to the JAPANESE command.

Format: EXACT [OFF] {A/B/C}

Description: Determines the accuracy of the commands which are used for sequential execution of operations in a program:

MOVED	MOVELD	SPLINED
MOVESD	MOVECD	SPLINELD

The EXACT and EXACT OFF modes are applied separately to each axis control group.

EXACT {A/B/C}	<p>Enables the EXACT mode for group A, group B or group C.</p> <p>When a movement command (with D suffix) is executed in EXACT mode, the axes reach the target position accurately (within a given position error tolerance).</p> <p>Movement <i>duration</i>, if specified in the movement command, is ignored when the command is executed in EXACT mode.</p>
EXACT OFF {A/B/C}	<p>Disables the EXACT mode for group A, group B or group C.</p> <p>When a movement command (with D suffix) is executed in EXACT OFF mode, the axes reach the target position within a specified <i>duration</i>. Position accuracy is not guaranteed.</p>

By default, all groups are in EXACT mode.

Examples:

- EXACT A EXACT on for group A.
- EXACT OFF A EXACT off for group A.
- EXACT OFF A
MOVED POS1 500 Axes reach POS1 and POS2 in 5 seconds.
MOVED POS2 500
- EXACT A
MOVED POS3 Axes reach POS3 with required accuracy,
 regardless of duration.

Notes: Parameter 260+axis determines the position error tolerance.

Refer to the commands MOVED, MOVESD, MOVELD, SPLINED, SPLINELD, and MOVECD.

Format: EXIT

Description: Quits EDIT mode and checks the logic of the program. Searches for errors, such as FOR commands without ENDFOR, IF without ENDIF, and GOTO without a proper LABEL.

If an error is found, a message is displayed:

```
PROGRAM NOT VALID
```

And, when possible, the cause of the error is indicated.

If no errors are found, the following message is displayed:

```
PROGRAM IS VALID
```

EXIT returns the controller to the DIRECT mode.

Format: FOR *var1=var2* TO *var3*

Where: *var1* is a variable;
 var2 and *var3* are variables or constants.

Description: Executes a subroutine for all values of *var1*, beginning with *var2* and ending with *var3*.

The last line of the subroutine must be the ENDFOR command.

Examples: ■ FOR L=M TO N
 MOVED POS[L]
 ENDFOR

 ■ FOR I=1 TO 16
 SET OUT[I]=1
 ENDFOR

Format: FORCE {IN/OUT} *n* {0/1}

FORCE ?

Where: IN is an input;
OUT is an output;
n is the I/O index, $1 \leq n \leq 16$;
0=off; 1=on

Description: FORCE Forces the specified input or output to the specified state.

This command is operative only for I/Os which have been disabled by the DISABLE command.

FORCE ?

Displays a list of all forced inputs and outputs, and their state.

Examples: ■ DISABLE IN 5
FORCE IN 5 1

Forces input 5 to ON state.

■ DISABLE OUT 11
FORCE OUT 11 0

Forces output 11 to OFF state.

■ >force ?
INput[5]=1
OUTput[11]=0

Displays status of forced I/O's:
Input 5 is in forced ON state.
Output 11 is in forced OFF state.

Note: Refer to the DISABLE command.

Format: FREE

Description: Displays a list of the available memory in user RAM:

- Available program lines
- Available variables
- Available points of group A
- Available points of group B
- Available points of group C
- Available bytes for comments

Format: GACCEL[A/B] *var*
GACCELC *var axis*

Where: *var* is a variable or constant, whose value is in the range [1...100]

Description: This command applies a global acceleration factor to all movements of all joints, making the maximum acceleration used in movements less than the maximum acceleration allowed for the arm.

This command is useful for: allowing a payload which is heavier than rated for the robot; creating smoother movements; increasing the smothing (rounding of corners) in spline movements.

GACCEL sets the acceleration factor of all axes.

GACCELA sets the acceleration factor of group A axes.

GACCELB sets the acceleration factor of group B axes.

GACCELC sets the acceleration factor of a specific axis in group C.

GACCEL can be issued at any time, whether or not the robot arm is moving, and takes effect immediately. If a GACCEL command is issued while the robot is in motion, the robot will immediately move according to the new acceleration.

To view current global acceleration settings, use the SHOW SPEED command.

Format: GET *var*

Where: *var* is a user variable.

Description: When the program encounters a GET command, it pauses and waits for a keyboard character to be pressed. The variable is assigned the ASCII value of the character that is pressed.

The GET command should be preceded by a PRINTLN command which will indicate to the user that the program is waiting for a character to be pressed.

Example:

```

■ PRINTLN "SELECT PROGRAM: P Q R"
  GET VP                (VP is the variable)
  IF VP=80              (80 is ASCII for P)
    ORIF VP=112        (112 is ASCII for p)
    RUN P
  ENDIF
  IF VP=81              (81 is ASCII for Q)
    ORIF VP=113        (113 is ASCII for q)
    RUN Q
  ENDIF
  IF VP=82              (82 is ASCII for R)
    ORIF VP=114        (114 is ASCII for r)
    RUN R
  ENDIF

```

Note: Refer to the READ command.

Format: GETCOM *n var*

Where: *n* is an RS232 communication port, $0 \leq n \leq 8$;
var is a variable.

Description: Companion to the SENDCOM command.

Receives one byte from the specified RS232 port.

The value of the byte is stored in the specified variable.

Example: ■ PROGRAM WAIT1

LABEL 1
GETCOM 1 RCV
PRINTLN "RECEIVING ASCII CODE : "RCV
GOTO 1
END

This program waits for a character to be received on RS232 port COM1, and then displays its value on the screen.

If the character A (ASCII 65) is pressed, the following is displayed on the screen:

```
RECEIVING ASCII CODE : 65
```

Note: Refer to the SENDCOM command.

Format: GLOBAL *var1* [*var2* ... *var12*]

Where: *var1* [*var2* ...*var12*] are user defined variables.

Description: Defines a global variable. A global variable can be used in any user program.
Up to twelve variables can be defined in one command.

Examples:

- GLOBAL HB Creates a global variable named HB.
- GLOBAL J BYE ME Creates global variables named J, BYE and ME.

Note: This command does not create a program line.

Format: GOSUB *prog*

Where: *prog* is a user program.

Description: Transfers program control from the main program to *prog*, starting at the first line of *prog*. When the END command in *prog* is reached, execution of the main program resumes with the command which follows the GOSUB command.

Example: ■ SET Z=10 After executing the SET command, and before
GOSUB SERVE executing the MOVE command, the program
MOVE P3 SERVE is executed in its entirety.

Format: GOTO *labeln*

Where: *labeln* is any number, $0 \leq n \leq 9999$

Description: Jumps to the line immediately following the LABEL *labeln* command.

LABEL *labeln* must be included in the same program as the GOTO command.

- Examples:**
- LABEL 5
MOVE POS13
SET A=B+C
GOSUB MAT
GOTO 5
This program is executed in an endless loop unless aborted manually.

 - LABEL 6
GOSUB BE
SET K=K+1
IF K<500
 GOTO 6
ENDIF
This program is executed 500 times and then stops.

Note: Refer to the LABEL command.

Format: GSPEED[A/B] *var*
 GSPEEDC *var axis*

Where: *var* is a variable or constant, whose value is in the range [-100...+100]

Description: This command applies a global speed factor to all movements of all joints.

Defines the speed of movements in percentages. Maximum speed is 100; minimum is 1. The default speed is 100.

GSPEED sets the speed factor of all axes.

GSPEEDA sets the speed factor of group A axes.

GSPEEDB sets the speed factor of group B axes.

GSPEEDC sets the speed factor of a specific axis in group C.

GSPEED can be issued at any time, whether or not the robot arm or accessory axis is moving, and takes effect immediately.

GSPEED can be assigned a *negative* value. In such instances, the arm will return on the same path to the point at which movement was initiated. At that starting position, the arm will stop and wait until a positive value is assigned to GSPEED.

Starting positions are defined as the following:

- For MOVE(L/C): the point at which movement began.
- For SPLINE(L): the point at which the current segment of the spline began; for example: if the arm was moving from *n1* to *n2*, the arm will return to position *n1* if a negative value is assigned to GSPEED.
- For MOVES: the robot's position at the time the MOVES command was executed.

To view current speed settings, use the SHOW SPEED command.

- Examples:**
- SPEED 80
 SPEEDL 560
 GSPEED 50
 GSPEED reduces all speeds by 50%: joint speed is thus reduced to 40% and linear speed is reduced to 280 mm/sec.
 - MOVED A
 MOVE B
 If a negative value (e.g., GSPEED -50) is issued while the arm is moving to B, the arm will return to A.
 - MOVED A
 SPLINE M *n1 n2*
 If a negative value (e.g., GSPEED -50) is issued while the arm is moving from M[*n*] to M[*n1*], the arm will return to M[*n*].

■ MOVED A
MOVES M n1 n2

If a negative value (e.g., GSPEED -50) is issued while the arm is moving from M[n] to M[n1], the arm will return to A.

Note:

Refer to the MOVE(D), MOVES(D), SPLINE(D), SPEEDL and SHOW SPEED commands.

Format: HELP [*topic*]

Description: When in DIRECT mode, HELP provides an on-line help screen for DIRECT commands, as follows:

HELP	A list of topics is displayed on your screen. ACL commands appear in uppercase letters; other subjects appear in lowercase letters.
HELP <i>topic</i>	Where <i>topic</i> is the name of a command or subject. A brief explanation of the topic is displayed on your screen.
DO HELP	Provides on-line help screen for EDIT commands.

When in EDIT mode, HELP provides a list and brief explanation of all EDIT commands.

,

This command does not create a program line.

Format: HERE *pos*

Where: *pos* is a position for any axis group.

HEREC *pos*

Where: *pos* is a robot (group A) position.

Description: Records an absolute position, according to the current location of the axes.

HERE *pos* Records in joint values the current coordinates of the axes for the specified position.

HEREC *pos* Records in Cartesian (world) coordinate values the current coordinates of the axes for the specified position. This command is valid for robot (group A) axes only.

If the position has an alphanumeric name, it must first be defined using the DEFP or DIMP command.

The DEFP command is not required if the position is a *numerically* named position for group A; it will be automatically defined when entered as part of the HERE/HEREC command.

- Examples:**
- HERE 3 Defines and records the coordinates of position 3 for group A.
 - DEFPB POINT
 HERE POINT Defines a position named POINT for group B; records the current coordinates for position POINT.
 - DIMP P[20]
 HEREC P[5] Defines a vector named P containing 20 position for group A; records Cartesian coordinates for position 5 in the vector.
 - MOVE POSA 300
 DELAY 100
 HERE PMID One second after movement to position POSA begins, an intermediate position, PMID, is recorded according to the axes' location at that moment.

Format:

```
HERER pos2 pos1
HERERC pos2 pos1
HERERT pos2 pos1
HERER pos2          DIRECT mode only.
HERERC pos2         DIRECT mode only.
```

Where: *pos1* is a recorded position for any group;
pos2 and *pos1* are defined for the same group.

HERER[C/T] pos2 pos1

Description: HERER *pos2 pos1* allows you to record a position relative to another position.

```
HERER pos2 pos1      Records the offset values of pos2, relative to pos1,
                     in joint values.
HERERC pos2 pos1     Records the offset values of pos2, relative to pos1,
                     in Cartesian coordinates.
HERERT pos2 pos1     Records the offset values of pos2, relative to pos1,
                     in Tool coordinates.
```

Pos1 must be recorded before *pos2* can be defined as relative to it.

Pos2 will always be relative to *pos1*, moving along with and maintaining its offset whenever *pos1* is moved.

If *pos1* has an alphanumeric name, it must first be defined using the DEFP or DIMP command.

The DEFP command is not required if *pos2* is a *numerically* named position for group A; it will be automatically defined when entered as part of the HERER command.

Examples:

```

■ >DEFP AA          Defines and records relative position AA.
  >HERER AA         AA will always be relative to the robot's current
    1 - [ . ] > 0   position by user defined values:
    2 - [ . ] > 500   0 counts in base
    3 - [ . ] > 250   500 resolver counts in shoulder
    4 - [ . ] > 0     250 resolver counts in elbow
    5 - [ . ] > 0     0 resolver counts in pitch
                       0 resolver counts in roll
  The values displayed in brackets are the offset
  values last recorded for this position. If no values
  have been recorded, the bracket is empty [ . ] .
```

■ HERE BB
(*move robot*)
HERER AA BB

Records position BB, then records position AA as relative to position BB by the offset values which are automatically entered by this command.

■ DIMPB PLT[5]
HERE PLT[1]
(*move device*)
HERER PLT[2] PLT[1]

Defines vector PLT for group B. Records position PLT[1], then records PLT[2] as relative to position PLT[1] by the offset values which are automatically entered by this command.

HERER *pos2*

Description: HERER *pos2* allows you to record a position relative to the current position.

HERER *pos2*

Records the offset values of *pos2*, relative to the current position, in joint values.

You must enter the offset values, as shown in the example below. *Pos2* will always be relative to the current position.

Example: ■ >DEFPB PST
>HERER PST
7 - [.] > 100
8 - [.] > 0

Defines and records relative position PST for group B. PST will always be relative (by 100 resolver counts on axis 7) to the current position of the device connected to axes 7 and 8.

Format: HOME [*n*]
HHOME *n*

Where: *n* is an axis, $1 \leq n \leq 8$.

Description: The HOME command activates the internal system procedure HOME.

HOME	Drives all robot axes to their home position by searching for a microswitch on each axis. The home search is performed only if Robot Type 3 was entered during configuration.
HOME <i>n</i>	Drives the specified axis to its home position by searching for a microswitch. The HOME <i>n</i> command allows you to create a homing program suitable for all axes in a particular configuration.
HHOME <i>n</i>	Drives the specified axis to its home position by searching for a hard stop. HHOME is used for a device, such as a linear slidebase, which does not have a microswitch. (Note: When hard homing a slidebase, the moving base must be near enough to the mechanical end stop of the LSB for the homing to succeed.)

Activating HOME aborts all running user programs and activates servo control (CON).

During the robot homing, the robot joints move and search for their home positions, one at a time. The following message is displayed:

```
WAIT!! HOMING...
```

If all axes reach their home position, a message is displayed:

```
HOMING COMPLETE (ROBOT)
```

If the homing process is not completed, an error message identifying the failure is displayed:

```
*** HOME FAILURE AXIS 6
```

The system records **Position 0** at the end of homing. This position contains the coordinates of the robot after it has been homed; the coordinate values are not necessarily 0.

If your robotic system has a non-standard configuration and you want to record positions without homing the axes, both PAR 460+*axis* and PAR 600+*axis* must be set to 0.

- Examples:**
- HOME 7
HOME 8 Searches for a microswitch home on axes 7, 8, and 9.

 - HHOME 7 Searches for hard stop home on axis 7.

Notes: Also refer to the *Controller-AC User's Manual* for more information on the robot homing routine.

Format: IF *var1 oper var2*

Where: *var1* is a variable;
var2 is a variable or constant;
oper can be: <, >, =, <=, >=, < >

Description: The IF command checks the relation between *var1* and *var2* .
 If it meets the specified conditions, the result is true, and the next sequential program line is executed (subroutine or command). If it is not true, another subroutine or command is executed.

Examples:

<ul style="list-style-type: none"> ■ IF C[1]=3 MOVE AA[1] ELSE GOSUB TOT ENDIF 	<p>If C[1] = 3, then move to AA[1]. If C[1] ≠ 3 , execute (subroutine) program TOT.</p>
<ul style="list-style-type: none"> ■ IF IN[3]=1 SET OUT[7]=1 ELSE MOVE 10 ENDIF 	<p>If input 3 is on, controller will turn on output 7; if input 3 is off, robot will move to position 10.</p>
<ul style="list-style-type: none"> ■ IF A > 5 GOSUB WKJ ENDIF 	<p>If variable A is greater than 5, (subroutine) program WKJ will be executed.</p>

Note: Refer to the commands ELSE, ANDIF, ORIF, and ENDIF.

Format: INIT CONTROL
 INIT EDITOR

INIT CONTROL

Description: Initializes all system control parameters.
 INIT CONTROL must be executed after any changes are made to the values of system control parameters.

Note: Refer to the LET PAR command.

INIT EDITOR

Description: Initializes controller's user RAM configuration—programs, positions and variables. It does not affect parameters.
 Warning! This command erases all user RAM, except parameters.
 The CONFIG command automatically performs this operation.

Format: `INSERT pvect[n]`

Where: *pvect* is a position vector;
 n is the index of one of the positions in the vector.

Description: Records the current coordinates of the robot or device (same as HERE or HEREC commands) for position *pvect*[*n*] and inserts the coordinates into the vector at index *n*. The inserted position is recorded according the type (JOINT or XYZ) of position whose coordinates currently occupy *pvect*[*n*].

All recorded positions above position *pvect*[*n*] are then moved up one place until an empty (unrecorded) position is encountered. If all positions in the vector above *pvect*[*n*] are recorded, an error message is displayed and the command is cancelled.

This command provides the means for modifying an existing SPLINE or MOVES trajectory, and for inserting a new position within a vector.

INSERT can only be applied to a position for a robot or multi-axis device which is dedicated to group A or group B. The command is not applicable to positions for a single axis device.

- Examples:**
- `INSERT AA[4]` Records position 4 in vector AA; inserts this position in vector AA at position AA[4]; the previous position AA[4] now becomes AA[5].

 - `HERE AA[6]` If coordinates have not yet been recorded for position AA[6], insertion is not required.

Note: Refer to the DELETE, SPLINE, and MOVES commands.

Format: JAPANESE

Description: Causes the controller messages to be displayed in Japanese.
If system messages are displayed on the screen in English, use this command to make the system communicate in Japanese.
The language definition is saved when the controller is switched off.

Note: Refer to the ENGLISH command.

Format: JOINT

Description: Sets the movement mode of the robot arm to joint movement.

When the target position of the current movement is altered by means of the SHIFT or SETPV command, the arm will move toward the target position in a joint movement.

The system remains in Joint movement mode after a MOVE(D), SPLINE(D) or MOVES command is executed.

Note: Refer to the LINEAR, SHIFT, SETP and SETPV commands.

Format: L *line1 line2*

Description: Displays a list of program lines, from the first line specified to the second line specified.

Example: ■ 16: ?L 3 13
***** listing 3 to 13*****
3: GOSUB MVMAX
4: IF MVMAX
5: IF VA >= VB
6: MOVE 0
7: DELAY 1
8: SET TI=LTA - LTB
9: IF TI > 100
10: MOVE 00 TI
11: ELSE
12: MOVE 00
13: ENDIF
**** End of listing ****

Format: LABEL *labeln*

Where: *labeln* is any number, $0 \leq labeln \leq 9999$.

Description: Marks the beginning of a program subroutine which is executed when the GOTO command is given.

Example: ■ LABEL 12
MOVE 1
MOVE 15 200
OPEN
MOVE JJ
GOTO 12

Note: Refer to the GOTO command.

Format: LET PAR *n var*
 LET PAR *n=var*

Where: *n* is a parameter number;
 var is a variable or constant.

Description: Sets the value of system parameter *n* to *var* .

Most parameters can be changed only when the PRIVILEGE mode is active. The following parameters can be accessed during normal operation:

- Gripper parameters: 73, 74, 75, 76, 274 and 275.
- Position Error parameters: 261-272

After you have set new system parameters, you must put them into effect by issuing the command:

```
INIT CONTROL
```

Examples: ■ LET PAR 73=9350 Sets parameter 73 to 9350.
 ■ LET PAR 261 100 Sets parameter 261 to 100.
 INIT CONTROL

Notes: *Warning! Only experienced users should attempt parameter manipulation.*
Refer to Chapter 6 for information on system parameters, and heed all warnings given there.
Refer to the PRIV command.

Format: LINEAR

Description: Sets the movement mode of the robot arm to linear movement.

When the target position of the current movement is altered by means of the SHIFT or SETPV command, the arm will move toward the target position in a linear movement.

The system remains in Linear movement mode after a MOVE(L(D), SPLINEL(D) or MOVEC(D) command is executed.

Note: Refer to the JOINT, SHIFT, SETP and SETPV commands.

Format: LIST [*prog*]

Where: *prog* is a program.

Description: LIST Displays all lines of all programs.

LIST *prog* Displays all lines of program *prog*.

LIST *prog* > PRN: Prints the specified program at a printer connected to a parallel communication port.

When using the LIST command to view program lines, the commands ENDFOR, ENDIF and ELSE are followed by the line number of the corresponding FOR and IF commands.

Example: ■ >LIST AAA Displays all lines in program AAA.

```
PROGRAM AAA
*****
25: LABEL 1
26: MOVED 31
27: MOVED 32
28: IF IN[3]=1
29:     SET OUT[7]=1
30: ELSE (28)
31:     SET OUT[5]=1
32: ENDIF (28)
33: MOVED 33
34: GOTO 1
35: END
(END)
```

Note: Refer to the SEND commands.

Format: LISTP

Description: Displays a list of all defined positions with alphanumeric names, and the group to which they are dedicated.

Positions with numeric names are not listed.

Example: ■ >LISTP

```
DEFINED POINTS
*****
```

```
point name: group:      (axis)
- - - - -
P[10]       : A
PICP[10]    : A
AA          : A
B1          : B
B2          : B
BBA[50]     : B
C3[100]     : C          : 8
```

and 13 additional numerical points defined.

Format: LISTPV *pos*
LISTPV POSITION

Description: LISTPV *pos* Displays in joint values the coordinates of the specified position.
If *pos* is a robot (group A) position, joint and Cartesian coordinates are both displayed.

LISTPV POSITION Displays the current coordinates of the robot arm.
POSITION is a reserved name for the current position of the robot (group A) axes.

Displays the type and coordinates of a recorded position, or POSITION:

- Position name, and type of position (one of the following):
 - Joint position
 - World A position (Cartesian coordinates in area A)
 - World B position (Cartesian coordinates in area B)
 - Relative by Joint to CURRENT position.
 - Relative by XYZ to CURRENT position.
 - Relative by Tool to CURRENT position.
 - Relative by Joint to position *PNAME*.
 - Relative by XYZ to position *PNAME*.
 - Relative by Tool to position *PNAME*.
- Joint values of the position: resolver counts for each axis.
- Cartesian coordinates of a robot (group A) position only; the distance from the robot's point of origin—the center and bottom of the robot's base—to the TCP (tool center point). X, Y, and Z are displayed in millimeters, accurate to a micron (thousandth of a millimeter). Pitch and roll (P and R) values are displayed in degrees with an accuracy of 0.002°.

Example: ■ >LISTPV POS1
Position POS1 (Joint)
1: 0 2: 5 3: 13926 4: 0 5: 0
X: 5.425 Y: 0.000 Z: 29.963 P: 12.640 R: -3.200

Format: LISTVAR

Description: Displays a list of all user and system variables.

Variable arrays include an index in square brackets, which indicates the dimension of the array; for example, IN[16].

Private variables include (in parentheses) the name of the program to which they are dedicated; for example, I(INOUT).

Example: ■ >LISTVAR

```
          SYSTEM VARIABLES
          *****
IN[ 16 ]
ENC[ 5 ]
LSCW[ 5 ]
LSCCW[ 5 ]
CPOS[ 12 ]
POSER[ 5 ]
JTARG[ 5 ]
XTARG[ 5 ]
TQ[ 5 ]
INDEX[ 5 ]
LTIME[ 5 ]
TIME
MFLAG
HOMED
CONST
ERROR
ERRPR
ERRLI
OUT[ 16 ]
JOG[ 5 ]
TQMAX[ 5 ]
TQMIN[ 5 ]

          USER VARIABLES
          *****
I ( DEMO )
J ( DEMO )
I ( IO )
I ( INOUT )
G1
G2
```

Note: Refer to Chapter 4 for a description of system variables.

Format: MODULO
 MODULO ROLL

Description: Returns the value of the roll axis to a value within the range of $\pm 360^\circ$, without moving the roll axis.

MODULO ROLL enables unlimited rotations of the roll axis, by preventing the (software/resolver) axis limits from being reached. It is therefore a useful when an application requires an end effector, such as a screwdriver, to move continuously in one direction.

MODULO ROLL is not executed until the movement buffer of the roll axis is empty, so as not to affect previously issued MOVE commands. Thus, a program which issues a MODULO ROLL command will be suspended until the roll axis movement buffer is empty.

Warning! Use this command with caution when cables or hoses are connected to the end effector (such as a gripper). Be sure the cables or hoses will not become improperly stretched or entangled following a MODULO ROLL command.

Example:	HERE POS1	Assuming roll value for <i>pos1</i> is 0° :
	LABEL 1	
	SHIFTC POS1 BY R 190	
	MOVE POS1	Roll rotates $+190^\circ$;
	SHIFTC POS1 BY R 190	
	MOVE POS1	Roll again rotates $+190^\circ$, reaching 380° ;
	MODULO	MODULO ROLL returns 380° to 20° ;
	SHIFTC POS1 BY R 190	Roll again rotates $+190^\circ$, reaching $+210^\circ$.
	MOVE POS1	
	GOTO 1	

Note that execution of MOVE is not synchronized with program flow. MOVED is usually more suitable for most applications.

Format: MOVE *pos* [*duration*]
MOVED *pos* [*duration*] EDIT mode only.
Where: *pos* is a position;
duration is a variable or a constant.

MOVE

Description: MOVE *pos* Moves the robot to the specified position, according to the speed defined by a preceding SPEED command.
MOVE *pos duration* Moves the robot to the position within the specified amount of time. *Duration* is defined in hundredths of a second.

The MOVE command deposits a movement command into the **movement buffer**. The program issuing the MOVE command does not wait for the operation to be completed, and continues regardless of when the MOVE command is executed.

If the program contains several consecutive MOVE commands, they are sent until the movement buffer is full, regardless of the actual execution. As a result, program commands other than MOVE may not be executed according to the intended sequence.

MOVE is executed according to speed (SPEED) or time (*duration*), regardless of how accurately the axes reach the target position.

Duration does not include the acceleration time necessary for the movement. Therefore, the actual movement will always be longer than the *duration* specified in the command.

MOVED

Description: The MOVED command ensures that operations defined in the program are executed sequentially.

A MOVED command is deposited into the movement buffer only when the previous MOVED command has been completely executed.

A MOVED command is terminated only when the axes have arrived at their target position within the specified accuracy, no matter how long it takes, and even when *duration* has been defined.

To ensure that the MOVED is executed within a defined period of duration, issue the EXACT OFF command. For example:

EXACT OFFA	
MOVED POS1 500	Axes reach POS1 and POS2 in 5 seconds.
MOVED POS2 500	
EXACT A	Axes reach POS3 with required accuracy,
MOVED POS3	regardless of duration.

MOVE, MOVED Summary

Whenever the program encounters a movement command *with* the D suffix (MOVED, MOVECD, MOVELD, MOVESD, SPLINED, SPLINELD), the program is suspended until the arm reaches and stops at the target position.

When the program contains movement commands *without* the D suffix (MOVE, MOVEC, MOVEL, MOVES, SPLINE, SPLINEL), movements are chained together in smooth sequences, as in spline commands.

MOVE	Easy to program, but cannot guarantee sequentiality or accuracy.
EXACT MOVED	Guarantees sequentiality and accuracy, but not duration.
EXACT OFF MOVED	Guarantees sequentiality and duration, but not accuracy.

Examples:

- ```
MOVE 3
MOVE AA
PRINT "COMMAND GIVEN"
```

The robot moves to position 3 and then to position AA. The line "COMMAND GIVEN" will probably be displayed before actual movement is completed.
  
- ```
MOVE 3
MOVE AA
MOVE POS[1]
SET OUT[1] = 1
DELAY 1000
```

The three movement commands are deposited almost simultaneously in the movement buffer. The robot moves to position 3, then to AA and then to POS[1]. Concurrent with the movement to position 3, output 1 is turned on, and the program is delayed for 10 seconds. This program ends about 10 seconds after its activation, regardless of the axes' location.

- ```
MOVE 3 500
DELAY 500
MOVE AA 800
DELAY 800
MOVE POS[1] 200
DELAY 200
SET OUT[1]=1
DELAY 1000
```

The robot moves to position 3 in 5 seconds, then to AA in 8 seconds, then to POS[1] in 2 seconds. Then output 1 is turned on, and a delay of 10 seconds occurs. Total time for program execution is 25 seconds, plus a negligible fraction of time for command executions.
  
- ```
MOVED 3
SET OUT[1]=1
DELAY 1000
MOVED AA
MOVED POS[1]
```

All the commands are executed in sequence. All positions are accurately reached. The axes will pause at some of the positions.

- ```
EXACT OFFA
MOVED 3
MOVED AA
EXACT A
MOVED POS[1]
CLOSE
SET OUT[1]=1
```

This program format is recommended, assuming that positions 3 and AA are along a path, and position POS[1] is where an object is picked up. Position 3 and AA are reached in specified time, regardless of accuracy. Position POS[1] is accurately reached, but with a possible delay. All commands in this program are activated in sequence.

**Note:** Refer to the EXACT command.

**Format:** MOVEC *pos1 pos2*

MOVECD *pos1 pos2*

EDIT mode only.

**Description:** Moves the robot's TCP (tool center point) along a **circular** path, from its current position to *pos1*, through *pos2*.

The coordinates of *pos2* and *pos1* determine the length of the path.

A preceding SPEEDL command defines the speed of the TCP. The duration of the movement is thus determined by the path length and the SPEEDL definition.

The starting position, *pos1*, and *pos2* should define a circle. These three points should not be aligned, and should have different coordinates.

MOVEC/MOVECD is executed in the Cartesian coordinate system, and is only valid for robot (group A) axes.

All other aspects of the MOVEC/MOVECD commands are similar to those of the MOVE/MOVED commands.

*Warning! Be careful when recording positions for MOVEC commands. Mechanical limitations or obstacles, such as the robot itself, may make the resulting path invalid.*

**Examples:** ■ MOVEC 1 2

Moves along a circular path from current position to position 1 via position 2.

■ SPEEDL 20  
MOVEC 2 1

Moves along a circular path from current position to position 2 via position 1, at a speed of 20mm per second.

**Note:** Refer to the SPEEDL command.

**Format:**            MOVEL *pos1* [*duration*]  
                      MOVELD *pos1* [*duration*]                            EDIT mode only.

**Description:**    Moves the robot's TCP (tool center point) along a **linear** path (straight line) from its current position to *pos1*.

If *duration* is not specified, the speed of the TCP is defined by a preceding SPEEDL command.

*Duration does not include the acceleration time necessary for the movement. Therefore, the actual movement may be slightly longer than the duration specified in the command.*

MOVEL/MOVELD is executed in the Cartesian coordinate system, and is only valid for robot (group A) axes.

All other aspects of the MOVEL/MOVELD commands are similar to those of the MOVE/ MOVED command.

*Warning! Be careful when recording positions for MOVEL commands. Mechanical limitations or obstacles, such as the robot itself, may make the resulting path invalid.*

**Example:**        ■ MOVELD TR                            Moves along a straight line to position TR.

**Note:**            Refer to the SPEEDL command.



**Format:**           MOVES *pvect n1 n2 [duration]*  
                   MOVESD *pvect n1 n2 [duration]*           EDIT mode only

Where:   *pvect* is the name of position vector;  
           *n1* is the index of the first position;  
           *n2* is the index of the last position to be reached.

**Description:**   Moves the axes through any number of consecutive vector positions, from *n1* to *n2*, without pausing. The trajectory is calculated by a linear interpolation algorithm, then smoothed according to parameter 219. (PAR 219 value is set on scale 1–200; 1=no smoothing; 200=smoothest.)

All positions in the vector must be absolute joint positions.

The duration of movement between any two consecutive positions is constant. The greater the distance between two consecutive vector positions, the faster the robot moves through that segment of the path. It is therefore recommended that vector positions be evenly spaced to allow a smooth movement.

If *duration* is not specified, the average speed of movement is determined by a preceding SPEED command.

*Duration* does not include the *acceleration time* necessary for the movement. Therefore, the actual movement may be slightly longer than the *duration* specified in the command.

MOVES/MOVESD can be executed only by a robot or multi-axis device, using group A or group B positions. The command is not applicable for a single axis device.

All other aspects of the MOVES/MOVESD commands are similar to those of the MOVE/MOVED commands.

**Example:**       ■   MOVED PATH[1]                   Moves to starting position PATH[1].  
                   MOVESD PATH 2 20           Moves in a continuous path through positions  
                   MOVESD PATH 19 1           PATH[2] to PATH[20].  
                                                   Then moves along the same path in the opposite  
                                                   direction.

**Note:**           Refer to the SPLINE and SPLINED commands.

**Format:** NOBREAK *n*

NOBREAK

Where: *n* is a program line number

**Description:** NOBREAK *n* Cancels the <Break> point at the specified line.

NOBREAK Cancels all <Break> points.

**Note:** Refer to BREAK, STEP, NOSTEP and RUN commands.

**Format:** NOECHO

**Description:** When in NOECHO mode, characters transmitted to the controller are not displayed on the screen.

The ECHO command cancels the NOECHO mode.

By default, the controller is in ECHO mode.

**Note:** Refer to the ECHO command.

**Format:** NOQUIET

**Description:** During program execution, all DIRECT commands within the program (that is, DIRECT commands preceded by @) are displayed as they are executed.

This is the default mode.

**Note:** Refer to the QUIET command.

**Format:** NOSTEP *prog*

Where: *prog* is a program

**Description:** Cancels the <Break> point at the first line of the specified program.

**Note:** Refer to the STEP, BREAK, NOBREAK and RUN commands.

**Format:** OPEN

**Description:** The OPEN command opens the gripper.  
The OPEN command activates the digital output which controls the gripper.  
Parameter 274 defines the number of the output which controls the gripper.

**Notes:** Refer to the CLOSE command.  
Also refer to the gripper parameters in Chapter 6.

**Format:** ORIF *var1 oper var2*

Where: *var1* and *var2* are variables or constants;  
*oper* can be: <, >, =, <=, >=, < >.

**Description:** An IF type command, ORIF logically combines a condition with other IF commands.

**Example:** ■ IF A=B                      If either A = B  
                  ORIF A=D                or A = D,  
                  CLOSE                    close the gripper;  
                  ELSE                     otherwise,  
                  OPEN                     open the gripper.  
                  ENDIF

**Note:** Refer to the IF command.

**P**

**EDIT**

**Format:** P

**Description:** Takes the editor to the preceding line in the program currently being edited.



**Format:** PANEL

**Description:** Restores (manual) control of the switches and lamps on the robot controller's front panel.

**Note:** Refer to the REMOTE command.

**Format:** PASSWORD

**Description:** A password is required in order to activate the PRIVILEGE mode.  
This command allows you to change the password which protects the PRIVILEGE mode.

```
>PASSWORD
ENTER PRESENT PASSWORD:
ENTER NEW PASSWORD:
ENTER AGAIN:
```

You are prompted to do the following, in sequence:

- Enter the currently defined password.
- Enter the new password; it may contain up to 8 characters.
- Again enter the new password.

The controller is factory-set to accept <Enter> as the password.

Following a controller configuration, the currently defined password is erased and reset to the factory-set default.

**Note:** Refer to the PRIV command.

**Format:**           PEND *var1* FROM *var2*  
                   POST *var3* TO *var2*

Where:    *var1* is a variable;  
             *var2* is a global variable;  
             *var3* is a variable or a constant.

**Description:**    The PEND and POST commands are used for synchronizing the simultaneous execution of programs.

When a program encounters a PEND *var1* FROM *var2* command, one of the following occurs:

- If *var2* has a value of zero, program execution is suspended until another running program “sends” a non-zero value by means of the POST *var3* TO *var2* command.
- If *var2* has a non-zero value, that value is assigned to *var1* and the value of *var2* is set to zero.

**Example:**

```

PROGRAM DOACT

GLOBAL SIGN
DEFINE VALUE
SET SIGN=0
PEND VALUE FROM SIGN
RUN ACT
END

PROGRAM SEND

POST 1 TO SIGN
END

```

The execution of program DOACT will be suspended until program SEND is activated and sets the value of SIGN to 1.

**Format:** PRCOM *n arg1 [arg2 arg3]*

Where: *n* is an RS232 communication port,  $0 \leq n \leq 8$ ;  
*arg* is a variable or a string within quotation marks (" ").

**Description:** Sends strings and variable values to the specified RS232 port.

The text following PRCOM *n* may contain up to 30 characters and spaces, not including the quotation marks. The text may contain a total of 3 arguments and/or variables.

A variable is one argument, regardless of length.

A string of up to ten characters is one argument. Strings which exceed 10 and 20 characters are treated, respectively, as two and three arguments.

**Examples:** ■ PRCOM 6 "TESTING"      The text TESTING will be transmitted to RS232 port COM6.

■ SET X=7  
PRCOM 5 "PRICE IS " X " DOLLARS"  
The text PRICE IS 7 DOLLARS will be transmitted to RS232 port COM5.

**Note:** Refer to the PRLNCOM command.

**Format:** PRINT *arg1* [*arg2* ... *arg4*]

Where: *arg* is a variable or a string within quotation marks (" ").

**Description:** Displays strings and variable values on screen.

The text following PRINT may contain up to 40 characters and spaces, not including the quotation marks. The text may contain a total of 4 arguments and/or variables.

A variable is one argument, regardless of length.

A string of up to ten characters is one argument. Strings which exceed 10, 20 and 30 characters are treated, respectively, as two, three and four arguments.

**Example:** ■ SET NA=5  
PRINT "THE ROBOT HAS " NA " AXES"

Will display on screen:

THE ROBOT HAS 5 AXES

The text THE ROBOT HAS is arguments 1 and 2 (contains 13 characters);  
the variable NA is argument 3;  
the text AXES is argument 4.

**Note:** Refer to the PRINTLN command.

**Format:** PRINTLN *arg* [*arg2* ... *arg4*]

Where: *arg* is a variable or a string within quotation marks (" ").

**Description:** Displays strings and variable values on screen.

Same as PRINT command, but inserts a carriage return (to beginning of line) and a line feed (to next line) before the displayed text.

The text following PRINTLN may contain up to 40 characters and spaces, not including the quotation marks. The text may contain a total of 4 arguments and/or variables.

A variable is one argument, regardless of length.

A string of up to ten characters is one argument. Strings which exceed 10, 20 and 30 characters are treated, respectively, as two, three and four arguments.

Entering PRINTLN without an argument simply enters a carriage return and a line feed.

**Example:** ■ SET X=7  
SET Y=15  
SET J=8  
SET K=20  
PRINTLN "TANK # " X " LEVEL IS: "Y  
PRINT " INCHES"  
PRINTLN "TANK # " J " LEVEL IS: "K  
PRINT " INCHES"

Will display:

```
TANK #7 LEVEL IS: 15 INCHES
TANK #8 LEVEL IS: 20 INCHES
```

**Note:** Refer to the PRINT command.

**Format:** PRIORITY *prog var*

Where: *prog* is a user program;  
*var* is a variable or a constant.

**Description:** Sets the priority of program *prog* to the value of *var* .

Priority ranges from 1 to 10, with 10 as the highest priority.  
If the value of *var* is greater than 10, priority is set to 10.  
If the value of *var* is less than 1, priority is set to 1.

By default (when controller is powered on), all programs are assigned a priority of 5.

If several programs are activated, those with a higher priority are executed first. Programs with equal priority run concurrently; these programs share CPU time by means of an equal distribution algorithm.

**Example:** ■ PRIORITY PALET 7 Assigns program PALET a priority of 7.

**Note:** Refer to the RUN and DIR commands.

**Format:** PRIV {ON/OFF}  
PRIVILEGE {ON/OFF}

**Description:** The PRIVILEGE mode prevents access to most of the controller's parameters and several **ACL** commands. This feature prevents accidental or improper manipulation of servo and other critical parameters.

The following commands are *protected*:

```
SET JOG
CLR
LET PAR
```

The following parameters are *not protected*:

```
PAR 73,74,75,76, Gripper parameters
 274, 275
PAR 260+axis Position error parameters
```

To activate the PRIVILEGE mode, use the command:

```
PRIV ON
```

You are then prompted to enter the password.

Once the PRIVILEGE mode is active, you may manipulate the protected parameters and commands.

To cancel the PRIVILEGE mode, use the command:

```
PRIV OFF
```

**Notes:** Refer to the PASSWORD command, and to the section, "Privilege Mode," in Chapter 2.

*Warning! Only experienced users should attempt parameter manipulation. Refer to Chapter 6 for information on system parameters, and heed all warnings given there.*



**Format:** PRLNCOM *n arg1 [arg2 arg3]*

Where: *n* is an RS232 communication port,  $0 \leq n \leq 8$ , and  
*arg* is a variable or a string within quotation marks (" ").

**Description:** Companion to READCOM command.

Sends strings and variable values to the specified RS232 port.

Same as the PRCOM command, but adds a carriage return *after* sending the text to the RS232 port.

The text following PRLNCOM *n* may contain up to 30 characters and spaces, not including the quotation marks. The text may contain a total of 3 arguments and/or variables.

A variable is one argument, regardless of length.

A string of up to ten characters is one argument. Strings which exceed 10 and 20 characters are treated, respectively, as two and three arguments.

**Example:** ■ PRLNCOM 7 "THE VALUE IS " VAL[I]

The text THE VALUE IS and the value of variable VAL[I] will be transmitted to RS232 port COM 7, followed by a carriage return .

If, for example, the value of VAL[I] is 26, the string 26 (not ASCII character 26) will be sent.

**Note:** Refer to the PRCOM and READCOM commands.

**Format:** SET *var*=PSTATUS *pos*

Where: *var* is a variable;  
*pos* is a position.

**Description:** Assigns *var* a value according to the type of the specified position, based on the following definitions:

Value = Type of Position

---

0 = Position defined, but coordinates not recorded

1 = Absolute Joint

2 = Absolute XYZ – World A

3 = Absolute XYZ – World B

4 = Relative by Joint to Another Position

5 = Relative by XYZ to Another Position

6 = Relative by Tool to Another Position

14 = Relative by Joint to Current Position

15 = Relative by XYZ to Current Position

16 = Relative by Tool to Current Position

If the position has invalid coordinates, the value is increased by 100 (e.g., 103, 116).

*Pos* cannot be defined as POSITION, which is reserved for the current coordinates of the robot.

**Example:** ■ SET PV=PSTATUS A

If A is a position whose coordinates have been recorded as relative to the current position by joint values, then PV will be assigned a value of 14.

## DIRECT

## PURGE

**Format:** PURGE

**Description:** Deletes from user RAM all global and private variables which are not used by any program.

**Format:**            `SET var=PVAL pos axis`

`SET var=PVALC pos coord`

Where:    *pos* is a robot (group A) position;  
          *axis* is an axis number;  
          *var* is a variable;  
          *coord* can be: X, Y, Z, P, R .

**Description:**    `SET var=PVAL pos axis` Assigns *var* one of the joint values of the specified axis in the specified position.

`SET var=PVALC pos coord` Assigns *var* one of the Cartesian coordinates of the specified axis in the specified position.

The value of the Cartesian coordinate which is assigned to the variable is defined in microns. Pitch and roll values are defined in millidegrees.

**Examples:**    ■ `SET JV=PVAL BUF1 1`    JV receives the joint coordinate value of axis 1 at position BUF1.

                  ■ `SET C=PVALC POSITION Y`    C receives the value of the robot's current Y-coordinate.

**Format:** QPEND *var1* from *var2*

QPOST *var3* to *var2*

Where: *var1* is a variable;  
*var2* is a global variable array;  
*var3* is a variable or constant.

**Description:** QPEND Takes values from a queue in the same order they were entered by the QPOST command.

QPOST Queues the values to be processed.

If the queue is exhausted, QPEND suspends program execution until a QPOST command enters a value.

The maximum size of the queue is equal to the dimension of the *var2* array minus 1. If the queue is full, QPOST suspends program execution until a QPEND command takes a value from the queue.

*A queue must be initialized before use by setting all its elements to zero.*

**Example:** ■ PROGRAM INITQ Defines and initializes the queue.

```
DIMG QUEUE[10]
DEFINE I
FOR I=1 TO 10
 SET QUEUE[I]=0
ENDFOR
END
```

PROGRAM DOACT Takes a value from a queue.  
 Program ACT will run when values are deposited in QUEUE by the program SEND. If no value has been sent, DOACT will be suspended until the arrival of a value.

```
DEFINE VALUE
LABEL 1
QPEND VALUE FROM QUEUE
RUN ACT
GOTO 1
END
```

PROGRAM SEND Puts a value in a queue.  
 QPOST 1 TO QUEUE  
 END

# QUIET

# DIRECT

**Format:** QUIET

**Description:** Cancels the NOQUIET mode.

When in QUIET mode, DIRECT commands within the program (those preceded by @) will **not** be displayed during the program's execution.

By default, the controller is in NOQUIET mode.

**Note:** Refer to the NOQUIET command.

**Format:**        `READ arg1 [arg2 ... arg4]`

Where:    `arg` is a variable or a string within quotation marks (" ").

**Description:**    When READ encounters an argument which is a **string**, the text will be displayed like a PRINT statement.

When READ encounters an argument which is a **variable**, a "?" will be displayed on screen, indicating that the system is waiting for a value to be entered.

The READ procedure is performed sequentially for all the arguments.

Your reply to "?" must be a numeric value. Pressing <Enter> without specifying a value will enter a value of 0.

Any other reply to "?" is interpreted as a command. If you enter a command, it will be executed, and the READ command will again prompt you to enter a value by displaying the message:

```
ENTER value >>
```

**Example:**    ■ `READ "enter value of x" X`

Will display on screen:

```
enter value of x ?
```

If you enter 254, the value 254 will be assigned to variable X.

**Note:**        Refer to the PRINT command.

**Format:** READCOM *n var*

Where: *n* is an RS232 communication port,  $0 \leq n \leq 8$ ;  
*var* is a variable.

**Description:** Companion to PRLNCOM command.

When a READCOM command from the specified port is encountered, it waits on line for a string which contains ASCII numbers followed by a carriage return. That numeric value is then assigned to the specified variable.

**Example:** ■ READCOM 1, RPART  
IF RPART > 9999  
PRINTLN "CAN'T MANUFACTURE MORE THAN 9999 PIECES"

**Note:** Refer to the PRLNCOM command.



**Format:** RECEIVE [*prog*]

**Description:** Loads data from a backup file in the host computer to the controller's user RAM, via the main RS232 channel (the controller's CONSOLE port.)

The file to be received must be in the format generated by a SEND command.

RECEIVE

*Warning! This command erases the contents of the controller's user RAM.*

Accepts the contents of a backup file which was generated by a SEND command.

After you enter the RECEIVE command, a warning will appear, and you will be prompted to confirm the operation. If your response is YES (complete word), the controller replies with the following message:

PLEASE SEND FILES

(Refer to your terminal documentation for exact instructions on sending and receiving files.)

RECEIVE *prog*

Accepts the contents of a backup file generated by the SEND commands.

Accepts only one program and inserts its contents into the *prog* specified. It does not affect the other programs and positions stored in the user RAM.

The host computer sends the file line by line to the controller. After each line the host computer waits for a colon ":" to be transmitted by the controller. This indicates that the next line can be sent.

The last line of the file to be transmitted must be the message:

( END )

To which the controller responds:

END OF LOADING

**Notes:**

The **ATS** Backup Manager performs the SEND, RECEIVE and APPEND procedures. Use that menu to backup and restore user RAM.

Refer to the chapter on the Backup Manager in the *ATS Reference Guide*.

Also refer to the SEND command.

**Format:** REMOTE

**Description:** By configuring parameters and issuing the command REMOTE, some panel functions (switches, lamps, LEDs) can be operated in Remote mode.

In Remote Mode, control of some of the controller's front panel functions are transferred to external switches and lamps by means of the system's digital inputs and outputs.

REMOTE will affect only the switches and lamps which have been configured for remote operation by parameter definition.

REMOTE will have not have any effect if the controller parameter for the specified switch or light is set to 0.

The command PANEL cancels the REMOTE command.

| <u>Controller Function</u> | <u>I/O Connection</u> | <u>Parameter</u> |
|----------------------------|-----------------------|------------------|
| Error Reset Switch         | Input                 | PAR 114          |
| STOP Push Button           | Input                 | PAR 113          |
| START Push Button          | Input                 | PAR 16           |
| Servo ON Switch            | Input                 | PAR 14           |
| Program Running Lamp       | Output                | PAR 117          |
| Error Indicator Lamp       | Output                | PAR 115          |
| Servo LED                  | Output                | PAR 119          |
| Hold LED                   | Output                | PAR 118          |
| Remote LED                 | Output                | PAR 116          |

**Examples:** ■ LET PAR 113=5      Transfers STOP control to an external switch which  
INIT CONTROL      is connected to controller input 5.  
REMOTE

**Notes** Refer to the PANEL and LET PAR commands.

Refer to the *Controller-AC User's Manual* for more information on controller functions.

# REMOVE

# DIRECT

**Format:** REMOVE *prog*

**Description:** Deletes a user program from the user RAM and frees all memory allocated to that program.

The system will prompt for verification:

Are you sure? (yes/no)

To confirm, respond by typing YES (complete word).

Any response other than YES (including Y) will be interpreted as NO.

If program *prog* is called or used by other programs, the REMOVE is not allowed, and a list of all program lines referring to *prog* is displayed.

Private variables assigned to this program are also deleted.

Use the EMPTY command if you want to delete all program lines without deleting the program itself.

**Example:** ■ REMOVE PALET                      Deletes program PALET.

**Note:** Refer to the EMPTY command.

**Format:**            `RENAME prog1 prog2`

**Description:**    Changes the name of user program from *prog1* to *prog2*  
If the name *prog2* is already in use, the command is not executed, and an error message is displayed.

Once a program name has been changed, the original *prog1* no longer exists.

**Example:**        ■ `RENAME PAL NEW`            Program PAL is now called NEW. Program PAL is no longer listed in the directory.

**Format:**            `RUN prog [var]`

Where:    *prog* is a program;  
          *var* is a variable or constant.

**Description:**    Starts execution of a task from the first line of program *prog* .

*Var* is the priority of the program, and ranges 1 to 10; 10 is the highest priority. If the value of *var* is greater than 10, priority is set to 10.

If the value of *var* is less than 1, priority is set to 1. By default (when controller is powered on), all programs are assigned a priority of 5.

When a running program encounters a `RUN prog` command, both programs are executed concurrently. If several programs are activated, those with a higher priority are executed first. Programs with equal priority run concurrently; these programs share CPU time by means of an equal distribution algorithm.

In EDIT mode, if priority is not specified in the `RUN` command, the program's priority is automatically set to a default value of 5.

In DIRECT mode, if priority is not specified in the `RUN` command, the program's priority is set to the value last defined by a preceding `PRIORITY` or `RUN` command.

- Examples:**
- `>PRIORITY 10`                      Programs DEMO and PLT run at the highest priority.  
`>RUN DEMO`  
`>RUN PLT`
  - `RUN DEMO`                              Program DEMO runs at default priority 5.
  - `RUN IOS 9`                              Program IOS runs with a priority value of 9.

**Note:**                Refer to the `PRIORITY` command.

**Format:** S [*line\_n*]

Where: *line\_n* is a program line number

**Description:** S Takes the editor to the first line of the program currently being edited.

S *line\_n* Takes the editor to the specified line of the program currently being edited.

# SEND

# DIRECT

**Format:** SEND SEND *prog*  
SENDPROG SENDVAR  
SENDPOINT SENDPAR

**Description:** SEND commands produce listings in a format compatible with the RECEIVE and APPEND commands. The listings produced by the SEND commands are displayed on the computer screen.

|                  |                                                                                                                                            |
|------------------|--------------------------------------------------------------------------------------------------------------------------------------------|
| SEND             | Generates a listing of all user programs, variables and positions, and parameters. SEND serves to create a complete backup of user RAM.    |
| SEND <i>prog</i> | Generates a listing of the specified user program in a format compatible with the RECEIVE <i>prog</i> command.                             |
| SENDPROG         | Generates a listing of all user programs, variables, and positions. SENDPROG serves to create a backup of user RAM, except for parameters. |
| SENDVAR          | Generates a listing of all user defined variables.                                                                                         |
| SENDPOINT        | Generates a listing of all user defined positions.                                                                                         |
| SENDPAR          | Generates a listing of all system parameters.                                                                                              |

If a printer is connected to the controller's parallel port, a hard copy of the data can be produced. Use the following commands:

|                  |                                                                      |
|------------------|----------------------------------------------------------------------|
| SEND > PRN:      | Prints all user data (programs, positions, parameters and variables) |
| SENDPAR > PRN:   | Prints a list of all parameters.                                     |
| SENDPOINT > PRN: | Prints a list of all positions.                                      |
| SENDPROG > PRN:  | Prints all programs (includes positions and variables).              |
| SENDVAR > PRN:   | Prints a list of variables.                                          |

**Notes:** The **ATS** Backup Manager performs the SEND, RECEIVE and APPEND procedures. Use that menu to backup and restore user RAM.

Refer to the chapter on the Backup Manager in the *ATS Reference Guide*.

Also refer to the RECEIVE and APPEND commands.



**Format:** SENDCOM *n var*

Where: *n* is an RS232 communication port,  $0 \leq n \leq 8$ ;  
*var* is a variable or constant.

**Description:** Companion to the GETCOM command.

Sends one byte through the specified RS232 port.

The value of the byte is specified by a variable or a constant.

**Example:**

```
■ PROGRAM ESC

DEFINE I
CLRCOM 2
FOR I=1 TO 5
SENDCOM 2, 27
DELAY 20
ENDFOR
END
```

This program clears the buffers of RS232 port 2. It then sends 27, the ASCII code for <Esc>, five times to port 2.

**Note:** Refer to the GETCOM command.

**Format:**

```
SET var1=var2
SET var1=oper var2
SET var1=var2 oper var3
SET var1=COMPLEMENT var2
SET var=PVAL pos axis
SET var=PVALC pos coord
SET var=PSTATUS pos
SET var=PAR n
```

**Where:** *var* and *var1* is a variable;  
*var2* and *var3* can be either a variable or a constant.

*oper* can be:

Arithmetic operator: + - \* /

Algebraic operator: ABS, EXP, LOG, MOD

Trigonometrical operator: COS, SIN, TAN, ATAN

Logical (Boolean) operator: AND, OR, NOT

*pos* is a position;

*axis* is an axis number;

*coord* is a Cartesian coordinate: X, Y, Z, or P or R;

*n* is a parameter number.

**Description:**

- |    |                                    |                                                                                                                                               |
|----|------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
| 1. | SET <i>var1</i> = <i>var2</i>      | Assigns the value of <i>var2</i> to <i>var1</i> .                                                                                             |
| 2. | SET <i>var1</i> = <i>oper var2</i> | The operation is performed on <i>var2</i> and the result is assigned to <i>var1</i> .                                                         |
|    | If <i>oper</i> is ABS              | Assigns the absolute value of <i>var2</i> to <i>var1</i>                                                                                      |
|    | If <i>oper</i> is NOT              | Assigns the logical negative value of <i>var2</i> to <i>var1</i> .<br>If <i>var2</i> ≤ 0, <i>var1</i> = 1; If <i>var2</i> >0, <i>var1</i> =0. |

3. SET *var1=var2 oper var3*
  - If *oper* is : +, -, \*, /, MOD      The operation is performed on *var2* and *var3* and the bitwise result is assigned to *var1* .
  - If *oper* is: AND, OR                      The binary operation is performed on *var2* and *var3* and the result is assigned to *var1*.
  - If *oper* is: COS, SIN, TAN              *The controller uses integer arithmetic; fractional values are therefore scaled in order to produce accurate results.*  
  
Since the result of these trigonometric functions is always in the range of -1 to 1, the function of *var3* is computed and then multiplied by *var2*. (*Var2* must be large enough to give the expected accuracy.) The value of *var3* is an expression of degrees.
  - If *oper* is: ATAN, EXP, LOG              In order to use a practical value for *var3*, *var3* is first divided by 1000; then the function is applied. The result is then multiplied by *var2*.  
  
(The result of the ATAN function is an expression of degrees.)
4. SET *var1=COMPLEMENT var2*
  - Each individual bit of the binary representation of *var2* is inverted, and the result is assigned to *var1* .
5. SET *var=PVAL pos axis*      Assigns *var* the joint value of the specified axis in the specified position. (Refer to the PVAL command.)
6. SET *var=PVALC pos coord*
  - Assigns *var* one of the Cartesian coordinates of the specified robot (group A) position. (Refer to the PVALC command.)
7. SET *var=PSTATUS pos*      Assigns *var* a value according to the type of the specified position. (Refer to the PSTATUS command.)
8. SET *var=PAR n*                      Assigns *var* the value of the specified parameter.

- Examples:**
- `SET A=B` Assigns value of B to A.
  - `SET A=NOT B` If B is 0 then A is set to 1.
  - `SET A=COMPLEMENT B` If B is 0 then A is set to -1.
  - `SET A=ABS B` If B is -1 then A is set to 1.
  - `SET A=B AND C` If B=1 and C=0, then A is set to 0.
  - `SET A=1000 COS 60` COS 60 = .5; Multiply by 1000; A is set to 500.
  - `SET ST=PSTATUS P1` If P1 is an absolute Joint position, then ST will be assigned a value of 1.
  - `SET XC=PVALC POS1 X` XC receives the value of the robot's X-coordinate position POS1.
  - `SET A=PAR 76` The value of parameter 76 is assigned to variable A.
  - `SET OUT[ 5 ]=1` Turns on output 5. (OUT[n] is a system variable.)
  - `SET CLOCK=TIME` Assigns value of system variable TIME to user variable CLOCK.

**Format:**            `SETP pos2=pos1`

Where:    *pos1* is a recorded position;  
           *pos1* and *pos2* are defined for the same group.

**Description:**    Copies the coordinate values and position type of *pos1* to *pos2*.  
                          Both positions are now identical.

If *pos2* has an alphanumeric name, it must first be defined using the DEFP or DIMP command. The DEFP command is not required if the *pos2* is a *numerically* named position for group A; it will automatically be defined when entered as part of the command.

This command is useful for preparing *pos2* so that the SETPV command can be used to change one value of that position.

- Examples:**
- `SETP POINT=PLACE`            Position POINT is assigned the coordinate values and type of position PLACE.
  - `SETP 100=POSITION`            Position 100 is assigned the coordinate values of the current robot position.
  - `DEFINE I`  
`FOR I=1-100`  
`SETP A[I]=A[I]`  
`ENDFOR`                            Copies positions 1 through 100 from vector A to a new vector named A.  
                                          These new positions can be manipulated by DELETE and INSERT commands.

**Format:** SETPV *pos* DIRECT mode only.

SETPV *pos axis var*

Where: *pos* is a robot (group A) position;  
*axis* is an axis number;  
*var* is a variable or constant.

---

## SETPV *pos*

**Description:** Records an absolute joint position, according to user defined values.

If the position has an alphanumeric name, it must first be defined using the DEFP or DIMP command.

The DEFP command is not required if the position is a *numerically* named position for group A; it will be automatically defined when entered as part of the command.

You are prompted to provide values for each of the joint coordinates of the specified position, in the following format:

```
>SETPV P
 1 -[2388] >
 2 -[22857] >
 3 -[68120] >
 4 -[21510] >
 5 -[20825] >
```

The coordinates are defined in resolver counts for each axis.

The value displayed in brackets is the *value last recorded* for this position. If coordinate values have not yet been recorded for this position, the bracket is empty [ . ].

Press <Enter> to accept the displayed value, or enter a new value.

If the position requested is not valid, the coordinates are not accepted, and an error message is displayed.

**Example:** ■ >HERE PQ Records position PQ in joint coordinates according to the robot's current location; then permits user to reset the joint values for each of the axes.  
>SETPV PQ

**Notes:** TEACH *pos* is the comparable command for recording an absolute XYZ position according to user defined values.

Refer to POSITION in Chapter 4.

---

## SETPV *pos axis var*

**Description:** Used for position modification, this command permits you to change one of the joint values of a recorded position.

The value of the coordinate which is modified by this command is defined in resolver counts.

SETPV *pos axis value* will not warn you of an invalid point coordinate until it tries and fails to reach it.

- Example:**
- SETPV PS 3 1000                      Changes the joint value of axis 3 for position PS to 1000.
  
  - SET VARP=100  
SETPV PS 3 VARP                      Changes the joint value of axis 3 for position PS to 1000.
  
  - SETPV POSITION 3 VARP              The robot will immediately move to the position where joint 3 = VARP

**Note:**                      SETPVC *pos coord var* is the comparable command for changing the value of a Cartesian coordinate.

**Format:**            `SETPVC pos coord var`

Where:    *pos* is a recorded robot (group A) position;  
          *coord* is a Cartesian coordinate: X, Y, Z, P or R;  
          *var* is a variable expressed in microns (X,Y,Z) or millidegrees (P,R).

**Description:**    Used for position modification, this command enables you to change one of the Cartesian coordinates of a recorded position.

The value of the Cartesian coordinate which is modified by this command is defined in microns. Pitch and roll values are defined in millidegrees.

SETPVC will warn you of an invalid point coordinate as soon as the controller attempts to record the new coordinate.

- Examples:**
- `SET VARA=7000`                      The Y coordinate for robot position POSA is changed to 7 millimeters.  
   `SETPVC POSA Y VARA`
  
  - `SETPVC POSA Y 7000`                The Y coordinate for robot position POSA is changed to 7 millimeters.
  
  - `SETP        PA=POSITION`            Position PA receives the coordinates values of the robot's current position. Then the value of position  
   `SETPVC    PA X 25000`                PA is changed by 25mm along the X axis and -45°  
   `SETPVC    PA P -45000`                on the pitch axis.

**Note:**            `SETPV pos axis var` is the comparable command for changing the value of a joint coordinate.



**Format:**           SHIFT *pos* BY *axis* *var*

Where:    *pos* is a recorded position;  
          *axis* is an axis number;  
          *var* is a variable or constant.

SHIFTC *pos* BY *coord* *var*

Where:    *pos* is a recorded robot (group A) position;  
          *coord* is a Cartesian coordinate: X, Y, Z, P or R;  
          *var* is a variable expressed in microns (X,Y,Z) or millidegrees (P,R).

**Description:**   Used for position modification, this command enables you to change the coordinates of a recorded position *by an offset value*.

SHIFT                               Modifies joint coordinates; shifts the position by one joint value.

SHIFTC                              Modifies Cartesian coordinates; shifts the position by one Cartesian coordinate.

The value of the Cartesian coordinate which is modified by this command is defined in microns. Pitch and roll values are defined in millidegrees.

- Examples:**
- SHIFT P200 BY 1 3000   Robot position P200 is offset by 3000 resolver counts along axis 1.
  - SHIFTC POS99 BY R 20000   Robot position POS99 is offset by 20° along the roll axis.
  - SET VV=20000  
SHIFTC POS99 BY R VV   Robot position POS99 is offset by 20° along the roll axis.

**Format:**

```
SHOW DIN SHOW ENCO SHOW SPEED
SHOW DOUT SHOW PAR n
```

---

## SHOW DIN

**Description:** Displays the status of the 16 individual inputs.  
1 indicates ON; 0 indicates OFF.

**Example:** ■ `>SHOW DIN`  
1 -> 16: 0 1 0 1 0 0 0 0 1 0 0 0 0 0 0 0  
O.K.

---

## SHOW DOUT

**Description:** Displays the status of the 16 individual outputs.  
1 indicates ON; 0 indicates OFF.

**Example:** ■ `>SHOW DOUT`  
1 -> 16: 1 0 0 0 0 0 1 0 0 0 1 0 0 0 0 0  
O.K.

---

## SHOW ENCO

**Description:** Displays the value of all resolvers (encoders) every 0.5 seconds.  
A screen zone is reserved for the display of resolver information.  
The displayed value of all resolvers is updated every 0.5 seconds, until <Ctrl>+C is pressed.

**Example:** ■ `>SHOW ENCO`  
enc1 enc2 enc3 enc4 enc5 enc6 enc7 enc8  
1000 1000 1000 2371 2371 100 100 1000

---

# SHOW PAR *n*

**Description:** Displays the value of system parameter *n*.

**Example:** ■ `>SHOW PAR 261`  
PAR 261=100  
O.K.

---

# SHOW SPEED

**Description:** Displays all current speed settings.

- Linear Speed: Affects MOVE(L(D) and MOVEC(D) and Linear SPLINE(D) commands.
- Joint Speed: Affects MOVE(D), MOVES(D), and Joint SPLINE(D) commands.
- Program: Speed of movement when command is executed from a running program.
- Manual: Speed of movement when command is executed in DIRECT mode.
- Global Speed: Current setting of global speed factor
- Global Acceleration: Current setting of global acceleration factor.

**Example:** ■ `>SHOW SPEED`

| Linear Speed (mm/sec) | Program | Manual  |              |                     |
|-----------------------|---------|---------|--------------|---------------------|
|                       | 500     | 500.000 |              |                     |
| Joint Speed (%)       | Program | Manual  | Global Speed | Global Acceleration |
| Group A               | 50      | 50      | 100          | 100                 |
| Group B               | 50      | 80      | 100          | 70                  |
| Axis 9                | 100     | 50      | 100          | 70                  |

The following chart describes how these speed settings are determined.

| Linear Speed: Program                                                                                               | Linear Speed: Manual                                                                                                                                                            |
|---------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Defined by command <b>SPEEDL</b> <i>var</i> in EDIT mode.<br>Displayed in millimeters/second.                       | Defined by command <b>SPEEDL</b> <i>var</i> in DIRECT mode.<br>Displayed in millimeters/second.                                                                                 |
|                                                                                                                     | Defined by teach pendant command <b>SPEEDL</b> in XYZ mode. (Entered as a percentage of maximum linear speed.)<br>Displayed in millimeters/second.                              |
| Joint Speed: Program                                                                                                | Joint Speed: Manual                                                                                                                                                             |
| Defined by command <b>SPEED</b> <i>var</i> in EDIT mode.<br>Displayed as a percentage of the maximum speed setting. | Defined by command <b>SPEED</b> <i>var</i> in DIRECT mode.<br>Displayed as a percentage of the maximum speed setting.                                                           |
|                                                                                                                     | Defined by teach pendant command <b>SPEED</b> in Joint mode. (Entered as a percentage of maximum joint speed.)<br>Displayed as a percentage of the maximum joint speed setting. |

**Note:** Refer to the SPEED, SPEEDL, GSPEED and GACCEL commands.

**Format:**            `SPEED[A/B] var`  
                      `SPEEDC var axis`

Where:    *var* is a variable or constant.

**Description:**    `SPEED` or `SPEEDA` sets the speed of group A axes.  
                      `SPEEDB` sets the speed of group B axes.  
                      `SPEEDC` sets the speed of a specific axis in group C.

Defines the speed of `MOVE`, `MOVES`, and Joint `SPLINE` movements in percentages. Maximum speed is 100; minimum is 1. The default speed is 50.

Movement commands which do not include a *duration* argument are executed according to the `SPEED` setting.

In `DIRECT` mode, the `SPEED` command takes effect immediately. Determines the speed of movement when the `MOVE(D)`, `MOVES(D)` and Joint `SPLINE(D)` commands are executed in `DIRECT` mode.

In `EDIT` mode, the `SPEED` command takes effect after it is executed from within a program. Determines the speed of movement when the `MOVE(D)`, `MOVES(D)` and Joint `SPLINE(D)` commands are executed from within a program.

To view current speed settings, use the `SHOW SPEED` command.

**Examples:**    ■ `SPEED 20`                                Sets speed of joint movements of group A to 20% of maximum speed.  
                      ■ `SPEEDB 50`                              Sets speed of joint movements of group A to 50% of maximum speed.

**Note:**            Refer to the `MOVE(D)`, `MOVES(D)`, `SPLINE(D)`, `SPEEDL` and `SHOW SPEED` commands.

**Format:**            `SPEEDL var`

Where:    `var` is a variable or constant expressed in mm/sec.

**Description:**    `SPEEDL` sets the speed of robot (group A) axes only.

Defines the speed of linear and circular (`MOVEL`, `MOVEC` and Linear `SPLINE`) robot movements in millimeters per second.

Movement commands which do not include a *duration* argument are executed according to the `SPEEDL` setting.

In `DIRECT` mode, the `SPEEDL` command takes effect immediately. Determines the speed of movement when the `MOVEL(D)`, `MOVEC(D)` and Linear `SPLINE` commands are executed in `DIRECT` mode.

In `EDIT` mode, the `SPEEDL` command takes effect after it is executed from within a program. Determines the speed of movement when the `MOVEL(D)`, `MOVEC(D)` and Linear `SPLINE` commands are executed from within a program.

To view current speed settings, use the `SHOW SPEED` command.

- Examples:**
- `SET VARSP 12`                      Sets speed of linear/circular movements of group A to 12 mm/sec.  
   `SPEEDL VARSP`
  
  - `SPEEDL 12`                         Sets speed of linear/circular movements of group A to 12 mm/sec.

**Notes:**            Refer to the `MOVE(D)`, `MOVES(D)`, `SPLINE(D)`, `SPEED` and `SHOW SPEED` commands.

**Format:**            `SPLINE pvect n1 n2 [duration]`  
                       `SPLINED pvect n1 n2 [duration]`            EDIT mode only

Where:    *pvect* a position vector;  
               *n1* is the index of the first position;  
               *n2* is the index of the last position to be reached.

**Description:**    `SPLINE`                            Moves the axes through or near any number of consecutive vector positions, from *n1* to *n2*, without pausing, in a smooth and continuous movement.

`SPLINED`                            Same as `SPLINE`, except that the command following the `SPLINED` command will not begin execution until the robot has reached last position (as in `MOVED` command).

Positions in the vector may be of any type (joint, XYZ, absolute, relative).

The `SPLINE` commands generate a smooth path of robot movement through or close to the points of the vector, from *n1* to *n2*. The trajectory is calculated so that the speed and acceleration are kept within safe limits, according to parameters 180+*axis* (maximum speed) and 520+*axis* (maximum acceleration). At low speeds, the trajectory passes through the positions in the vector. At high speeds, the trajectory “rounds the corners” in order to keep acceleration within safe limits.

The joint speed of the movement between any two consecutive positions is constant.

*Duration* is defined in hundredths of a second. Commands which do not include a *duration* argument are executed according to the `SPEED` setting.

The trajectory goes through the positions in a joint movement, (as in a `MOVE` command). The joint speed is kept constant during the movement, except for acceleration and deceleration at the start and end of the `SPLINE` movement.

The `SPLINE` trajectory is most suitable for applications which require a smooth and quick path, such as pick and place operations, and palletizing.

**Format:**           SPLINEL *pvect n1 n2 [duration]*  
                   SPLINELD *pvect n1 n2 [duration]*           EDIT mode only

Where:    *pvect* a robot (group A) position vector;  
           *n1* is the index of the first position;  
           *n2* is the index of the last position to be reached.

**Description:**   SPLINEL                   Moves the robot axes through or near any number of consecutive vector positions, from *n1* to *n2*, without pausing, in a smooth and continuous movement.

                  SPLINELD                 Same as SPLINEL, except that the command following the SPLINELD command will not begin execution until the robot has reached last position (as in MOVED command).

Positions in the vector may be of any type (joint, XYZ, absolute, relative).

The SPLINEL command is applicable only to robot (group A) axes.

The SPLINEL commands generate a smooth path of robot movement through or close to the points of the vector, from *n1* to *n2*. The trajectory is calculated so that the speed and acceleration are kept within safe limits, according to parameters 536, 537 and 538 (maximum linear, pitch and roll speed), and parameters 533, 534 and 535 (maximum linear, pitch and roll acceleration). At low speeds, the trajectory passes through the positions in the vector. At high speeds, the trajectory “rounds the corners” in order to keep acceleration within safe limits.

The linear speed of the movement between any two consecutive positions is constant.

*Duration* is defined in hundredths of a second. Commands which do not include a *duration* argument are executed according to the SPEEDL setting.

The trajectory goes through the positions in a linear movement (as in a MOVE command). The linear speed of the robot’s TCP (tool center point) is kept constant, except for acceleration and deceleration at the start and end of the SPLINEL movement.

The SPLINEL trajectory is most suitable for applications which require a geometrical path, such as welding, spray painting, gluing, and deburring.



**Format:** STAT  
 STATUS  
 STAT[US] ALL  
 STAT[US] SYS

**Description:** STAT Displays the status of active user programs.  
 STAT ALL Displays the status of both system tasks and active user programs.  
 STAT Displays the status of system tasks only.

The four columns provide the following information:

- Program name.
- Program priority.
- Current status of program.  
 PEND is displayed if a program is waiting for a movement command to be completed.
- Program's current line number and the command being executed.

**Example:** ■ `>STAT`

| job name | priority | status    | position |
|----------|----------|-----------|----------|
| BOOM     | 5        | DELAY     | 3:DELAY  |
| DEMO     | 5        | PEND      | 15:MOVED |
| SS1      | 9        | SUSPENDED | 312:HERE |

**Format:**           STEP *prog*

Where:    *prog* is a program

**Description:**   Sets a <Break> point at the first line of the specified program.

When execution reaches the first line of the program (marked by the <Break> point), it will suspend execution, and display a prompt in the following format:

```
Break at task: OUT7 in program: OUT8
 480: <Break> SET OUT[8]=1
G/S/E)
```

The prompt displays the name of the task (e.g., program OUT7) which calls the routine (e.g., program OUT8) whose first line contains a <Break> point.

The prompt allows you to continue by doing one of the following:

|           |                                                                                                                  |
|-----------|------------------------------------------------------------------------------------------------------------------|
| G <Enter> | (Go) Program will resume continuous execution, unless it reaches another break point.                            |
| S <Enter> | (Step) Program will continue one line at a time, and display the (G/S/E) prompt after execution of each command. |
| E <Enter> | (Exit) Program will be aborted.                                                                                  |

**Note:**           Refer to the NOSTEP, BREAK, NOBREAK and RUN commands.

**Format:** STOP [*prog*]

**Description:** STOP Aborts all programs and all movements.  
STOP *prog* Aborts the running of the specific program only.

**Examples:** ■ STOP DEMO Aborts program DEMO.  
■ STOP MYPRG  
CLRBUF Aborts program MYPRG;  
Clears the movement buffers, thereby halting all movements.

**Note:** Refer to the CLRBUF command.

**Format:**            `SUSPEND prog`

**Description:**    Suspends execution of the specified program.

The program completes the current movement command and all movement commands remaining in movement buffer, and then goes into suspension.

To resume execution of a suspended program from the point of suspension, use the CONTINUE command.

**Example:**        ■ `SUSPEND DEMO`

**Note:**            Refer to the CONTINUE command.

**Format:** TEACH *pos*

Where: *pos* is a robot (group A) position.

**Description:** Records an absolute XYZ position, according to user defined values.

If the position has an alphanumeric name, it must first be defined using the DEFP or DIMP command.

The DEFP command is not required if the position is a *numerically* named position for group A; it will be automatically defined when entered as part of the command.

You are prompted to provide values for each of the Cartesian coordinates of the specified position, in the following format:

```
>TEACH PP
 X -[50000] >
 Y -[0] >
 Z -[30000] >
 P -[-900] >
 R -[0] >
```

The Cartesian (X, Y, Z) coordinates are defined in millimeters. Pitch and roll (P, R) values are defined in degrees.

The value displayed in brackets is the *value last recorded* for this position. If coordinate values have not yet been recorded for this position, the bracket is empty [ . ] .

Press <Enter> to accept the displayed value, or enter a new value (accurate to a micron or a millidegree.)

If the position entered is not valid, the coordinates are not accepted, and an error message is displayed.

**Note:** SETPV *pos* is the comparable command for recording an absolute joint position according to user defined values.

**Format:**       TEACHR *pos2 pos1*  
                  TEACHRT *pos2 pos1*

Where:    *pos1* is a recorded robot (group A) position;  
           *pos2* is defined for the robot (group A).

TEACHR *pos2*  
TEACHRT *pos2*

---

## TEACHR[T] *pos2 pos1*

**Description:**   TEACHR *pos2 pos1*       Record a robot position relative to another position.  
                                                  Records the offset values of *pos2*, relative to *pos1*,  
                                                  in Cartesian coordinates.

                  TEACHRT *pos2 pos1*       Records the offset values of *pos2*, relative to *pos1*,  
                                                  in Tool coordinates.

*Pos1* must be recorded before this command can be entered.

*Pos2* will always be relative to *pos1*, moving along with and maintaining its offset whenever *pos1* is moved.

If *pos2* has an alphanumeric name, it must first be defined using the DEFP or DIMP command. The DEFP command is not required if the position is a *numerically* named position for group A; it will be automatically defined when entered as part of the command.

You are prompted to provide relative values for each coordinate of the specified position, as shown in the examples below.

The Cartesian (X, Y, Z) coordinates are defined in millimeters. Pitch and roll (P, R) values are defined in degrees.

The value displayed in brackets is the *offset value last recorded* for this position. If coordinate values have not yet been recorded for this position, the bracket is empty [ . ] .

Press <Enter> to accept the displayed value, or enter a new offset value (accurate to a micron or a millidegree.)

**Example:** ■ >TEACHR OVER  
 X [.] > 0  
 Y [.] > 0  
 Z [.] > 60.5  
 P [.] > 0  
 R [.] > 0

Relative position OVER will always be 60.05 mm vertically above the current position of the robot.

## TEACHR[T] *pos2*

**Description:** TEACHR *pos2*

Allows you to record a robot position relative to the current position of the robot.

Records the offset values of *pos2*, relative to the current position of the robot, in Cartesian coordinates.

TEACHRT *pos2*

Records the offset values of *pos2*, relative to the current position of the robot, in Tool coordinates.

You must enter the offset values, as shown in the example below.

*Pos2* will always be relative to the current position.

**Example:** ■ >DEFP PLACE  
 >DEFP OVER  
 >HERE PLACE  
 >TEACHR OVER PLACE  
 X [.] > 0  
 Y [.] > 0  
 Z [.] > 200  
 P [.] > 0  
 R [.] > 0

Positions PLACE and OVER are defined;

Current coordinates of robot are recorded for position PLACE;

Relative position OVER is recorded as 200mm vertically above position PLACE.

Whenever the coordinates of PLACE are changed, OVER will maintain a 200mm vertical offset.

**Format:** TOOL *length offset angle*

Where: *length* is the distance from flange to the TCP;  
defined in microns.

*offset* is the distance from the axis of symmetry of the flange to  
the TCP; defined in microns.


*angle* is the angle of TCP relative to the horizontal position when  
link 4 is horizontal and roll is 0; defined in thousandths of a degree.

*length*, *offset* and *angle* can be a variable or a constant.

**Description:** TOOL defines the position of the end effector relative to the robot's flange. MOVEC, MOVEL, Linear SPLINE, and teach pendant movement commands are executed according to the robot's TCP (tool center point).

**Example:** ■ GLOBAL L O A  
SET L=200000                      Length is 200 mm.  
SET O=75350                        Offset is 75.35 mm.  
SET A=45350                        Angle is 45.3°  
TOOL L O A

**Note:** The TOOL command sets the values of parameters 308, 309 and 310. When the parameter values are defined by the user, default settings for TOOL can be loaded from a parameter backup file.





**Format:** TRIGGER *prog* BY {IN/OUT} *n* [0/1]

Where: *prog* is a program;  
 IN is an input; OUT is an output;  
*n* is the I/O index,  $1 \leq n \leq 16$ ;  
 0=off; 1=on

**Description:** The TRIGGER command starts the execution of a specific program when the specified input or output is turned either on or off. If an input state (off or on) is not specified, execution of the program begins as soon as the specified I/O changes its state.

TRIGGER is a one-shot command. It execute a program only once, regardless of subsequent changes in the I/O state. You must repeat the TRIGGER command to reactivate the program it calls.

When used in the robotic system, sensors are connected to the controller inputs. The TRIGGER command enables the system to respond immediately and automatically to sensory signals whose timing is undefined or unpredictable. If such an application requires repeated sensor interrupts, the TRIGGER command must be entered prior to each expected sensor interrupt. The TRIGGER command can be included at the end of the called subroutine.

**Examples:** ■ TRIGGER WW BY OUT 8 Program WW is activated when output 8 changes its state.

■ PROGRAM DRILL  
 \*\*\*\*\*

```
MOVE P28
SET OUT[3]=1
DELAY 500
SET OUT[3]=0
MOVE P27
TRIGGER DRILL BY IN 15 1
END
```

Program MAIN activates program DRILL for the first time; thereafter, the TRIGGER command within program DRILL reactivates program DRILL whenever input 15 is turned on.

```
PROGRAM MAIN

TRIGGER DRILL BY IN 15 1
```

**Format:** UNDEF *pos*  
 UNDEF *pvect*  
 UNDEF *pvect*[*n*]

Where: *n* is the index of a position in the vector.

**Description:** Erases position values. The position is still defined, but does not have coordinate values.


UNDEF *pos* Clears the coordinate values of the specified position.

UNDEF *pvect* Clears the coordinate values of all the positions in the vector.

UNDEF *pvect*[*n*] Clears the values of position *n* in the vector.

This command is useful when you intend to issue the APPEND command, since APPEND can assign coordinate values to a defined position only when it does not already values.

**Examples:** ■ UNDEF VECTV[5] Clears the coordinate values of position 5 in vector VECTV.



- UNDEF VECTV                      Clears the coordinate values of all positions in vector VECTV.

**Note:**                      This command does not create a program line.

# UPLOAD

# DIRECT

**Format:** UPLOAD

**Description:** Servo control parameters for each axis are programmed onto an EEPROM on the DDC card for each axis.

UPLOAD copies the servo control parameters for all configured axes from the EEPROMs on the DDC cards to the controller's BBRAM.

After the UPLOAD command is issued, a parameter (CBU) file can be saved to disk by means of the ATS Backup Manager (<Shift>+F10).

**Note:** Refer to the DOWNLOAD command.

**Format:** VER

**Description:** Displays the EPROM version and creation date.

**Example:** ■ `>VER`  
--- ESHED ROBOTECT ---  
CONTROLLER: AC  
VERSION: AC30.25  
DATE : 29.09.96

**Format:**            `WAIT var1 oper var2`  
Where:    `var1` is a variable;  
          `var2` is a variable or a constant;  
          `oper` can be: `<`, `>`, `>=`, `<=`, `=`, `<>`

**Description:**    Program execution is suspended until the specified condition is true.  
When a program is waiting for an input to reach a specific state, this command is very useful, since **WAIT** uses little CPU power while waiting for an event.

- Examples:**
- `WAIT IN[5]=1`                      Waits until input 5 is ON
  - `WAIT X<Y`                            Wait until the value of X is less than the value of Y.

**Format:** ZSET

**Description:** This command initializes the parameters used in the homing procedure.

ZSET should be executed *only* after maintenance of resolvers or mechanical components and before homing the axes.

If no servicing was performed on the motor, resolver or home switch, *do not use* the ZSET command. Doing so may alter the robot's fixed reference position.

**Format:** <Enter>

**Description:** In EDIT mode, checks the syntax of the line, then goes to the next line in program and displays its number.

In DIRECT mode, confirms and executes the command.

The following **ACL** commands do not require <Enter> for execution:

|          |                                                                                       |
|----------|---------------------------------------------------------------------------------------|
| <Ctrl>+A | Immediately aborts all running user programs and stops axes movement.                 |
| ~        | Toggles Manual Keyboard mode on and off.                                              |
| <Ctrl>+C | Cancels the display of data resulting from SHOW ENCO, LIST, SEND, and other commands. |



## EDIT

\*

**Format:**        \**user comment*

Where        *user comment* is a string of up to 40 characters and spaces.

**Description:**    Allows you to annotate your programs.

The \* character precedes textual comments within your program.

These comments are not displayed during program execution.

**Example:**        ■ \*THIS IS AN EXAMPLE OF A COMMENT

**Format:** @ *directcom*

Where: *directcom* is a string written in DIRECT command format.

**Description:** Allows the execution of a DIRECT command from a running user program.

The @ command relays the string to the controller as if it were a command entered in the DIRECT mode. However, the running program will not wait for the @ command to be executed. To make sure the command is executed before the program continues, enter a short delay command after each @ command.

Although programs can run while editing is being performed, the @ command will cause a running program to terminate if editing is being performed. Therefore, *do not execute @ commands and edit programs at the same time.*

**Examples:** ■ @ SHOW DIN

When program reaches this command line, the states of all inputs will be displayed.

■ @ ATTACH LOAD  
DELAY 10  
@ LISTPV POSITION  
DELAY 10

The DELAY command ensures the ATTACH command will be executed before the LISTPV command.

**Format:** ~

<Alt>+M

**Description:** Activates and deactivates manual control of the robot from the keyboard.

When you press ~, Manual Keyboard mode is activated, and the following message is displayed:

```

MANUAL MODE! or MANUAL MODE! or MANUAL MODE!
>_ >_ >_
JOINT MODE XYZ MODE TOOL MODE

```

The system's response indicates the currently active coordinate system.

When you again press ~, Manual Keyboard mode is deactivated, and the following message is displayed:

```

EXIT manual mode
>_

```

When using **ATS**, if your keyboard does not include the ~ character, you can also toggle Manual Keyboard mode by pressing <Alt>+M.

Manual Keyboard mode enables several direct control operations from the keyboard, as described in the items.

## Coordinate System

Manual Keyboard mode permits direct user manipulation of the axes.

Manual keyboard control varies, depending upon the currently active coordinate system.

- When the coordinate system is set to the **XYZ or Tool** mode:
  - Movement commands to the X, Y or Z axis result in a linear motion of the **tool center point (TCP)** along the respective axis, while maintaining a constant orientation of the tool.
  - Movement commands to the pitch or roll axis will change the orientation of the tool, while maintaining a constant TCP position.
- When the coordinate system is set to the **Tool** mode, the X, Y and Z axes are defined as follows.
  - The Z-axis is the axis which intersects the flange at its center point, and is perpendicular to it.
  - The X-axis is horizontal and perpendicular to the Z-axis.
  - The Y-axis is vertical and perpendicular to both the Z and X axes.

- When the coordinate system is set to the **Joint** mode, movement commands cause the robot to move one joint.

(Peripheral axes always move according to Joint coordinates.)


When Manual Keyboard mode is active, use the following keys to change the movement coordinate systems:

- J                                      Joints coordinate system
- X                                      Cartesian (XYZ) coordinate system.
- Z                                      Tool coordinate system.


The following chart summarized the resulting movements when the axes are controlled from the keyboard in Manual mode. The axes will move as long as the activating key is depressed, or until a fixed stop is reached.

Note the differences in axis action for the different coordinate systems.

| Keys  | ACTION<br>XYZ / TOOL mode                                                                                         | ACTION<br>JOINT mode                                |
|-------|-------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------|
| X / J | Toggles between JOINTS and XYZ mode.                                                                              |                                                     |
| 1 / Q | All/some axes move in order to move TCP along X+ and X- axis.                                                     | Moves BASE (axis 1) counterclockwise and clockwise. |
| 2 / W | All/some axes move in order to move TCP along Y+ and Y- axis.                                                     | Moves SHOULDER (axis 2) up and down.                |
| 3 / E | All/some axes move in order to move TCP along Z+ and Z- axis.                                                     | Moves ELBOW (axis 3) up and down.                   |
| 4 / F | Shoulder, elbow and pitch axes move, causing the pitch angle to change while maintaining the position of the TCP. | Moves wrist PITCH (axis 4) up and down.             |
| 5 / T | Moves wrist ROLL (axis 5) clockwise and counterclockwise (as seen from above, when end effector pointed down).    |                                                     |
| 6 / Y | Moves axis 6.                                                                                                     |                                                     |
| 7 / U | Moves axis 7.                                                                                                     |                                                     |
| 8 / I | Moves axis 8.                                                                                                     |                                                     |



*Cartesian (XYZ) Coordinates*



*Tool Coordinates*

This page intentionally left blank.

---

# Predefined System Elements

---

In addition to user commands and data elements, **ACL** has a number of predefined system elements which are used during the programming and operation of the robotic system.

---

## System Procedures

### HOME

The HOME procedure performs a microswitch home search on all robot axes.

This procedure is activated either by entering the **ACL** command HOME, or by keying in RUN 0 from the teach pendant.

If the Robot Type is defined as 0 in the controller configuration, you must use command HOME *n* or HHOME *n* for each individual axis. Axes in group B and group C must also be homed individually.

Refer to the command HOME in Chapter 3.

---

## Reserved Program Names

ACL has six reserved names for user programs: AUTO, BACKG, CRASH, EMERG, RECOV and START. You can create and edit these programs in EDIT mode, like any other **ACL** user program.

The system will run the program automatically, if it exists, when certain conditions occur.

### AUTO

The AUTO program is automatically executed when the controller is powered on or reset after being shut down while in COFF. (See program RECOV below.)

The following items are suggested for inclusion in the AUTO program:

- I/O settings.
- ATTACH positions for teach pendant.
- RUN (execution of) user programs

## Example

```
PROGRAM AUTO

HOME
DIMP PV
ATTACH PV
DELAY 10
RUN OPER
END
```

When system is powered on or reset, the following occurs: the robot searches for its home position; a position vector PV is defined and attached to the teach pendant; program OPER is executed.

## BACKG

The BACKG program is automatically executed when the controller is powered on or reset, and as soon as the EMERGENCY button is released.

The BACKG program is a protection routine which can serve to prevent unintentional user errors which could result in physical injury or damage to the robotic system. BACKG continually checks the safety of operations and responds to hazardous situations.

BACKG can be written to suit the specific requirements of the user's application. For example, it can check and ensure that the robot's base axis remains stationary while the gripper is placing an object into a machine. Thus, if a command entered from the keyboard or teach pendant causes the base axis to move, BACKG can immediately issue a COFF command to halt the movement of the robot.

To run BACKG after it has been edited, press and release the emergency button.

BACKG runs continually in the background and *will not be aborted* by any of the following:

- Entering the command A or <Ctrl>+A.
- Switching control to the teach pendant.
- Executing HOME, HOME *axis* or HHOME *axis*.

Since BACKG cannot be aborted as easily as other **ACL** programs, you must be absolutely certain that BACKG will not result in a dangerous situation, such as unexpected movement of a robot or device.

To abort the running of BACKG, do one of the following:

- Enter the command A BACKG.
- Use the STOP BACKG command line in another program.
- Press the EMERGENCY button.  
*Remember! Releasing the EMERGENCY button automatically activates BACKG.*



## CRASH

The CRASH program is automatically executed when an impact, thermic, or “excessive speed” error occurs.

The following items are suggested for inclusion in the CRASH program:

- Commands to save the status of the system at the time of the crash.
- Messages to be sent to the host computer via the RS232 channel.

### Example

```
PROGRAM CRASH

* OUTPUT 16 = EMERGENCY BUZZER
SET OUT[16]=1
PRINTLN "ROBOT HAS STOPPED"
PRINTLN "CHECK AND CORRECT PROBLEM"
PRINTLN "RESTART APPLICATION"
END
```

## EMERG

The EMERG program is automatically executed when any emergency switch or button is pressed.

You may want to create this program in order to turn inputs and outputs off or on when the emergency status is in effect.

### Example

```
PROGRAM EMERG

* TURNS OFF OUTPUT FOR SAFETY
SET OUT[7]=0
END
```

## RECOV

The RECOV program is automatically executed when the controller is powered on or reset after being shut down while in CON(similar to AUTO which runs after a shutdown in COFF).

This program can be used to execute special recovery routines if a power failure occurs during robot operation.

## START

The START program is automatically executed when the Start push button on the controller is pressed, or when a remote Start switch is activated.

This program can be used to start a process manually and immediately, by simply pressing a button.

## Example

```
PROGRAM START

* INPUT 10 IS SELECTOR
IF INPUT[10]=1
 GOSUB PROG1
ELSE
 GOSUB PROG2
ENDIF
END
```

As soon as the Start button is pressed, the status of input 10 is checked. If the input is on, PROG1 is executed; if the input is off, PROG2 is executed.

---

## Position POSITION

POSITION is a system defined position, reserved for the coordinate values of the robot's current position (location).

POSITION can be used for reading the values of the robot's current position, and for assigning those values to variables or other positions.

### Examples

Following are examples of commands which access and utilize POSITION.

■ LISTPV POSITION

Displays the current coordinate values of the robot arm.

■ SETP 100=POSITION

Position 100 receives the coordinate values of the robot's current position. The equivalent of the command HERE 100 .

■ SET var=PVALC POSITION X  
SET var=PVALC POSITION Y  
SET var=PVALC POSITION Z  
SET var=PVALC POSITION P  
SET var=PVALC POSITION R

Var receives the specified Cartesian coordinate value of the robot's current position.

You can also change the actual location of the robot by using POSITION, as shown in the following four examples.

*Warning! The robot will immediately move to the new POSITION; therefore, make only small changes in the coordinates.*

■ SHIFT POSITION BY 2 100

■ SHIFTC POSITION BY Z 0.5

■ SETPV POSITION 1 80000

■ SETPVC POSITION Y 5000

■ SETP POSITION=P[1000]

The type of movement used to move to the new position is defined by the JOINT or LINEAR command.

# System Variables

System defined variables contain values which indicate the status of inputs, outputs, encoders, and other control system elements. The **ACL** system variables enable you to perform diagnostic tests and recovery programs, and to execute applications which require real-time information about the system's status.

ACL contains 22 system variables:

|            |            |            |
|------------|------------|------------|
| IN[ 16 ]   | TQ[ 5 ]    | ERROR      |
| ENC[ 5 ]   | INDEX[ 5 ] | ERRPR      |
| LSCW[ 5 ]  | LTIME[ 5 ] | ERRLI      |
| LSCCW[ 5 ] | TIME       | OUT[ 16 ]  |
| CPOS[ 12 ] | MFLAG      | JOG[ 5 ]   |
| POSER[ 5 ] | HOMED      | TQMAX[ 5 ] |
| JTARG[ 5 ] | CONST      | TQMIN[ 5 ] |
| XTARG[ 5 ] |            |            |

The indices indicate the dimensions of the array variables.

The values of the system variables are manipulated in the same manner as user defined variables. However, system variables cannot be deleted.

The values of some system variables are updated at every controller clock tick. Since any value assigned to these variables will be overwritten immediately, they are considered read-only variables.

## IN[n]

The value of this variable indicates the state of the specified digital input.

The value of IN[n] is updated at each controller clock tick according to the actual state of the input. Any value written to this variable will be overwritten within one clock tick.

IN[n] is considered a read-only variable.

*n* = the index of the input; may be a variable or a constant; may not exceed the number of inputs configured.

### Examples

| Purpose                                     | Program Command                         | Display | Notes         |
|---------------------------------------------|-----------------------------------------|---------|---------------|
| To view the current status of the input.    | PRINTLN IN[ 3 ]                         | 1       | =input is ON  |
|                                             |                                         | 0       | =input is OFF |
| To control programs running in a work cell. | IF IN[ I ]=0<br>SET OUT[ 2 ]=1<br>ENDIF |         |               |

## ENC[n]

The value of this variable indicates the number of resolver counts for the specified axis at its current position.

The value of ENC[n] is updated at each controller clock tick according to the actual state of the encoder. Any value written to this variable will be overwritten within one clock tick.

ENC[n] is considered a read-only variable.

$n$  = the index of the axis; may be a variable or a constant; may not exceed the number of axes configured.

### Examples

| Purpose                                    | Program Command  | Display | Notes                                   |
|--------------------------------------------|------------------|---------|-----------------------------------------|
| To view the current status of the input.   | PRINTLN ENC[ 1 ] | 0       | ENC[1]=0 resolver counts.               |
|                                            |                  | 6844    | ENC[1]=6844 resolver counts.            |
| To assign the encoder value to a variable. | SET X=ENC[ 5 ]   |         | The value of encoder 5 is written to X. |

## LSCW[n] and LSCCW[n]

The value of the variables LSCW[n] and LSCCW[n] indicates the status of the clockwise and counter-clockwise limit switches, respectively, for the specified axis at its current position.

In order to obtain a correct value when manually moving the axis from one limit to the opposite one, you must press the controller's Error Reset button.

These are read-only variables.

$n$  = the index of the axis; may be a variable or a constant; may not exceed the number of axes configured.

### Example

| Purpose                                                        | Program Command                                     | Notes                                                                                                                                   |
|----------------------------------------------------------------|-----------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|
| Used during maintenance, repair and testing of the controller. | LABEL 1<br>PRINTLN LSCW[ 4 ]<br>DELAY 100<br>GOTO 1 | Depending on the actual wiring connections, the value of LSCW will change to either 1 or 0 when the clockwise limit switch is detected. |

## **CPOS[*n*]**

This variable contains the current command position in resolver counts. At each clock tick this value is calculated by the controller for the specified axis.

This is a read-only variable.

*n* = the index of the axis; may be a variable or a constant; may not exceed the number of axes configured.

## **POSER[*n*]**

This variable contains the position error; that is, the difference between the exact command position, as calculated by the driver, and the actual position, as measured by the resolver. At each clock tick this value is calculated by the controller for the specified axis.

This is a read-only variable.

*n* = the index of the axis; may be a variable or a constant; may not exceed the number of axes configured.

## **JTARG[*n*] and XTARG[*n*]**

JTARG[*n*] and XTARG[*n*] contain the Joint / Cartesian coordinates of the final target position for the movement command currently being executed.

This is a read-only variable.

*n* = the index of the axis; may be a variable or a constant; may not exceed the number of axes configured.

## **TQ[*n*]**

This variable contains a value proportional to the torque output of the motor.

This is a read-only variable.

*n* = the index of the axis; may be a variable or a constant; may not exceed the number of axes configured.

The value of TQ[*n*] is in the range:  $\pm 5000$ , where 5000 represents the maximum peak torque for the specified motor.

## INDEX[n]

This variable contains the index number of the next position to be passed during the execution of a MOVES movement.

This is a read-only variable.

For axis group A,  $n = 1$ ; for axis group B,  $n = 2$ ; for individual axes (group C),  $n =$ the axis number.

### Example

| Purpose                                                               | Program Command                                                                    | Notes                                                                                                            |
|-----------------------------------------------------------------------|------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------|
| Allows changes to speed during different sections of MOVES movements. | <pre>MOVES M 1 100 FOR K = 2 100   WAIT INDEX[1]&gt;=K   GSPEED SP[K] ENDFOR</pre> | Each section of the MOVES movement is monitored. When section K is reached, the appropriate global speed is set. |

## TIME

This variable contains the current value of the real-time clock.

When the controller is turned on or reset, the clock is initialized to 0. Every 10 milliseconds the clock value is incremented by 1.

TIME is considered a read-only variable.

### Example

| Purpose                                                    | Program Command                                                                                                         | Display             |
|------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------|---------------------|
| To determine the actual duration of the executed movement. | <pre>PROGRAM TIME ***** SET TIMEA=TIME MOVED POS99 SET TIMEA=TIME-TIMEA PRINTLN "MOVE DONE IN " PRINT TIMEA " MS"</pre> | MOVE DONE IN 500 MS |

## LTIME[n]

The value of these variables indicate the time (that is, the controller clock value; as for TIME variable) at which the specified axis group will reach the target position last received. The actual arrival time may be slightly later than the value of LTIME[n]. LTIME[n] is considered read-only variables.

For axis group A,  $n = 1$ ; for axis group B,  $n = 2$ ; for individual axes (group C),  $n =$ the axis number.

This variable is used when movements commands MOVE, MOVEC, and MOVES are placed in the buffer. These variables enable practical scheduling and work cell synchronization; for example: conveyor pick-up, synchronization of two axis groups, and so on.

### Example

| Purpose                                                                                                                                                               | Program Command                                                             |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------|
| To synchronize the arrival of group A axes and group B axes at their respective destinations.<br>(POSA5 is a position of group A and POSB3 is a position of group B.) | PROGRAM SYNCH<br>*****<br>MOVE POSA5<br>SET V=LTIME[1]-TIME<br>MOVE POSB3 V |

## CONST

This value of this variable indicates whether or not an axis group or an axis is in CON.

CONST is considered a read-only variable.

Whenever a CONcommand is executed, the 8 least significant bits of the variable CONST are switched on, according to the following:

- Bit 1 is ON                      if group A (robot axes) is in CONstate
- Bit 2 is ON                      if group B exists and is in CONstate
- Bits  $n$  is ON                    if an individual axis in group C exists and is in  
(where  $n = 2, 3 - 9$ )            CON state.

Bits 9 – 32 are always set to 0.

Use the AND operator of the SET command to mask the unwanted bit(s) of the CONST variable.

(The CONST variable functions in the same manner as the MFLAG variable; see following.)



## MFLAG

The value of this variable indicates which axes are currently in motion.

MFLAG is considered a read-only variable.

Whenever a MOVE command is executed, the 8 least significant bits of the variable MFLAG are switched on, according to the following:

- Bit 1 is ON if group A (robot axes) is in motion
- Bit 2 is ON if group B exists and is in motion
- Bits  $n$  is ON if an individual axis in group C exists and is in motion.  
(where  $n=2,3-9$ )

Bits 9 – 32 are always set to 0.

### Example

Assuming the controller is configured with five axes in group A, two axes (6 and 7) in group B, and 1 axis (8) in group C, the value of MFLAG will indicate movement of the axes as shown in the following chart:

| Bit Value | 1             | 2    | 4 | 8 | 16 | 32 | 64 | 128 |
|-----------|---------------|------|---|---|----|----|----|-----|
| Group     | A             | B    | — | — | —  | —  | —  | C   |
| Axis      | 1, 2, 3, 4, 5 | 6, 7 | — | — | —  | —  | —  | 8   |

| Purpose                      | Program Command | Display | Notes                                                          |
|------------------------------|-----------------|---------|----------------------------------------------------------------|
| Movement status of the axes. | PRINTLN MFLAG   | 1       | All axes in group A are currently in motion.                   |
|                              |                 | 3       | All axes in groups A and B are currently in motion.            |
|                              |                 | 129     | All axes in group A and axis 8 are currently in motion.        |
|                              |                 | 131     | All axes in groups A and B and axis 8 are currently in motion. |

Use the AND operator of the SET command to mask the unwanted bit(s) of the MFLAG variable; for example: SET M=MFLAG AND 1 will give the movement status of group A and mask all other groups.


# HOMED

This variable indicates whether or not an axis has been homed.

The value of this variable indicates which axes are currently in motion.

HOMED is considered a read-only variable.

Whenever an axis group or an axis has been homed, the 32 bits of the binary representation of HOMED are switched on, according to the following chart:



Bits 9 through 32 are always set to 0.

## Example

Assuming the controller is configured with five axes in group A, two axes (6 and 7) in group B, and 1 axis (8) in group C, the value of HOMED will indicate homed axes, as shown in the following chart:

|                  |   |   |   |   |    |    |    |     |
|------------------|---|---|---|---|----|----|----|-----|
| <b>Bit Value</b> | 1 | 2 | 4 | 8 | 16 | 32 | 64 | 128 |
| <b>Group</b>     | A |   |   |   |    | B  |    | C   |
| <b>Axis</b>      | 1 | 2 | 3 | 4 | 5  | 6  | 7  | 8   |

| Purpose                                   | Program Command | Display | Notes                                                                                     |
|-------------------------------------------|-----------------|---------|-------------------------------------------------------------------------------------------|
| To determined which axes have been homed. | PRINTLN HOMED   | 31      | 31=1+2+4+8+16;<br>All axes in group A have been homed.                                    |
|                                           |                 | 127     | 127=31+32+64;<br>All axes in group A group B have been homed. Group C has not been homed. |

You can use the AND operator of the SET command to mask the unwanted bit(s) of the HOMED variable; for example: SET H=HOMED AND 31 will mask all bits of group B and C.

## ERROR, ERRPR and ERRLI

When a system error occurs during run time, these error variables are assigned values in the following manner:

- The value of ERROR indicates the specific error. An error message is also displayed.
- The value of ERRPG indicates the identity of the program (ID number, as displayed by DIR command) that initiated the task in which the error occurred.
- The value of ERRLI indicates the line number within the program at which the error occurred.

Refer to Chapter 5 for explanations of the error messages.

These are read/write variables. Each of these three variables *must have an initial value of 0*; otherwise, the value of the variable will not change during program execution.

### Example

| Purpose                      | Program Command                                                                                       | Display | Notes                                       |
|------------------------------|-------------------------------------------------------------------------------------------------------|---------|---------------------------------------------|
| To identify run-time errors. | PROGRAM MOVE<br>*****<br>LABEL 1<br>MOVE POS66<br>MOVE POS67<br>GO TO 1<br><br>PROGRAM ERROR<br>***** |         | Simultaneously run programs ERROR and MOVE. |
|                              | SET ERROR=0<br>SET ERRPR=0<br>SET ERRLI=0<br>* wait for error to occur<br>WAIT ERROR <>0              |         |                                             |
|                              | PRINTLN "ERROR NO. " ERROR                                                                            | 53      | Error ID number                             |
|                              | PRINTLN "TASK ID " ERRPG                                                                              | 7       | Task number                                 |
|                              | PRINTLN "AT LINE " ERRLI                                                                              | 144     | Line number                                 |

## OUT[n]

The value of this variable determines the state of the specified output.

The value of OUT[n] is applied to the actual output at each controller clock tick.

OUT[n] is a read/write variable.

n = the index of the output; may be a variable or a constant; may not exceed the number of outputs configured.

### Examples

| Purpose                                                      | Program Command                      | Display | Notes                                        |
|--------------------------------------------------------------|--------------------------------------|---------|----------------------------------------------|
| To view the current status of the input.                     | PRINTLN OUT[7]                       | 1       | =output 7 is ON                              |
|                                                              |                                      | 0       | =output 7 is OFF                             |
| To check and change status of device connected to an output. | IF OUT[5]=0<br>SET OUT[5]=1<br>ENDIF |         | If output 5 (e.g., lamp) is off; turn it on. |
| To change the state of an output.                            | SET<br>OUT[5]=1-OUT[5]               |         |                                              |

## JOG[n]

**Warning:** This variable is for maintenance purposes only. Do not manipulate this variable unless you are authorized to do so!

The value of this variable defines a constant speed for movement of an axis.

n = the index of the axis; may be a variable or a constant; may not exceed the number of axes configured.

The value of JOG is in units of (resolver counts × 128) ÷ controller clock tick.

Using the SET command with the JOG variable overrides normal servo control; it should therefore be used only for maintenance purposes. This variable is protected by the PRIVILEGE mode.

### Example

| Program Command                                                                       | Notes                                                                                              |
|---------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------|
| PRIV ON<br>(Enter password)<br>SET JOG[3]=12800<br>DELAY 100<br>SET JOG[0]=0<br>@COFF | This will move axis 3 at a relatively slow speed of 100 resolver counts per controller clock tick. |

## TQMAX[n] and TQMIN[n]

TQMIN and TQMAX contain the minimum and maximum torque setting for the specified axis.

TQMIN and TQMAX are two clamping values which limit the working range of the servo controller. If the axis reaches either of these limits during movement, the axis' position error will increase, but the torque will remain within the defined range. If the position error reaches the maximum allowed, as defined by the impact parameters, an impact error condition will result.

TQMIN and TQMAX are automatically reset to -5000 and +5000, respectively, when control is disabled.

$n$  = the index of the axis; may be a variable or a constant; may not exceed the number of axes configured.

The torque limits are written to the axis controller only when the value of TQMAX is set. Thus, to change only TQMIN, you must rewrite the value of TQMAX.

The value of TQMIN and TQMAX is in the range:  $\pm 5000$ .

### Example

| Purpose                                                  | Program Command                      | Notes                                                                                                                                                                                                              |
|----------------------------------------------------------|--------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| To limit the torque during execution of a delicate task. | SET TQMAX[4]=950<br>SET TQMIN[4]=600 | Monitoring variable TQ[4] during program execution showed a torque range of 700-850 during the delicate segment of the program. Setting the torque limits in the range 600-950 protects against impact conditions. |

This page intentionally left blank.

# System Messages

---

This chapter contains a listing of the system messages which may appear on your screen during **ACL** operation and programming.

Italicized text in the messages shown here will be replaced by the actual item (for example, name of program, name of position, axis number) when the message is displayed.

When an equivalent message is also displayed on the teach pendant, that message is included [boxed text] in the description. Refer to the *Teach Pendant User's Manual* for an alphabetical listing and of the teach pendant messages.

The explanations of error messages include instructions for correcting the situation which caused them. System messages which prompt you for a Yes/No response and other self-explanatory messages are not included in this chapter.

When a system error occurs at run time, system variables ERROR, ERRPG and ERRLI receive values which indicate, respectively, the type of error, the program, and the line number at which the error occurred. Each of these three variables *must have an initial value of 0*; otherwise, the value of the variable will not change during program execution. Refer to the description of the error variables in Chapter 4.

- (3) ACL - Unknown command.

The command entered is not a recognized ACL command.

- (4) SHOW - Unknown command.

The command entered after the SHOW request is missing or is not a recognized SHOW command. SHOW commands are: SHOW ENCO, SHOW DIN, SHOW DOUT, SHOW SPEED.

- (6) *Prg\_name* not found.

A program with the specified name was not found, or does not exist.

- (12) Cannot remove files while jobs are running.

You attempted to delete a program (REMOVE) while that program or another program was running.

- You must first stop execution of all programs: use the abort command A <Enter>. You may then enter the REMOVE command.

(17) Program *prog* is running.

When in DIRECT mode, you cannot issue a command to RUN a program which is already running..

(18) Program *prog* is running. Cannot access editor.

You attempted to EDIT a program while it is running.

- You must stop the program before you can edit it.

(22) Cannot delete constant or system variables.

System variables and system constants cannot be deleted.

(33) \*\*\* UPPER LIMIT AXIS *n*

(34) \*\*\* LOWER LIMIT AXIS *n*

During keyboard or TP manual movement of the specified axis, its encoder attained its maximum or minimum allowed value, or a limit switch was reached. Robot has reached the limits of its working envelope.

- Use the TP or the keyboard to move the axis in the opposite direction, and thus return the axis to its working range.

(35) Input or Output must be disabled prior to FORCE operation.

A FORCE command appears without a prior DISABLE command.

- Before you can force an input or output to a different value, the input/output must be in the DISABLE mode.

(36) Invalid index or value.

Index or data error

The command has an incorrect index value.

(37) INput or OUTput?

A FORCE command appears without an input or outputs specified.

- Include an input or output number in the FORCE command.

(39) Incorrect number of arguments.

The command has an incorrect number of arguments.

(40) Cannot hard home *axis n*.

No hard Homing

The specified axis has not been configured for hard homing.

- Use the HOME command (instead of HHOME). OR
- Check the type of homing suitable for that axis. If necessary, change the system parameters to allow hard homing of the axis.



(41) AC INPUT POWER FAILURE.

- There is an AC power supply failure.

(43) RUN RECOV (<Enter> TO ABORT)

- When the controller was turned on, after being shut down while in the CON state, ACL detected the RECOV program. Unless the user intervenes (presses <Enter>) within two seconds, the RECOV program will run automatically.

(44) RUN AUTO (<Enter> to ABORT).

- When the controller was turned on, after being shut down while in the COFF state, ACL detected the AUTO program. Unless the user intervenes (presses <Enter>) within two seconds, the AUTO program will run automatically.

(51) \*\*\* HOME FAILURE AXIS *n*.

**HOME FAIL *n*.**

The homing procedure failed for the specified axis. Possible causes:

- (1) The home microswitch was not found.
- (2) The Servo switch is turned off.
- (3) Hardware fault on the axis.
- (4) Invalid configuration for the axis.

(52) \*\*\* TRAJECTORY ERROR !

This error affects the ERROR system variable.

During movement, the robot arm reached its envelope limits, and the system aborted the movement. This may occur when executing the following types of movements: linear (MOVEL), circular (MOVEC), MOVES, and SPLINE. Since the trajectory is not computed prior to motion, the movement may exceed the limits of the working envelope.

- Modify the coordinate values of the positions which define the trajectory.
- Reenable the axis (CON).

(53) \*\*\* IMPACT PROTECTION axis *n*

**IMPACT AX *n***

This error affects the ERROR system variable.

The controller has detected a position error which is too large. The system aborted all movements of that axis group, and disabled all axes of that group. The user routine CRASH, if it exists, has been executed.

- Determine and correct the cause of the position error (e.g., obstacle, payload too heavy). Then reenable servo control of the motors (CON), and restart the program.

(54) \*\*\* OUT OF RANGE axis *n*

RANGE *n*

This error affects the ERROR system variable.

An attempt was made to record a position (HERE, HEREC, etc. ) while the robot arm was out of its working envelope.

- Manually move the arm to a location within its working envelope. Then repeat the command.

(58) Cannot execute program. Waiting for an available task...

Too many tasks (more than 40) are running concurrently, and you cannot run another one. Possible causes:

(1) You have run too many programs concurrently, and have not terminated them.

(2) One program runs indefinitely, and concurrently to itself, without being terminated.

(3) One of the programs executes another program in a closed loop.

- Abort all programs. A list of the aborted programs will be displayed on the screen. This will indicate which program is running too many time. OR
- Use the STOP command . This will halt all concurrent executions of the same program. OR
- Correct your program(s) as necessary.

(61) \*\*\* RUN TIME WARNING \*\*\* Triggered program not found.

An attempt was made to trigger a program which does not exist any more.

(62) \*\*\* RUN TIME WARNING \*\*\* Invalid I/O number for trigger.

The input or output number used in the TRIGGER command is out of range.

(63) \*\*\* WARNING \*\*\* var already exists.

You attempted to define a variable with a name which is already in use.

(64) Not enough contiguous memory for array.

The controller does not have enough contiguous memory available for the array you want to define.

- Backup and restore all your programs. This will rearrange the memory allocation. OR
- Type PURGE on keyboard; all unused variables will be deleted. OR
- Backup your current programs. Use the CONFIG command to increase the number of positions and/or variables in the configuration. Then restore all your programs.

(69) TP Teach mode disabled. Type AUTO <Enter> for Auto mode.

The Auto/Teach switch on the teach pendant has been switched from Teach to Auto. The teach pendant is no longer operative.

- Enter the command AUTO to reestablish keyboard control.

(72) CONTROL DISABLED.

**CONTROL DISABLED.**

Motors have been disconnected from servo control and BRAKE has been activated. Possible causes:

- (1) COFF (control off) command was issued.
  - (2) CON (control on) has not been issued; the motors have not been activated.
  - (3) A previous error (such as Impact Protection, Thermic Protection of Trajectory Error) activated COFF, thereby disabling the arm.
- If the axes were disabled due to Impact, Thermic, or Trajectory error, check the last movements executed. A movement may have failed because excessive speed or an invalid position resulted in a trajectory beyond the limits of the robot envelope.

(73) CONTROL ENABLED.

**CONTROL ENABLED.**

Motors are now under servo control and BRAKE has been released. Motors can now be activated .

(74) No coordinate values for position.

**Point not assigned.**

The position has been defined using DEFP command, but its coordinates have not been recorded or set.

- Use HERE or other commands to assign coordinates to the position.

(75) Invalid position coordinate values.

The position could not be recorded or reached because its coordinates are out of the working envelope.

(76) \*\*\* WARNING \*\*\* No robot configuration.

You attempted to use a command which indicates the presence of a robotic arm. The command cannot be executed because the robot has not been configured.

(77) \*\*\* WARNING \*\*\* Array *name* truncated.

During a restore operation, the controller did not have enough memory to restore the specified array, and the array has been truncated.

- Backup and restore all your programs. This will rearrange the memory allocation. OR
- Type PURGE on keyboard; all unused variables will be deleted. OR
- Backup your current programs. Use the CONFIG command to increase the number of positions and/or variables in the configuration. Then restore all your programs.

(79) USER RAM CHECKPOINT ERROR !  
INSTALLING DEFAULT SETUP.  
Reconfigure and reload parameters for specific robot used.

This message appears in the following instances:

- (1) When controller is powered on for the first time.
- (2) After controller memory has been erased (CPU battery removed).
- (3) CPU battery is low.
- (4) After a power input failure occurred while the system was being configured.
  - If your system is a standard configuration, you can ignore this message. If your system is not the standard configuration, use the command CONFIG to configure the controller. Restore programs from backup.
  - Check the battery and housing. Replace the battery, if required

(85) No available task. Cannot execute program.

When in DIRECT mode, the program indicated by the RUN command cannot be executed since the task memory is full.

(86) Home task is already active.

You attempted to use the HOME command while a HOME command is still being executed.

- Wait until the current HOME command has been completed. OR
- Abort the homing by entering the command A <Enter>.

(89) Cannot execute XYZ movement at that position.

The movement could not be executed because the XYZ coordinate system is not supported in that part of the envelope.

- Switch to JOINT mode, and manually move to a valid XYZ position.

- (92) Current configuration includes auxiliary RS232 card.  
Press C <Enter> if immediate reconfiguration required.

Your system is currently configured for an RS232 auxiliary card.

If the card exists, simply wait and the system will start normally.

If you have removed the auxiliary RS232 card, press C <Enter> to bring up the configuration menu, and reconfigure the controller.

If you do not change the configuration to indicate that the auxiliary RS232 card is not installed, the system will try to communicate with the card, resulting in a BUS ERROR.

- (98) Axis *n* not configured for homing.

The homing parameters for the axis has not been set; as a result, the homing procedure will not be performed on the axis.

- (99) \*\*\* SPEED TOO FAST axis *n*.

**TOO FAST AX *n*.**

This error affects the ERROR system variable.

The controller has detected a movement which is too fast; that is, the required displacement of the encoder, as calculated from the speed limit parameter, PAR 180+*axis*, is too great. Possible causes:

(1) Since the trajectory is not calculated prior to a linear or circular movement, the linear or circular movement may cause one of the joints to move too fast.

- Lower the value of speed for that movement.

(2) Driver malfunction.

- (100) Out of memory - programs.

The number of programs (created in EDIT) has reached the maximum limit allowed by the controller configuration.

- Delete unused programs. OR
- Backup your current programs. Use the CONFIG command to increase the number of programs in the configuration. Then restore all your programs.

- (101) Syntax error.

The command has a syntax error.

- (102) Undefined variable(s).

The variable has not been defined, or has an undefined variable index.

- (103) Missing argument.

The command is missing an argument.

- (104) Undefined program.

A program with the specified name does not exist.

- EXIT the program you are currently editing. Use EDIT to create a new program with the specified name (the program may remain empty). You may then resume editing your original program.

(105) Undefined variable - PRIORITY.

The variable in the PRIORITY command has not been defined, or has an undefined variable index.

(106) Undefined variable - PEND/POST.

A variable in the PEND/POST/QPEND/QPOST command has not been defined, or has an undefined variable index.

(109) Out of memory - program lines.

The number of program lines has reached the maximum limit allowed by the controller configuration. OR

- Delete unused programs.
- Backup your current programs. Use the CONFIG command to increase the number of program lines in the configuration. Then restore all your programs.

(110) Position is undefined, not recorded, or for other group.

|               |
|---------------|
| POS NOT FOUND |
|---------------|

The position you attempted to use cannot be reached. Possible causes:

- (1) The position has not been defined.
  - (2) The position coordinate values have not been recorded.
  - (3) The command indicated the use of a position belonging to a group which is incompatible with the command.
- Define and/or record the position.

(111) Out of memory - variables.

(112) Out of memory - group *group* positions.

The number of variables / positions has reached the maximum limit allowed by the controller configuration.

- Type PURGE on keyboard; all unused variables will be deleted. OR
- Backup your current programs. Use the CONFIG command to increase the number of variables or positions in the configuration. Then restore all your programs.

(113) Invalid position name.

The position could not be defined because the name is invalid.

(114) First variable undefined.

- The first variable in the command has not been defined, or has an undefined variable index.
- (115) Second variable undefined.  
The second variable in the command has not been defined, or has an undefined variable index.
- (116) Undefined variable - SPEED.  
The variable in the SPEED command has not been defined, or has an undefined variable index.
- (117) Out of memory - strings.  
The number of string commands (PRINT, \* and @) has reached the maximum limit allowed by the controller configuration.
- Delete unused strings. OR
  - Backup your current programs. Use the CONFIG command to increase the number of strings in the configuration. Then restore all your programs.
- (118) Invalid argument(s).  
The command has an invalid argument.
- (119) Undefined variable (loop counter) - FOR.  
The variable which sets the loop counter in the FOR command has not been defined, or has an undefined variable index.
- (120) Invalid variable (loop counter) - FOR.  
You cannot use a constant value for the loop counter in the FOR command.
- (121) Third variable undefined.  
The third variable in the command has not been defined, or has an undefined variable index.
- (122) Undefined variable - TRIGGER.  
The variable which sets the input/output in the TRIGGER command has not been defined.
- (123) Invalid input/output.  
The input or output number used in the command is out of range.
- (124) Invalid or undefined axis.  
The variable used to designate the axis has not been defined, or its index has not been defined, or the axis is not configured (out of range).
- (125) Name already in use or invalid axis.

- (1) You attempted to define a position (DEFP) with a name which is already in use.
- (2) You used an invalid axis number when attempting to define a position in group C.
- (126) Invalid dimension.  
The dimension of the array (DIM, DIMG or DIMP) must be designated by a constant value.
- (127) Syntax error - index  
Index brackets [ ] are not balanced.
- (128) Constant too big.  
ACL's limit for a constant absolute value is 999999999.
- (129) Invalid sequence in program *prog*.  
Program contains a logic error. For example:  
(1) FOR loop not closed by an ENDFOR.  
(2) IF section not closed by an ENDIF.  
(3) ELSE section not closed by an ENDIF.
- (130) Nesting too deep at line *n*.  
Nesting is too deep in FOR/ENDFOR or IF/ENDIF routines.
- (131) Missing IF for line *n*.  
An ENDIF command appears without a preceding IF command.
- (132) Missing IF for line *n*.  
An ANDIF or an ORIF command appears without an immediately preceding IF command.
- (133) Missing FOR for line *n*.  
An ENDFOR command appears without a preceding FOR command.
- (135) Label number already defined.  
You attempted to use a LABEL *n* command which is already in use in the same program.
- (136) Missing or invalid operator.  
An operator in the command is either missing or invalid.
- (137) Missing argument - SPEED.  
The SPEED command is missing the speed argument.
- (138) Name already in use.



You attempted to define a variable or position array (DIM, DIMG or DIMP) with a name which is already in use.

(139) Relative chain loops or exceeds 32 positions.

ACL permits relative positions to be linked to one another in a chain of up to 32 positions. This relative chain of positions must be anchored to one absolute (root) position.

You attempted to define a relative position. The error may be:

(1) One of the positions encountered in the relative chain is the position you attempted to record (a position cannot be relative to itself).

(2) You have linked the relative positions in an invalid or infinite loop.

(3) You have linked more than 31 relative positions.

(140) Invalid variable name - too long.

You attempted to define a variable with a name which exceeds 5 characters.

(142) Missing LABEL for GOTO at line *n*.

A GOTO command appears without a corresponding LABEL in the same program.

(143) Error in downloaded command, at line *n*.

An error occurred while restoring a program. Possible causes:

(1) The backup file is corrupted.

(2) The controller configuration has changed, and a command in the restored program is not valid for the current configuration.

(144) Invalid argument - too long.

The command has an argument which exceeds 10 characters.

(145) Position is not defined or is not a vector.

**POS NOT DEF / ARRAY**

The position has not been defined, or the name used does not define a vector.

(146) \*\*\*WARNING\*\*\* *name*: Invalid name.

You cannot use a constant in the DEFINE or GLOBAL command.

(147) Invalid port number.

The port number used in the command is out of range.

(148) To perform *action* - release emergency button.

**EMERGENCY**

The emergency switch has been pressed.

- To resume normal operation: release the emergency button; abort the user routine, EMERG, if it exists; then activate CON (or HOME).

(149) Cannot change parameter - privilege.

Most system parameters are password-protected, and can only be altered when the PRIVILEGE mode is active.

(150) Command ignored - privilege.

You attempted to execute a password-protected command. The command can only be performed when the PRIVILEGE mode is active.

(152) Invalid remote parameters.

The I/O number(s) you attempted to assign to the remote parameter(s) is out of range, incompatible, or already in use.

(153) Cannot execute command. TP must be in Auto mode.

This command can only be executed when the TP is in Auto mode.

(154) Value too low - SPEED.

The value for the SPEED command must be greater than 0.

(155) Cannot execute command. Type AUTO <Enter> for Auto mode.

- You have switched the TP to the AUTO position, but you must also enter the AUTO command in order to return control to the controller. Only then will your command be executed.

(157) Excessive speed required.

The value entered for the time argument of the MOVE, MOVEL, MOVEC, MOVES, or SPLINE command would cause the speed of movement to exceed the maximum limit.

(159) No free space to insert position.

**NO FREE SPACE.**

All positions in the vector have coordinate values; no memory available.

- You must first delete (DELETE) any unrequired positions in the vector.

(160) Insert position is empty, use HERE or HEREC.

**use HERE or HEREC.**

Since the vector position at the place of insertion does not have coordinate values, the INSERT command you attempted to use cannot be executed. Use HERE or HEREC instead.

- (162) INSERT/DELETE not allowed for a single axis group.  
INSERT and DELETE can only be applied to a position for a robot or multi-axis device which is dedicated to group A or group B. The command is not applicable to positions for a single axis device.
- (163) Index out of range.  
**INDEX RANGE**  
The value of the index is out of the defined range.
- (165) Cannot execute command when in TP Teach mode.  
Switch the Auto/Manual switch on the teach pendant to Auto.  
Then enter the command AUTO from the keyboard.
- (166) Invalid Axis  
You attempted to use an invalid axis number in a CON or BRAKE command.
- (167) Pressure was applied on handle before switch activation or payload is too heavy for Direct Teach  
**HANDLE PUSHED**  
When using the Direct Teach handles, you must first grasp the dead man switch on the handle. Only then can you begin to apply pressure in order to move the robot.
- Press the Error Reset button and begin the Direct Teach again.
- (201) SERVO switch is OFF.  
**SERVO SWITCH IS OFF**  
The command could not be executed because the controller's Servo switch is off.
- Be sure the Servo switch is turned on. Then repeat the command.
- (205) Programs Aborted  
**ALL PROGRAMS ABORTED**
- (1) The command A or <Ctrl>+A was entered from the keyboard.
  - (2) The Abort key on the teach pendant was pressed.
  - (3) The hand-held teach pendant was switched from Auto to Teach mode during program execution.
  - (4) The mounted teach pendant, in Teach mode, was removed from the fixture during program execution.

- (206) \*\*\* WARNING \*\*\*  
'BACKG' is a reserved name for Background routine.  
'BACKG' remains active unless EMERGENCY pressed.  
'BACKG' cannot be aborted by A<Enter>.

This message will appear when you begin to edit a user program with the reserved name BACKG. Refer to the section describing BACKG in Chapter 4, and heed all warnings given there.

- (212) Error must be reset.

**SERVO ERROR**

An error occurred and must be cleared by pressing the controller's Error Reset button.

- (218) Over Voltage axis *n*.

The driver of the specified axis detected excessive voltage and disabled the axis.  
Possible causes:

- (1) The AC input power was higher than the maximum voltage allowed.
- (2) An accessory motor has caused excessive power regeneration.

- (219) Thermic Overload axis *n*.

This error affects the ERROR system variable.

Software has detected AN excessive average RMS current inside motor. Possible causes:

- (1) Movement too fast or payload too heavy.
- (2) Too many consecutive high speed movements. Although ACL allows fast movements, and takes advantage of the peak current allowed in motors, this peak current cannot be used continuously. The software constantly checks the true RMS power dissipated in the motors and protects them from burning out.
- (3) The arm attempted to reach a position, which could not be reached due to an obstacle (for example, a position defined as being above a table, but actually slightly below the table's surface). The impact protection is not activated because the obstacle is close to the target position. However, integral feedback will increase the motor current and the motor will overheat, subsequently causing the Thermic Protection to be activated.
  - Check the positions, the axis driver card and parameters. Reenable servo control of the motors ( CON ).

- (220) Over Current axis *n*.

The software has detected excessive current in the motor for the specified axis.  
Possible causes:

- (1) A short circuit in the motor wires or in the motor itself.
- (2) A momentary resolver error caused a large spike in the motors.

(221) Resolver Error axis  $n$ .

A bad resolver connection has been detected. This error will clear the fixed reference position.

- Check the resolver connections.
- Execute the HOME routine.
- Refer to the troubleshooting instructions in the *Controller-AC User's Manual*.

(222) Clockwise Limit axis  $n$ .

The specified axis has reached its clockwise limit, and the system aborted the movement. Use the TP or keyboard to send the robot back into its working envelope.

(223) Counter-Clockwise Limit axis  $n$ .

The specified axis has reached its counter-clockwise limit, and the system aborted the movement. Use the TP or keyboard to send the robot back into its working envelope.

(225) Under Voltage at axis  $n$ .

The driver of the specified axis detected low voltage and disabled the axis.

(226) AC fail at axis  $n$ .

A discontinuity of the AC power supply has been detected, and **ACL** was stopped. If power was restored and controller was not properly restarted, you must restart the controller: turn it off, wait one minute and then turn it on again.

(227) DPRAM watchdog error at axis  $n$ .

A malfunction caused a communication interruption between the main CPU card and the DDC.

- Reset the controller: turn it off, wait one minute, and then turn it on again.

Refer to the troubleshooting instructions in the *Controller-AC User's Manual*.

(228) Hardware watchdog error at axis  $n$ .

Software or hardware failure of the DDC driver card for the specified axis.

(229) Driver not responding at axis *n*.

A problem has occurred with the DDC driver card for the specified axis.

If, in addition, axis 1 is not responding, disregard all other axis messages until the problem with axis 1 has been corrected.

- Make sure the DDC card for the specified axis is correctly inserted.
- Exchange the DDC card for the specified axis with a DDC card for another axis.
- If still not responding, change the DPU card for the specified axis.

Refer to the troubleshooting instructions in the *Controller-AC User's Manual*.

(234) Bad connection of robot cable, or Fan failure.

- Make sure the robot power cable connector is well secured.
- Check the internal fan and the fan on the back panel. Replace fan, if necessary.

(243) \*\*\* WARNING \*\*\*

'AUTO' is a reserved name for automatic start at power on. 'AUTO' will run at power on if controller was last powered off while servo disabled. Otherwise, program 'RECOV' will run.

This message will appear when you begin to edit a user program with the reserved name AUTO. Refer to the section describing AUTO in Chapter 4.

(248) \*\*\* WARNING \*\*\*

'RECOV' is a reserved name for automatic start at power on. 'RECOV' will run at power on if controller was last powered off while servo enabled. At normal power on, program 'AUTO' will run.

This message will appear when you begin to edit a user program with the reserved name RECOV. Refer to the section describing RECOV in Chapter 4.

(253) \*\*\* WARNING \*\*\*

'EMERG' is a reserved name for emergency procedure. 'EMERG' will run when emergency switch is activated.

This message will appear when you begin to edit a user program with the reserved name EMERG. Refer to the section describing EMERG in Chapter 4.

(256) \*\*\* WARNING \*\*\*

'CRASH' is a reserved program name. 'CRASH' will run if an impact or motor error occurs.

This message will appear when you begin to edit a user program with the reserved name CRASH. Refer to the section describing CRASH in Chapter 4.

(260) \*\*\* WARNING \*\*\*

'START' is a reserved program name.  
'START' will run if the Start push button is pressed.

This message will appear when you begin to edit a user program with the reserved name START. Refer to the section describing START in Chapter 4.

(262) !! HOLD !!

The controller's Hold/Run selector switch has been switched to Hold, thereby suspending axis movement and all running programs.

(263) !! CONTINUE !!

The controller's Hold/Run selector switch has been switched to Run, thereby resuming suspended movements and programs.

(301) Group/Axis has not been homed.

**HOME NOT DONE**

You attempted to move the arm to a recorded positions, or to record a position, before homing was performed on the group or axis.

(302) Arithmetic overflow (or division by zero)

**ARITHMETIC OVERFLOW**

The SET command was used with values which caused an overflow.

Check the values of variables used. The result should be in the long integer range:  $-2^{31} \text{ --- } 2^{31}$ .

(303) No coordinate values for position *n*.

**POS NOT RECORDED**

The position has been defined using DEFP command, but its coordinates have not been recorded or set.

- Use HERE or other commands to assign coordinates to the position.

(304) Axis disabled.

**AXIS DISABLED**

Possible causes:

(1) A movement command could not be executed because servo control of the arm has been disabled (COFF).

(2) A previous movement of the arm resulted in an Impact or Trajectory error, thereby activating COFF and disabling the arm.

- Check the movements of the robot, and correct the command(s).

(305) Nesting too deep.

**TOO DEEP NESTING**

Too many nested GOSUB, IF or FOR commands.

- Do not nest (repeat) any one of these commands (GOSUB, IF or FOR) within the same command more than 10 times.

(306) Invalid program.

**INVALID PROGRAM**

The RUN, GOSUB, TRIGGER or PRIORITY command cannot be executed due to faulty syntax or logic in the program. Or, the @ command cannot be executed while the edit mode is active.

(309) Index value out of range.

**INDEX RANGE**

The value of the index is out of range.

(310) Invalid axis.

**BAD AXIS**

The axis is not in the group specified by the command, or the axis is not configured.

(311) Relative chain loops or exceeds 32 positions.

**POINT LOOP**

ACL permits relative positions to be linked to one another in a chain of up to 32 positions. This relative chain of positions must be anchored to one absolute (root) position.

You attempted to define a relative position. The error may be:

- (1) One of the positions encountered in the relative chain is the position you attempted to record (a position cannot be relative to itself).
- (2) You have linked the relative positions in an invalid or infinite loop.
- (3) You have linked more than 31 relative positions.

(312) Invalid position coordinate values.

**BAD POINT *pos***

You attempted to use an invalid position. For example, the relative position you have defined is out of the axis' range.

- Record new coordinates for the position.

You attempted to use an XYZ movement command (MOVEL, MOVEC and Linear SPLINE) in which movement crosses from World Space A to B, or B to A.

- All positions referenced in the XYZ command must belong to *either* World Space A or World Space B.



(313) Incompatible position type *pos*.

**POS TYPE *pos***

Some **ACL** commands cannot use two different types of positions in one command. You have attempted to use a position whose type is incompatible with the command; the error may be, for example:

- (1) **SHIFT** of a relative position by XYZ coordinate values.
- (2) **SHIFTC** of a relative position by JOINT coordinate values.
- (3) **SETPV** of a relative position by XYZ coordinate values.
- (4) **SETPVC** of a relative position by JOINT coordinate values.
- (5) **SHIFTC** of a relative position to current position.

(315) Incompatible positions.

**INCOMPATIBLE POS**

You have attempted to use the **HERER** command for positions in different axis groups, or positions which are both of group C but assigned to different axes.

(316) No gripper configuration.

**NO GRIPPER**

You attempted to use a command which indicates the presence of a gripper. The command cannot be executed because a gripper has not been configured.

(317) Invalid Cartesian position *pos*.

**BAD XYZ POSITION**

The position could not be recorded or reached because its XYZ coordinates are out of the XYZ envelope.

- Switch to JOINT mode.

(319) Motor power switch is OFF.

**MOTORS OFF**

The command could not be executed because the controller's Servo switch is off.

- Be sure the Servo switch is turned on. Then repeat the command.

(320) Robot is not in XYZ space.

**NOT XYZ SPACE**

The robot is at a position at which the XYZ coordinate system is not supported.

- Switch to JOINT mode.

(321) **MOVES/SPLINE** not allows for a single axis group.

**BAD GROUP**

**MOVES** and **SPLINE** can only be applied to a robot or multi-axis device which is dedicated to group A or group B. The command cannot be executed on a single axis group.

This page intentionally left blank.

# Parameters

---

Many of the controller functions depend on the setting of the system parameters. System parameters determine operations and conditions such as:

- Work envelope
- Axis protection
- Speed limits
- Gripper operation
- Teach pendant and manual operation
- Cartesian kinematic calculations

---

## Warnings

- Only skilled operators should attempt to manipulate parameters.
- Backup your current system parameters before you change parameter values.
- Activate COFF before you change parameter values.  
Never change parameter values while robot is in motion.  
Never change parameters values while programs are running.
- Be sure impact protection parameters are properly set. These parameters monitor the axes for abnormal conditions, such as resolver and power failure, and impact. When such conditions are detected, the motors are disabled. Working without active impact protection may result in damage to the robot arm.

---

## Parameter Protection

The parameters are divided into two access groups: password-protected parameters and non-protected parameters.

Protected parameters may be accessed and manipulated only after you have activated the PRIVILEGE mode. This feature prevents accidental or incorrect manipulation of servo and other critical parameters.

The status of parameter 19 indicates whether or not the PRIVILEGE mode is active. If PAR 19=0, a password is required to access the protected parameters; if PAR 19=1, no password is required.

Non-protected parameters may be accessed and manipulated at any time. The following parameters do not required the PRIVILEGE mode:

- Gripper parameters: 73, 74, 75, 76, 274 and 275
- Position Error parameters: 261–272

Refer to the commands PASSWORD and PRIV[ILEGE] in Chapter 3 for more information on the PRIVILEGE mode.

---

## Parameter Commands

The parameters may be accessed and manipulated by the following **ACL** commands:

|                       |                                                                                                                                                                                          |
|-----------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| SHOW PAR <i>n</i>     | DIRECT mode.<br>Displays the value of parameter <i>n</i> .                                                                                                                               |
| LET PAR <i>n=var</i>  | DIRECT/EDIT modes.<br>Changes the value of parameter <i>n</i> to <i>var</i> (either a constant or a variable).                                                                           |
| SET <i>var1=PAR n</i> | DIRECT/EDIT modes.<br>Assigns the value of parameters to a variable.                                                                                                                     |
| SENDPAR               | DIRECT mode.<br>Generates a listing of all system parameters, which, if captured into a file, can later be transmitted to the host computer by means of the RECEIVE and APPEND commands. |
| INIT CONTROL          | DIRECT mode.<br>Must be issued after changing a parameter; otherwise the new value will not take effect.                                                                                 |

---

## Parameter Descriptions

ACL has two types of parameters:

- Parameters applicable to a device regardless of the axis to which it is connected. For example, PAR 239 defines the acceleration at the start of a manual movement.
- Parameters which are applied to each axis individually. These parameters are allotted a range of numbers, at intervals of 20, in the controller's table of parameters. The range is indicated by the term PAR  $n+axis$ ; for example PAR  $200+axis$ .  
Parameters 243, 263 and 283, for example, are parameters for axis 3; parameters 262, 263 and 264 define the position error constants for axes 2, 3, and 4, respectively.

Parameters which set motor current values are defined in the range  $\pm 5000$  (equivalent to rated peak current of motor). Other parameter values are expressed in units such as resolver counts, controller clock ticks, linear measurements, and so on.

*The parameters supplied with the robot are appropriate for most robotic applications. Do not change them unless necessary. **Read the documentation carefully before making parameter changes.***

The following two tables describe all the parameters for the MK3 controller.

- **Parameter Table 1** gives brief descriptions of the parameters, classified according to their functions.
- **Parameter Table 2** gives complete descriptions of the parameters, arranged in numerical order.

*Non-protected parameters are indicated by shaded numbers.*

| Parameter Table 1                     |                                                                                  |                                                                                      |
|---------------------------------------|----------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|
| <b>System Setting Parameters</b>      |                                                                                  |                                                                                      |
| I/Os for Remote<br>(External) Control | 14                                                                               | Defines controller input # for external Servo ON switch                              |
|                                       | 15                                                                               | Defines controller input # for external Run/Hold switch.                             |
|                                       | 16                                                                               | Defines controller input # for external Start switch.                                |
|                                       | 113                                                                              | Defines controller input # for external Stop switch.                                 |
|                                       | 114                                                                              | Defines controller input # for external Error Reset switch.                          |
|                                       | 115                                                                              | Defines controller output # for external Error indicator.                            |
|                                       | 116                                                                              | Defines controller output # for external Remote indicator.                           |
|                                       | 117                                                                              | Defines controller output # for external Program Running indicator.                  |
|                                       | 118                                                                              | Defines controller output # for external Hold indicator.                             |
|                                       | 119                                                                              | Defines controller output # for external Servo indicator.                            |
|                                       | 18                                                                               | Identifies the production model of the controller.                                   |
|                                       | 19                                                                               | Defines whether PRIVILEGE mechanism is required.                                     |
| <b>Axis Limit Parameters</b>          |                                                                                  |                                                                                      |
|                                       | 100 + <i>axis</i>                                                                | Upper limit of axis motion, in resolver counts.                                      |
|                                       | 120 + <i>axis</i>                                                                | Lower limit of axis motion, in resolver counts.                                      |
|                                       | 540 + <i>axis</i>                                                                | Maximum resolver range.                                                              |
| <b>Impact Parameters</b>              |                                                                                  |                                                                                      |
| Run Mode                              | 240                                                                              | Defines axis group which responds when impact detected.                              |
|                                       | 240 + <i>axis</i>                                                                | Value for detecting homing start error.                                              |
|                                       | 680 + <i>axis</i>                                                                | Value for detecting servo error at run time/during homing.                           |
| Manual Mode                           | 280 + <i>axis</i>                                                                | Maximum torque allowed while moving the axes manually (TP or keyboard).              |
|                                       | 780 + <i>axis</i>                                                                | Value for detecting servo error during manual movement.                              |
|                                       | 700 + <i>axis</i><br>720 + <i>axis</i><br>740 + <i>axis</i><br>760 + <i>axis</i> | Values for setting manual movement torque limitation.                                |
|                                       |                                                                                  |                                                                                      |
| <b>Speed Setting Parameters</b>       |                                                                                  |                                                                                      |
|                                       | 180 + <i>axis</i>                                                                | Maximum speed setting, in (degrees/second), (mm/second), or (resolver counts/10 ms). |
|                                       | 533                                                                              | Maximum linear acceleration.                                                         |
|                                       | 534                                                                              | Maximum pitch/roll acceleration.                                                     |
|                                       | 535                                                                              | Maximum roll acceleration.                                                           |
|                                       | 536                                                                              | Maximum linear speed.                                                                |
|                                       | 537                                                                              | Maximum pitch/roll speed .                                                           |
|                                       | 538                                                                              | Maximum roll speed.                                                                  |

| <b>Parameter Table 1</b>                                                                                                                                                                                                                                                        |                   |                                                                                  |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|----------------------------------------------------------------------------------|
| <b>Manual Speed Parameters</b>                                                                                                                                                                                                                                                  |                   |                                                                                  |
|                                                                                                                                                                                                                                                                                 | 220 + <i>axis</i> | Speed setting for manual operation.                                              |
|                                                                                                                                                                                                                                                                                 | 239               | Acceleration at start of a manual movement.                                      |
|                                                                                                                                                                                                                                                                                 | 500 + <i>axis</i> | Deceleration of movement after key is released.                                  |
|                                                                                                                                                                                                                                                                                 | 238               | Deceleration of Cartesian movement after key is released.                        |
|                                                                                                                                                                                                                                                                                 | 294               | Maximum speed for manual Cartesian movement.                                     |
| <b>Keyboard Manual Parameter</b>                                                                                                                                                                                                                                                |                   |                                                                                  |
|                                                                                                                                                                                                                                                                                 | 300               | Time required for key repetition, to produce a smooth, continuous axis movement. |
| <b>Homing Parameters</b>                                                                                                                                                                                                                                                        |                   |                                                                                  |
|                                                                                                                                                                                                                                                                                 | 200               | Defines whether double homing procedure is used.                                 |
|                                                                                                                                                                                                                                                                                 | 200 + <i>axis</i> | Maximum torque value allowed while homing.                                       |
|                                                                                                                                                                                                                                                                                 | 460 + <i>axis</i> | Speed of search for the home switch.                                             |
|                                                                                                                                                                                                                                                                                 | 13                | Slows motion during home switch homing.                                          |
|                                                                                                                                                                                                                                                                                 | 420 + <i>axis</i> | Position at which resolver reading is zero.                                      |
|                                                                                                                                                                                                                                                                                 | 440 + <i>axis</i> | Number of resolver counts for a 90° turn of motor.                               |
|                                                                                                                                                                                                                                                                                 | 600 + <i>axis</i> | Torque value to be applied to the axis during search for hard home.              |
| <b>Cartesian Calculations Parameters</b>                                                                                                                                                                                                                                        |                   |                                                                                  |
| <p>These parameters define the mechanical arm lengths, resolver and gear ratios, and the robot's home position; they are used to calculate the Cartesian position of the arm.</p> <p>The robot's structural type must be correctly defined in the controller configuration.</p> |                   |                                                                                  |
| Rotation Scaling<br>(for robot axes only)                                                                                                                                                                                                                                       | 33                | Number of resolver counts for +90° of axis 1.                                    |
|                                                                                                                                                                                                                                                                                 | 34                | Number of resolver counts for +90° of axis 2.                                    |
|                                                                                                                                                                                                                                                                                 | 35                | Number of resolver counts for +90° of axis 3.                                    |
|                                                                                                                                                                                                                                                                                 | 36                | Number of resolver counts for +90° of axis 4.                                    |
|                                                                                                                                                                                                                                                                                 | 37                | Number of resolver counts for +90° of axis 5.                                    |
| Horizontal Reference<br>Position                                                                                                                                                                                                                                                | 1                 | Resolver 1 reading at horizontal reference position.                             |
|                                                                                                                                                                                                                                                                                 | 2                 | Resolver 2 reading at horizontal reference position.                             |
|                                                                                                                                                                                                                                                                                 | 3                 | Resolver 3 reading at horizontal reference position.                             |
|                                                                                                                                                                                                                                                                                 | 4                 | Resolver 4 reading at horizontal reference position.                             |
|                                                                                                                                                                                                                                                                                 | 5                 | Resolver 5 reading at horizontal reference position.                             |
|                                                                                                                                                                                                                                                                                 | 260               | Compensation of roll angle to maintain orientation of tool.                      |
| <b>Length Parameters</b>                                                                                                                                                                                                                                                        |                   |                                                                                  |
| All units are in microns ( $10^{-3}$ millimeters) or millidegrees.                                                                                                                                                                                                              |                   |                                                                                  |
|                                                                                                                                                                                                                                                                                 | 301               | X coordinate of the rotation axis of arm link 2 when robot is at home.           |
|                                                                                                                                                                                                                                                                                 | 302               | Y coordinate of the TCP when robot is at home.                                   |
|                                                                                                                                                                                                                                                                                 | 303               | Z coordinate of the rotation axis of arm link 2.                                 |

| <b>Parameter Table 1</b>     |                          |                                                                                                                                                                           |
|------------------------------|--------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                              | 304                      | Length of link 2; from the first articulated joint.                                                                                                                       |
|                              | 305                      | Length of link 3; from the second articulated joint.                                                                                                                      |
|                              | 306                      | Distance from pitch axis / flange to TCP.                                                                                                                                 |
|                              | 307                      | Distance from pitch axis to flange.                                                                                                                                       |
|                              | 308                      | Length. Value from TOOL command.                                                                                                                                          |
|                              | 309                      | Offset. Value from TOOL command.                                                                                                                                          |
|                              | 310                      | Angle. Value from TOOL command.                                                                                                                                           |
|                              | 237                      | Cartesian limit.                                                                                                                                                          |
| <b>Trajectory Parameters</b> |                          |                                                                                                                                                                           |
|                              | 520 + <i>axis</i>        | Maximum acceleration/deceleration.                                                                                                                                        |
|                              | 580 + <i>axis</i>        | Deceleration smoothness.                                                                                                                                                  |
|                              | 199                      | Rate of deceleration when Run/Hold switch is switched to Hold.                                                                                                            |
|                              | <b>260 + <i>axis</i></b> | Maximum position error at end of MOVED, MOVELD or MOVECD.                                                                                                                 |
|                              | 800 + <i>n</i>           | Bandwidth of the smoothing filter for trajectory.<br>( <i>n</i> =1 for group A; <i>n</i> =2 for group B; <i>n</i> =axis number for individual axis in group C or gripper. |
|                              | 810 + <i>n</i>           | Offset angle between the motor and the resolver.                                                                                                                          |
| <b>Gripper Parameters</b>    |                          |                                                                                                                                                                           |
|                              | <b>73</b>                | Gripper resolver range.                                                                                                                                                   |
|                              | <b>74</b>                | Resolver count at closed position.                                                                                                                                        |
|                              | <b>75</b>                | Maximum torque value for closing and opening gripper.                                                                                                                     |
|                              | <b>76</b>                | Duration of gripper closing and opening.                                                                                                                                  |
|                              | <b>274</b>               | Controller output # for pneumatic gripper.                                                                                                                                |
|                              | <b>275</b>               | Torque value to be applied to the gripper after the completion of a CLOSE gripper command.                                                                                |
|                              | 276                      | Torque value to be applied at the start of gripper movement.                                                                                                              |
|                              | 277                      | Duration of PAR 276.                                                                                                                                                      |
|                              | <b>260+<i>axis</i></b>   | When <i>axis</i> =gripper: maximum fluctuation of resolver value while gripper blocked.                                                                                   |



| Parameter Table 2          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|----------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Parameter                  | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 1<br>2<br>3<br>4<br>5      | Used by controller for XYZ calculations. For robot axes only:<br>Reading of resolver 1 at horizontal reference position.<br>Reading of resolver 2 at horizontal reference position.<br>Reading of resolver 3 at horizontal reference position.<br>Reading of resolver 4 at horizontal reference position.<br>Reading of resolver 5 at horizontal reference position.<br>These parameters define the resolver offset from the home position to a position in which all axes are aligned and in the horizontal position, including a horizontal gripper plane. |
| 13                         | <b>Slow Homing:</b> Slows motion during home switch homing. This parameter slows the final search for the switch.<br>If PAR 13=0: Default value<br>If PAR 13=1: Twice as slow<br>If PAR 13=3: Three times as slow                                                                                                                                                                                                                                                                                                                                            |
| 14                         | <b>Servo On Switch</b><br>Defines the controller input to which a remote Servo On switch is connected.<br>PAR 16 may have a value of 1–16. If PAR 16=0: switch not installed; not defined.                                                                                                                                                                                                                                                                                                                                                                   |
| 15                         | <b>Run/Hold Program Switch.</b><br>Defines the controller input to which a remote Run/Hold switch is connected.<br>PAR 15 may have a value of 1–16. If PAR 15=0: switch not installed; not defined.<br>PAR 199 defines rate of axis deceleration at switch to Hold.                                                                                                                                                                                                                                                                                          |
| 16                         | <b>Start Program Switch.</b><br>Defines the controller input to which a remote Start program switch is connected.<br>PAR 16 may have a value of 1–16. If PAR 16=0: switch not installed; not defined.                                                                                                                                                                                                                                                                                                                                                        |
| 18                         | <b>Controller ID.</b> Identifies the production model of the controller in which the software is operating. Factory set; <i>not</i> for user manipulation.                                                                                                                                                                                                                                                                                                                                                                                                   |
| 19                         | Determines whether <b>PRIVILEGE mode</b> is active or not.<br>If PAR 19=0: Controller is always in PRIVILEGE mode; no parameter protection.<br>If PAR 19=1: PRIVILEGE mode must be activated by means of password-protected PRIV command.                                                                                                                                                                                                                                                                                                                    |
| 33<br>34<br>35<br>36<br>37 | Used by controller for XYZ calculations. For robot axes only:<br>Number of resolver counts for +90° of axis 1.<br>Number of resolver counts for +90° of axis 2.<br>Number of resolver counts for +90° of axis 3.<br>Number of resolver counts for +90° of axis 4.<br>Number of resolver counts for +90° of axis 5.                                                                                                                                                                                                                                           |
| 73                         | <b>Gripper Resolver Range.</b> Number of resolver counts required to close gripper from fully open position. Valid only for a gripper with resolver feedback.<br>If PAR 73=0, there is no resolver on the gripper.                                                                                                                                                                                                                                                                                                                                           |
| 74                         | <b>Gripper Resolver Count at closed position.</b> Valid only for a gripper with resolver feedback.                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 75                         | <b>DAC Value applied to gripper motor</b> when closing and opening gripper.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |

| Parameter Table 2 |                                                                                                                                                                                                                                                 |
|-------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Parameter         | Description                                                                                                                                                                                                                                     |
| 76                | <b>Gripper Closing Duration.</b> The amount of time required to close and open gripper (in clock ticks). Valid only for a servo gripper <i>without</i> resolver feedback and for a pneumatic gripper.                                           |
| 100+axis          | <b>Upper Limit</b> of axis motion, in resolver counts, per axis.                                                                                                                                                                                |
| 113               | <b>Stop Switch</b> . Defines the controller input to which a remote Stop switch is connected. PAR 113 may have a value of 1–16. If PAR 113=0: switch not installed; not defined.                                                                |
| 114               | <b>Error Reset Switch.</b> Defines the controller input to which a remote Error Reset switch is connected. PAR 114 may have a value of 1–16. If PAR 114=0: switch not installed; not defined.                                                   |
| 115               | <b>Error Indicator.</b><br>Defines the controller output to which an external Error indicator is connected. PAR 115 may have a value of 1–16. If PAR 115=0:indicator not installed; not defined.                                                |
| 116               | <b>REMOTE Indicator.</b><br>Defines the controller output to which an external REMOTE mode indicator is connected. PAR 116 may have a value of 1–16. If PAR 116=0:indicator not installed; not defined.                                         |
| 117               | <b>Program Running Indicator.</b><br>Defines the controller output to which an external Program Running indicator is connected. PAR 117 may have a value of 1–16. If PAR 117=0:indicator not installed; not defined.                            |
| 118               | <b>Hold Indicator.</b><br>Defines the controller output to which an external Hold Program indicator is connected. PAR 118 may have a value of 1–16. If PAR 118=0:indicator not installed; not defined.                                          |
| 119               | <b>Servo Indicator.</b><br>Defines the controller output to which an external Servo On indicator is connected. PAR 119 may have a value of 1–16. If PAR 119=0:indicator not installed; not defined.                                             |
| 120+axis          | <b>Lower Limit</b> of axis motion, in resolver counts, per axis.                                                                                                                                                                                |
| 180+axis          | <b>Maximum Speed Setting.</b><br>For robot axes: in (degrees/second).<br>For non-robot axes: in (resolver counts/10 milliseconds).                                                                                                              |
| 199               | <b>Rate of Deceleration</b> of axis motion when the Run/Hold switch is switched to Hold. Defined as a percentage of maximum speed, as defined by PAR 180+axis: 1=slow; 100=immediate. Typical value: 4–5.                                       |
| 200               | <b>Homing.</b><br>If PAR 200=0, the homing procedure will run twice for high precision.<br>If PAR 200=1, a faster homing procedure will be performed.<br>For robots with resolver index pulse (C-pulse), double homing is usually not required. |
| 200+axis          | The <b>Maximum Torque Value</b> allowed while homing. If torque reaches this value while homing, the homing routine will interpret it as a mechanically blocked motor and will change the direction of the search or stop the homing procedure. |
| 220+axis          | Defines the <b>speed setting for manual operation</b> of each axis. Defined as a percentage of the maximum speed, as defined by PAR 180+axis.                                                                                                   |

| Parameter Table 2 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|-------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Parameter         | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| 237               | <b>Cartesian Limit</b> parameter. Minimum allowed angle, in degrees, between the two main robot joints while the robot is moving in Cartesian coordinates. This parameter prevents movement through the singular point of the Cartesian to Joint transformation.                                                                                                                                                                                                                                                                                        |
| 238               | <b>Manual Cartesian Movement Deceleration.</b> The rate of deceleration after a Cartesian manual movement key is released.<br>A percentage of maximum acceleration, as defined by PAR 533, PAR 534, and PAR 536.                                                                                                                                                                                                                                                                                                                                        |
| 239               | <b>Manual Movement Acceleration.</b> The rate of acceleration at the start of a manual movement. The value of this parameter is the number of clock ticks required for the arm to reach its requested normal speed.                                                                                                                                                                                                                                                                                                                                     |
| 240               | <b>Impact Protection Response Mode.</b> Defines axis group which reponds when an impact condition is detected.<br>If PAR 240≠0: when an impact error is detected, only the motors in the group to which the impacted motor belongs are shut off.<br>If PAR 240=0: when an impact error is detected, all motors are stopped (default).                                                                                                                                                                                                                   |
| 240+axis          | <b>Homing Start Error.</b> If a position error (in resolver counts) at the start of the homing routine is greater than the parameter value, an error condition is detected.                                                                                                                                                                                                                                                                                                                                                                             |
| 260               | <b>Roll Compensation for Maintaining Tool Orientation.</b> When executing a linear movement, if pitch value is close to +90° or -90°, the controller will compensate the roll angle in order to maintain the orientation of the tool (parallel to itself).<br>PAR 260 determines the range in which the compensation algorithm is executed:<br>(± 90° – PAR 260) < <i>pitch angle</i> < (± 90°+ PAR 260). Average range: 0–20.                                                                                                                          |
| 260+axis          | These parameters define the <b>Maximum Position Error</b> per axis, in resolver counts, which is allowed for the completion of MOVED, MOVELD, MOVECD, MOVESD and SPLINED commands. (These parameters are active only in the EXACT mode.)<br>If <i>axis</i> is a servo gripper, this parameter defines the maximum fluctuation of the resolver value while the gripper is blocked.                                                                                                                                                                       |
| 274               | <b>Pneumatic Gripper (OPEN/CLOSE) Configuration</b><br>Defines the controller output to which the pneumatic gripper is connected.<br>Thus PAR 274 may have a value of 1–16.<br>Allows the use of OPEN and CLOSE commands from keyboard and from teach pendant for controlling pneumatic gripper.<br>If gripper opens in response to a CLOSE command (and vice versa, due to incorrect I/O wiring connections), the sign of the parameter value should be reversed; for example, PAR 274=-1. If PAR 274=0: pneumatic gripper not installed; not defined. |
| 275               | <b>Gripper Holding Power.</b> A constant analog output value to be applied to the gripper after the completion of a close gripper command. Be careful not to set this value too high. Typical value: 1000 or lower. Valid only for a servo gripper <i>without</i> resolver feedback.                                                                                                                                                                                                                                                                    |
| 276               | <b>DAC Value</b> to be applied <b>at the start of gripper movement</b> for the amount of time specified in PAR 277.                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 277               | <b>Duration of PAR 276.</b> Time value, defined in hundreths of a second.                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |

| <b>Parameter Table 2</b> |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|--------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Parameter</b>         | <b>Description</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 280+axis                 | <b>Manual Movement Torque Limit.</b> The maximum torque allowed while moving the axes manually (by means of TP or keyboard). DAC value: 0–5000.                                                                                                                                                                                                                                                                                                                                                                                                              |
| 294                      | <b>Manual Cartesian Movement</b> maximum speed. A percentage of maximum linear speed, as defined by PAR 536.                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 300                      | <b>Keyboard Stroke Rate.</b> When operating robot in Manual keyboard mode, time required to hold down key before character is repeated, thus producing a smooth, continuous axis movement.                                                                                                                                                                                                                                                                                                                                                                   |
| 301                      | X coordinate of the rotation axis of arm link 2 when the robot is in the home position. Defined in microns.                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 302                      | Y coordinate (offset from center along the Y-axis) of the TCP when the robot is in the home position. Defined in microns.                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 303                      | Z coordinate of the rotation axis of arm link 2. Defined in microns.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| 304                      | Length of arm link 2 (from the first articulated joint). Defined in microns.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 305                      | Length of arm link 3 (from the second articulated joint). Defined in microns.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| 306                      | Distance from pitch axis to the TCP. Defined in microns. Calculated from PAR 307 and PAR 308.                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| 307                      | Distance from pitch axis to flange; defined in microns.<br>The value of this parameter must be set to the exact dimension of the specific robot. The TOOL command then sets parameters 308, 309, 310 and 306 to the proper values.                                                                                                                                                                                                                                                                                                                           |
| 308                      | Length value from TOOL command. Distance from flange to the TCP; defined in microns.                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| 309                      | Offset value from TOOL command. Distance from the axis of symmetry of the flange to the TCP; defined in microns.                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| 310                      | Angle value from TOOL command. Angle of TCP relative to the horizontal position when link 4 is horizontal and roll is 0; defined in thousandths of a degree.                                                                                                                                                                                                                                                                                                                                                                                                 |
| 420+axis                 | <b>Index Pulse Position.</b> Records the distance, in resolver counts, between the home switch transition and the index pulse position.<br>During initial operation this value is 0. After the first homing of each axis, this parameter automatically records the detected value. This value is then used by future home operations for verification. If the motor resolver or any other mechanical component is changed, set this parameter to 0 for the specific axis and rehome. This will insert the new value automatically into the proper parameter. |
| 440+axis                 | The number of resolver counts for a <b>90° turn of motor.</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| 460+axis                 | <b>Speed of Search</b> for the home switch. The sign of this parameter also determines which side of the home switch is sensed as the homing position.<br>If PAR 460+axis=0: search for home switch is not allowed for the specific axis.                                                                                                                                                                                                                                                                                                                    |
| 500+axis                 | <b>Manual Movement Deceleration.</b> The rate of deceleration after the manual movement key is released. Defined as a percentage of maximum acceleration, as defined by PAR 520.                                                                                                                                                                                                                                                                                                                                                                             |

| Parameter Table 2                            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|----------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Parameter                                    | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| 520+axis                                     | <b>Maximum Acceleration/Deceleration</b> allowed for each axis during movement. In units of <i>resolver counts / (clock tick)<sup>2</sup></i> .                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| 533                                          | <b>Maximum Linear Acceleration</b> in microns/(hundreths of a second) <sup>2</sup> .                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 534                                          | <b>Maximum Pitch Acceleration</b> , in millidegrees/(hundreths of a second) <sup>2</sup> .                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| 535                                          | <b>Maximum Roll Acceleration</b> , in millidegrees/(hundreths of a second) <sup>2</sup> .                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| 536                                          | <b>Maximum Linear Speed</b> in (microns/second).                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 537                                          | <b>Maximum Pitch Speed</b> , in (millidegrees/second).                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 538                                          | <b>Maximum Roll Speed</b> , in (millidegrees/second).                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| 540+axis                                     | <b>Maximum Resolver Range</b> . An envelope value used for various calculations. This value should be set to more than twice the maximum range of axis motion.                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 580+axis                                     | <b>Deceleration Smoothness</b> . Used to adjust the smoothness of the stop following an abort (by A or CLRBUF command). In units of <i>resolver counts / (clock tick)<sup>2</sup></i> . Typical value: 5 (smooth stop) – 100 (abrupt stop).                                                                                                                                                                                                                                                                                                                                                                                       |
| 600+axis                                     | <b>Analog output value</b> to be applied to the axis when performing a hard home search. If PAR 600+axis=0: Hard home not allowed for specified axis.                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| 680+axis                                     | <b>Servo Error</b> . At run time and during homing, if a position error is greater than that defined by the parameter, an impact condition is detected. Typical values: 1000–2000 resolver counts.                                                                                                                                                                                                                                                                                                                                                                                                                                |
| 700+axis<br>720+axis<br>740+axis<br>760+axis | <b>Manual Movement Torque Limitation</b> .<br>Whenever the axis resolver moves more counts than the value of PAR 700+axis, the torque value is sampled, and written to the system variable T0.<br>In addition, the actual torque, <i>T</i> , is measured at each clock tick, and compared to the stored value T0.<br>Each time $(T - T0) > T_{max}$ , an internal counter is incremented. When the value of the counter equals the value of PAR 740+axis, an impact condition is detected.<br>Maximum allowed torque is defined as:<br>$T_{max} = (\text{PAR } 720+axis) + [(\text{PAR } 760+axis) \times \textit{acceleration}]$ |
| 780+axis                                     | <b>Servo Error</b> . During manual movement, if a position error is greater than that defined by the parameter, an impact condition is detected. Typical value: 1000–2000 resolver counts.                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| 810+axis                                     | Offset angle between resolver and motor phases.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| 820 – 2048                                   | <i>Reserved system parameters. Do not manipulate!</i>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |